


TB70SS 41CDT70C966  
Engine Assembly

Page 1 of 4




TB70SS 41CDT70C966  
Engine Assembly

Page 2 of 4

Ref #	Part Number	Qty	S/P/F	Description
1	753-04511	1	/P	Air Cleaner Cover Assembly (Incl. Ref No. 2 & 29)
2	791-180350B	1	/P	Air Cleaner Filter
3	791-180351	1		Carburetor Mounting Screw Assembly
4	936-0271	1	/P	Wavey Washer
5	791-182202	1	/P	Choke Knob w/Screw
6	753-04418	1	/P	Choke Lever (Incl. Ref No. 5)
7	753-04419	1	/P	Choke Plate (Incl. Ref No. 6)
8	753-05133	1		Carburetor Assembly (Incl. Ref No. 9)
9	791-610675	1		Carburetor Gasket
10	791-181860	1		Carb Mount Screw
11	791-683974B	1	/P	Primer & Hose Assembly
12	753-1196	1	/P	Carb Mount Assembly (Incl. Ref No. 10, 13 & 14)
13	791-684451	1		Reed Assembly
14	753-1208	1	/P	O-Ring
15	791-612134	1		Rear Mounting Pad
16	753-04307	1	/P	Fuel Tank Assembly (Incl. Ref No. 17)
17	791-182529	1		Fuel Cap Assembly
18	791-145308	1		Front Mounting Pad
19	753-05091	1	/P	Shroud Extension & Stand (Incl. Ref No. 29)
20	753-05240	1	/P	Flywheel Assembly
20	914-04016	1	/P	Woodruff Key.125 x .375 Not shown
21	791-181525	1		Spacer
22	753-1200	1		Rope Guide
23	631-04164	1	S	Pull Handle
24	791-613103	1		Rope
25	753-04402	1		Starter Housing Assembly (Incl. Ref No. 22-24, 26 & 29)
26	791-181862	1	/P	Housing Screw
27	753-05860	1	/P	Clutch Rotor Assembly
28	753-04403	1		Clutch Cover Assembly (Incl. Ref No. 29-32)
29	791-181345	1	/P	Cover Screw
30	791-182519	1		Anti-Rotation Screw
31	753-04003	1		Clamping Screw
32	791-180217	1	S	Clamping Nut
33	753-05025	1	/P	Wire Leads and Sleeve
34	791-611063	1	/P	Ground Tab
35	753-04336	1		Module Assembly
36	791-610311B	1	/P	Spark Plug
37	753-05169	1	/P	Muffler Assembly (Incl. Ref No. 38, 39 & Spark Arrestor)
38	753-04619	1	/P	Exhaust Gasket
39	710-04188A	1	/P	Muffler Mounting Bolts
40	753-04814	1	/P	Cylinder Assembly (Incl. Ref No. 42 & 43)
41	753-04367	1	/P	Piston and Rod Assembly
42	753-04182	1		Cylinder Gasket
43	791-182723	1		Cylinder Bolt
	753-1209	1		Piston Ring Set Not Shown
	753-04812	1	/P	Short Block Assembly Not Shown (Incl. Ref No. 10, 36 & 40-43 & Crankcase )

TB70SS 41CDT70C966  
General Assembly



TB70SS 41CDT70C966  
General Assembly

Page 4 of 4

Ref #	Part Number	Qty	S/P/F	Description
1	753-04234	1		Throttle Housing Assembly (Incl. Ref No. 2-4)
2	753-04119	1	/P	Throttle Trigger
3	791-182690	1		Throttle Trigger Spring
4	791-182405	1	/P	Switch
5	746-04085A	1	/P	Throttle Cable Assembly
6	753-04344	1	/P	Upper Drive Shaft Housing Assembly
7	791-180869	1		Deluxe D-Handle Assembly (Incl. Ref No. 8-10)
8	791-181070	1		Screw
9	791-182167	1		Deluxe D-Handle
10	791-182168	1		Bottom Clamp
11	753-1190	1	/P	Split Boom Coupler (Incl. Ref No. 12-15)
12	791-182057	1		Screw
13	791-181617	1		Bolt
14	791-181981	1		Adjustment Knob
15	712-04018A	1	/P	Knob Retaining Nut
16	753-04089	1	/P	Lower Drive Shaft Housing Assembly
17	753-05182	1		Lower Flexible Drive Shaft
18	791-145569	1	/P	Anti-Rotation Screw
19	753-05183	1		Gear Box Assembly (Incl. Ref No. 23-27)
20	791-180547	1		Shield Mounting Hardware
21	791-180548	1	/P	Shield Assembly (Incl. Ref No. 22)
22	791-682061	1		Blade Assembly
23	791-153619	1		Outer Spool Assembly (Incl. Ref No. 24)
24	791-610660	1		Retaining
25	791-610317B	1	/P	Spring
26	753-1155	1	/P	Inner Reel
27	791-153066B	1	/P	Bump Head Knob Assembly
28	791-610327	1		Shoulder Strap Clip
	953-1156	1	/P	Reel and Line Assembly Not Shown, Optional Accessories
	791-682075B	1	/P	Shoulder Strap Not Shown, Optional Accessories