


TP720r 41AJTP-A054  
General Assembly

Page 1 of 2



TP720r 41AJTP-A054  
General Assembly

Page 2 of 2

Ref #	Part Number	Qty	S/P/F	Description
1	791-180966B	1		Blade (2 pack)
2	791-181153	1		Blade Cover
3	791-181155	1		Blade Clamp
4	791-181156	1		Blade Clamp Screw and Washer Assembly
5	791-181874	1		Arbor Assembly
6	791-181875	1		Bevel Gear
7	791-181876	1		Washer
8	791-181877	1		Pinion Bevel Gear
9	791-181851	1		Insulator
10	791-181878	1	/P	Slide Bushing
11	791-181879	1	/P	Felt Seal
12	791-181880	1		Slider (2-pack)
13	791-181881	1		Rubber Plug
14	791-181991	1		Housing set
15	791-181345	1	/P	Housing Screw (8 required)
16	791-181883	1		Anti-Rotation Screw
17	791-181166	1		Drive Shaft Assembly
18	791-181992	1		Drive Shaft Housing Assembly
19	791-612605	1	/P	Hanger
20	791-181980	1		Coupler (includes items 21-24)
21	791-181617	1		Bolt
22	791-181981	1		Adjustment Knob
23	791-181886	1		Knob Retaining Nut
24	791-182057	1		Screw
25	791-181161	1	S	Extension Boom and Flex Shaft Assembly
26	753-1214	1		Anti-Rotation Screw
	791-181167	1		Allen Wrench 9/64" Not shown
	791-682075B	1	/P	Shoulder Harness Not shown