

## Service Kit 753-04867

DATE: May 06, 2004

SUBJECT: Grass Bag Assembly

Replacement

MODELS AFFECTED: Not Applicable

PURPOSE: Use this Service Kit when it is necessary to replace grass bag, P/N 764-0475A. This kit includes an updated grass bag and frame.

NOTE: Keep this instruction sheet. Refer to it when ordering replacement parts for the grass bag assembly.

## **Service Kit Contents**

REF.	PART	QTY	DESCRIPTION
NO.	NUMBER		
1	764-04003-0637	1	FRAME: REAR
2	764-04004-0637	1	FRAME: FRONT
3	664-04014	1	BAG: GRASS
4	769-01259	1	THIS INSTRUCTION SHEET

## Instructions:

- 1. Remove and DISCARD original grass bag and frame. IMPORTANT: Do not attempt to modify original grass bag and/or frame.
- 2. Clean grass debris from underside of rear door.
- 3. Install Grass Bag Assembly provided in this kit in accordance with the "Attaching the Grass Catcher" section instructions in the Operator's Manual.

Service Kit 753-04867 Page 1 of 1 Form No. 769-01259