


2006 ATV 250 UTILITY RED (A2006KUE2BUSR)
AIR INTAKE ASSEMBLY

Page 1 of 71




2006 ATV 250 UTILITY RED (A2006KUE2BUSR)
AIR INTAKE ASSEMBLY

Page 2 of 71

Ref #	Part Number	Qty	S/P/F	Description
1	3303-705	1		Cover, Air Filter Housing
2	3303-708	4		Clip, Spring
3	3303-703	1		Seal, Air Filter Housing Cover
4	3303-704	1		Filter, Air - Assembly (inc. 5)
5	0	1	F	Filter, Foam
6	3304-416	1		Clamp, Hose w/Screw
7	3303-707	1		Body, Air Filter Housing
8	3304-652	2		Screw w/Washer
9	3303-713	1		Clip, Tube
10	3304-168	1	/P	Tube, Drain
11	3303-709	2		Clamp, Hose w/Screw
12	3303-710	1		Duct
13	3304-062	1		Screw, Body
14	3304-433	2		Clip, Tube
15	3303-711	1		Joint, Blow-By
16	3304-117	2		Screw, Pan-Head w/Washer
17	3303-734	1		Tube B - Oil Catch (inc. one No. 18)
18	3303-714	2		Clip, Tube
19	3303-706	1		Catch, Oil
20	3304-553	2		Bolt, Flange
21	3303-735	1		Tube C - Oil Catch (inc. two No. 22)
22	3303-712	3		Clip, Tube
23	3303-733	1		Tube A - Oil Catch (inc. one No. 18)
24	3304-167	1		Clamp

2006 ATV 250 UTILITY RED (A2006KUE2BUSR)
AUXILIARY BRAKE ASSEMBLY


Page 3 of 71



2006 ATV 250 UTILITY RED (A2006KUE2BUSR)
AUXILIARY BRAKE ASSEMBLY

Page 4 of 71

Ref #	Part Number	Qty	S/P/F	Description
1	3303-926	1		Lever, Brake
2	3304-139	2		Washer
3	3304-143	1		Pin
4	3303-855	1		Spring, Stop - Brake Lever
5	3303-929	1		Spring, Set - Brake Lever
6	3303-854	1		Switch, Brake
7	3303-927	1		Pin, Clevis
8	3304-050	1		Washer
9	3304-141	1		Pin, Cotter
10	3304-306	1		Brake Assembly - Rear (inc. 11-20)
11	3303-928	1		Actuator, Push Rod
12	3304-128	2		Nut, Jam
13	0	1	F	Master Cylinder
14	3303-321	1		Screw w/Washer
15	3304-307	1		Connector
16	3303-895	2		Clamp, Brake Hose
17	3304-308	1		Hose, Brake
18	3303-896	1		Reservoir, Brake
19	3304-332	1		Cover, Brake Reservoir
20	3304-119	2		Screw, Flat-Head
21	3304-551	3	/P	Screw, Cap
22	3303-284	4	/P	Washer, Crush
23	3303-257	2	/P	Bolt, Banjo-Fitting
24	3303-889	1		Hose, Brake - Assembly - Rear
25	3303-891	1		Clamp, Brake Hose - Rear




2006 ATV 250 UTILITY RED (A2006KUE2BUSR)
BATTERY ASSEMBLY

Page 6 of 71

Ref #	Part Number	Qty	S/P/F	Description
1	3303-937	1		Strap, Battery
2	3303-995	1		Cover, Battery
3	3304-275	1	/P	Battery
4	3304-029	2	/P	Bolt

2006 ATV 250 UTILITY RED (A2006KUE2BUSR)
CARBURETOR ASSEMBLY

Page 7 of 71




2006 ATV 250 UTILITY RED (A2006KUE2BUSR)
CARBURETOR ASSEMBLY

Page 8 of 71

Ref #	Part Number	Qty	S/P/F	Description
	3303-698	1		Complete Carburetor Assembly
1	3304-218	1		Cover, Top - Assembly (inc. 2)
2	3304-217	1		Gasket, Top
3	3304-230	1		Spring, Compression
4	3304-454	1		Clip, Needle
5	3304-240	1		Clip, E
6	3304-448	1		Needle, Jet
7	3304-216	1		Valve, Throttle
8	3304-456	1		Jet, Needle
9	3304-215	1		Screw, Adjuster
10	3304-232	1		Spring, Compression
11	3304-250	1		Washer
12	3304-237	1		O-Ring
13	3304-427	2		Screw w/Washer
14	3304-229	1		Plate, Cover - Diaphragm
15	3304-449	1		Spring, Compression
16	3304-227	1		Diaphragm
17	3304-450	1		Clip, E
18	3304-238	1		O-Ring
19	3304-447	1		Holder, Needle Jet
20	3304-441	1		Jet, Main
21	3304-214	1		Holder, Main Jet
22	3304-445	1		Jet, Slow
23	3304-231	1		Spring, Compression
24	3304-455	1		Screw, Stop
25	3304-233	1		Spring, Torsion
26	3303-627	1		Lever, Choke
27	3304-443	1		Bracket, Choke Cable
28	3304-241	1		Clamp, C
29	3303-319	1	S	Screw w/Washer
30	3304-429	1		Screw w/Washer
31	3304-242	1		Valve, Float
32	3304-249	1		Clip, Float Valve
33	3304-451	1		Pin, Float Arm
34	3304-444	1		Float, Set
35	3304-220	1		Chamber, Float - Assembly
36	3304-243	1		Screw, Drain
37	3304-239	1		O-Ring
38	3304-219	1		Gasket, Float Chamber
39	3304-452	1		Clip, Tube
40	3304-446	1		Tube, Set
41	3304-453	1		Clip, Tube
42	3304-428	3		Screw w/Washer
43	3305-268	1	S	Tube, Drain

2006 ATV 250 UTILITY RED (A2006KUE2BUSR)
CLUTCH ASSEMBLY

Page 9 of 71




2006 ATV 250 UTILITY RED (A2006KUE2BUSR)
CLUTCH ASSEMBLY

Page 10 of 71

Ref #	Part Number	Qty	S/P/F	Description
1	3303-774	3		Slide
2	3303-773	1		Plate, Ramp
3	3303-772	6		Guide, Roller
4	3303-770	1		Face, Movable Drive (inc. 5-6)
5	3304-160	1		Ring, Retaining
6	3303-771	1		Bushing
7	3303-769	1		Sleeve, Drive Face
8	3303-782	1		Belt, Drive
9	3303-768	1		Face, Fixed - Drive
10	3304-024	1		Nut, Jam
11	3303-781	1		Clutch, Driven - Assembly (inc. 12-31)
12	3303-783	1		Face, Fixed - Driven (inc. 13-15)
13	3304-072	1		Bearing
14	3304-149	1		Circlip
15	3304-070	1		Bearing
16	3303-786	4		Pin, Roller Guide
17	3303-787	4		Roller, Guide
18	3304-082	2		Seal, Oil
19	3303-785	1		Face, Movable - Driven
20	3304-107	2		O-Ring
21	3303-789	1		Collar, Seal
22	3303-788	1		Spring, Driven Face
23	3303-790	1		Collar, Spring
24	3303-775	1		Clutch, Centrifugal - Assembly (inc. 25-30)
25	3304-054	3		E-Ring
26	3303-777	1		Plate, Side
27	3303-778	3		Spring, Clutch
28	3303-779	3		Weight, Clutch
29	3303-780	3		Rubber, Clutch Damper
30	3303-776	1		Plate, Drive Clutch
31	3304-025	1	/P	Nut
32	3303-767	1		Clutch, Outer
33	3303-638	1		Sleeve, Driveshaft
34	3304-023	1		Nut, Jam
35	3303-828	1		Ratchet, Face

2006 ATV 250 UTILITY RED (A2006KUE2BUSR)
COOLING ASSEMBLY

Page 11 of 71




2006 ATV 250 UTILITY RED (A2006KUE2BUSR)
COOLING ASSEMBLY

Page 12 of 71

Ref #	Part Number	Qty	S/P/F	Description
1	3303-743	1	/P	Shroud, Radiator
2	3304-653	4	S	Screw w/Washer
3	3303-744	1		Screen, Radiator
4	3304-123	6	/P	Screw w/Washer
5	3303-741	1		Fan, Cooling
6	3303-742	1		Motor, Fan
7	3303-739	1		Shroud, Fan
8	3304-586	3	/P	Bolt
9	3303-984	1		Bracket, Radiator - Lower
10	3304-116	4		Bolt w/Washer
11	3303-737	1		Radiator Assembly
12	3303-759	1		Hose, Cooling - Radiator/Engine
13	3304-164	2		Clamp, Hose
14	3303-862	1		Switch, Temperature
15	3304-587	6	/P	Bolt w/Washer
16	3303-983	1		Bracket, Radiator - Upper
17	3304-165	4	/P	Clamp, Hose
18	3303-761	1		Hose, Cooling - Radiator
19	3304-553	1		Bolt, Flange
20	3303-738	1		Neck, Filler
21	3303-748	1		Cap, Radiator
22	3304-654	2	/P	Nut
23	3303-740	1		Bracket, Mounting - Filler Neck
24	3304-066	1		Tube Assembly - Water Pump (inc. 25)
25	3304-161	2		Clip, Tube
26	3303-993	1		Shield, Master Cylinder
27	3303-749	1		Cap, Reserve Tank
28	3304-253	1		Tank, Reserve
29	3304-163	2		Clip, Tube
30	3303-349	1		Clip, Tube
31	3303-745	1		Hose, Drain - Reserve Tank
32	3303-746	1		Hose, Reserve Tank
33	3304-650	8	/P	Screw, Self-Tapping
34	3303-637	1		Duct, Cooling - Cover
35	3303-709	1		Clamp w/Screw
36	3303-633	1		Duct, Cooling
37	3303-636	1		Clamp w/Screw
38	3303-635	1		Clamp w/Screw
39	3303-634	1		Duct, Cooling
40	3303-640	1		Element, Duct
41	3303-320	3		Screw w/Washer
42	3303-760	1		Hose, Cooling - Engine/Radiator

2006 ATV 250 UTILITY RED (A2006KUE2BUSR)
CRANKCASE ASSEMBLY

Page 13 of 71




2006 ATV 250 UTILITY RED (A2006KUE2BUSR)
CRANKCASE ASSEMBLY

Page 14 of 71

Ref #	Part Number	Qty	S/P/F	Description
1	3304-008	2		Bolt, Stud
2	3303-626	1		Crankcase - Right (inc. 3)
3	3304-065	1		Plug, Cone-Type
4	3303-628	1		Gasket, Crankcase
5	3303-342	4		Pin, Dowel
6	3304-091	1		Seal, Oil
7	3304-198	2		Bearing
8	3304-191	4	/P	Screw, Cap
9	3303-629	1		Crankcase - Left
10	3304-009	2		Bolt, Stud
11	3304-195	1		Bearing
12	3304-074	1	/P	Bearing
13	3304-079	1		Seal, Oil
14	3303-283	1	S	Plug, Drain
15	3304-205	1		Ball, Steel
16	3304-063	1		Spring, Bolt Seat Inner
17	3304-021	1		Washer, Bolt Seat
18	3304-109	1		Bolt, Seat Ball Stopper
19	3303-365	1		Screw, Cap
20	3303-381	3		Screw, Cap
21	3304-158	1		Clip, Wire
22	3304-005	2		Screw, Cap
23	3304-039	2		Plate, Bearing Holder
24	3303-642	1		Gasket, Crankcase Cover - Left
25	3303-843	2		Clamp, Wire
26	3303-856	1		Cable, Gear Change
27	3304-187	1		Screw, Cap
28	3304-073	1	/P	Bearing
29	3303-632	1		Cover, Crankcase - Left
30	3304-003	8		Screw, Cap
31	3304-101	1		Gasket, Starter Cover
32	3303-341	2		Pin, Dowel
33	3303-643	1		Recoil Starter - Assembly (inc. 34-47)
34	3304-113	1		Bolt, Hex
35	3303-651	1		Insert, Collar
36	3303-649	1		Guide, Ratchet
37	3303-646	2		Ratchet
38	3303-647	1		Spring, Ratchet Guide
39	3303-645	1		Spiral, Starter
40	3303-644	1		Reel, Starter Spiral
41	3303-648	1		Spacer, Starter - Reel/Cover
42	3303-639	1		Cover, Starter (inc. 43)
43	3303-650	1		Rope, Starter
44	3303-652	1		Handle, Starter Rope (inc. 45)
45	3304-103	1		O-Ring
46	3305-269	1		Cap, Starter Rope Handle
47	3304-137	1		Washer
48	3304-190	2		Screw, Cap
49	3303-384	3	/P	Screw, Cap
50	3304-004	2		Bolt, Flange

2006 ATV 250 UTILITY RED (A2006KUE2BUSR)
CRANKCASE COVER ASSEMBLY

Page 15 of 71



2006 ATV 250 UTILITY RED (A2006KUE2BUSR)
CRANKCASE COVER ASSEMBLY

Page 16 of 71


Ref #	Part Number	Qty	S/P/F	Description
1	3304-192	8		Screw, Cap
2	3303-387	4		Screw, Cap
3	3303-385	2		Screw, Cap
4	3303-619	2	/P	Screw, Cap
5	3303-752	1		Cover, Water Pump
6	3304-186	1		Screw, Cap
7	3304-049	1		Washer
8	3303-753	1		Gasket, Water Pump
9	3303-341	2		Pin, Dowel
10	3303-750	1		Impeller, Water Pump
11	3304-038	1		Washer
12	3303-382	3	/P	Screw, Cap
13	3304-013	1		Cap, Crankcase Cover - Assembly (inc. one No. 14 and 15)
14	3303-302	2	S	O-Ring
15	3304-098	1		O-Ring
16	3303-695	1		Gauge, Oil Level (inc. 17)
17	3303-306	1	S	O-Ring
18	3304-012	1		Cap
19	3304-099	1		O-Ring
20	3303-631	1		Cover, Crankcase (inc. 21-25)
21	3303-751	1		Seal, Mechanical
22	3304-078	1		Seal, Oil
23	3304-068	1		Bearing
24	3303-696	1		Finder, Oil Level
25	0	1	F	Sleeve
26	3304-165	2	/P	Clip, Hose
27	3303-758	1		Hose, Water
28	3303-342	2		Pin, Dowel
29	3303-048	1	S	Screen, Oil Filter
30	3303-049	1	S	Spring, Oil Filter
31	3303-021	1		Cap, Oil Filter
32	3303-641	1		Gasket
33	3303-754	1		Shaft, Water Pump
34	3304-193	1		Bearing
35	3304-148	1		Circlip



2006 ATV 250 UTILITY RED (A2006KUE2BUSR)
CYLINDER HEAD ASSEMBLY

Page 18 of 71

Ref #	Part Number	Qty	S/P/F	Description
	3303-622	1	F	Complete Engine Assembly AC50AA
1	3303-756	1		Housing, Thermostat - Upper
2	3303-617	1	/P	Bolt, Flange
3	3303-860	1		Terminal, Ground
4	3303-861	1		Unit, Thermostat
5	3304-094	1		O-Ring
6	3303-755	1		Thermostat
7	3303-757	1		Housing, Thermostat - Lower
8	3304-118	2		Screw, Pan-Head
9	3303-360	4		Screw, Cap
10	3303-660	1		Cover, Cylinder Head
11	3303-661	1		Gasket, Cylinder Head Cover
12	3303-332	4		Nut, Lock
13	3303-277	4	S	Washer
14	3303-658	1		Holder, Camshaft
15	3303-342	4		Pin, Dowel
16	3303-670	1		Plate, Stopper - Assembly
17	3303-390	2		Screw, Cap
18	3304-049	2		Washer
19	3303-249	2		Bolt, Stud
20	3303-702	1		Manifold, Intake (inc. 21)
21	3304-097	1		O-Ring
22	3304-124	4		Nut, Lock
23	3304-114	4		Bolt, Stud
24	3304-209	1	S	Spark Plug
25	3304-157	1		Clip, Wire
26	3303-655	1		Head, Cylinder (inc. 27-29)
27	3303-656	1		Bolt, Sealing
28	0	2	F	Guide, Valve
29	0	2	F	O-Ring
30	3303-680	1		Valve, Intake
31	3303-681	1		Valve, Exhaust
32	3303-659	1		Gasket, Head Cylinder
33	3303-017	2	S	Seal, Valve Stem
34	3303-043	2		Seat, Valve Spring
35	3303-683	2		Spring, Valve - Inner
36	3303-682	2		Spring, Valve - Outer
37	3303-042	2	/P	Retainer, Valve Spring
38	3303-044	4		Valve, Cotter
39	3303-669	1		Camshaft
40	3303-674	1		Shaft, Rocker Arm - Intake
41	3303-675	1		Shaft, Rocker Arm - Exhaust
42	3303-246	2	S	Screw, Gap Adjuster
43	3303-673	2		Arm, Rocker
44	3303-260	2	S	Nut, Gap Adjuster




2006 ATV 250 UTILITY RED (A2006KUE2BUSR)
DECALS

Page 20 of 71

Ref #	Part Number	Qty	S/P/F	Description
1	1411-173	1		Decal, Pre-Ride Inspection
2	1411-201	1		Decal, Warning - Rack
3	1411-190	1		Decal, Instrument Pod
4	0411-401	1		Decal, Warning - Age
5	0411-576	1		Decal, Warning - Rack
6	0411-814	1	/P	Decal, "Arctic Cat" - White
7	0411-435	1		Decal, Warning - Passenger
8	1411-102	1		Decal, Warning - Towing
9	1411-178	1		Decal, Reflector - Rear - Right
9	1411-179	1		Decal, Reflector - Rear - Left
10	1411-188	1		Decal, Side - Lower Right
10	1411-189	1		Decal, Side - Lower Left
11	1411-184	1		Decal, Side - Upper Right
11	1411-185	1		Decal, Side - Upper Left
12	1411-108	1		Decal, Warning -Tire/Load
13	0411-218	1		Decal, Warning - General
14	1411-180	1		Decal, Reflector - Front - Right
14	1411-181	1		Decal, Reflector - Front - Left
15	1411-194	1		Decal, Front

2006 ATV 250 UTILITY RED (A2006KUE2BUSR)
ELECTRICAL AND WIRING HARNESS ASSEMBLY

Page 21 of 71




2006 ATV 250 UTILITY RED (A2006KUE2BUSR)
ELECTRICAL AND WIRING HARNESS ASSEMBLY

Page 22 of 71

Ref #	Part Number	Qty	S/P/F	Description
1	3303-838	1		Harness, Main (inc. 2)
2	3304-210	1		Fuse - 10 Amp
2	3304-211	2		Fuse - 15 Amp
2	3304-212	1		Fuse - 30 Amp
3	3303-836	1		Regulator, Voltage
4	3303-331	4	/P	Nut
5	3303-830	1		Coil, Ignition (inc. 6)
6	3303-831	1		Cap, Noise Suppression
7	3303-382	2	/P	Screw, Cap
8	3303-829	1		CDI Unit
9	3303-867	1		Relay, Start-in-Gear
10	3303-841	1		Cable, Battery
11	3303-850	1		Switch, Ignition - Assembly (inc. 12-15)
12	0	1	F	Switch, Ignition
13	3304-522	1		Cover, Key - "Arctic Cat"
14	3304-520	1	F	Key, Ignition w/Cover Right Side Cut
15	3304-521	1	F	Key, Ignition w/Cover Left Side Cut
16	3303-134	1	/P	Sub-Cord
17	3303-857	1		Relay, Starter
18	3303-840	1		Cable Tie
19	3303-837	1		Diode, Neutral
20	3304-523	1		Relay, Lighting Control

2006 ATV 250 UTILITY RED (A2006KUE2BUSR)
EXHAUST ASSEMBLY

Page 23 of 71




2006 ATV 250 UTILITY RED (A2006KUE2BUSR)
EXHAUST ASSEMBLY

Page 24 of 71

Ref #	Part Number	Qty	S/P/F	Description
1	3303-729	1		Muffler Assembly (inc. 2-9)
2	3303-727	4		Packing, Exhaust Shield
3	3303-730	1		Shield, Exhaust
4	3304-134	2		Washer
5	3304-140	2		Washer, Spring
6	3303-381	2		Bolt, Flange
7	3303-726	2		Bushing, Rubber
8	3303-728	4		Packing, Muffler Assembly
9	3303-731	2		Collar, Muffler Assembly
10	3303-332	1		Nut, Flange
11	3304-175	1		Bolt, Flange
12	3303-725	1		Gasket, Exhaust Pipe
13	3304-125	2		Nut, Hex

2006 ATV 250 UTILITY RED (A2006KUE2BUSR)
FINAL DRIVE ASSEMBLY

Page 25 of 71




2006 ATV 250 UTILITY RED (A2006KUE2BUSR)
FINAL DRIVE ASSEMBLY

Page 26 of 71

Ref #	Part Number	Qty	S/P/F	Description
1	3304-170	1	/P	Bladder, Rear Gearcase
2	3304-669	1		Clip
3	3303-877	1		Fitting, Bladder
4	3304-177	6		Screw, Cap
5	3303-365	2		Screw, Cap
6	3303-591	2		Washer
7	3304-178	2		Screw, Cap
8	3303-873	1		Cover, Rear Gearcase
9	3303-879	1		Shim
10	3303-878	1		Pin, Ring Gear
11	3304-095	2		O-Ring
12	3304-670	1		O-Ring
13	3304-092	1		Seal, Oil
14	3304-194	2		Bearing
15	3305-311	AR		Shim, 46 x 54 x 1.47 mm
15	3303-881	AR		Shim
15	3305-310	AR		Shim
16	3303-876	1		Gear, Ring
17	3304-093	1		Seal, Oil
18	3303-872	1		Gearcase - Rear
19	3303-021	1		Plug, Fill
20	3304-096	1	/P	O-Ring
21	3304-076	1		Bearing, Needle
22	3303-874	1		O-Ring
23	3303-875	1		Gear, Pinion
24	3305-313	AR		Shim, 31 x 40 x 1.97 mm
24	3305-312	AR		Shim
24	3303-880	AR		Shim
25	3304-085	1		Seal, Dust
26	3304-196	1		Bearing
27	3304-027	1		Nut, Lock
28	3313-670	1		Seal

2006 ATV 250 UTILITY RED (A2006KUE2BUSR)
FRAME AND RELATED PARTS ASSEMBLY

Page 27 of 71




2006 ATV 250 UTILITY RED (A2006KUE2BUSR)
FRAME AND RELATED PARTS ASSEMBLY

Page 28 of 71

Ref #	Part Number	Qty	S/P/F	Description
1	3303-933	1		Frame, Main
2	3304-064	1		Seal, Dust
3	3303-942	1		Bracket, Mounting - Front Rack - Right
3	3303-943	1		Bracket, Mounting - Front Rack - Left
4	3304-553	4		Screw, Cap
5	3303-938	2		Bracket, Mounting - Engine
6	3304-543	8	/P	Screw, Cap
7	3304-150	1		Circlip
8	3304-203	1		Bearing
9	3303-298	1		Seal, Oil
10	3303-935	1	/P	Bracket, Mounting - Clutch/Gas Tank
11	3304-659	4	S	Nut, Flange
12	3303-265	3	S	Nut
13	3304-661	1	S	Screw, Cap
14	3304-660	2	S	Screw, Cap
15	3304-658	2		Cap, End
16	3303-999	2		Cap, End
17	3303-936	1		Bracket, Mounting - Rear Rack
18	3303-239	4		Grommet, Rubber
19	3303-934	1		Bracket, Mounting - Starter/Magneto Switch
20	3304-409	1	/P	Bolt w/Washer
21	3304-655	1		Bracket, Mounting - Brake Switch

2006 ATV 250 UTILITY RED (A2006KUE2BUSR)
FRONT BODY PANEL ASSEMBLY

Page 29 of 71




2006 ATV 250 UTILITY RED (A2006KUE2BUSR)
FRONT BODY PANEL ASSEMBLY

Page 30 of 71

Ref #	Part Number	Qty	S/P/F	Description
1	3303-978	1		Cover, Front
2	3304-029	6	/P	Bolt w/Washer
3	3303-721	1		Grommet, Gas Tank Cover
4	3303-976	1		Guide, Shift Handle
5	3304-650	2	/P	Screw, Self-Tapping
6	3304-539	1		Cover, Gas Tank
7	3304-061	6	/P	Nut, Clip
8	3303-974	1		Fender, Front
9	3304-651	2		Screw, Self-Tapping
10	3304-156	2		Clip, Wire
11	3304-645	4	/P	Screw
12	3303-981	1		Grill, Front
13	3303-980	1	S	Bumper, Front
14	3304-587	4	/P	Bolt w/Washer
15	3303-720	1		Tube, Fuel Drain (inc. 16)
16	3303-349	1		Clip, Tube

2006 ATV 250 UTILITY RED (A2006KUE2BUSR)
FRONT SUSPENSION ASSEMBLY

Page 31 of 71




2006 ATV 250 UTILITY RED (A2006KUE2BUSR)
FRONT SUSPENSION ASSEMBLY

Page 32 of 71

Ref #	Part Number	Qty	S/P/F	Description
1	3303-964	1		A-Arm Assembly - Upper Right (inc. 2-4)
1	3303-967	1		A-Arm Assembly - Upper Left (inc. 2-4)
2	3304-090	16		Seal, Oil
3	3304-689	16	/P	Bushing, Swing Arm
4	3304-199	8		Bearing
5	3303-265	12	S	Nut
6	3304-663	8	S	Bolt, Flange
7	3303-376	2	/P	Bolt, Flange
8	3303-930	1		Knuckle - Assembly - Right
8	3303-932	1		Knuckle - Assembly - Left
9	3303-941	2		Cushion - Assembly - Front
10	3304-595	2	/P	Bolt, Flange
11	3303-966	1		A-Arm Assembly - Lower Right (inc. 2-4)
11	3303-968	1		A-Arm Assembly - Lower Left (inc. 2-4)
12	3303-335	4		Washer
13	3303-328	4		Nut, Castle
14	3303-339	4		Pin, Cotter
15	3303-920	2		Guard, Brake Disc
16	3304-664	4	S	Bolt, Flange

2006 ATV 250 UTILITY RED (A2006KUE2BUSR)
FRONT WHEELS AND BRAKE ASSEMBLY

Page 33 of 71




2006 ATV 250 UTILITY RED (A2006KUE2BUSR)
FRONT WHEELS AND BRAKE ASSEMBLY

Page 34 of 71

Ref #	Part Number	Qty	S/P/F	Description
1	3303-931	2		Cap, Wheel
2	3303-340	2		Pin, Cotter
3	3303-330	2		Nut
4	3303-902	2	/P	Wheel, Front
5	3304-562	2		Valve, Wheel
6	3304-028	8		Nut, Wheel
7	3303-903	2		Hub, Wheel - Assembly - Front (inc. 8-16)
8	0	2	F	Hub, Wheel - Front
9	3304-089	2		Seal, Oil
10	3303-898	2		Collar, Wheel - Inside
11	3304-200	2		Bearing
12	3303-900	2		Collar, Wheel - Center
13	3304-202	2		Bearing
14	3303-899	2		Collar, Wheel - Outside
15	3304-088	2		Seal, Oil
16	3304-014	8		Bolt, Hub
17	3303-912	1		Disc, Brake - Front - Right
17	3303-918	1		Disc, Brake - Front - Left
18	3304-015	6		Bolt
19	3304-313	1	/P	Caliper Assembly - Front - Right (inc. 20-32)
19	3303-921	1		Caliper Assembly - Front - Left (inc. 20-32)
20	0	1	F	Housing, Caliper - Assembly - Right
20	0	1	F	Housing, Caliper - Assembly - Left
21	3304-334	2		Plug
22	3304-326	4		Pin
23	3304-330	2		Valve, Bleed
24	3304-331	2		Cap, Bleed Valve
25	3304-317	1		Bracket, Right
25	3304-328	1		Bracket, Left
26	3303-908	2		Pad, Brake - Set
27	3304-315	2		Spring, Brake Pad
28	3304-322	2		Boot A
29	3304-329	1		Bushing
30	3303-922	2		Seal, Piston - Inner
31	3303-910	2		Seal, Dust - Outer
32	3303-909	2		Piston
33	3304-174	4		Screw, Cap
34	3303-904	2		Tire, Front

2006 ATV 250 UTILITY RED (A2006KUE2BUSR)
GAS TANK ASSEMBLY

Page 35 of 71




2006 ATV 250 UTILITY RED (A2006KUE2BUSR)
GAS TANK ASSEMBLY

Page 36 of 71

Ref #	Part Number	Qty	S/P/F	Description
1	3304-246	1	/P	Cap, Gas Tank - Assembly (inc. 2, one No. 3, and 4)
2	3304-169	1		Hose, Vent
3	3303-348	3		Clip, Tube
4	0	1	F	Diaphragm
5	3303-058	1		Screen, Fuel Strainer
6	3303-717	1		Tank Assembly - Gas (inc. 7-10)
7	3304-647	2		Grommet, Rubber
8	3303-406	2		Grommet, Rubber
9	0	1	F	Seal, Gas Tank
10	0	1	F	Collar, Gas Tank
11	3304-646	4		Screw w/Washer
12	3303-865	1		Sensor, Fuel Level
13	3303-226	4		Collar, Front Fender
14	3303-331	2	/P	Nut
15	3304-551	2	/P	Screw, Cap
16	3303-718	2		Tube Assembly - Gas Tank (inc. 17 and two No. 18)
17	3303-351	2		Clamp, Tube
18	3303-349	4		Clip, Tube
19	3303-700	1		Valve, Gas Tank (inc. 20)
20	3301-828	1	/P	Screw
21	3303-316	2		Screw, Pan-Head
22	3303-701	1		Cover, Gas Tank Valve
23	3303-056	1	S	Strainer, Fuel - Assembly
24	3304-171	1		Tube Assembly - Fuel Strainer (inc. two No. 18)
25	3304-172	1		Tube Assembly - Fuel Strainer (inc. two No. 3)
26	3303-724	1		Bracket, Mounting - Gas Tank Valve
27	3304-409	2	/P	Screw

2006 ATV 250 UTILITY RED (A2006KUE2BUSR)
HANDLEBAR AND CONTROLS ASSEMBLY

Page 37 of 71




2006 ATV 250 UTILITY RED (A2006KUE2BUSR)
HANDLEBAR AND CONTROLS ASSEMBLY

Page 38 of 71

Ref #	Part Number	Qty	S/P/F	Description
1	3303-953	1		Lever, Throttle - Assembly
2	3303-723	1		Cable, Choke
3	1502-094	1	/P	Cable, Throttle - Kit
4	3303-839	1		Cable Tie
5	3304-016	2		Bolt w/Washer
6	3303-952	2		Cap, End - Handlebar
7	3303-203	2	S	Grip, Handlebar
8	3303-852	1	/P	Switch Assembly - Left
9	3303-950	1		Handlebar
10	3304-029	2	/P	Bolt w/Washer
11	3303-958	1		Instrument Pod
12	3304-110	4		Bolt
13	3304-135	4	/P	Washer
14	3303-951	1		Bracket, Instrument Pod
15	3304-552	1		Clip
16	3303-954	2		Holder, Handlebar - Upper
17	3303-955	2		Holder, Handlebar - Lower
18	3303-336	2	S	Washer
19	3303-325	2		Nut

2006 ATV 250 UTILITY RED (A2006KUE2BUSR)
HEADLIGHT ASSEMBLY

Page 39 of 71




2006 ATV 250 UTILITY RED (A2006KUE2BUSR)
HEADLIGHT ASSEMBLY

Page 40 of 71

Ref #	Part Number	Qty	S/P/F	Description
1	3303-844	1		Headlight Assembly - Right (inc. 2-5)
1	3303-845	1		Headlight Assembly - Left (inc. 2-5)
2	3304-643	1		Lens, Headlight - Right
2	3304-644	1		Lens, Headlight - Left
3	3303-846	2	/P	Bulb, Headlight
4	3303-847	2		Bulb, Position
5	0	2	F	Socket Assembly
6	3304-587	2	/P	Screw w/Washer
7	3304-057	2	/P	Clip, Fender
8	3304-645	6	/P	Screw, Self-Tapping

2006 ATV 250 UTILITY RED (A2006KUE2BUSR)
HYDRAULIC BRAKE HOSE AND HAND BRAKE ASSEMBLY

Page 41 of 71




2006 ATV 250 UTILITY RED (A2006KUE2BUSR)
HYDRAULIC BRAKE HOSE AND HAND BRAKE ASSEMBLY

Page 42 of 71

Ref #	Part Number	Qty	S/P/F	Description
1	3303-257	4	/P	Bolt, Banjo-Fitting
2	3303-284	11	/P	Washer, Crush
3	3304-553	2		Bolt, Flange
4	3303-919	2		Clamp, Brake Hose - Front
5	3304-320	1		Hose, Brake w/Junction Block - Front
6	3304-662	1		Screw, Cap
7	3304-673	1	S	Hose, Brake - Assembly - Front
8	3304-674	1	/P	Bolt, Banjo-Fitting - Double
9	3303-914	1		Hose, Brake - Assembly - Rear
10	3304-664	1	S	Screw, Cap
11	3303-891	1		Clamp, Brake Hose - Rear
12	3304-611	2	S	Screw, Cap
13	3304-676	1		Master Cylinder - Assembly - Rear Brake (inc. 14-17)
14	3303-318	2		Screw, Flat-Head
15	3303-175	1	/P	Clamp, Master Cylinder
16	3303-923	1		Cover, Master Cylinder
17	3303-925	1		Diaphragm, Master Cylinder
18	3303-956	1	S	Lever, Brake
19	3304-017	1		Bolt, Brake Lever
20	3304-132	1	S	Nut, Flange
21	3303-141	1	/P	Switch, Brake
22	3303-321	1		Screw w/Washer
23	3304-677	1	S	Lock, Brake Lever
24	3304-678	1		Spring, Return - Brake Lever
25	3304-679	1		Pin - Brake Lever
26	3304-680	1		Clip - Brake Lever
27	3304-675	1		Clip, Hose - Double

2006 ATV 250 UTILITY RED (A2006KUE2BUSR)
PISTON AND CRANKSHAFT ASSEMBLY

Page 43 of 71




2006 ATV 250 UTILITY RED (A2006KUE2BUSR)
PISTON AND CRANKSHAFT ASSEMBLY

Page 44 of 71

Ref #	Part Number	Qty	S/P/F	Description
1	3303-663	1		Crankshaft Assembly (inc. 2)
2	3304-419	2	S	Bearing
3	3304-145	1		Key
4	3303-694	1		Spring, Oil Through
5	3303-693	1		Oil Through
6	3304-236	1		Gear, Timing
7	3303-689	1		Gear, Oil Pump Drive
8	3303-671	1		Chain, Cam
9	3303-679	1		Guide, Cam Chain
11	3303-676	1		Tensioner, Cam Chain
10	3303-678	1		Pivot, Cam Chain Tensioner
12	3303-653	1		Cylinder Assembly
13	3303-664	1	/P	Ring Set, Piston
14	3304-159	2		Circlip
15	3303-677	1		Lifter, Cam Chain Tensioner
16	3303-035	1		Gasket, Cylinder
17	3304-006	2		Screw w/Washer
18	3303-243	2	S	Screw, Cap
19	3303-305	1	S	O-Ring
20	3303-342	2		Pin, Dowel
21	3303-665	1		Piston
22	3303-666	1		Pin, Piston
23	3303-654	1	S	Gasket, Cylinder
24	3303-667	1		Balancer, Crankshaft (inc. 25)
25	3304-439	1		Key

2006 ATV 250 UTILITY RED (A2006KUE2BUSR)
RACKS AND BUMPER ASSEMBLY

Page 45 of 71




2006 ATV 250 UTILITY RED (A2006KUE2BUSR)
RACKS AND BUMPER ASSEMBLY

Page 46 of 71

Ref #	Part Number	Qty	S/P/F	Description
1	3303-987	1		Rack, Rear
2	3304-668	2		Nut, Flange
3	3304-543	18	/P	Screw, Cap
4	3303-332	2		Nut
5	3304-667	2	S	Bolt, Flange
6	3303-939	1		Bracket, Floor Panel - Right
6	3303-940	1		Bracket, Floor Panel - Left
7	3303-988	1		Rack, Front
8	3303-871	1		Plate, Skid - Assembly
9	3304-544	3		Screw, Cap
10	3304-001	1		Bumper, Front - Assembly

2006 ATV 250 UTILITY RED (A2006KUE2BUSR)
REAR BODY PANEL ASSEMBLY

Page 47 of 71




2006 ATV 250 UTILITY RED (A2006KUE2BUSR)
 REAR BODY PANEL ASSEMBLY

Page 48 of 71

Ref #	Part Number	Qty	S/P/F	Description
1	3304-587	19	/P	Bolt
2	3303-991	1		Mudguard, Floor - Right
2	3303-992	1		Mudguard, Floor - Left
3	3303-251	11	/P	Screw
4	3304-538	11	S	Nut
5	3303-592	3		Clip, Mudguard
6	3303-997	1		Fender, Rear - Lower Right
6	3303-998	1		Fender, Rear - Lower Left
7	3303-989	1		Fender, Rear
8	3303-233	2		Collar, Insert
9	3303-227	2		Grommet, Rubber
10	3304-650	10	/P	Screw, Self-Tapping
11	3303-232	2		Grommet, Rubber
12	3304-061	2	/P	Nut, Clip
13	3304-651	1		Screw, Self-Tapping
14	3304-156	1		Clip, Wire
15	3303-994	1		Molding, Rear Fender
16	3304-586	2	/P	Bolt w/Washer

2006 ATV 250 UTILITY RED (A2006KUE2BUSR)
REAR SUSPENSION ASSEMBLY

Page 49 of 71




2006 ATV 250 UTILITY RED (A2006KUE2BUSR)
 REAR SUSPENSION ASSEMBLY

Page 50 of 71

Ref #	Part Number	Qty	S/P/F	Description
1	3303-949	1		Cushion - Assembly - Rear
2	3304-665	1	S	Bolt, Flange
3	3303-265	2	S	Nut
4	3304-185	1		Bolt, Flange
5	3303-944	1		Fork - Assembly - Rear (inc. 6-10)
6	3304-086	2		Seal, Dust
7	3304-666	2		Bearing
8	3303-946	2		Seal, Grease
9	3304-201	2		Bearing
10	3304-106	1		O-Ring
11	3303-948	1	S	Gasket w/Seal (inc. 12)
12	3304-084	1	S	Seal, Oil
13	3304-544	3		Screw, Cap
14	3304-181	8		Screw, Cap
15	3304-018	1		Bolt, Right
16	3304-019	1		Bolt, Left
17	3304-020	1		Nut

2006 ATV 250 UTILITY RED (A2006KUE2BUSR)
REAR WHEELS, AXLE, AND BRAKE ASSEMBLY

Page 51 of 71



2006 ATV 250 UTILITY RED (A2006KUE2BUSR)
REAR WHEELS, AXLE, AND BRAKE ASSEMBLY

Page 52 of 71

Ref #	Part Number	Qty	S/P/F	Description
1	3303-931	2		Cap, Wheel
2	3303-340	2		Pin, Cotter
3	3304-129	2		Nut
4	3303-883	2	/P	Wheel, Rear
5	3304-562	2		Valve, Wheel
6	3304-028	8		Nut, Wheel
7	3304-296	2		Hub, Wheel - Rear (inc. 8)
8	3304-014	8		Bolt, Hub
9	3303-893	1		Hub, Brake Disc
10	3303-913	1		Disc, Brake - Rear
11	3304-015	3		Bolt
12	3303-888	1		Caliper Assembly - Foot Brake (inc. 13-25)
12	3303-892	1		Caliper Assembly - Hand Brake (inc. 13-25)
13	0	1	F	Housing, Caliper - Assembly - Right
13	0	1	F	Housing, Caliper - Assembly - Left
14	3304-334	2		Plug
15	3304-326	4		Pin
16	3304-330	2		Bleed Valve
17	3304-331	2		Cap, Bleed Valve
18	3303-911	2		Bracket
19	3303-908	2		Pad, Brake - Set
20	3304-315	2		Spring, Brake Pad
21	3304-322	2		Boot A
22	3304-329	2		Bushing
23	3305-380	1	/P	Seal, Piston - Inner - Foot Brake
23	3303-922	1		Seal, Piston - Inner - Hand Brake
24	3305-377	1	/P	Seal, Dust - Outer - Foot Brake
24	3303-910	1		Seal, Dust -Outer - Hand Brake
25	3303-909	1		Piston - Hand Brake
25	3304-314	1	/P	Piston - Foot Brake
26	3303-368	4	S	Screw, Cap
27	3303-882	1	S	Axle, Wheel - Rear
28	3303-885	2		Tire, Rear

No
Diagram
Available

Parts List
Only


2006 ATV 250 UTILITY RED (A2006KUE2BUSR)
RELATED ITEMS

Page 54 of 71

Ref #	Part Number	Qty	S/P/F	Description
	0436-381	1		Cover, Green and Black
	2257-452	1		Manual, Illustrated Parts
	2257-319	1		Manual, Operator's (E)
	2257-370	1		Manuel d'utilisation (F)
	0436-005	1	S	Oil, Engine - 10W40
	0436-003	1	S	Oil, Engine - 5W30

2006 ATV 250 UTILITY RED (A2006KUE2BUSR)
SEAT AND TOOL KIT ASSEMBLY

Page 55 of 71




2006 ATV 250 UTILITY RED (A2006KUE2BUSR)
SEAT AND TOOL KIT ASSEMBLY

Page 56 of 71

Ref #	Part Number	Qty	S/P/F	Description
1	3303-985	1		Seat Assembly (inc. 2)
2	3303-986	1		Latch, Seat - Hook Assembly
3	3304-648	1		Kit, Tool
4	3303-242	1		Band, Tool Kit

2006 ATV 250 UTILITY RED (A2006KUE2BUSR)
SHIFT LEVER ASSEMBLY

Page 57 of 71




2006 ATV 250 UTILITY RED (A2006KUE2BUSR)
SHIFT LEVER ASSEMBLY

Page 58 of 71

Ref #	Part Number	Qty	S/P/F	Description
1	3303-823	1		Handle, Gear Shift Rod
2	3304-401	1		Bolt, Socket
3	3303-816	1	/P	Rod, Gear Shift
4	3303-817	1		Pin, Gear Shift
5	3304-138	2		Washer
6	3303-818	1		Spring, Gear Shift
7	3303-819	1		Bracket, Gear Shift
8	3304-127	1	S	Nut, Hex
9	3304-188	1	S	Bolt, Flange
10	3304-142	1		Pin, Cotter
11	3303-821	1		Lever, Gear Shift
12	3303-8203305-289	1		Cover, Gear Shift
13	3303-970	1		Ball Joint, Tie Rod - Right
14	3304-125	1		Nut, Hex
15	3303-607	2	/P	Washer
16	3303-822	1		Tie Rod
17	3304-126	1		Nut, Hex
18	3303-972	1		Ball Joint, Tie Rod - Left
19	3303-332	4		Nut
20	3303-814	1		Link, Gear Shift
21	3304-662	2		Screw, Cap

2006 ATV 250 UTILITY RED (A2006KUE2BUSR)
SPEEDOMETER AND CABLE ASSEMBLY

Page 59 of 71




2006 ATV 250 UTILITY RED (A2006KUE2BUSR)
SPEEDOMETER AND CABLE ASSEMBLY

Page 60 of 71

Ref #	Part Number	Qty	S/P/F	Description
1	3303-906	1	/P	Cable, Speedometer
2	3303-859	1		Gauge, Speedometer - Assembly
3	3304-645	3	/P	Screw

2006 ATV 250 UTILITY RED (A2006KUE2BUSR)
STARTER MOTOR AND MAGNETO ASSEMBLY

Page 61 of 71




2006 ATV 250 UTILITY RED (A2006KUE2BUSR)
STARTER MOTOR AND MAGNETO ASSEMBLY

Page 62 of 71

Ref #	Part Number	Qty	S/P/F	Description
1	3303-833	1		Stator
2	3304-118	2		Screw
3	3304-111	3		Bolt, Flange
4	3304-024	1		Nut
5	3304-208	3		Bolt, Socket
6	3303-832	1		Flywheel
7	3303-827	1		Clutch, One-Way
8	3303-825	1		Shaft, Starter Reduction
9	3303-824	1		Gear, Starter Reduction
10	3303-826	1	S	Gear, Starter
11	3303-687	1		Pump, Oil
12	3303-385	2		Screw, Cap
13	3303-688	1		Sprocket, Drive - Oil Pump
14	3303-690	1		Chain, Oil Pump
15	3304-146	1		Circlip
16	3303-697	1		Separator, Oil
17	3303-381	2		Screw, Cap
18	3304-274	1		Motor, Starter (inc. 19-20)
19	3304-104	1		O-Ring
20	3304-011	2		Nut w/Washer
21	3303-243	2	S	Screw, Cap
22	3304-277	1		Cable, Starter Motor
23	3303-842	1		Cable, Ground
24	3304-036	1		Washer, Thrust
25	3304-279	1		Cable, Ground
26	3304-036	1		Washer, Thrust

2006 ATV 250 UTILITY RED (A2006KUE2BUSR)
STEERING POST ASSEMBLY

Page 63 of 71




2006 ATV 250 UTILITY RED (A2006KUE2BUSR)
STEERING POST ASSEMBLY

Page 64 of 71

Ref #	Part Number	Qty	S/P/F	Description
1	3303-963	1	S	Bushing, Sleeve
2	3303-957	1		Post, Steering
3	3303-961	2		Block, Mounting - Steering Post
4	3304-649	2		Screw, Cap
5	3303-962	1		Clamp, Mounting Block
6	3304-130	4		Nut, Castle
7	3304-136	2		Washer
8	3303-960	1		Collar, Steering Post - Lower
9	3304-032	1		Nut, Flange
10	3303-339	1		Pin, Cotter
11	3303-969	2		Tie Rod - Assembly (inc. 12-16)
12	3303-973	2		Ball Joint, Tie Rod - Left
13	3303-327	2		Nut, Hex - Left
14	3304-376	2		Tube, Tie Rod
15	3303-326	2		Nut, Hex - Right
16	3303-971	2		Ball Joint, Tie Rod - Right
17	3304-143	4		Pin, Cotter

2006 ATV 250 UTILITY RED (A2006KUE2BUSR)
TAILLIGHT ASSEMBLY

Page 65 of 71




2006 ATV 250 UTILITY RED (A2006KUE2BUSR)
TAILLIGHT ASSEMBLY

Page 66 of 71

Ref #	Part Number	Qty	S/P/F	Description
1	3304-671	1	S	Taillight - Assembly (inc. 2-5)
2	3303-422	1		Base, Taillight
3	3303-444	1	S	Bulb, Taillight
4	3304-672	1	S	Lens, Taillight
5	3304-537	2		Screw
6	3303-226	2		Collar, Front Fender
7	3303-331	2	/P	Nut, Flange

2006 ATV 250 UTILITY RED (A2006KUE2BUSR)
TRANSMISSION ASSEMBLY

Page 67 of 71



2006 ATV 250 UTILITY RED (A2006KUE2BUSR)
TRANSMISSION ASSEMBLY

Page 68 of 71

Ref #	Part Number	Qty	S/P/F	Description
1	3303-812	1		Spindle, Shift Cam
2	3303-815	1		Gear, Shift Handle
3	3304-153	3		Circlip
4	3303-813	1		Spring, Gear Shift Return
5	3304-036	1		Washer, Thrust
6	3304-623	1	S	Cam, Gear Shift - Assembly
7	3303-805	1		Fork, Gear Shift - Left
8	3303-806	1		Shaft, Gear Shift Fork
9	3303-807	1		Sleeve, Fork
10	3303-804	1		Fork, Gear Shift - Right
11	3303-808	1		Guide, Right Fork
12	3304-821	1	/P	Spring, Cam
13	3304-051	1		Washer
14	3304-154	1		E-Ring
15	3304-197	1		Bearing
16	3304-637	1		Washer, Thrust
17	3303-799	1	S	Shift, Forward - Dog
18	3304-638	1		Circlip
19	3304-046	1		Washer
20	3304-621	1		Gear, Forward
21	3304-636	1	S	Washer, Thrust
22	3303-793	1		Gear, Counter
23	3304-042	2		Washer, Thrust
24	3304-194	1		Bearing
25	3304-525	AR		Shim, Driven Bevel Gear - A
25	3304-526	AR		Shim, Driven Bevel Gear - B
25	3304-527	AR		Shim, Driven Bevel Gear - C
25	3304-528	AR		Shim, Driven Bevel Gear - D
25	3304-529	AR		Shim, Driven Bevel Gear - E
25	3304-530	AR		Shim, Driven Bevel Gear - F
25	3304-531	AR		Shim, Driven Bevel Gear - G
25	3304-532	AR		Shim, Driven Bevel Gear - H
25	3304-533	AR		Shim, Driven Bevel Gear - I
25	3304-534	AR		Shim, Driven Bevel Gear - J
25	3304-535	AR		Shim, Driven Bevel Gear - K
25	3304-536	AR		Shim, Driven Bevel Gear - L
26	3303-801	1		Gear, Bevel - Drive
27	3303-784	1		Shaft, Main
28	3304-044	1		Washer, Thrust
29	3304-622	1		Gear, Lower - Driven
30	3304-045	1		Washer, Spline
31	3304-056	1		Circlip
32	3303-798	1	S	Shift, Reverse - Dog
33	3304-043	1		Washer, Thrust
34	3303-797	1		Gear, Reverse
35	3304-074	1	/P	Bearing, Needle
36	3304-147	1	/P	Circlip
37	3303-791	1		Driveshaft
38	3304-005	3		Screw, Cap
39	3304-041	1		Plate, Holder
40	3304-033	1		Nut
41	3304-112	1		Bolt, Flange
42	3304-067	1		Bushing

2006 ATV 250 UTILITY RED (A2006KUE2BUSR)
TRANSMISSION ASSEMBLY

Page 69 of 71

Ref #	Part Number	Qty	S/P/F	Description
43	3304-040	1		Plate, Bearing Holder
44	3303-792	1		Countershaft
45	3303-800	1		Gear, Lower - Drive

2006 ATV 250 UTILITY RED (A2006KUE2BUSR)
TRANSMISSION CASE ASSEMBLY

Page 71 of 71

Ref #	Part Number	Qty	S/P/F	Description
1	3303-615	2		Screw, Cap
2	3303-614	7	S	Screw, Cap
3	3304-081	1		Seal, Oil
4	3303-365	1		Screw, Drain
5	3303-591	1		Washer
6	3303-383	7	/P	Screw, Cap
7	3303-763	1		Cap, Transmission Case
8	3303-766	1		Gasket, Transmission Case Cap
9	3304-108	1	/P	Bolt, Tachometer
10	3304-047	1	/P	Washer
11	3303-662	1		Gear, Tachometer
12	3304-077	2	/P	Seal, Oil
13	3303-762	1		Case, Transmission (inc. one No. 12)
14	3303-283	1	S	Plug, Drain
15	3303-765	1		Gasket, Transmission Case
16	3303-342	2		Pin, Dowel
17	3304-131	1		Nut
18	3303-802	1		Gear, Bevel - Driven
19	3304-624	AR		Shim, Drive Bevel Gear - A
19	3304-625	AR		Shim, Drive Bevel Gear - B
19	3304-626	AR		Shim, Drive Bevel Gear - C
19	3304-627	AR		Shim, Drive Bevel Gear - D
19	3304-628	AR		Shim, Drive Bevel Gear - E
19	3304-629	AR		Shim, Drive Bevel Gear - F
19	3304-630	AR		Shim, Drive Bevel Gear - G
19	3304-631	AR		Shim, Drive Bevel Gear - H
19	3304-632	AR		Shim, Drive Bevel Gear - I
19	3304-633	AR		Shim, Drive Bevel Gear - J
19	3304-634	AR		Shim, Drive Bevel Gear - K
19	3304-635	AR		Shim, Drive Bevel Gear - L
20	3304-151	1		Circlip
21	3304-069	1		Bearing
22	3304-105	1		O-Ring
23	3303-764	1		Case, Final Shaft
24	3304-152	1		Circlip
25	3304-071	1		Bearing
26	3304-642	1	/P	Shaft, Final
27	3304-087	1		Seal, Oil
28	3303-869	1		Joint, Yoke
29	3303-868	1		Shaft, Propeller
30	3303-870	1		Spring, Propeller Shaft
31	3303-945	1		Boot, Joint
32	3303-630	1		Tube, Breather - Transmission
33	3304-433	1		Clip, Tube
34	3304-058	1		Clamp
35	3304-059	1		Clamp