


Page 1 of 93



2008 ATV 700 EFI AUTOMATIC TRANSMISSION 4X4 FIS M4 CAMO (A2008IBT40450) Page 93  
 AIR INTAKE ASSEMBLY

| Ref # | Part Number | Qty | S/P/F | Description                     |
|-------|-------------|-----|-------|---------------------------------|
| 1     | 0413-091    | 1   |       | Diverter, Air - Top             |
| 2     | 0413-093    | 1   |       | Diverter, Air - Bottom          |
| 3     | 1406-785    | 1   |       | Shroud, Splash                  |
| 4     | 0623-362    | 2   |       | Rivet, Reinstallable            |
| 5     | 0423-551    | 2   |       | Clamp                           |
| 6     | 0423-342    | 2   | /P    | Screw, Self-Tapping             |
| 7     | 0413-096    | 1   |       | Cap, Air Intake - Diverter      |
| 8     | 0470-583    | 1   |       | Boot, Air Intake                |
| 9     | 0423-380    | 1   | /P    | Clamp                           |
| 10    | 0423-716    | 2   |       | Wing Nut                        |
| 11    | 0470-616    | 1   | S     | Cover, Air Intake               |
| 12    | 0470-580    | 1   |       | Filter, Air                     |
| 13    | 0470-731    | 1   | /P    | Cage, Air Filter                |
| 14    | 0570-211    | 1   |       | Housing, Air Intake             |
| 15    | 0406-877    | 4   | /P    | Bumper                          |
| 16    | 0470-442    | 2   | /P    | Valve, Drain                    |
| 17    | 0423-045    | 2   |       | Clamp                           |
| 18    | 0410-103    | 1   |       | Hose, Vent - Crankcase          |
| 19    | 0470-582    | 1   |       | Boot, Throttle Body             |
| 20    | 0423-066    | 1   |       | Clamp, Hose                     |
| 21    | 2406-149    | 1   |       | Panel, Shield                   |
| 22    | 3006-657    | 1   |       | Grommet, Air Temperature Sensor |
| 23    | 3006-656    | 1   |       | Sensor, Air Temperature         |
| 24    | 0430-066    | 1   |       | Support, Sensor                 |


2008 ATV 700 EFI AUTOMATIC TRANSMISSION 4X4 FIS M4 CAMO (A20081BT4450) of 93  
AUXILIARY BRAKE ASSEMBLY



2008 ATV 700 EFI AUTOMATIC TRANSMISSION 4X4 FIS M4 CAMO (A2008IBT404SC) Page 93 of 93  
 AUXILIARY BRAKE ASSEMBLY

| Ref # | Part Number | Qty | S/P/F | Description                                                          |
|-------|-------------|-----|-------|----------------------------------------------------------------------|
|       | 1502-292    | 1   |       | Master Cylinder Replacement Kit                                      |
| 1     | 1502-063    | 1   |       | Lever, Brake                                                         |
| 2     | 1602-213    | 2   | /P    | O-Ring                                                               |
| 3     | 8050-252    | 1   |       | Washer                                                               |
| 4     | 8408-816    | 1   |       | Screw, Cap                                                           |
| 5     | 0502-807    | 1   |       | Spring, Brake Lever                                                  |
| 6     | 1502-293    | 1   |       | Brake Assembly (inc. 7-9)                                            |
| 7     | 0           | 1   | F     | Master Cylinder                                                      |
| 8     | 0           | 1   | F     | Hose, Brake Fluid Reservoir w/Clamps                                 |
| 9     | 1502-155    | 1   |       | Reservoir, Brake Fluid w/Clamp                                       |
| 10    | 0623-038    | 1   |       | Nut, Flanged                                                         |
| 11    | 8476-616    | 1   |       | Screw, Machine                                                       |
| 12    | 0123-788    | 1   | /P    | Cable Tie - 7.5 in.                                                  |
| 13    | 1502-139    | 1   |       | Hose, Brake                                                          |
| 14    | 0423-178    | 6   |       | Washer, Crush                                                        |
| 15    | 0423-413    | 3   |       | Bolt, Banjo-Fitting                                                  |
| 16    | 1502-179    | 1   |       | Bracket, Switch                                                      |
| 17    | 8408-625    | 2   |       | Screw, Cap                                                           |
| 18    | 0502-785    | 1   |       | Spring, Brake Switch                                                 |
| 19    | 1436-163    | 1   |       | Caliper, Brake (inc. 20-23, one No. 24, and 25-27)                   |
| 20    | 8408-821    | 2   | /P    | Screw, Cap                                                           |
| 21    | 1436-161    | 1   | /P    | Housing, Caliper - Assembly - Right Rear (inc. 22-23 and one No. 24) |
| 22    | 0502-606    | 1   |       | Piston/Seal Set (inc. 23)                                            |
| 23    | 0502-607    | 1   |       | Seal Set                                                             |
| 24    | 0502-609    | 2   | /P    | Valve, Bleed                                                         |
| 25    | 0502-608    | 1   |       | O-Ring, Guide - Set                                                  |
| 26    | 0502-605    | 1   |       | Bracket Assembly                                                     |
| 27    | 0502-875    | 1   | S     | Pad, Brake - Set                                                     |
| 28    | 1502-115    | 2   |       | Clip, Brake Hose                                                     |
| 29    | 1502-296    | 1   | /P    | Adapter, Hose                                                        |


2008 ATV 700 EFI AUTOMATIC TRANSMISSION 4X4 FIS M4 CAMO (A2008IBT4450) Page 50 of 93  
BATTERY ASSEMBLY



2008 ATV 700 EFI AUTOMATIC TRANSMISSION 4X4 FIS M4 CAMO (A2008IBT40430) Page 30 of 93  
 BATTERY ASSEMBLY

| Ref # | Part Number | Qty | S/P/F | Description                                 |
|-------|-------------|-----|-------|---------------------------------------------|
| 1     | 5991-395    | 1   | S     | Battery Cover/Tool Tray Assembly (inc. 2-3) |
| 2     | 2406-815    | 1   | /P    | Cover, Battery                              |
| 3     | 0406-288    | 2   |       | Pad, Battery                                |
| 3     | 0444-122    | 1   | S/P/F | Kit, Tool                                   |
| 4     | 0745-047    | 1   | /P    | Battery Assembly (inc. 5-8)                 |
| 5     | 0645-045    | 6   |       | Cap, Battery                                |
| 6     | 0645-152    | 1   |       | Clamp, Hose                                 |
| 7     | 0645-263    | 1   | /P    | Hose, Battery Vent                          |
| 8     | 0645-151    | 1   |       | Label, Warning - Battery                    |
| 8     | 0645-198    | 1   | F     | Hardware, Battery - Kit                     |
| 9     | 0123-788    | 1   | /P    | Cable Tie                                   |
| 10    | 8476-620    | 2   |       | Screw, Machine                              |

2008 ATV 700 EFI AUTOMATIC TRANSMISSION 4X4 FIS M4 CAMO (A2008IBT4450) of 93  
BODY PANELS AND DECALS




2008 ATV 700 EFI AUTOMATIC TRANSMISSION 4X4 FIS M4 CAMO (A2008IBT4450) Page 8 of 93  
 BODY PANELS AND DECALS

| Ref # | Part Number | Qty | S/P/F | Description                                     |
|-------|-------------|-----|-------|-------------------------------------------------|
| 1     | 0411-501    | 1   |       | Decal, Front                                    |
| 1     | 1411-725    | 1   |       | Decal, Rear                                     |
| 2     | 1411-050    | 1   | /P    | Decal, "Speedrack"                              |
| 3     | 1411-813    | 1   |       | Decal, Instrument Pod                           |
| 4     | 0411-426    | 1   |       | Decal, Warning - Clutch Cover                   |
| 5     | 0411-966    | 1   |       | Decal, Warning - Differential Lock              |
| 6     | 1411-301    | 2   |       | Decal, Side - Upper                             |
| 7     | 0411-965    | 2   |       | Decal, "Speedrack"                              |
| 8     | 1411-077    | 1   |       | Decal, Warning - Towing                         |
| 9     | 2506-316    | 1   | S     | Panel, Fender - Front (inc. 10-15)              |
| 10    | 0411-818    | 1   |       | Decal, Reflector - Front - Right                |
| 10    | 0411-819    | 1   |       | Decal, Reflector - Front - Left                 |
| 11    | 0411-401    | 1   |       | Decal, Warning - Age                            |
| 12    | 0411-218    | 1   |       | Decal, Warning - General                        |
| 13    | 1411-574    | 1   |       | Decal, Warning - Off-Road Only                  |
| 14    | 1411-250    | 1   |       | Decal, Warning - Reverse/Pre-Ride               |
| 15    | 0411-835    | 1   |       | Decal, Warning - Turn/Hill                      |
| 16    | 2506-707    | 1   | S     | Panel, Fender - Rear (inc. 17-20 and one No. 1) |
| 17    | 1411-592    | 1   | /P    | Decal, Reflector - Rear - Right                 |
| 17    | 1411-593    | 1   | /P    | Decal, Reflector - Rear - Left                  |
| 18    | 0470-658    | 1   |       | Shield, Heat                                    |
| 19    | 0411-430    | 1   |       | Decal, Warning - Tire Pressure                  |
| 20    | 0411-435    | 1   |       | Decal, Passenger                                |
| 21    | 1411-865    | 1   |       | Decal, Warning - Brake Lever Lock               |




2008 ATV 700 EFI AUTOMATIC TRANSMISSION 4X4 FIS M4 CAMO (A2008IBT4450) of 93  
CAM CHAIN ASSEMBLY



2008 ATV 700 EFI AUTOMATIC TRANSMISSION 4X4 FIS M4 CAMO (A20081BFA4GUSC) of 93  
 CAM CHAIN ASSEMBLY

| Ref # | Part Number | Qty | S/P/F | Description                                 |
|-------|-------------|-----|-------|---------------------------------------------|
| 1     | 3403-104    | 1   |       | Gear, Cam Chain Idler                       |
| 2     | 3403-105    | 1   |       | Shaft, Cam Chain Idler                      |
| 3     | 3403-106    | 1   | /P    | Gasket, Idler Shaft                         |
| 4     | 3403-107    | 1   |       | Shim, Cam Chain Idler                       |
| 4     | 3403-108    | 1   |       | Shim, Cam Chain Idler                       |
| 4     | 3403-109    | 1   |       | Shim, Cam Chain Idler                       |
| 4     | 3403-110    | 1   |       | Shim, Cam Chain Idler                       |
| 4     | 3403-111    | 1   |       | Shim, Cam Chain Idler                       |
| 4     | 3403-112    | 1   |       | Shim, Cam Chain Idler                       |
| 5     | 3403-113    | 1   |       | Chain, Cam                                  |
| 6     | 3403-114    | 1   |       | Guide, Chain                                |
| 7     | 3403-115    | 1   |       | Tensioner, Cam Chain                        |
| 8     | 3423-810    | 1   |       | Bolt, Cam Chain Tensioner                   |
| 9     | 3423-811    | 1   |       | Washer                                      |
| 10    | 3402-283    | 1   |       | Adjuster, Tensioner - Assembly (inc. 11-14) |
| 11    | 3423-286    | 1   |       | O-Ring                                      |
| 12    | 3402-284    | 1   |       | Spring                                      |
| 13    | 3402-285    | 1   |       | Plug                                        |
| 14    | 3402-286    | 1   |       | Bar                                         |
| 15    | 3402-287    | 1   |       | Gasket, Tensioner Adjuster                  |
| 16    | 3004-576    | 2   | S     | Screw, Machine                              |


2008 ATV 700 EFI AUTOMATIC TRANSMISSION 4X4 FIS M4 CAMO (A20081BFA01510) of 93  
CAMSHAFT/VALVE ASSEMBLY



2008 ATV 700 EFI AUTOMATIC TRANSMISSION 4X4 FIS M4 CAMO (A20081BFA0150) of 93  
CAMSHAFT/VALVE ASSEMBLY

| Ref # | Part Number | Qty | S/P/F | Description            |
|-------|-------------|-----|-------|------------------------|
|       | 3402-931    | 1   |       | Shim, Tappet - Set     |
| 1     | 3403-099    | 1   |       | Camshaft - Intake      |
| 2     | 3403-100    | 1   |       | Camshaft - Exhaust     |
| 3     | 3403-101    | 2   |       | Valve, Intake          |
| 4     | 3403-102    | 2   |       | Valve, Exhaust         |
| 5     | 3403-103    | 4   |       | Spring, Valve          |
| 6     | 3402-934    | 4   |       | Retainer, Valve Spring |
| 7     | 0693-281    | 8   | /P    | Cotter, Valve          |
| 8     | 3402-880    | 4   |       | Seat, Valve Spring     |
| 9     | 3402-226    | 4   |       | Seal, Oil              |
| 10    | 3402-851    | 4   |       | Tappet                 |
| 11    | 3402-852    | AR  |       | Shim, Tappet - 2.30 mm |
| 11    | 3402-853    | AR  |       | Shim, Tappet - 2.35 mm |
| 11    | 3402-854    | AR  |       | Shim, Tappet - 2.40 mm |
| 11    | 3402-855    | AR  |       | Shim, Tappet - 2.45 mm |
| 11    | 3402-856    | AR  |       | Shim, Tappet - 2.50 mm |
| 11    | 3402-857    | AR  |       | Shim, Tappet - 2.55 mm |
| 11    | 3402-858    | AR  |       | Shim, Tappet - 2.60 mm |
| 11    | 3402-859    | AR  |       | Shim, Tappet - 2.65 mm |
| 11    | 3402-860    | AR  |       | Shim, Tappet - 2.70 mm |
| 11    | 3402-861    | AR  |       | Shim, Tappet - 2.75 mm |
| 11    | 3402-862    | AR  |       | Shim, Tappet - 2.80 mm |
| 11    | 3402-863    | AR  |       | Shim, Tappet - 2.85 mm |
| 11    | 3402-864    | AR  |       | Shim, Tappet - 2.90 mm |
| 11    | 3402-865    | AR  |       | Shim, Tappet - 2.95 mm |
| 11    | 3402-866    | AR  |       | Shim, Tappet - 3.00 mm |
| 11    | 3402-867    | AR  |       | Shim, Tappet - 3.05 mm |
| 11    | 3402-868    | AR  |       | Shim, Tappet - 3.10 mm |
| 11    | 3402-869    | AR  |       | Shim, Tappet - 3.15 mm |
| 11    | 3402-870    | AR  |       | Shim, Tappet - 3.20 mm |
| 11    | 3402-871    | AR  |       | Shim, Tappet - 3.25 mm |
| 11    | 3402-872    | AR  |       | Shim, Tappet - 3.30 mm |
| 11    | 3402-873    | AR  |       | Shim, Tappet - 3.35 mm |
| 11    | 3402-874    | AR  |       | Shim, Tappet - 3.40 mm |
| 11    | 3402-875    | AR  |       | Shim, Tappet - 3.45 mm |
| 11    | 3402-876    | AR  |       | Shim, Tappet - 3.50 mm |


2008 ATV 700 EFI AUTOMATIC TRANSMISSION 4X4 FIS M4 CAMO (A20081BFA4US0) of 93  
CASE/BELT COOLING ASSEMBLY



2008 ATV 700 EFI AUTOMATIC TRANSMISSION 4X4 FIS M4 CAMO (A20081BFA4USC) of 93  
CASE/BELT COOLING ASSEMBLY

| Ref # | Part Number | Qty | S/P/F | Description                |
|-------|-------------|-----|-------|----------------------------|
| 1     | 0413-126    | 1   |       | Duct, Belt Cooling - Front |
| 2     | 0470-442    | 2   | /P    | Valve, Drain               |
| 3     | 0423-578    | 1   |       | Clamp, Boot                |
| 4     | 0413-160    | 1   | /P    | Boot, Belt Cooling - Front |
| 5     | 0423-550    | 1   |       | Clamp, Boot                |
| 6     | 0423-342    | 1   | /P    | Screw, Self-Tapping        |
| 7     | 0423-018    | 2   |       | Clamp, Boot                |
| 8     | 0413-128    | 1   |       | Boot, Belt Cooling - Rear  |
| 9     | 0413-129    | 1   |       | Duct, Belt Cooling - Rear  |
| 10    | 0123-903    | 1   |       | Cable Tie - 11.5 in.       |

2008 ATV 700 EFI AUTOMATIC TRANSMISSION 4X4 FIS M4 CAMO (A20081BFA0150) of 93  
CLUTCH/V-BELT/MAGNETO COVER ASSEMBLY




2008 ATV 700 EFI AUTOMATIC TRANSMISSION 4X4 FIS M4 CAMO (A20081BFA4GUSC) of 93  
 CLUTCH/V-BELT/MAGNETO COVER ASSEMBLY

| Ref # | Part Number | Qty | S/P/F | Description                          |
|-------|-------------|-----|-------|--------------------------------------|
| 1     | 3403-066    | 1   |       | Cover, Clutch                        |
| 2     | 3403-067    | 1   |       | Housing, V-Belt Bearing              |
| 3     | 3403-068    | 1   |       | Cover, V-Belt - Inner                |
| 4     | 3423-800    | 1   |       | Plug                                 |
| 5     | 3403-069    | 1   |       | Cover, V-Belt - Outer                |
| 6     | 3403-070    | 1   |       | Gasket, Clutch Cover                 |
| 7     | 3403-071    | 1   |       | Gasket, V-Belt Cover - Inner - Rear  |
| 8     | 3403-072    | 1   |       | Gasket, V-Belt Cover - Inner - Front |
| 9     | 3403-073    | 1   |       | Gasket, V-Belt Cover - Outer         |
| 10    | 3007-369    | 46  | /P    | Bolt                                 |
| 11    | 0693-327    | 6   | S     | Bolt                                 |
| 12    | 3004-822    | 4   |       | Pin                                  |
| 13    | 3423-610    | 2   |       | Pin                                  |
| 14    | 3403-074    | 1   | S     | Cover, Magneto                       |
| 15    | 3403-075    | 1   |       | Gasket, Magneto Cover                |
| 16    | 3402-438    | 1   |       | Gauge, Oil Level                     |
| 17    | 3423-055    | 1   |       | O-Ring                               |
| 18    | 3402-040    | 1   | /P    | Plug, Check                          |
| 19    | 3403-200    | 1   |       | Gasket, Check Plug                   |
| 20    | 0820-062    | 1   |       | Cover, Magneto - Outer               |
| 21    | 0826-008    | 4   |       | Screw, Machine                       |




2008 ATV 700 EFI AUTOMATIC TRANSMISSION 4X4 FIS M4 CAMO (A20081BFA0150) of 93  
CONTROL SWITCH HOUSING ASSEMBLY



2008 ATV 700 EFI AUTOMATIC TRANSMISSION 4X4 FIS M4 CAMO (A20081BFA4GUSC) of 93  
 CONTROL SWITCH HOUSING ASSEMBLY

| Ref # | Part Number | Qty | S/P/F | Description                           |
|-------|-------------|-----|-------|---------------------------------------|
| 1     | 0509-014    | 1   |       | Switch, Control - Assembly (inc. 2-4) |
| 2     | 0409-027    | 1   |       | Screw, Machine                        |
| 3     | 0409-028    | 1   |       | Screw, Machine                        |
| 4     | 3409-019    | 1   |       | Cover, Switch Housing                 |


Page 93 of 93



2008 ATV 700 EFI AUTOMATIC TRANSMISSION 4X4 FIS M4 CAMO (A20081BFA0000) Page 20 of 93  
COOLING ASSEMBLY

| Ref # | Part Number | Qty | S/P/F | Description                   |
|-------|-------------|-----|-------|-------------------------------|
| 1     | 0413-172    | 1   | S     | Radiator Assembly (inc. 2-13) |
| 2     | 0413-184    | 1   | /P    | Radiator                      |
| 3     | 0413-007    | 1   |       | Screen, Radiator              |
| 4     | 0413-002    | 1   | S     | Cap, Radiator                 |
| 5     | 0423-030    | 2   |       | Grommet                       |
| 6     | 0610-016    | AR  | /P    | Hose - 25 ft                  |
| 7     | 0413-046    | 1   |       | Shroud, Fan                   |
| 8     | 0413-123    | 1   | /P    | Fan, Cooling                  |
| 9     | 8475-512    | 12  |       | Screw, Machine                |
| 10    | 0423-351    | 1   |       | Clamp, Wire                   |
| 11    | 0123-397    | 1   |       | Clamp, Cable                  |
| 12    | 0413-168    | 1   |       | Switch, Sensor - Temperature  |
| 13    | 0423-390    | 1   | S     | O-Ring                        |
| 14    | 0423-484    | 2   |       | Screw, Shoulder               |
| 15    | 0623-038    | 2   |       | Nut w/Washer                  |
| 16    | 0423-028    | 2   |       | Bushing, Stem                 |
| 17    | 0423-496    | 4   |       | Clamp, Hose                   |
| 18    | 0410-105    | 1   |       | Hose, Coolant - Upper         |
| 19    | 0410-055    | 1   |       | Hose, Coolant - Lower         |
| 20    | 3006-324    | 2   |       | Clamp                         |
| 21    | 3410-021    | 1   |       | Hose, Coolant - Crossover     |
| 22    | 0124-045    | 1   | /P    | Clamp, Hose                   |
| 23    | 0413-086    | 1   |       | Tank, Coolant Overflow        |
| 24    | 0413-087    | 1   |       | Stopper, Coolant Tank         |
| 25    | 0610-011    | AR  | /P    | Hose, Clear - 25 ft           |
| 26    | 0623-316    | 1   |       | Cable Tie                     |
| 27    | 0123-788    | 2   | /P    | Cable Tie                     |


2008 ATV 700 EFI AUTOMATIC TRANSMISSION 4X4 FIS M4 CAMO (A20081BFA0010) Page 81 of 93  
CRANK BALANCER ASSEMBLY



2008 ATV 700 EFI AUTOMATIC TRANSMISSION 4X4 FIS M4 CAMO (A20081BFA4GUSC) of 93  
 CRANK BALANCER ASSEMBLY

| Ref # | Part Number | Qty | S/P/F | Description                        |
|-------|-------------|-----|-------|------------------------------------|
| 1     | 3403-093    | 2   |       | Balancer, Crank                    |
| 2     | 3403-094    | 2   |       | Gear, Driven - Crank Balancer      |
| 3     | 3423-555    | 2   |       | Bolt                               |
| 4     | 3423-808    | 2   |       | Key                                |
| 5     | 3423-401    | 2   |       | Washer                             |
| 6     | 3403-095    | 2   |       | Bearing                            |
| 7     | 3403-096    | 2   |       | Bearing                            |
| 8     | 3446-031    | 4   | /P    | Retainer, Bearing - Crank Balancer |
| 9     | 3423-370    | 4   |       | Bolt                               |
| 10    | 3403-097    | 1   |       | Sprocket, Drive - Oil Pump         |
| 11    | 3403-098    | 1   |       | Gear, Drive - Water Pump           |

2008 ATV 700 EFI AUTOMATIC TRANSMISSION 4X4 FIS M4 CAMO (A20081BFA00000) of 93  
CRANKCASE ASSEMBLY




2008 ATV 700 EFI AUTOMATIC TRANSMISSION 4X4 FIS M4 CAMO (A20081BFA4USC) Page 24 of 93  
 CRANKCASE ASSEMBLY

| Ref # | Part Number | Qty | S/P/F | Description                   |
|-------|-------------|-----|-------|-------------------------------|
| 1     | 3403-063    | 1   | S     | Crankcase Assembly (inc. 2-7) |
| 2     | 3004-822    | 2   |       | Pin                           |
| 3     | 3423-307    | 11  | S     | Bolt                          |
| 4     | 3423-392    | 1   |       | Bolt                          |
| 5     | 3423-094    | 1   |       | Bolt                          |
| 6     | 3007-399    | 4   | /P    | Bolt                          |
| 7     | 3004-424    | 2   |       | Bolt                          |
| 8     | 3007-407    | 2   | /P    | Plug, Oil Gallery             |
| 9     | 3402-436    | 2   | /P    | Gasket, Oil Gallery Plug      |
| 10    | 3403-064    | 1   |       | Plug, Drain                   |
| 11    | 3402-011    | 1   |       | Gasket, Drain Plug            |
| 12    | 3403-065    | 1   |       | Jet, Oil Gallery              |
| 13    | 3423-051    | 1   |       | O-Ring                        |
| 14    | 3423-456    | 2   |       | Bolt, Engine Mounting         |
| 15    | 3423-457    | 2   | S     | Nut, Engine Mounting          |
| 16    | 3423-799    | 4   |       | Bushing, Engine Mounting      |




2008 ATV 700 EFI AUTOMATIC TRANSMISSION 4X4 FIS M4 CAMO (A20081BFA00000) Page 25 of 93  
CRANKSHAFT AND PISTON ASSEMBLY



2008 ATV 700 EFI AUTOMATIC TRANSMISSION 4X4 FIS M4 CAMO (A20081BFA00000) Page 23 of 93  
 CRANKSHAFT AND PISTON ASSEMBLY

| Ref # | Part Number | Qty | S/P/F | Description                    |
|-------|-------------|-----|-------|--------------------------------|
| 1     | 3403-221    | 1   | S     | Crankshaft Assembly (inc. 2-7) |
| 2     | 3403-077    | 1   |       | Rod, Connecting                |
| 3     | 3403-078    | 1   |       | Pin, Crank                     |
| 4     | 3403-222    | 1   | /P    | Crankshaft - Right             |
| 5     | 3403-223    | 1   |       | Crankshaft - Left              |
| 6     | 3423-801    | 2   |       | Washer                         |
| 7     | 3403-081    | 1   |       | Bearing                        |
| 8     | 3403-082    | 1   | /P    | Bearing - Right                |
| 9     | 3403-083    | 1   |       | Bearing - Left                 |
| 10    | 3402-573    | 1   |       | Seal, Oil                      |
| 11    | 3403-084    | 1   | S     | Gear, Drive - Crank Balancer   |
| 12    | 3423-802    | 1   |       | Nut, Crank Balancer Drive Gear |
| 13    | 3423-803    | 1   |       | Washer                         |
| 14    | 3423-047    | 1   |       | Pin                            |
| 15    | 3402-051    | 1   |       | Bearing                        |
| 16    | 3403-085    | 1   |       | Seal, Oil                      |
| 17    | 3423-826    | 1   | /P    | Circlip                        |
| 18    | 3403-086    | 1   |       | Piston                         |
| 19    | 3403-087    | 1   |       | Ring, Piston - Set             |
| 20    | 3403-088    | 1   |       | Pin, Piston                    |
| 21    | 3423-344    | 2   |       | Circlip, Piston Pin            |


2008 ATV 700 EFI AUTOMATIC TRANSMISSION 4X4 FIS M4 CAMO (A20081BFA0150) of 93  
CYLINDER ASSEMBLY



2008 ATV 700 EFI AUTOMATIC TRANSMISSION 4X4 FIS M4 CAMO (A20081BFA00000) of 93  
CYLINDER ASSEMBLY

| Ref # | Part Number | Qty | S/P/F | Description       |
|-------|-------------|-----|-------|-------------------|
| 1     | 3403-214    | 1   | /P    | Cylinder          |
| 2     | 3403-062    | 1   |       | Gasket, Cylinder  |
| 3     | 3423-088    | 2   |       | Pin, Dowel        |
| 4     | 3423-384    | 2   | S     | Bolt, Stud        |
| 5     | 3007-373    | 2   | /P    | Nut               |
| 6     | 3413-040    | 1   |       | Union, Water Hose |
| 7     | 3423-058    | 1   |       | O-Ring            |
| 8     | 3423-121    | 1   | S     | Screw, Machine    |


2008 ATV 700 EFI AUTOMATIC TRANSMISSION 4X4 FIS M4 CAMO (A2008IBF4G1230) of 93  
CYLINDER HEAD ASSEMBLY



2008 ATV 700 EFI AUTOMATIC TRANSMISSION 4X4 FIS M4 CAMO (A20081BFA4GUSC) of 93  
CYLINDER HEAD ASSEMBLY

| Ref # | Part Number | Qty | S/P/F | Description                          |
|-------|-------------|-----|-------|--------------------------------------|
| 1     | 3403-055    | 1   |       | Head, Cylinder - Assembly (inc. 2-3) |
| 2     | 3423-794    | 8   |       | Screw, Cap                           |
| 3     | 3423-043    | 4   | /P    | Pin                                  |
| 4     | 3403-056    | 4   | /P    | Guide, Valve                         |
| 5     | 3403-057    | 1   |       | Gasket, Cylinder Head                |
| 6     | 3423-795    | 5   |       | Screw, Cap                           |
| 7     | 3006-650    | 2   |       | Screw, Cap                           |
| 8     | 3423-796    | 2   |       | Screw, Cap                           |
| 9     | 3423-088    | 2   |       | Pin, Dowel                           |
| 10    | 3007-497    | 1   |       | Plug, Cylinder Head                  |
| 11    | 3003-290    | 1   | /P    | O-Ring                               |
| 12    | 0217-632    | 1   |       | Spark Plug (NGK CR6E)                |
| 13    | 3403-058    | 1   |       | Pipe, Intake - Assembly              |
| 14    | 3423-797    | 2   |       | Screw, Cap                           |
| 15    | 3402-236    | 1   | /P    | Clamp, Intake Pipe                   |
| 16    | 3530-046    | 1   |       | Switch, Water Temperature            |
| 17    | 3007-215    | 1   |       | Gasket, Water Temperature Switch     |
| 18    | 3413-038    | 1   |       | Cover, Thermostat                    |
| 19    | 3413-039    | 1   |       | Thermostat                           |
| 20    | 3007-377    | 2   | /P    | Screw, Cap                           |
| 21    | 3423-798    | 1   | S     | Plate, Engine Mounting Damper        |
| 22    | 3403-059    | 1   |       | Damper, Engine Mounting              |
| 23    | 3403-060    | 1   |       | Stopper, Engine Mounting             |
| 24    | 3007-407    | 2   | /P    | Screw, Cap                           |

2008 ATV 700 EFI AUTOMATIC TRANSMISSION 4X4 FIS M4 CAMO (A20081BFA0US10) of 93  
CYLINDER HEAD COVER ASSEMBLY




2008 ATV 700 EFI AUTOMATIC TRANSMISSION 4X4 FIS M4 CAMO (A20081BFAUSC) Page 52 of 93  
CYLINDER HEAD COVER ASSEMBLY

| Ref # | Part Number | Qty | S/P/F | Description                 |
|-------|-------------|-----|-------|-----------------------------|
| 1     | 3403-053    | 1   |       | Cover, Cylinder Head        |
| 2     | 3403-054    | 1   |       | Gasket, Cylinder Head Cover |
| 3     | 3423-646    | 4   |       | Bolt                        |
| 4     | 3423-680    | 4   |       | Washer                      |




2008 ATV 700 EFI AUTOMATIC TRANSMISSION 4X4 FIS M4 CAMO (A20081BFA4GUSC) of 93  
DRIVE TRAIN ASSEMBLY



2008 ATV 700 EFI AUTOMATIC TRANSMISSION 4X4 FIS M4 CAMO (A20081BFA4USC) of 93  
DRIVE TRAIN ASSEMBLY

| Ref # | Part Number | Qty | S/P/F | Description                               |
|-------|-------------|-----|-------|-------------------------------------------|
| 1     | 0402-147    | 2   | S     | Bladder, Gearcase                         |
| 2     | 0423-315    | 4   |       | Clamp, Fitting                            |
| 3     | 8428-002    | 4   |       | Nut, Lock                                 |
| 4     | 0423-426    | 8   |       | Washer                                    |
| 5     | 0423-404    | 4   |       | Screw, Cap                                |
| 6     | 1502-242    | 1   |       | Gearcase, Front                           |
| 7     | 0502-500    | 1   |       | Plate, Cable                              |
| 8     | 0423-396    | 2   |       | Screw, Self-Tapping                       |
| 9     | 0502-909    | 1   |       | Gearcase, Rear                            |
| 10    | 0410-070    | AR  | /P    | Hose, Vent - 25 ft                        |
| 11    | 0470-462    | 1   |       | Fitting, Vent                             |
| 12    | 0423-393    | 2   |       | Clamp, Boot                               |
| 13    | 0402-985    | 2   | /P    | Boot                                      |
| 14    | 0423-411    | 2   |       | Clamp, Boot                               |
| 15    | 1402-234    | 1   |       | Shaft, Propeller                          |
| 16    | 0402-950    | 1   |       | Flange, Output                            |
| 17    | 8408-820    | 4   | /P    | Screw, Cap                                |
| 18    | 0502-918    | 1   |       | Driveshaft, Front - Assembly (inc. 19-23) |
| 19    | 0502-915    | 1   |       | Yoke, Front Slip                          |
| 20    | 1402-164    | 2   | /P    | Joint, Universal (inc. 21)                |
| 21    | 0423-450    | 8   |       | Ring, Retaining                           |
| 22    | 0502-917    | 1   |       | Driveshaft, Front                         |
| 23    | 1402-439    | 1   |       | Yoke, Slip                                |
| 24    | 1402-521    | 1   |       | Spring                                    |
| 25    | 0123-788    | AR  | /P    | Tie, Cable                                |


2008 ATV 700 EFI AUTOMATIC TRANSMISSION 4X4 FIS M4 CAMO (A20081BFA00000) of 93  
ENGINE AND EXHAUST



2008 ATV 700 EFI AUTOMATIC TRANSMISSION 4X4 FIS M4 CAMO (A20081BFA4GUSC) of 93  
ENGINE AND EXHAUST

| Ref # | Part Number | Qty | S/P/F | Description                                          |
|-------|-------------|-----|-------|------------------------------------------------------|
| 1     | 0462-046    | 1   | /P    | Engine                                               |
| 2     | 3423-456    | 2   |       | Screw, Cap                                           |
| 3     | 8428-002    | 2   |       | Nut, Lock                                            |
| 4     | 0412-361    | 1   |       | Gasket, Exhaust Pipe                                 |
| 5     | 8424-802    | 2   |       | Nut, Hex                                             |
| 6     | 0512-294    | 1   |       | Pipe, Exhaust - Assembly (inc. 7-9 and three No. 10) |
| 7     | 0512-293    | 1   |       | Pipe, Exhaust                                        |
| 8     | 0412-364    | 1   |       | Shield, Exhaust Pipe - Inner                         |
| 9     | 0412-365    | 1   |       | Shield, Exhaust Pipe - Outer                         |
| 10    | 0423-317    | 5   | /P    | Hose Clamp                                           |
| 11    | 0512-317    | 1   |       | Support, Exhaust Pipe                                |
| 12    | 8477-620    | 1   |       | Screw, Machine                                       |
| 13    | 0512-318    | 1   |       | Bracket, Exhaust Pipe                                |
| 14    | 0412-375    | 1   | /P    | Seal, Exhaust                                        |
| 15    | 0612-668    | 2   | /P    | Spring, Extension                                    |
| 16    | 0412-369    | 1   |       | Shield, Exhaust Pipe - Rear                          |
| 17    | 0512-305    | 1   |       | Muffler - Assembly (inc. 18-20)                      |
| 18    | 8408-616    | 3   |       | Screw, Cap                                           |
| 19    | 0512-219    | 1   | /P    | Arrester, Spark - Assembly                           |
| 20    | 0412-313    | 1   |       | Gasket, Spark Arrester                               |
| 21    | 0412-215    | 3   | S     | Bushing, Exhaust Pipe                                |
| 22    | 1506-732    | 1   |       | Channel, Muffler Support                             |
| 23    | 0412-373    | 1   | /P    | Cover, Muffler                                       |
| 24    | 8477-610    | 3   |       | Screw, Machine                                       |


2008 ATV 700 EFI AUTOMATIC TRANSMISSION 4X4 FIS M4 CAMO (A20081BFA0150) of 93  
FRAME AND RELATED PARTS



2008 ATV 700 EFI AUTOMATIC TRANSMISSION 4X4 FIS M4 CAMO (A20081BFA4GUSC) of 93  
FRAME AND RELATED PARTS

| Ref # | Part Number | Qty | S/P/F | Description                        |
|-------|-------------|-----|-------|------------------------------------|
| 1     | 2506-555    | 1   |       | Frame, Main                        |
| 2     | 8409-020    | 4   | /P    | Screw, Cap                         |
| 3     | 1506-596    | 1   | /P    | Channel, Bumper Support - Right    |
| 3     | 0506-653    | 1   | S     | Channel, Bumper Support - Left     |
| 4     | 1506-562    | 1   |       | Bracket, Mounting - Bumper - Right |
| 4     | 1506-563    | 1   |       | Bracket, Mounting - Bumper - Left  |
| 5     | 8408-816    | 6   |       | Screw, Cap                         |
| 6     | 1506-855    | 1   | /P    | Bumper                             |
| 7     | 1406-360    | 1   |       | Grille, Bumper                     |
| 8     | 0423-419    | 2   |       | Screw, Machine                     |
| 9     | 0423-101    | 12  |       | Screw, Body                        |
| 10    | 8428-002    | 2   |       | Nut, Lock                          |
| 11    | 1506-429    | 1   | S     | Brace, A-Arm                       |
| 12    | 8409-025    | 2   |       | Screw, Cap                         |
| 13    | 1506-981    | 1   |       | Foam, Frame                        |
| 14    | 0406-289    | 1   |       | Pad, Frame                         |
| 15    | 2406-139    | 1   |       | Panel, Belly                       |
| 16    | 8424-802    | 4   |       | Nut, Flange                        |
| 17    | 8409-016    | 4   |       | Screw, Cap                         |
| 18    | 1506-380    | 1   |       | Footrest - Right                   |
| 18    | 1506-379    | 1   |       | Footrest - Left                    |
| 19    | 2506-423    | 2   |       | Rod, Support                       |
| 20    | 0123-788    | 1   | /P    | Cable Tie                          |
| 21    | 0423-075    | 1   |       | Cable Tie, Push-Mount              |

2008 ATV 700 EFI AUTOMATIC TRANSMISSION 4X4 FIS M4 CAMO (A20081BFA0000) of 93  
FRONT DRIVE GEARCASE ASSEMBLY



2008 ATV 700 EFI AUTOMATIC TRANSMISSION 4X4 FIS M4 CAMO (A20081BFA40450) of 93  
FRONT DRIVE GEARCASE ASSEMBLY


| Ref # | Part Number | Qty | S/P/F | Description                                              |
|-------|-------------|-----|-------|----------------------------------------------------------|
|       | 1502-242    | 1   |       | Complete Front Drive Gearcase Assembly                   |
| 1     | 0502-923    | 1   |       | Shaft, Propeller - Assembly (inc. 2-3)                   |
| 2     | 1402-438    | 1   |       | Shaft, Input                                             |
| 3     | 1402-168    | 1   |       | Deflector                                                |
| 4     | 1402-011    | 1   |       | Seal                                                     |
| 5     | 0423-423    | 1   |       | Ring, Retaining                                          |
| 6     | 0502-347    | 1   |       | Bracket, Actuator                                        |
| 7     | 0502-579    | 1   |       | Actuator (inc. one No. 8)                                |
| 8     | 0423-498    | 2   | S     | O-Ring                                                   |
| 9     | 0423-396    | 3   |       | Screw, Self-Tapping                                      |
| 10    | 1402-043    | 1   |       | Bearing                                                  |
| 11    | 0423-118    | 11  |       | Screw, Self-Tapping                                      |
| 12    | 0502-528    | 1   | /P    | Housing, Pinion                                          |
| 13    | 0402-947    | 1   |       | Gasket, Flange                                           |
| 14    | 0423-417    | 1   |       | Ring, Retaining                                          |
| 15    | 0402-413    | 1   |       | Coupler, Drive                                           |
| 16    | 0402-357    | 1   |       | Collar, Lock                                             |
| 17    | 0502-783    | 1   |       | Gear, Pinion - Assembly - 10T (inc. 18-19)               |
| 18    | 0402-336    | 1   |       | Collar, Retaining                                        |
| 19    | 0402-327    | 1   |       | Bearing                                                  |
| 20    | 0402-328    | 1   |       | Bearing                                                  |
| 21    | 0502-514    | 1   |       | Housing, Gearcase                                        |
| 22    | 0402-411    | 1   |       | Pin, Dowel                                               |
| 23    | 0402-999    | 1   |       | Spring, Return                                           |
| 24    | 0423-147    | 1   |       | O-Ring                                                   |
| 25    | 0402-417    | 1   |       | Shaft, Shuttle                                           |
| 26    | 0402-998    | 1   |       | Fork, Selector                                           |
| 27    | 0423-402    | 1   |       | Ring, Retaining                                          |
| 28    | 0402-997    | 1   |       | Shaft, Selector                                          |
| 29    | 1402-210    | 1   | /P    | Plug, Magnetic (inc. one No. 30)                         |
| 30    | 0423-153    | 2   |       | O-Ring                                                   |
| 31    | 0423-149    | 1   |       | O-Ring                                                   |
| 32    | 0402-393    | 1   |       | Bearing                                                  |
| 33    | 0402-405    | AR  |       | Shim                                                     |
| 33    | 0402-406    | AR  |       | Shim                                                     |
| 33    | 0402-407    | AR  |       | Shim                                                     |
| 33    | 0402-408    | AR  |       | Shim                                                     |
| 33    | 0402-409    | AR  |       | Shim                                                     |
| 34    | 1502-234    | 1   | S     | Gear, Ring - 36T                                         |
| 35    | 1402-074    | AR  |       | Shim                                                     |
| 35    | 1402-075    | AR  |       | Shim                                                     |
| 35    | 1402-076    | AR  |       | Shim                                                     |
| 35    | 1402-077    | AR  |       | Shim                                                     |
| 35    | 1402-078    | AR  |       | Shim                                                     |
| 36    | 1502-097    | 1   |       | Cover, Gearcase (inc. one No. 30, 37-52, and one No. 53) |
| 37    | 1402-053    | 1   |       | Bearing                                                  |
| 38    | 0502-413    | 1   |       | Flange, Bearing                                          |
| 39    | 1402-079    | 1   |       | Pin, Parallel                                            |
| 40    | 1402-042    | 1   |       | Collar, Sliding                                          |
| 41    | 1402-054    | 1   |       | Fork                                                     |
| 42    | 1402-058    | 2   |       | Ring, Retaining                                          |



2008 ATV 700 EFI AUTOMATIC TRANSMISSION 4X4 FIS M4 CAMO (A20081BFA4USC) of 93  
 FRONT DRIVE GEARCASE ASSEMBLY

| Ref # | Part Number | Qty | S/P/F | Description               |
|-------|-------------|-----|-------|---------------------------|
| 43    | 1402-057    | 1   |       | Spring                    |
| 44    | 1402-063    | 1   |       | Spring                    |
| 45    | 1402-055    | 1   |       | Shaft, Lock               |
| 46    | 0402-419    | 1   |       | Switch, Indicator         |
| 47    | 1402-104    | 1   |       | Fitting                   |
| 48    | 0423-133    | 1   |       | O-Ring                    |
| 49    | 0423-132    | 1   |       | Washer                    |
| 50    | 0423-424    | 1   |       | Ring, Retaining           |
| 51    | 1402-056    | 1   |       | Seal                      |
| 52    | 1402-211    | 1   |       | Plug, Oil Level (inc. 30) |
| 53    | 1402-441    | 2   | S     | Seal                      |
| 54    | 0402-333    | 1   | /P    | Plug, Fill (inc. 55)      |
| 55    | 0423-154    | 1   |       | O-Ring                    |


2008 ATV 700 EFI AUTOMATIC TRANSMISSION 4X4 FIS M4 CAMO (A20081BFA4GUSC) of 93  
FRONT RACK AND HEADLIGHT ASSEMBLIES



2008 ATV 700 EFI AUTOMATIC TRANSMISSION 4X4 FIS M4 CAMO (A2008IBF4GUSC) of 93  
 FRONT RACK AND HEADLIGHT ASSEMBLIES

| Ref # | Part Number | Qty | S/P/F | Description                           |
|-------|-------------|-----|-------|---------------------------------------|
| 1     | 2506-106    | 1   |       | Rack, Front - Assembly (inc. 2-3)     |
| 2     | 0411-576    | 1   |       | Decal, Warning - Front Rack Load      |
| 3     | 0441-592    | 4   | /P    | Bushing, Rack                         |
| 4     | 8410-830    | 4   |       | Screw, Cap                            |
| 5     | 0423-669    | 4   |       | Spacer                                |
| 6     | 0423-465    | 4   |       | Grommet                               |
| 7     | 8432-802    | 4   |       | Nut, Lock                             |
| 8     | 0423-654    | 2   |       | Screw, Shoulder                       |
| 9     | 8050-222    | 2   | /P    | Washer                                |
| 10    | 0423-540    | 2   |       | Nut, Lock                             |
| 11    | 0509-034    | 1   | S     | Headlight Assembly - Right (inc. 12)  |
| 11    | 0509-035    | 1   |       | Headlight Assembly - Left (inc. 12)   |
| 12    | 0409-055    | 4   |       | Bulb, Headlight                       |
| 13    | 0423-514    | 2   |       | Stud, Adjuster - Headlight            |
| 14    | 0423-522    | 2   |       | Spring, Adjuster                      |
| 15    | 0423-513    | 2   |       | Knob, Adjuster                        |
| 16    | 0623-785    | 4   |       | Screw, Self-Tapping                   |
| 17    | 8050-217    | 8   | /P    | Washer                                |
| 18    | 0423-447    | 4   |       | Grommet                               |
| 19    | 2406-358    | 1   |       | Panel, Side - Lower - Right           |
| 19    | 2406-359    | 1   |       | Panel, Side - Lower - Left            |
| 20    | 0423-678    | 8   |       | Grommet                               |
| 21    | 1406-358    | 1   |       | Cover, Access                         |
| 22    | 0423-535    | 2   |       | Rivet, Reinstallable                  |
| 23    | 1406-484    | 1   |       | Cover, Steering Post                  |
| 24    | 0623-362    | 4   |       | Rivet, Reinstallable                  |
| 25    | 0470-513    | 1   |       | Cover, Storage Box                    |
| 26    | 1406-573    | 1   |       | Box, Storage                          |
| 27    | 2506-234    | 1   |       | Lid, Storage Box w/Latch (inc. 28-29) |
| 28    | 1406-599    | 1   |       | Latch, Storage Box                    |
| 29    | 0470-514    | 1   |       | Lid, Storage Box                      |
| 30    | 0423-101    | 5   |       | Screw, Body                           |
| 31    | 1406-354    | 1   |       | Panel, Splash - Right                 |
| 31    | 1406-355    | 1   | S     | Panel, Splash - Left                  |
| 32    | 0423-719    | 4   |       | Screw, Self-Tapping                   |
| 33    | 0123-788    | AR  | /P    | Cable Tie - 7.5 in.                   |


2008 ATV 700 EFI AUTOMATIC TRANSMISSION 4X4 FIS M4 CAMO (A20081BFA4USC) of 93  
FRONT SUSPENSION ASSEMBLY



2008 ATV 700 EFI AUTOMATIC TRANSMISSION 4X4 FIS M4 CAMO (A20081BFA4G150) of 93  
 FRONT SUSPENSION ASSEMBLY

| Ref # | Part Number | Qty | S/P/F | Description                               |
|-------|-------------|-----|-------|-------------------------------------------|
| 1     | 0441-587    | 1   |       | Wrench, Spanner                           |
| 2     | 0403-180    | 2   |       | Shock Absorber - Front (inc. 3)           |
| 3     | 0403-182    | 4   |       | Bushing, Double-Bonded                    |
| 4     | 0403-102    | 2   |       | Cam, Spring Adjuster                      |
| 5     | 0403-177    | 2   |       | Spring, Shock Absorber                    |
| 6     | 1603-889    | 2   | /P    | Retainer, Spring                          |
| 7     | 8409-040    | 4   |       | Screw, Cap                                |
| 8     | 8428-002    | 10  |       | Nut, Lock                                 |
| 9     | 0503-196    | 1   | S     | A-Arm, Upper Right (inc. 10-13)           |
| 9     | 0503-197    | 1   |       | A-Arm, Upper Left (inc. 10-13)            |
| 10    | 0403-081    | 4   | S     | Bushing                                   |
| 11    | 0403-080    | 2   |       | Collar                                    |
| 12    | 0423-009    | 4   | /P    | Clip, Ball Joint                          |
| 13    | 0405-115    | 4   | /P    | Ball Joint - Front                        |
| 14    | 0503-334    | 1   | S     | A-Arm, Lower Right (inc. 12-13 and 15-16) |
| 14    | 0503-335    | 1   | S     | A-Arm, Lower Left (inc. 12-13 and 15-16)  |
| 15    | 0403-115    | 8   | S     | Bushing                                   |
| 16    | 0403-114    | 4   | S     | Collar                                    |
| 17    | 0505-460    | 1   |       | Knuckle - Assembly - Right (inc. 18-19)   |
| 17    | 0505-461    | 1   | S     | Knuckle - Assembly - Left (inc. 18-19)    |
| 18    | 1402-027    | 2   | S/P   | Bearing, Wheel Hub                        |
| 19    | 0423-423    | 2   |       | Ring, Retaining                           |
| 20    | 8409-030    | 4   |       | Screw, Cap                                |
| 21    | 0423-334    | 2   |       | Screw, Cap                                |
| 22    | 8409-075    | 4   |       | Screw, Cap                                |
| 23    | 0502-812    | 1   | S     | Axle, Drive - Front - Right (inc. 24-25)  |
| 23    | 0502-813    | 1   | S     | Axle, Drive - Front - Left (inc. 24-25)   |
| 24    | 1441-109    | 2   | S     | Clip, Retaining                           |
| 25    | 0436-276    | 2   | S     | Repair Kit, Boot - Front Axle             |
| 26    | 1406-034    | 1   |       | Guard, Boot - Axle - Right                |
| 26    | 1406-035    | 1   |       | Guard, Boot - Axle - Left                 |
| 27    | 0423-545    | 4   | /P    | Screw, Body                               |


2008 ATV 700 EFI AUTOMATIC TRANSMISSION 4X4 FIS M4 CAMO (A20081BFA40430) of 93  
GAS TANK ASSEMBLY



2008 ATV 700 EFI AUTOMATIC TRANSMISSION 4X4 FIS M4 CAMO (A20081BFA4USC) of 93  
 GAS TANK ASSEMBLY

| Ref # | Part Number | Qty | S/P/F | Description                                   |
|-------|-------------|-----|-------|-----------------------------------------------|
| 1     | 0570-159    | 1   |       | Tank, Gas - Assembly (inc. 2-5 and one No. 9) |
| 2     | 0470-438    | 1   | /P    | Cap, Gas Tank (inc. 3)                        |
| 3     | 0109-733    | 1   | /P    | Gasket, Gas Tank Cap                          |
| 4     | 0470-606    | 1   |       | Plate, Mounting - Fuel Pump                   |
| 5     | 8476-612    | 4   |       | Screw, Self-Tapping                           |
| 6     | 0570-207    | 1   | S     | Pump, Fuel - Assembly (inc. 7-9)              |
| 7     | 0570-208    | 1   | S     | Sensor, Fuel Level - Kit (inc. 8-9)           |
| 8     | 0470-614    | 1   |       | Seal, Fuel Pump                               |
| 9     | 0470-613    | 1   |       | Seal, Fuel Pump                               |
| 10    | 0470-611    | 1   |       | Hose, Gasline - Assembly                      |
| 11    | 0423-670    | 1   |       | Clamp, Hose                                   |
| 12    | 0410-070    | AR  | /P    | Hose, Gasline - 25 ft                         |
| 13    | 0423-460    | 2   |       | Grommet                                       |
| 14    | 0470-709    | 1   |       | Shield, Heat - Gas Tank - Front               |
| 15    | 0470-710    | 1   |       | Shield, Heat - Gas Tank - Rear                |
| 16    | 0623-797    | 4   |       | Screw, Self-Tapping                           |
| 17    | 0423-732    | 2   |       | Screw, Gas Tank                               |

2008 ATV 700 EFI AUTOMATIC TRANSMISSION 4X4 FIS M4 CAMO (A20081BFA4GUSC) of 93  
GEAR SHIFTING ASSEMBLY






2008 ATV 700 EFI AUTOMATIC TRANSMISSION 4X4 FIS M4 CAMO (A20081BFA40430) of 93  
 GEAR SHIFTING ASSEMBLY

| Ref # | Part Number | Qty | S/P/F | Description                             |
|-------|-------------|-----|-------|-----------------------------------------|
| 1     | 3446-031    | 2   | /P    | Retainer, Shift Cam                     |
| 2     | 3446-423    | 1   |       | Fork, Reverse Gear Shift                |
| 3     | 3403-163    | 1   |       | Cam, Reverse Gear Shift                 |
| 4     | 3403-164    | 1   |       | Stopper, Shift Cam                      |
| 5     | 3423-839    | 1   |       | Spring, Shift Cam Stopper               |
| 6     | 3403-031    | 1   | S     | Arm, Select                             |
| 7     | 0693-489    | 1   | /P    | Nut, Select Arm                         |
| 8     | 3403-166    | 1   |       | Plate, Gear Shift Cam Stopper           |
| 9     | 3403-167    | 1   |       | Shaft, Gear Shift                       |
| 10    | 3403-168    | 1   |       | Shaft, Shift - No. 2                    |
| 11    | 3403-169    | 1   |       | Gear, Shift Shaft                       |
| 12    | 3446-424    | 1   |       | Fork, Gear Shift                        |
| 13    | 3403-170    | 1   |       | Cam, Gear Shift                         |
| 14    | 3423-840    | 1   |       | Spring, Shift Fork                      |
| 15    | 3423-841    | 1   |       | Spring, Shift Shaft Return              |
| 16    | 3403-171    | 1   |       | Shaft, Gear Shift (inc. 17)             |
| 17    | 3423-114    | 1   | /P    | Pin, Gear Shift                         |
| 18    | 3423-652    | 1   |       | Bolt, Shift Cam                         |
| 19    | 3423-370    | 2   |       | Screw, Shift Retainer                   |
| 20    | 3423-445    | 2   |       | Washer, Shift Shaft                     |
| 21    | 3402-382    | 1   |       | Washer, Shift Fork Spring               |
| 22    | 3402-068    | 1   | /P    | Seal, Shift Shaft                       |
| 23    | 3004-341    | 2   | S/P   | Bolt, Gear Shift                        |
| 24    | 3423-191    | 3   | /P    | Circlip, Gear Shift Shaft               |
| 25    | 3403-172    | 1   |       | Bearing, Gear Shift Shaft               |
| 26    | 3423-615    | 1   |       | Washer, Shift Cam Stopper               |
| 27    | 3423-546    | 1   |       | Circlip, Shift Shaft                    |
| 28    | 3423-418    | 2   |       | Bolt, Gear Shift Position Switch        |
| 29    | 3530-052    | 1   |       | Switch, Gear Shift Position             |
| 30    | 3423-044    | 2   |       | Contact, Gear Shift Position Switch     |
| 31    | 3423-842    | 1   |       | O-Ring, Gear Shift Position Switch      |
| 32    | 3004-787    | 2   |       | Clamp, Gear Shift Switch Position Lever |
| 33    | 3402-087    | 2   |       | Spring, Gear Shift Position Switch      |


2008 ATV 700 EFI AUTOMATIC TRANSMISSION 4X4 FIS M4 CAMO (A20081BFA00000) of 93  
HANDLEBAR ASSEMBLY



2008 ATV 700 EFI AUTOMATIC TRANSMISSION 4X4 FIS M4 CAMO (A20081BFA0510) of 93  
HANDLEBAR ASSEMBLY

| Ref # | Part Number | Qty | S/P/F | Description                             |
|-------|-------------|-----|-------|-----------------------------------------|
| 1     | 0505-476    | 1   |       | Tube, Handlebar                         |
| 2     | 0405-218    | 2   |       | Plug, Handlebar                         |
| 3     | 0405-149    | 2   |       | End Cap, Handlebar                      |
| 4     | 8050-247    | 2   | /P    | Washer                                  |
| 5     | 8477-845    | 2   |       | Screw, Machine                          |
| 6     | 0405-147    | 2   |       | Grip, Handlebar                         |
| 7     | 0430-069    | 1   | S     | Switch, Ignition - Assembly (inc. 8-10) |
| 8     | 0430-050    | 1   |       | Nut, Flange - Ignition Switch           |
| 9     | 0430-042    | 1   |       | Key, Ignition                           |
| 9     | 0430-043    | 1   |       | Key, Ignition                           |
| 10    | 0430-054    | 1   |       | Cover, Key                              |
| 11    | 0405-280    | 1   |       | Instrument Pod                          |
| 12    | 0641-897    | 1   | /P    | Outlet, Accessory - 12V                 |
| 13    | 0520-023    | 1   |       | Gauge, LCD                              |
| 14    | 0420-065    | 1   | /P    | Clamp, Plastic                          |
| 15    | 0423-493    | 2   |       | Nut, Hex                                |
| 16    | 2506-470    | 1   |       | Bracket, Mounting - Instrument Pod      |
| 17    | 0423-535    | 2   |       | Rivet, Reinstallable                    |
| 18    | 0502-527    | 1   |       | Control, Differential Lock (inc. 19)    |
| 19    | 0502-613    | 1   |       | Clamp, Differential Lock Control - Kit  |
| 20    | 0487-050    | 1   | /P    | Cable, Differential Lock                |


2008 ATV 700 EFI AUTOMATIC TRANSMISSION 4X4 FIS M4 CAMO (A20081BFA40USC) of 93  
HYDRAULIC BRAKE ASSEMBLY



2008 ATV 700 EFI AUTOMATIC TRANSMISSION 4X4 FIS M4 CAMO (A20081BFA0050) of 93  
 HYDRAULIC BRAKE ASSEMBLY

| Ref # | Part Number | Qty | S/P/F | Description                                          |
|-------|-------------|-----|-------|------------------------------------------------------|
| 1     | 1502-015    | 1   |       | Hose, Brake - Assembly                               |
| 2     | 8476-625    | 1   |       | Screw, Cap                                           |
| 3     | 8408-821    | 4   | /P    | Screw, Cap                                           |
| 4     | 0502-878    | 1   | S     | Caliper, Brake - Right Front (inc. 5-11)             |
| 4     | 0502-879    | 1   | S     | Caliper, Brake - Left Front (inc. 5-11)              |
| 5     | 0502-603    | 1   | S     | Housing, Caliper - Assembly - Right Front (inc. 6-8) |
| 5     | 0502-611    | 1   | S     | Housing, Caliper - Assembly - Left Front (inc. 6-8)  |
| 6     | 0502-606    | 2   |       | Piston/Seal Set (inc. 7)                             |
| 7     | 0502-607    | 2   |       | Seal Set                                             |
| 8     | 0502-609    | 2   | /P    | Valve, Bleed                                         |
| 9     | 0502-608    | 2   |       | O-Ring, Guide - Set                                  |
| 10    | 0502-605    | 2   |       | Bracket Assembly                                     |
| 11    | 0502-875    | 2   | S     | Pad, Brake - Set                                     |
| 12    | 0423-178    | 4   |       | Washer, Crush                                        |
| 13    | 0423-413    | 2   |       | Bolt, Banjo-Fitting                                  |
| 14    | 0623-038    | 1   |       | Nut, Lock                                            |


2008 ATV 700 EFI AUTOMATIC TRANSMISSION 4X4 FIS M4 CAMO (A20081BFA4G15C) of 93  
HYDRAULIC HAND BRAKE ASSEMBLY



2008 ATV 700 EFI AUTOMATIC TRANSMISSION 4X4 FIS M4 CAMO (A2008IBF4G150) of 93  
 HYDRAULIC HAND BRAKE ASSEMBLY

| Ref # | Part Number | Qty | S/P/F | Description                  |
|-------|-------------|-----|-------|------------------------------|
| 1     | 0502-914    | 1   | S     | Brake Assembly (inc. 2-10)   |
| 2     | 0502-566    | 1   |       | Screw, Reservoir Cover       |
| 3     | 0502-868    | 1   | /P    | Cover, Reservoir             |
| 4     | 0502-568    | 1   |       | Screw, Master Cylinder Clamp |
| 5     | 0502-869    | 1   |       | Clamp, Master Cylinder       |
| 6     | 0502-704    | 1   |       | Master Cylinder Assembly     |
| 7     | 0502-866    | 1   |       | Lever Assembly (inc. 8-9)    |
| 8     | 0502-867    | 1   | /P    | Lock, Brake Lever - Kit      |
| 9     | 0502-580    | 1   |       | Lever Pin - Kit              |
| 10    | 0502-564    | 1   | /P    | Switch, Brake - Kit          |
| 11    | 0423-178    | 2   |       | Washer, Crush                |
| 12    | 0423-413    | 1   |       | Bolt, Banjo-Fitting          |

2008 ATV 700 EFI AUTOMATIC TRANSMISSION 4X4 FIS M4 CAMO (A20081BFA0150) of 93  
MAGNETO ASSEMBLY






2008 ATV 700 EFI AUTOMATIC TRANSMISSION 4X4 FIS M4 CAMO (A20081BFA0150) of 93  
MAGNETO ASSEMBLY

| Ref # | Part Number | Qty | S/P/F | Description         |
|-------|-------------|-----|-------|---------------------|
| 1     | 3430-067    | 1   |       | Stator - Assembly   |
| 2     | 3430-068    | 1   |       | Rotor/Flywheel      |
| 3     | 3004-484    | 3   | S     | Screw, Cap          |
| 4     | 0691-785    | 1   |       | Key                 |
| 5     | 3423-086    | 1   |       | Nut                 |
| 6     | 3423-005    | 4   | /P    | Bolt                |
| 7     | 3430-005    | 2   |       | Clamp, Magneto Lead |


2008 ATV 700 EFI AUTOMATIC TRANSMISSION 4X4 FIS M4 CAMO (A20081BFA0150) of 93  
OIL FILTER/PUMP ASSEMBLY



2008 ATV 700 EFI AUTOMATIC TRANSMISSION 4X4 FIS M4 CAMO (A20081BFA0150) of 93  
 OIL FILTER/PUMP ASSEMBLY

| Ref # | Part Number | Qty | S/P/F | Description           |
|-------|-------------|-----|-------|-----------------------|
| 1     | 3403-123    | 1   |       | Pump, Oil             |
| 2     | 3423-510    | 3   |       | Screw, Machine        |
| 3     | 3403-124    | 1   |       | Chain, Drive          |
| 4     | 3403-125    | 1   |       | Sprocket, Drive Chain |
| 5     | 3423-443    | 1   |       | Washer                |
| 6     | 3423-046    | 1   |       | Pin                   |
| 7     | 3423-184    | 1   | S     | Circlip               |
| 8     | 3403-126    | 1   |       | Strainer, Oil         |
| 9     | 0812-029    | 1   | S     | Filter, Oil           |
| 10    | 3403-219    | 1   | /P    | Union, Oil Filter     |


2008 ATV 700 EFI AUTOMATIC TRANSMISSION 4X4 FIS M4 CAMO (A20081BFA00000) of 93  
REAR DRIVE GEARCASE ASSEMBLY



2008 ATV 700 EFI AUTOMATIC TRANSMISSION 4X4 FIS M4 CAMO (A20081BFA0510) of 93  
 REAR DRIVE GEARCASE ASSEMBLY

| Ref # | Part Number | Qty | S/P/F | Description                                |
|-------|-------------|-----|-------|--------------------------------------------|
|       | 0502-909    | 1   |       | Complete Rear Gearcase Assembly            |
| 1     | 0502-911    | 1   |       | Housing, Gearcase                          |
| 2     | 0402-393    | 2   |       | Bearing                                    |
| 3     | 0402-394    | 2   | S     | Seal                                       |
| 4     | 1402-032    | 1   |       | Gear, Ring - 36T                           |
| 5     | 0402-405    | AR  |       | Shim                                       |
| 5     | 0402-406    | AR  |       | Shim                                       |
| 5     | 0402-407    | AR  |       | Shim                                       |
| 5     | 0402-408    | AR  |       | Shim                                       |
| 5     | 0402-409    | AR  |       | Shim                                       |
| 6     | 0402-326    | 1   |       | Button, Thrust                             |
| 7     | 0423-149    | 1   |       | O-Ring                                     |
| 8     | 0402-429    | AR  |       | Shim                                       |
| 8     | 0402-430    | AR  |       | Shim                                       |
| 8     | 0402-431    | AR  |       | Shim                                       |
| 8     | 0402-432    | AR  |       | Shim                                       |
| 8     | 0402-433    | AR  |       | Shim                                       |
| 9     | 0502-920    | 1   |       | Cover, Gearcase                            |
| 10    | 1402-102    | 1   |       | Fitting                                    |
| 11    | 0402-333    | 1   | /P    | Plug, Fill (inc. 12)                       |
| 12    | 0423-154    | 1   |       | O-Ring                                     |
| 13    | 0423-118    | 11  |       | Screw, Self-Tapping                        |
| 14    | 0402-450    | 1   | S     | Plug, Magnetic (inc. 15)                   |
| 15    | 0423-153    | 1   |       | O-Ring                                     |
| 16    | 0402-328    | 1   |       | Bearing                                    |
| 17    | 0502-783    | 1   |       | Gear, Pinion - Assembly - 10T (inc. 18-19) |
| 18    | 0402-327    | 1   |       | Bearing                                    |
| 19    | 0402-336    | 1   |       | Collar, Retaining                          |
| 20    | 0402-411    | 1   |       | Pin, Dowel                                 |
| 21    | 0402-331    | 1   |       | Collar, Lock                               |
| 22    | 0402-982    | 1   |       | Washer, Wave                               |
| 23    | 0402-981    | 1   |       | Collar, Shaft                              |
| 24    | 0402-947    | 1   |       | Gasket, Flange                             |
| 25    | 0502-529    | 1   |       | Housing, Pinion                            |
| 26    | 0423-417    | 1   |       | Ring, Retaining                            |
| 27    | 1402-043    | 1   |       | Bearing                                    |
| 28    | 0423-423    | 1   |       | Ring, Retaining                            |
| 29    | 1402-011    | 1   |       | Seal                                       |
| 30    | 0502-407    | 1   | S     | Shaft, Input                               |
| 31    | 1402-211    | 1   |       | Plug, Oil Level                            |


2008 ATV 700 EFI AUTOMATIC TRANSMISSION 4X4 FIS M4 CAMO (A20081BFA0050) of 93  
REAR RACK AND FOOTWELL ASSEMBLIES



2008 ATV 700 EFI AUTOMATIC TRANSMISSION 4X4 FIS M4 CAMO (A20081BFA4GUSC) of 93  
 REAR RACK AND FOOTWELL ASSEMBLIES

| Ref # | Part Number | Qty | S/P/F | Description                      |
|-------|-------------|-----|-------|----------------------------------|
| 1     | 2506-125    | 1   |       | Rack, Rear - Assembly (inc. 2-3) |
| 2     | 0411-648    | 1   |       | Decal, Warning - Rear Rack Load  |
| 3     | 0441-592    | 4   | /P    | Bushing, Rack                    |
| 4     | 8410-830    | 4   |       | Screw, Cap                       |
| 5     | 0423-669    | 4   |       | Spacer                           |
| 6     | 0423-465    | 4   |       | Grommet                          |
| 7     | 8432-802    | 4   |       | Nut, Lock                        |
| 8     | 0423-654    | 2   |       | Screw, Shoulder                  |
| 9     | 8050-222    | 2   | /P    | Washer                           |
| 10    | 0423-540    | 24  |       | Nut, Lock                        |
| 11    | 0423-101    | 2   |       | Screw, Body                      |
| 12    | 1406-356    | 1   |       | Footwell - Right                 |
| 12    | 2406-425    | 1   | /P    | Footwell - Left                  |
| 13    | 0623-362    | 2   |       | Rivet, Reinstallable             |
| 14    | 0423-419    | 16  |       | Screw, Machine                   |
| 15    | 0423-355    | 4   |       | Screw, Shoulder                  |
| 16    | 1506-125    | 2   | /P    | Footpeg                          |

2008 ATV 700 EFI AUTOMATIC TRANSMISSION 4X4 FIS M4 CAMO (A20081BFA4GUSC) of 93  
REAR SUSPENSION ASSEMBLY






2008 ATV 700 EFI AUTOMATIC TRANSMISSION 4X4 FIS M4 CAMO (A20081BFA4GUSC) of 93  
 REAR SUSPENSION ASSEMBLY

| Ref # | Part Number | Qty | S/P/F | Description                               |
|-------|-------------|-----|-------|-------------------------------------------|
| 1     | 0504-372    | 1   | S     | Knuckle, Right Rear - Assembly (inc. 2-5) |
| 1     | 0504-373    | 1   | S/P   | Knuckle, Left Rear - Assembly (inc. 2-5)  |
| 2     | 1402-027    | 2   | S/P   | Bearing, Wheel Hub                        |
| 3     | 0423-423    | 2   |       | Ring, Retaining                           |
| 4     | 0403-038    | 4   | S/P   | Collar, Suspension Bushing                |
| 5     | 0403-032    | 8   | S     | Bushing, Suspension                       |
| 6     | 0504-438    | 1   | /P    | A-Arm, Rear - Lower Right (inc. 7-8)      |
| 6     | 0504-439    | 1   | S     | A-Arm, Rear - Lower Left (inc. 7-8)       |
| 7     | 0403-115    | 16  | S     | Bushing                                   |
| 8     | 0403-114    | 8   | S     | Collar                                    |
| 9     | 8428-002    | 14  |       | Nut, Lock                                 |
| 10    | 8409-000    | 4   |       | Screw, Cap                                |
| 11    | 0504-470    | 1   |       | A-Arm, Rear - Upper Right (inc. 7-8)      |
| 11    | 0504-471    | 1   | S     | A-Arm, Rear - Upper Left (inc. 7-8)       |
| 12    | 1406-068    | 1   |       | Guard, Boot - Right                       |
| 12    | 1406-069    | 1   |       | Guard, Boot - Left                        |
| 13    | 0423-545    | 4   | /P    | Screw, Body                               |
| 14    | 8409-075    | 8   |       | Screw, Cap                                |
| 15    | 0502-811    | 2   | S     | Axle, Drive (inc. 16-17)                  |
| 16    | 0441-893    | 2   | S     | Clip, Retaining                           |
| 17    | 0436-276    | 2   | S     | Repair Kit, Boot - Rear Axle              |
| 18    | 0441-587    | 1   |       | Wrench, Spanner                           |
| 19    | 1603-889    | 2   | /P    | Retainer, Spring                          |
| 20    | 0404-112    | 2   |       | Spring, Suspension                        |
| 21    | 0404-057    | 2   |       | Cam, Spring Adjuster                      |
| 22    | 0404-150    | 2   |       | Shock Absorber - Rear (inc. 23-25)        |
| 23    | 0403-182    | 2   |       | Bushing, Double-Bonded                    |
| 24    | 0603-955    | 4   |       | Bushing, Shock Absorber                   |
| 25    | 1603-219    | 2   | S     | Sleeve, Shock Absorber                    |
| 26    | 0423-087    | 2   |       | Washer                                    |
| 27    | 8408-820    | 2   | /P    | Screw, Cap                                |
| 28    | 8409-040    | 1   |       | Screw, Cap - Right                        |
| 28    | 8409-050    | 1   |       | Screw, Cap - Left                         |
| 29    | 0123-788    | 2   | /P    | Cable Tie                                 |


2008 ATV 700 EFI AUTOMATIC TRANSMISSION 4X4 FIS M4 CAMO (A20081BFA0150) of 93  
SEAT ASSEMBLY



2008 ATV 700 EFI AUTOMATIC TRANSMISSION 4X4 FIS M4 CAMO (A20081B40150) of 93  
 SEAT ASSEMBLY

| Ref # | Part Number | Qty | S/P/F | Description                      |
|-------|-------------|-----|-------|----------------------------------|
| 1     | 1506-937    | 1   | S/P   | Seat Assembly (inc. 2-9)         |
| 2     | 1506-209    | 1   |       | Cover, Seat                      |
| 3     | 1506-208    | 1   |       | Foam, Seat                       |
| 4     | 2406-144    | 1   | S/P   | Base, Seat - Assembly (inc. 5-6) |
| 5     | 0406-879    | 2   |       | Bumper, Seat - Rear              |
| 6     | 0406-877    | 4   | /P    | Bumper, Seat - Front             |
| 7     | 0624-263    | AR  |       | Staple                           |
| 8     | 1406-592    | 1   | /P    | Spring, Seat Latch               |
| 9     | 1506-156    | 1   |       | Latch, Seat                      |


2008 ATV 700 EFI AUTOMATIC TRANSMISSION 4X4 FIS M4 CAMO (A20081BFA00000) of 93  
SECONDARY DRIVE ASSEMBLY



2008 ATV 700 EFI AUTOMATIC TRANSMISSION 4X4 FIS M4 CAMO (A20081BFA00000) of 93  
SECONDARY DRIVE ASSEMBLY

| Ref # | Part Number | Qty | S/P/F | Description                         |
|-------|-------------|-----|-------|-------------------------------------|
| 1     | 3423-069    | 1   |       | C-Ring, Secondary Driven Output     |
| 2     | 3423-191    | 1   | /P    | Circlip, Front Drive Output         |
| 3     | 3423-835    | 1   |       | Collar, Front Drive Output (inc. 4) |
| 4     | 3423-836    | 1   |       | Plate, Front Drive Output Collar    |
| 5     | 3423-837    | 1   |       | O-Ring, Front Drive Output          |
| 6     | 3402-072    | 2   |       | Seal, Output Shaft                  |
| 7     | 3423-194    | 1   | S     | Circlip, Front Drive Output Shaft   |
| 8     | 3423-845    | 1   |       | Washer, Front Drive Output Yoke     |
| 9     | 3004-209    | 1   | /P    | Bearing, Front Drive Output         |
| 10    | 3004-576    | 1   | S     | Bolt, Front Bearing Housing         |
| 11    | 3403-160    | 1   |       | Housing, Front Drive Output Shaft   |
| 12    | 3423-838    | 1   |       | O-Ring, Front Bearing Housing       |
| 13    | 3403-216    | 1   | /P    | Shaft, Secondary Output - Front     |
| 14    | 3403-175    | 1   |       | Bearing, Front Drive Output - Rear  |
| 15    | 3423-023    | 1   |       | Nut, Secondary Drive Output         |
| 16    | 3005-372    | 1   |       | Washer, Secondary Drive Bevel       |
| 17    | 3403-157    | 1   |       | Gear, Secondary Drive Bevel         |
| 18    | 3423-549    | AR  |       | Shim, Secondary Drive Bevel - Set   |
| 19    | 3423-136    | 1   |       | Nut, Secondary Driven Output        |
| 20    | 3423-137    | 1   |       | Washer, Output Shaft Gear           |
| 21    | 3403-215    | 1   | /P    | Gear, Secondary Driven Output       |
| 22    | 3402-515    | 1   | /P    | Bearing, Secondary Driven Gear      |
| 23    | 3423-072    | 1   |       | Ring, Secondary Driven Gear         |
| 24    | 3403-158    | 1   |       | Gear, Secondary Driven Bevel        |
| 25    | 3403-161    | 1   |       | Shaft, Secondary Output - Rear      |
| 26    | 3402-017    | AR  |       | Shim, 25 x 34 x 0.60 mm             |
| 26    | 3402-018    | AR  |       | Shim, 25 x 34 x 0.65 mm             |
| 26    | 3402-019    | AR  |       | Shim, 25 x 34 x 0.70 mm             |
| 26    | 3402-020    | AR  |       | Shim, 25 x 34 x 0.75 mm             |
| 26    | 3403-217    | AR  | /P    | Shim, 25 x 34 x 0.80 mm             |
| 26    | 3402-022    | AR  |       | Shim, 25 x 34 x 0.85 mm             |
| 26    | 3402-023    | AR  |       | Shim, 25 x 34 x 0.90 mm             |
| 26    | 3402-024    | AR  |       | Shim, 25 x 34 x 0.95 mm             |
| 26    | 3423-421    | AR  | /P    | Shim, 25 x 34 x 1.00 mm             |
| 26    | 3402-028    | AR  |       | Shim, 25 x 34 x 1.05 mm             |
| 26    | 3402-029    | AR  |       | Shim, 25 x 34 x 1.10 mm             |
| 26    | 3402-030    | AR  |       | Shim, 25 x 34 x 1.15 mm             |
| 26    | 3402-031    | AR  |       | Shim, 25 x 34 x 1.20 mm             |
| 27    | 3403-210    | 1   | /P    | Bearing, Rear Output Shaft          |
| 28    | 3402-514    | 1   | /P    | Flange, Rear Output Joint           |
| 29    | 3423-028    | 1   |       | Washer, Rear Drive Output Yoke      |
| 30    | 3423-025    | 1   |       | Nut, Rear Drive Output Yoke         |


2008 ATV 700 EFI AUTOMATIC TRANSMISSION 4X4 FIS M4 CAMO (A20081BFA00000) of 93  
SECONDARY TRANSMISSION ASSEMBLY



2008 ATV 700 EFI AUTOMATIC TRANSMISSION 4X4 FIS M4 CAMO (A20081BFA0US10) of 93  
 SECONDARY TRANSMISSION ASSEMBLY

| Ref # | Part Number | Qty | S/P/F | Description                   |
|-------|-------------|-----|-------|-------------------------------|
| 1     | 3423-821    | 1   | /P    | Spacer, Driveshaft            |
| 2     | 3446-031    | 4   | /P    | Retainer, Driveshaft          |
| 3     | 3403-142    | 1   | S     | Driveshaft                    |
| 4     | 3403-143    | 1   |       | Countershaft                  |
| 5     | 3446-380    | 1   |       | Bushing, Driven Gear - Low    |
| 6     | 3403-144    | 1   |       | Gear, Driven - Low            |
| 7     | 3403-145    | 1   |       | Gear, Driven - High           |
| 8     | 3403-146    | 1   |       | Dog, Gear Shift - High        |
| 9     | 3423-828    | 1   |       | Spacer                        |
| 10    | 3403-147    | 1   |       | Gear, Drive                   |
| 11    | 3423-370    | 4   |       | Screw, Retainer               |
| 12    | 3423-829    | 1   |       | Washer                        |
| 13    | 3423-830    | 1   |       | Spacer                        |
| 14    | 3402-979    | 1   | /P    | Bearing                       |
| 15    | 3402-499    | 1   |       | Bearing                       |
| 16    | 3423-831    | 1   | /P    | O-Ring                        |
| 17    | 3403-148    | 1   | /P    | Seal, Driveshaft              |
| 18    | 3423-547    | 1   |       | Bushing, Driven Gear          |
| 19    | 3004-209    | 1   | /P    | Bearing, Driveshaft - Left    |
| 20    | 3402-219    | 1   |       | Bearing, Countershaft - Left  |
| 21    | 3423-832    | 1   |       | Washer, Driven Gear - Right   |
| 22    | 3423-833    | 1   |       | Washer, Driven Gear - Left    |
| 23    | 3423-191    | 1   | /P    | Circlip                       |
| 24    | 3403-149    | 1   |       | Shaft, Output                 |
| 25    | 3402-207    | 1   |       | Spacer, Output Shaft          |
| 26    | 3403-150    | 1   |       | Bearing, Output Shaft - Right |
| 27    | 3530-051    | 1   |       | Sensor, Speedometer           |
| 28    | 3423-614    | 1   | S     | Screw, Machine                |
| 29    | 3403-151    | 1   |       | Seal, Output Shaft - Left     |
| 30    | 3004-209    | 1   | /P    | Bearing, Output Shaft - Left  |
| 31    | 3403-152    | 1   |       | Gear, Reverse Idler           |
| 32    | 3403-153    | 1   |       | Gear, Reverse Driven          |
| 33    | 3403-154    | 1   |       | Dog, Select                   |
| 34    | 3446-380    | 1   |       | Bushing, Reverse Driven Gear  |
| 35    | 3423-828    | 1   |       | Spacer, Reverse Select        |
| 36    | 3423-262    | 1   |       | Washer, Lock                  |
| 37    | 3423-266    | 1   |       | Washer, Lock                  |
| 38    | 3403-155    | 1   |       | Shaft, Reverse Idler          |
| 39    | 3402-195    | 1   |       | Washer, Reverse Idler Gear    |
| 40    | 3403-156    | 1   |       | Bearing, Reverse Idler Gear   |

2008 ATV 700 EFI AUTOMATIC TRANSMISSION 4X4 FIS M4 CAMO (A20081BFA4USC) of 93  
SHIFT LEVER ASSEMBLY






2008 ATV 700 EFI AUTOMATIC TRANSMISSION 4X4 FIS M4 CAMO (A20081BFA4USC) of 93  
SHIFT LEVER ASSEMBLY

| Ref # | Part Number | Qty | S/P/F | Description                 |
|-------|-------------|-----|-------|-----------------------------|
| 1     | 0402-843    | 1   | /P    | Knob, Reverse Shift Lever   |
| 2     | 0423-345    | 1   |       | Clip, Push                  |
| 3     | 1402-576    | 1   |       | Plate, Shift                |
| 4     | 0423-357    | 4   |       | Nut, Stamped                |
| 5     | 0502-659    | 1   |       | Lever, Reverse Shift        |
| 6     | 0502-410    | 1   | S     | Spring, Reverse Shift Lever |
| 7     | 0502-950    | 1   |       | Axle, Reverse Shift Lever   |
| 8     | 8424-602    | 1   | /P    | Nut                         |
| 9     | 0423-182    | 2   | /P    | O-Ring                      |
| 10    | 0402-675    | 1   |       | Axle, Pivot                 |
| 11    | 0423-299    | 2   | /P    | O-Ring                      |
| 12    | 8408-812    | 1   |       | Screw, Cap                  |
| 13    | 0423-087    | 1   |       | Washer                      |
| 14    | 0624-250    | 1   |       | Nut                         |
| 15    | 0423-648    | 1   |       | End, Rod                    |
| 16    | 0423-649    | 1   |       | Nut, Jam                    |
| 17    | 2406-201    | 1   |       | Linkage, Shift              |


2008 ATV 700 EFI AUTOMATIC TRANSMISSION 4X4 FIS M4 CAMO (A20081BFA00000) Page 50 of 93  
STARTER CLUTCH ASSEMBLY



2008 ATV 700 EFI AUTOMATIC TRANSMISSION 4X4 FIS M4 CAMO (A2008IBF4GUS) of 93  
 STARTER CLUTCH ASSEMBLY

| Ref # | Part Number | Qty | S/P/F | Description                       |
|-------|-------------|-----|-------|-----------------------------------|
| 1     | 3403-089    | 1   |       | Clutch, Starter - Set (inc. 2)    |
| 2     | 3403-090    | 1   |       | Bearing                           |
| 3     | 3423-509    | 1   |       | Bolt                              |
| 4     | 3403-091    | 1   |       | Gear, Starter Idler - No. 2       |
| 5     | 3423-805    | 1   |       | Pin, Starter Idler Gear No. 2     |
| 6     | 3403-092    | 1   |       | Limiter, Starter Idler Gear No. 2 |
| 7     | 3423-806    | 2   |       | Bushing, Limiter Gear Shaft       |
| 8     | 3423-103    | 2   | /P    | Washer                            |
| 9     | 3402-043    | 1   | /P    | Bearing                           |
| 10    | 3423-807    | 1   |       | Circlip                           |


2008 ATV 700 EFI AUTOMATIC TRANSMISSION 4X4 FIS M4 CAMO (A20081BFA00000) of 93  
STARTER MOTOR ASSEMBLY



2008 ATV 700 EFI AUTOMATIC TRANSMISSION 4X4 FIS M4 CAMO (A20081BFA050) of 93  
 STARTER MOTOR ASSEMBLY

| Ref # | Part Number | Qty | S/P/F | Description                          |
|-------|-------------|-----|-------|--------------------------------------|
| 1     | 3545-020    | 1   |       | Motor, Starter - Assembly (inc. 2-9) |
| 2     | 3008-094    | 1   | /P    | Terminal Set, Brush (inc. 3)         |
| 3     | 3008-164    | 1   |       | O-Ring                               |
| 4     | 3008-095    | 1   | /P    | Holder Set, Brush (inc. 5)           |
| 5     | 3008-096    | 4   |       | Spring, Brush                        |
| 6     | 3008-099    | 1   |       | Washer Set                           |
| 7     | 3008-553    | 2   | /P    | O-Ring                               |
| 8     | 3423-085    | 2   |       | Through-Bolt                         |
| 9     | 3423-272    | 1   |       | O-Ring                               |
| 10    | 3007-369    | 2   | /P    | Screw, Cap                           |
| 11    | 3423-195    | 1   | /P    | Nut                                  |


2008 ATV 700 EFI AUTOMATIC TRANSMISSION 4X4 FIS M4 CAMO (A20081BFA00000) of 93  
STEERING ASSEMBLY



2008 ATV 700 EFI AUTOMATIC TRANSMISSION 4X4 FIS M4 CAMO (A2008IBF4GUSC) of 93  
STEERING ASSEMBLY

| Ref # | Part Number | Qty | S/P/F | Description                                                           |
|-------|-------------|-----|-------|-----------------------------------------------------------------------|
| 1     | 8408-860    | 4   |       | Screw, Cap                                                            |
| 2     | 0405-035    | 4   |       | Cap, Steering Adjuster                                                |
| 3     | 0423-505    | 2   |       | Screw, Shoulder                                                       |
| 4     | 0505-484    | 1   |       | Cap, Housing                                                          |
| 5     | 0405-138    | 1   |       | Housing, Lower                                                        |
| 6     | 0405-139    | 1   |       | Housing, Upper                                                        |
| 7     | 0505-451    | 1   | S     | Post, Steering                                                        |
| 8     | 8408-816    | 2   |       | Screw, Cap                                                            |
| 9     | 0602-233    | 1   |       | Flange, Bearing                                                       |
| 10    | 0405-052    | 1   |       | Bearing w/Inverted Oil Seal                                           |
| 11    | 0423-073    | 1   |       | Washer                                                                |
| 12    | 8409-020    | 1   | /P    | Screw, Cap                                                            |
| 13    | 0505-499    | 2   | /P    | Tie Rod - Assembly (inc. 14-20)                                       |
| 14    | 0505-511    | 2   | /P    | End, Tie Rod - Left-Hand Thread - Kit (inc. 15-16 and two No. 21-22)  |
| 15    | 0           | 2   | F     | End, Tie Rod - Left Hand Thread                                       |
| 16    | 0423-013    | 2   |       | Nut - Left-Hand Thread                                                |
| 17    | 0405-281    | 2   | /P    | Tie Rod                                                               |
| 18    | 0505-510    | 2   | /P    | End, Tie Rod - Right-Hand Thread - Kit (inc. 19-20 and two No. 21-22) |
| 19    | 0           | 2   | F     | End, Tie Rod - Right-Hand Thread                                      |
| 20    | 8420-002    | 2   | /P    | Nut - Right-Hand Thread                                               |
| 21    | 0423-157    | 4   |       | Nut, Lock                                                             |
| 22    | 0623-175    | 4   |       | Pin, Cotter                                                           |

2008 ATV 700 EFI AUTOMATIC TRANSMISSION 4X4 FIS M4 CAMO (A2008IBF4GUSC) of 93  
TAILLIGHT ASSEMBLY





2008 ATV 700 EFI AUTOMATIC TRANSMISSION 4X4 FIS M4 CAMO (A2008IBF4GUS1C) of 93  
 TAILLIGHT ASSEMBLY

| Ref # | Part Number | Qty | S/P/F | Description                   |
|-------|-------------|-----|-------|-------------------------------|
| 1     | 0509-022    | 1   |       | Taillight Assembly (inc. 2-4) |
| 2     | 0509-025    | 1   |       | Housing, Taillight            |
| 3     | 0409-056    | 1   |       | Bulb, Taillight               |
| 4     | 0409-057    | 1   |       | Socket, Taillight             |
| 5     | 0623-301    | 2   | /P    | Screw, Self-Tapping           |
| 6     | 8053-212    | 2   | /P    | Washer, Lock - External Tooth |


Page 49 of 93



2008 ATV 700 EFI AUTOMATIC TRANSMISSION 4X4 FIS M4 CAMO (A20081BFA4GUSC) of 93  
 THROTTLE BODY ASSEMBLY

| Ref # | Part Number | Qty | S/P/F | Description                           |
|-------|-------------|-----|-------|---------------------------------------|
| 1     | 3403-116    | 1   |       | Body, Throttle - Assembly (inc. 2-12) |
| 2     | 3403-117    | 1   |       | ISC Valve                             |
| 3     | 3423-812    | 1   |       | O-Ring                                |
| 4     | 3403-118    | 1   |       | Cover                                 |
| 5     | 3530-048    | 1   |       | Sensor - Assembly                     |
| 6     | 3423-813    | 5   |       | Screw                                 |
| 7     | 3423-814    | 2   |       | Screw                                 |
| 8     | 3403-119    | 1   |       | Hose                                  |
| 9     | 3403-120    | 1   |       | Injector - Assembly (inc. 10)         |
| 10    | 3423-815    | 1   |       | O-Ring                                |
| 11    | 3403-121    | 1   |       | Seal                                  |
| 12    | 3403-122    | 1   |       | Delivery Pipe                         |
| 13    | 3530-049    | 1   |       | Sensor, Air Pressure                  |
| 14    | 3530-050    | 1   |       | Holder, Air Pressure                  |
| 15    | 0487-032    | 1   |       | Cable, Throttle                       |


2008 ATV 700 EFI AUTOMATIC TRANSMISSION 4X4 FIS M4 CAMO (A20081B74GUSC) of 93  
THROTTLE CASE ASSEMBLY



2008 ATV 700 EFI AUTOMATIC TRANSMISSION 4X4 FIS M4 CAMO (A20081BFA00000) of 93  
THROTTLE CASE ASSEMBLY

| Ref # | Part Number | Qty | S/P/F | Description                          |
|-------|-------------|-----|-------|--------------------------------------|
| 1     | 0509-012    | 1   |       | Case, Throttle - Assembly (inc. 2-9) |
| 2     | 3409-001    | 1   |       | Lever                                |
| 3     | 3004-533    | 1   | S/P   | Screw, Cap                           |
| 4     | 3004-447    | 1   | /P    | Washer, Lock                         |
| 5     | 3003-030    | 1   | /P    | Washer                               |
| 6     | 3423-014    | 1   |       | Screw                                |
| 7     | 3423-327    | 1   |       | Nut                                  |
| 8     | 3423-199    | 2   |       | Screw                                |
| 9     | 0409-048    | 1   |       | Cover, Throttle w/Switch             |


2008 ATV 700 EFI AUTOMATIC TRANSMISSION 4X4 FIS M4 CAMO (A20081BFA4GUSC) of 93  
TRANSMISSION ASSEMBLY



2008 ATV 700 EFI AUTOMATIC TRANSMISSION 4X4 FIS M4 CAMO (A20081BFA0150) of 93  
TRANSMISSION ASSEMBLY

| Ref # | Part Number | Qty | S/P/F | Description                     |
|-------|-------------|-----|-------|---------------------------------|
| 1     | 3403-130    | 1   |       | Face, Fixed Drive               |
| 2     | 3403-131    | 1   |       | Face, Movable Drive             |
| 3     | 3403-132    | 2   |       | Seal, Movable Drive Face        |
| 4     | 3423-843    | 1   |       | Spacer, Movable Drive Face      |
| 5     | 3403-133    | 1   |       | Face, Fixed Driven              |
| 6     | 3403-134    | 1   |       | Face, Movable Driven            |
| 7     | 3402-474    | 1   | /P    | Spring, Movable Driven Face     |
| 8     | 3402-475    | 2   |       | O-Ring, Movable Driven Face     |
| 9     | 3403-135    | 2   |       | Seal, Movable Driven Face       |
| 10    | 3402-477    | 4   |       | Pin, Movable Driven Face        |
| 11    | 3402-478    | 4   |       | Spacer, Movable Driven Face     |
| 12    | 3403-136    | 1   |       | Plate, Movable Drive Face       |
| 13    | 3402-756    | 1   |       | Sheet, Movable Driven Face      |
| 14    | 3402-481    | 4   |       | Damper, Movable Drive Face      |
| 15    | 3423-406    | 1   |       | Nut, Driven Pulley Spring       |
| 16    | 3402-482    | 1   |       | Holder, Movable Driven Face     |
| 17    | 3403-137    | 8   |       | Roller, Movable Driven Face     |
| 18    | 3423-819    | 1   |       | Bolt, Drive Face                |
| 19    | 3423-820    | 1   |       | Bolt, Driven Face               |
| 20    | 3403-138    | 1   |       | Housing, Clutch                 |
| 21    | 3423-821    | 1   | /P    | Spacer, Primary Shaft           |
| 22    | 3423-822    | 1   |       | Spacer, Clutch Housing          |
| 23    | 3423-823    | 1   |       | Cap, V-Belt Bearing             |
| 24    | 3446-003    | 1   |       | Clutch, One-Way                 |
| 25    | 3403-139    | 1   |       | Centrifugal Clutch - Assembly   |
| 26    | 3423-824    | 2   |       | Retainer, Bearing               |
| 27    | 3423-018    | 2   |       | Screw, Bearing Retainer         |
| 28    | 3423-501    | 1   |       | Nut                             |
| 29    | 3423-825    | 1   |       | Washer                          |
| 30    | 3402-221    | 1   |       | Bearing, Clutch Housing - Left  |
| 31    | 3403-140    | 1   |       | Bearing, Clutch Housing - Right |
| 32    | 3423-831    | 1   | /P    | O-Ring                          |
| 33    | 3403-173    | 1   |       | Seal, Clutch Housing - Right    |
| 34    | 3403-148    | 1   | /P    | Seal, Clutch Housing - Left     |
| 35    | 3423-826    | 1   | /P    | Circlip, Clutch Housing         |
| 36    | 3403-141    | 1   |       | V-Belt                          |

2008 ATV 700 EFI AUTOMATIC TRANSMISSION 4X4 FIS M4 CAMO (A20081BFA00000) of 93  
WATER PUMP ASSEMBLY






2008 ATV 700 EFI AUTOMATIC TRANSMISSION 4X4 FIS M4 CAMO (A20081BFA4GUSC) of 93  
WATER PUMP ASSEMBLY

| Ref # | Part Number | Qty | S/P/F | Description                        |
|-------|-------------|-----|-------|------------------------------------|
| 1     | 3403-128    | 1   |       | Pump, Water - Assembly (inc. 2-11) |
| 2     | 3413-041    | 1   |       | Impeller                           |
| 3     | 3005-909    | 1   | /P    | Seal, Mechanical                   |
| 4     | 3406-143    | 1   |       | Seal, Oil                          |
| 5     | 3423-816    | 1   |       | O-Ring                             |
| 6     | 3423-772    | 1   |       | Washer                             |
| 7     | 3423-817    | 1   |       | Pin                                |
| 8     | 3423-185    | 1   |       | Bolt                               |
| 9     | 3402-436    | 1   | /P    | Washer                             |
| 10    | 3423-818    | 1   |       | O-Ring                             |
| 11    | 3007-511    | 1   | /P    | Screw                              |
| 12    | 3403-129    | 1   |       | Gear, Driven - Water Pump          |
| 13    | 3004-521    | 1   | /P    | O-Ring                             |
| 14    | 3423-091    | 1   | S     | Bolt                               |
| 15    | 3007-370    | 1   | /P    | Bolt                               |
| 16    | 3423-443    | 1   |       | Washer                             |
| 17    | 3423-184    | 1   | S     | Circlip                            |
| 18    | 3007-075    | 1   |       | Fitting, Coolant Bypass            |
| 19    | 3423-855    | 2   |       | Clamp                              |
| 20    | 3410-022    | 1   |       | Hose, Coolant Bypass               |


2008 ATV 700 EFI AUTOMATIC TRANSMISSION 4X4 FIS M4 CAMO (A20081BFA0000) of 93  
WHEEL AND TIRE ASSEMBLY



2008 ATV 700 EFI AUTOMATIC TRANSMISSION 4X4 FIS M4 CAMO (A20081BFA0510) of 93  
 WHEEL AND TIRE ASSEMBLY

| Ref # | Part Number | Qty | S/P/F | Description                        |
|-------|-------------|-----|-------|------------------------------------|
| 1     | 0423-557    | 12  |       | Screw, Shoulder                    |
| 2     | 1402-225    | 3   | S     | Disc, Brake                        |
| 3     | 0502-599    | 2   | S     | Hub, Wheel - Front (inc. 4)        |
| 4     | 0402-974    | 16  | /P    | Stud, Wheel Hub                    |
| 5     | 0502-601    | 1   | S     | Hub, Wheel - Rear - Left (inc. 4)  |
| 5     | 0502-599    | 1   | S     | Hub, Wheel - Rear - Right (inc. 4) |
| 6     | 0423-607    | 4   |       | Nut, Castle                        |
| 7     | 0423-407    | 4   |       | Pin, Cotter                        |
| 8     | 1402-332    | 2   |       | Wheel - Front                      |
| 8     | 1402-333    | 2   |       | Wheel - Rear                       |
| 9     | 0423-408    | 16  | /P    | Nut, Lug                           |
| 10    | 1402-548    | AR  |       | Tire - Front Goodyear              |
| 10    | 1402-549    | AR  |       | Tire - Rear Goodyear               |
| 11    | 0402-064    | 4   |       | Stem, Valve (inc. 12)              |
| 12    | 0402-140    | 4   |       | Cap, Valve Stem                    |

2008 ATV 700 EFI AUTOMATIC TRANSMISSION 4X4 FIS M4 CAMO (A20081BFA00000) of 93  
WIRING HARNESS ASSEMBLY



2008 ATV 700 EFI AUTOMATIC TRANSMISSION 4X4 FIS M4 CAMO (A20081BFA4GUSC) of 93  
WIRING HARNESS ASSEMBLY

| Ref # | Part Number | Qty | S/P/F | Description                       |
|-------|-------------|-----|-------|-----------------------------------|
|       | 0644-347    | 1   | F     | Wrench, Spark Plug                |
| 1     | 0486-245    | 1   |       | Harness, Main (inc. 2-8)          |
| 2     | 0486-164    | 1   |       | Tether, Accessory Connector       |
| 3     | 0530-008    | 1   |       | Cover, Fuse Block                 |
| 4     | 0430-037    | 1   |       | Holder, Fuse                      |
| 5     | 0430-034    | 4   |       | Diode                             |
| 6     | 0430-045    | 3   | /P    | Relay (4-Pin) - 20 Amp            |
| 7     | 0430-032    | 5   |       | Fuse - 10 Amp                     |
| 7     | 0430-031    | 3   |       | Fuse - 15 Amp                     |
| 7     | 0430-030    | 2   |       | Fuse - 30 Amp                     |
| 8     | 1411-673    | 1   |       | Decal, Fuse Block                 |
| 9     | 0430-052    | 2   |       | Relay (5-Pin) - 30 Amp            |
| 10    | 0123-788    | AR  | /P    | Cable Tie - 7.5 in.               |
| 11    | 0824-037    | 1   | /P    | Regulator, Voltage                |
| 12    | 8476-625    | 4   |       | Screw, Machine                    |
| 13    | 0623-038    | 6   |       | Nut w/Washer                      |
| 14    | 0445-058    | 1   | /P    | Solenoid                          |
| 15    | 0445-062    | 1   |       | Cable, Battery/Solenoid           |
| 16    | 0445-064    | 1   |       | Cable, Solenoid/Starter (inc. 16) |
| 17    | 0645-019    | 1   |       | Boot, Terminal                    |
| 18    | 0645-327    | 1   |       | Boot, Terminal                    |
| 19    | 0123-903    | AR  |       | Cable Tie - 11.5 in.              |
| 20    | 2406-406    | 1   |       | Plate, Shield                     |
| 21    | 2406-105    | 1   |       | Tray, Electrical                  |
| 22    | 0623-797    | 3   |       | Screw, Self-Tapping               |
| 23    | 0623-362    | 6   |       | Rivet, Reinstallable              |
| 24    | 8050-217    | 2   | /P    | Washer                            |
| 25    | 0409-089    | 1   |       | Switch, Brake - Assembly          |
| 26    | 3430-063    | 1   |       | Electronic Control Unit           |
| 27    | 0445-065    | 1   |       | Cable, Battery/Ground             |
| 28    | 3430-064    | 1   | S     | Coil, Ignition - Assembly         |
| 29    | 8476-620    | 2   |       | Screw, Machine                    |
| 30    | 3430-009    | 1   | /P    | Seal, High Tension Wire           |
| 31    | 3409-044    | 1   | S     | Cap, Spark Plug                   |
| 32    | 3409-031    | 1   |       | Cover, Spark Plug Cap             |
| 33    | 3409-030    | 1   |       | Seal, Spark Plug Cap              |
| 34    | 0423-493    | 2   |       | Nut, Hex                          |
| 35    | 0409-064    | 1   |       | Switch, Tilt Sensor               |
| 36    | 8468-425    | 2   |       | Screw, Machine                    |
| 37    | 0123-802    | 2   |       | Washer                            |