Illustrated Parts List Model Series 12X800 to 12X899

TYPE NUMBERS 0015, 0113, 0115, 0116, 0117.


TO FIND THE CORRECT NUMBER OF THE PART YOU NEED: FOLLOW THE INSTRUCTIONS BELOW

- A. Refer to Engine Model, Type and Code Number that is stamped on the blower housing of engine. Engine type numbers such as 0123 01 are listed only as 0123 in most instances. The two digits (01 or 02, etc.) to the right of the space may be required for more accurate parts identification in some instances. Select the Illustrated Parts List covering the correct Model Series and Type Number.
- B. Refer to the Illustrations and compare the original part with Illustration. The number next to the illustration is the Reference Number. Assemblies include all parts shown in frames. All parts shown in assembly frames having individual reference numbers can be purchased separately.
- C. After the Reference Number has been identified, refer to the Numerical text, where Reference and Primary Part Number are listed. THE PRIMARY PART IS USED ON ALL TYPE NUMBERS EXCEPT THOSE TYPE NUMBERS UNDER "NOTE."
- D. If a "Note" appears below the Primary Part Number, it means that this part differs from the Primary Part for certain types. If your Type number is listed under "Note," order the part referred to at the "Note."
- E. If your Engine Type Number does not appear after any part number listed under "Note," use the Primary Part Number.
- F. For Engine Type Numbers not covered by this book, check other Parts Lists having the same engine model or contact your source of supply.

PRINTED IN U.S.A.




COPYRIGHT by BRIGGS & STRATTON CORPORATION
All rights reserved. No part of this material may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permission in writing from Briggs & Stratton Corporation.



		10131111		<u>.تا لــٰ</u>	O OWINER O MAIN	OAL	INSTRU	CTION MANUAL.
REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1 2		Cylinder Assembly Kit–Bushing/Seal	287	94511	Screw (Dipstick Tube)	842	*280393	Seal–O-Ring (Dipstick/Tube)
3	★299819		306 307	690450 690345		847	495263	Assembly
5		(Magneto Side) Head-Cylinder	337		(Cylinder Shield) Sparkplug	869	691155	Seat-Valve (Intake)
8	695250	Gasket–Cylinder Head Breather Assembly	383 523	495264	Wrench–Sparkplug Dipstick	870	690380	(Exhaust)
10	94650	Gasket–Breather Screw (Breather Assembly)	524 525 584	495265	Seal–Dipstick Tube Tube–Dipstick Cover–Breather	871	262001	Bushing–Valve Guide (Exhaust Valve) Note ———
11 13	231933 94547	Tube-Breather	585	★272238	Passage Gasket–Breather Passage			63709 Bushing–Valve Guide (Intake Valve)
50 51 54		Manifold-Intake Gasket-Intake	635 684	66538 690345	Boot-Sparkplug	1019 1058	694881 274265	` '

[★] Included in Engine Gasket Set–Ref. 358.
• Included in Carburetor Overhaul Kit–Ref. 121.


 [◆] Included in Carburetor Gasket Set–Ref. 977.
 Ø Included in Valve Overhaul Gasket Set–Ref. 1095



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
25	499429	Piston Assembly (Standard) Note	26	499425	Ring Set (Standard) — Note ———	27 28	499423	Lock–Piston Pin Pin–Piston (Standard)
		499430 Piston Assembly (.010" O.S.)			499426 Ring Set (.010" O.S.) 499427 Ring Set	29 32		Rod-Connecting (Standard) Screw
		499431 Piston			(.020" O.S.)			(Connecting Rod)
		Assembly (.020" O.S.) 499432 Piston Assembly (.030" O.S.)			499428 Ring Set (.030" O.S.)	32A	695759	Screw (Connecting Rod) (Used After Code Date 00042200).
		ing Cooket Cat Def 250				la al ira O a mla s		

<sup>Included in Engine Gasket Set–Ref. 358.
Included in Carburetor Overhaul Kit–Ref. 121.</sup>


 [◆] Included in Carburetor Gasket Set–Ref. 977.
 Ø Included in Valve Overhaul Gasket Set–Ref. 1095



REF.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
16		Crankshaft Note 691450 Crankshaft Used on Type No(s). 0113. 691452 Crankshaft Used on Type No(s). 0115. 691454 Crankshaft Used on Type No(s). 0116, 0117.	24 33 34 35	222698 262651 262652	Key-Flywheel Valve-Exhaust Valve-Intake Spring-Valve (Intake)	36 40 45 146 741	691270 93312 690548 94388	Spring-Valve (Exhaust) Retainer-Valve Tappet-Valve Key-Timing Gear-Timing
L. In alice	de die Fee	ing Gasket Set_Ref 358				L		ket Set Def 077

◆ Included in Carburetor Gasket Set–Ref. 977.
 Ø Included in Valve Overhaul Gasket Set–Ref. 1095


[★] Included in Engine Gasket Set–Ref. 358.
• Included in Carburetor Overhaul Kit–Ref. 121.



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
4 4A		Sump-Engine Sump-Engine (Auxiliary Drive)	22	691092	Screw (Crankcase Cover) ——— Note	83	231671	Shaft–Auxiliary Drive Used on Type No(s). 0116.
12 15		Gasket–Crankcase Plug–Oil Drain (Square Socket)			691092 Screw (Crankcase Cover) (One Used in Hole	101 374	691074	Pin–Shaft Washer (Camshaft)
15A		Plug-Oil Drain (Hex Socket)	43 46	493737 691449	Nearest Breather) Slinger–Governor/Oil Camshaft	715 721		Screw (Stop Shaft) Shaft–Stop
20 20A		Seal-Oil (PTO Side) Seal-Oil	46A	691459	Camshaft (Counterclockwise)	743		Gear–Drive (Counterclockwise)
200	331404	(Auxiliary PTO)			Used on Type No(s). 0116.			Used on Type No(s). 0116.

◆ Included in Carburetor Gasket Set–Ref. 977.
 Ø Included in Valve Overhaul Gasket Set–Ref. 1095


<sup>Included in Engine Gasket Set–Ref. 358.
Included in Carburetor Overhaul Kit–Ref. 121.</sup>



REF. PAF NO. NO	T . DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
95 940 97 4932 104 •6912	DESCRIPTION Serve (Throttle Valve) Shaft–Throttle Pin–Float Hinge Jet–Main (Standard) Note 497315 Jet–Main (High Altitude)	NO. 125 127 130 133 134 137 163*	NO. 694882 •694468 691203 398187 •398188 •693981 ••4272653	DESCRIPTION Carburetor Plug-Welch Valve-Throttle Float-Carburetor Kit-Needle/Seat Gasket-Float Bowl Gasket-Air Cleaner Washer-Sealing	NO. 365 617 ●	NO. 94840 ◆270344 ◆691321	DESCRIPTION Screw (Carburetor) Seal–O Ring (Intake Manifold) Seal–Choke/Throttle Shaft Bowl–Float

<sup>Included in Engine Gasket Set–Ref. 358.
Included in Carburetor Overhaul Kit–Ref. 121.</sup>


 [◆] Included in Carburetor Gasket Set–Ref. 977.
 Ø Included in Valve Overhaul Gasket Set–Ref. 1095



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
188	94644	(Control Bracket)	268	691072	Casing–Control Wire (48" Long, Cut To	271 621	396847	Lever–Control Switch–Stop
202	262579	Link–Mechanical Governor			Required Length) Note	668	★493823	Spacer (Includes 2)
209	691292	Spring–Governor Note ———			65616 Casing–Control Wire	745	94512	Screw (Brake)
		263042 Spring– Governor Used on Type No(s).			(72" Long, Cut To Required Length)	843		Sleeve-Lever (Speed Control)
		0113.	269	26099	Wire–Control (54" Long, Cut To	922 923	262640 493442	Spring-Brake
222	497203	Bracket–Control (Primer Remote/Manual Friction)			Required Length) Note 26633 Wire–Control	923	493442	Diake
236	262461	Link-Lockout			(78" Long, Cut To			
265		Clamp-Casing	070	00.400	Required Length)			
267	94882	(Casing Clamp)	270	63426	(Control Wire Casing)			

<sup>Included in Engine Gasket Set–Ref. 358.
Included in Carburetor Overhaul Kit–Ref. 121.</sup>

 [◆] Included in Carburetor Gasket Set–Ref. 977.
 Ø Included in Valve Overhaul Gasket Set–Ref. 1095




REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
227	690783	Lever–Governor Control	505	231082	Nut (Governor Control	615	690340	Retainer–Governor Shaft
333		Armature–Magneto			Lever)	616		Crank-Governor
334	94731	Screw (Magneto Armature)	562	92613	Bolt (Governor Control	851	493880	Terminal-Sparkplug
356	692390	Wire-Stop			Lever)			
404	690272	Washer (Governor Crank)	578	398153	Wire Assembly			


[★] Included in Engine Gasket Set–Ref. 358.


Ø Included in Valve Overhaul Gasket Set–Ref. 1095

Included in Carburetor Overhaul Kit–Ref. 121.

[◆] Included in Carburetor Gasket Set-Ref. 977.







1036 LABEL-EMISSION


	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
187 691		E-Fuel Long, Cut To Juired Length)	601 670 957	280512	Clamp–Hose Spacer–Fuel Tank Cap–Fuel Tank	1036	695111	Label–Emission (Used After Code Date 99093000).
190 94	94511 Scre		972		Tank-Fuel			Mote ————————————————————————————————————
						1059	398540	Kit-Screw/Washer


[★] Included in Engine Gasket Set-Ref. 358.


◆ Included in Carburetor Gasket Set-Ref. 977.


Ø Included in Valve Overhaul Gasket Set–Ref. 1095


[•] Included in Carburetor Overhaul Kit-Ref. 121.












REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
81 159		Lock-Muffler Screw Bracket-Air Cleaner Primer	529	281299	Grommet (Air Cleaner Primer Base)	966 967	496116 493537	Base–Air Cleaner Primer Filter–Pre Cleaner
163 ★ € 300	◆272653 694048	Gasket-Air Cleaner	613	691114	,	968 970		Cover-Air Cleaner
		(Super Lo Tone Catalyst)	676	396548	Deflector–Muffler (Single Louver)			(Air Cleaner Primer Bracket)
425	94872	(Air Cleaner Cover)	677	94896	Screw (Muffler Deflector)	976	496115	Primer–Carburetor
443	94873	Screw (Air Cleaner Primer Base)	832	497683	Guard–Muffler (Used with Super Lo Tone Catalyst Muffler)			
445	491588	Filter-Air Cleaner Cartridge	836	94874	Screw (Muffler Guard)			

<sup>Included in Engine Gasket Set–Ref. 358.
Included in Carburetor Overhaul Kit–Ref. 121.</sup>


 [◆] Included in Carburetor Gasket Set–Ref. 977.
 Ø Included in Valve Overhaul Gasket Set–Ref. 1095



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
23	492177	Flywheel (Rewind Start Only)	304	694092	Housing–Blower Note ——	332	94877	Nut (Flywheel)
37		Guard-Flywheel			694879 Housing-	363		Puller-Flywheel
78	691108	(Flywheel Guard)	305	691108	Blower Used on Type No(s). 0113.	455 921		Cup-Flywheel Cover-Blower Housing (Static Guard, Satin
			305	691108	Screw (Blower Housing)	969	691138	Black) Screw (Blower Housing Cover)

<sup>Included in Engine Gasket Set–Ref. 358.
Included in Carburetor Overhaul Kit–Ref. 121.</sup>


 [◆] Included in Carburetor Gasket Set–Ref. 977.
 Ø Included in Valve Overhaul Gasket Set–Ref. 1095





REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
55	691421	Housing–Rewind	456		Plate-Pawl Friction	689		Spring–Friction
58	281464	Starter Rope–Starter	459 592	281505 94908		1210	498144	Pulley/Spring Assembly
		(Cut To Required Length)	597	94943		1211	498144	(Pulley) Pulley/Spring
60 65		Grip–Starter Rope Screw	608	497680	(Pawl Friction Plate) Starter–Rewind			Assembly (Spring)
	J-1504	(Rewind Starter)	000	401000	Clartor Rowling			(Opinig)


<sup>Included in Engine Gasket Set–Ref. 358.
Included in Carburetor Overhaul Kit–Ref. 121.</sup>

 [◆] Included in Carburetor Gasket Set–Ref. 977.
 Ø Included in Valve Overhaul Gasket Set–Ref. 1095









REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
3	★299819	Seal-Oil	127	•694468	Plug-Welch	668	* 493823	Spacer
		(Magneto Side)	134	●398188	Kit-Needle/Seat			(Includes 2)
7	★ Ø272916	Gasket-Cylinder Head	137	♦693981	Gasket-Float Bowl	633	♦691321	Seal-Choke/Throttle
9	★ Ø 27248 1	Gasket-Breather	163★● ◆272653 Gasket–Air Clea		Gasket-Air Cleaner			Shaft
12	*272198	Gasket-Crankcase	276	◆271716	Washer-Sealing	842	*280393	Seal-O-Ring
20	★399781	Seal-Oil	358	497316	Gasket Set-Engine			(Dipstick/Tube)
		(PTO Side)	524		Seal-Dipstick Tube	977	498261	Gasket Set-Carburetor
51	*272199	Gasket–Intake	585		Gasket–Breather	1095	498528	Gasket Set-Valve
104	●691242	Pin-Float Hinge			Passage			
121		Kit-Carburetor	617	◆270344	Seal-O Ring			
		Overhaul			(Intake Manifold)			

<sup>Included in Engine Gasket Set–Ref. 358.
Included in Carburetor Overhaul Kit–Ref. 121.</sup>

[◆] Included in Carburetor Gasket Set-Ref. 977. Ø Included in Valve Overhaul Gasket Set-Ref. 1095