FORM MS-2832-10/97 REPLACES FORM MS-2832-5/97 FILE IN SECT. 2 OF SERVICE MANUAL

194400 to 194499

Illustrated Parts List Model Series 194400 to 194499

TYPE NUMBERS 1110, 1112, 1114, 1120, 1121, 1123 through 1131, 1150, 1151.


TO FIND THE CORRECT NUMBER OF THE PART YOU NEED: FOLLOW THE INSTRUCTIONS BELOW

- A. Refer to Engine Model, Type and Code Number that is stamped on the blower housing of engine. Engine type numbers such as 0123 01 are listed only as 0123 in most instances. The two digits (01 or 02, etc.) to the right of the space may be required for more accurate parts identification in some instances. Select the Illustrated Parts List covering the correct Model Series and Type Number.
- B. Refer to the Illustrations and compare the original part with Illustration. The number next to the illustration is the Reference Number. Assemblies include all parts shown in frames. All parts shown in assembly frames having individual reference numbers can be purchased separately.
- C. After the Reference Number has been identified, refer to the Numerical text, where Reference and Primary Part Number are listed. THE PRIMARY PART IS USED ON ALL TYPE NUMBERS EXCEPT THOSE TYPE NUMBERS UNDER "NOTE."
- D. If a "Note" appears below the Primary Part Number, it means that this part differs from the Primary Part for certain types. If your Type number is listed under "Note," order the part referred to at the "Note."
- E. If your Engine Type Number does not appear after any part number listed under "Note," use the Primary Part Number.
- F. For Engine Type Numbers not covered by this book, check other Parts Lists having the same engine model or contact your source of supply.



PRINTED IN U.S.A.

COPYRIGHT by BRIGGS & STRATTON CORPORATION All rights reserved. No part of this material may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permission in writing from Briggs & Stratton Corporation.



★ REQUIRES SPECIAL TOOLS TO INSTALL. SEE REPAIR INSTRUCTION MANUAL.

1019 LABEL KIT

1058 OWNER'S MANUAL


REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1 2 3 5 6	NO. 495656 495657 ★391086 214015 22963 ★Ø272163 495724 ★Ø27803 94719 280267 94565 94733	Cylinder Assembly (Includes OIL GARD® Cover) Bushing		94239 496797 94930 224896 492167 220197 293739 94726 89838			NO. 66538 211661 262924 261961	Boot–Spark Plug

Included in Gasket Set–Part No. 299577. Included in Carburetor Kit–Part No. 398235.

Ø Included in Valve Overhaul Gasket Set-Part No. 498533.

2832-2

Assemblies include all parts shown in frames.




REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
16	495832	Crankshaft ——— Note ——— 495790 Crankshaft Used on Type No(s). 1112, 1114, 1120,	27		Lock–Piston Pin Note 68546 Lock–Piston Pin (Used Before Code Date 96102800).	34 35	65906	Valve-Intake Spring-Valve (Intake and Exhaust) (Used After Code Date 95041600).
24	222698	1121, 1129, 1130, 1150, 1151. 496974 Crankshaft Used on Type No(s). 1131. Key–Flywheel	28	499302	Pin-Piston (Standard) Note 499303 Pin-Piston (.005" O.S.)	36 40	26828 221596	Spring-Valve (Exhaust Only) (Used Before Code Date 95041700). Retainer-Valve
25		Piston Assembly (Standard) Note 499274 Piston Assy. (.010" O.S.			295840 Pin–Piston (Standard) 295841 Pin–Piston (.005" O.S.) (Used Before Code	41	292260	(Intake) Retainer–Valve (Exhaust) (Used Before Code Date 95041700).
		499275 Piston Assy. (.020" O.S.) 499276 Piston Assy. (.030" O.S.)	29	390401	Date 96102800). Rod–Connecting (Standard) ——— Note ——— 390773 Rod–Conn.	42 45		Keeper–Valve (Used Before Code Date 95041700). Tappet–Valve
26	393881	Ring Set (Standard) Note 299743 Ring Set (Chrome Standard) 393882 Ring Set (.010" O.S.) 393883 Ring Set	30 31 32 33	92659	(.020" Undersize) Dipper-Conn. Rod Lock-Rod Screw Screw-Conn. Rod Valve-Exhaust (Used After Code Date 95041600).	146 741	94388	Key-Timing Gear-Timing Note 262479 Gear-Timing (Used Before Code Date 95022000)
		(.020" O.S.) 393884 Ring Set (.030" O.S.)	33A	390420	Valve–Exhaust (Used Before Code Date 95041700).			ot Sat. Dort No. 409522

[★] Included in Gasket Set-Part No. 299577.

2832-3

Included in Carburetor Kit–Part No. 398235.

Ø Included in Valve Overhaul Gasket Set−Part No. 498533.




REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
12	*271701	Gasket–Crankcase (.015" Thick) Note *27876 Gasket– Crankcase (.005" Thick) *27877 Gasket– Crankcase (.009" Thick)	15A 15B 18 19 20	94802 392676	Plug-Oil Plug-Oil Drain Cover-Crankcase Bushing Seal-Oil	21 22 46 219 220	93585 211689 494845	Cap-Oil Fill Screw-Hex. Gear-Cam Gear-Governor Washer-Thrust

Included in Gasket Set–Part No. 299577. Included in Carburetor Kit–Part No. 398235.

Ø Included in Valve Overhaul Gasket Set-Part No. 498533.

2832-4

Assemblies include all parts shown in frames.



REF. PART REF. PART NO. NO. DESCRIPTION NO. NO. DESCRIPTION	REF. PART NO. NO. DESCRIPTION
90 390323 Carburetor 91 399443 Body Assembly—Upper 93 23108 Bushing—Throttle Shaft 94 •292681 Valve—Idle Adjustment 95 93499 Screw—Slotted 96 223370 Valve—Throttle 97 298826 Shaft—Throttle 98 91920 Screw—Slotted 99 26157 Spring—Friction 100 212904 Stop—Throttle	110 222712 Washer 111 26155 Spring-Lever 112 23123 Screw-Shoulder 113 •398202 Nozzle-Carburetor 114 •68667 Gasket-Nozzle 118 •99525 Valve-High Speed 119 94152 Screw-Torx® Hex. 843 280149 Sleeve-Lever


[★] Included in Gasket Set-Part No. 299577.

Ø Included in Valve Overhaul Gasket Set-Part No. 498533.

2832-5

Assemblies include all parts shown in frames. 5

Included in Carburetor Kit–Part No. 398235.



		NO.	NO.	DESCRIPTION	NO.	NO.	DESCRIPTION
★•270684 ★Ø27828 93956 94616 93208 94627 231266 26855 261959 260695	Manifold-Intake Gasket-Intake Gasket-Intake Screw-Shoulder Screw-Torx® Hex. Screw-Phillips Screw-Hex. Nut Spring-Control Rod Rod-Governor Control Spring-Governor Link-Throttle	222 227 230 232 307A 333 334 353 354A 356 356A 474	399151 391965 94927 260478 93343 398811 94731 92791 90576 491391 398838	DESCRIPTION Bracket–Control Lever–Governor Washer Spring–Link Screw–Hex. Armature–Magneto Screw–Hex. Washer–Lock Nut–Hex. Wire–Stop Wire–Stop Alternator	NO. 482 507 520 562 592 614 615 616 616A 851 877 878	93621 398525 93722 92613 231082 93306 93307 231057 495241 493880 393814	Screw-Hex. Insulator Terminal Bolt-Carriage Nut-Hex. Pin-Cotter Retainer Crank-Governor Crank-Governor Terminal-Cable Wire-Alternator Harness-Alternator


[★] Included in Gasket Set-Part No. 299577.


Ø Included in Valve Overhaul Gasket Set-Part No. 498533.

2832-6

Assemblies include all parts shown in frames.

Included in Carburetor Kit–Part No. 398235.





REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
REF. NO. 188 346 353 354A 729	94627 93705 92791 90576	DESCRIPTION Screw—Hex. Screw—Hex. Washer—Lock Nut—Hex. Clip—Wire	NO. 948	NO. 398661 *271736 494807	Harness–Wiring		94657 94139 398660	DESCRIPTION Screw-Hex. Screw-Hex. Light-Indicator Bracket-Light


[★] Included in Gasket Set-Part No. 299577.

Included in Carburetor Kit–Part No. 398235.

Ø Included in Valve Overhaul Gasket Set-Part No. 498533.

2832-7

Assemblies include all parts shown in frames. 7




REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
NO. 116 180 181 182 182A 183 184 185	280203 290816 392305 222758 495664 291367	Seal-O-Ring Tank-Fuel (4 Quart) Cap-Fuel Tank Bracket-Fuel Tank Bracket-Fuel Tank (Upper) Strap-Fuel Tank Screw-Slotted	186 186A 187 188 198 199 210	67218 230318 296004 94627 293934 297563	DESCRIPTION Connector-Hose Connector-Hose Line-Fuel (Cut to Required Length) Screw-Hex. Screw-Shut Off Valve-Shut Off Strainer-Fuel	961 972	298090 93053 223271 493988 399517 492990 94095	DESCRIPTION Filter-Fuel Clamp-Hose Handle-Shut Off Valve Cap-Fuel Tank Valve-Shut-Off Bracket-Fuel Tank (Lower) Screw-Hex. Tank-Fuel

Ø Included in Valve Overhaul Gasket Set-Part No. 498533.

2832-8

Assemblies include all parts shown in frames. 8

Included in Gasket Set–Part No. 299577. Included in Carburetor Kit–Part No. 398235.



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
81 161		Lock–Muffler Screw Pipe–Air Cleaner Use(s): 271265 Seal–O-Ring	302 346 445 467	93705	Locknut-Muffler Screw-Hex. Filter-Air	642 642A 643 676	496093 222272	Cover–Air Cleaner Cover–Air Cleaner Retainer–Air Filter Deflector–Muffler
165 167 300 300A	65978 393010	Nut-Wing Seal-O-Ring Muffler-Exhaust Muffler-Exhaust	535 536 536A 613	271794 391063 399810	Filter–Air Cleaner–Air Cleaner–Air Screw–Shoulder	850 862	271793 392105 272309	Seal–Base Strap–Cleaner Mtg. Gasket–Exhaust Arrester–Spark
	30.070	maille Exhaust	0.0	0.10.12	Sich Choulds		3000-11	, moder opan


[★] Included in Gasket Set-Part No. 299577.

Ø Included in Valve Overhaul Gasket Set-Part No. 498533.

2832-9

Assemblies include all parts shown in frames.

Included in Carburetor Kit–Part No. 398235.




REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
23 23A 37 38 66 67 68 70	222475 94811 399671 394897 63770	Flywheel ———————————————————————————————————	71 73 74 75 215 304	221796 93758 224061 221760	Cover–Ratchet Screen–Rotating Screw–Hex. Washer Guide–Air Housing–Blower — Note — 491592 Housing– Blower Used on Type No(s). 1120, 1124, 1127, 1128, 1129, 1150.	305 363 423 575 726 727	19165 94073 396691 392134	Screw-Hex. Flywheel Puller Screw-Shoulder Switch-Rotary Gear-Ring Cover-Starter drive

Ø Included in Valve Overhaul Gasket Set-Part No. 498533.

2832-10

Included in Gasket Set–Part No. 299577. Included in Carburetor Kit–Part No. 398235.




REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
55 56	393576 295871	Housing–Rewind Starter Pulley–Starter — Note — Includes 63" Rope; if	57 58		Spring–Rewind Starter Rope–Starter (63" Long) Note 66894 Rope–Starter	64 65 373 608 655	94128 92987 390391	Adapter–Spring Screw–Hex. Nut–Hex. Starter–Rewind Anchor–Rewind
		Longer Rope is Required, Order Part No. 66894 and Cut to Required Length.	59 60 63	490652	(99" Long) Insert–Grip Grip–Starter Rope Spring–Ratchet	930 1016		Spring Guard–Rewind Spacer
		olicat Cot. Dort No. 200577			~			-+ C-+ D-+ No. 400522

Included in Gasket Set–Part No. 299577. Included in Carburetor Kit–Part No. 398235.

Ø Included in Valve Overhaul Gasket Set-Part No. 498533.

2832-11

Assemblies include all parts shown in frames. 11




REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
309	693054	Motor-Starter	544	497603	,	797	92278	
		(3 5/8" Housing Lgth.)			(3 5/8" Housing Lgth.)			(Starter Terminal)
310	94003	Bolt	675	225137	Washer	801	394856	Cap-Drive
		(Starter Motor)			(Starter Motor)	802	497607	Cap-End
		(3 5/8" Housing Lgth.)	697	94773	Screw	803	497604	Housing-Starter
311	497608	Brush Set			(Starter Motor			(3 5/8" Housing Lgth.)
503	806000	Strap-Starter			Mounting)	1051	263080	Ring-Retainer
510		Drive-Starter	729	225170	Clip-Wire	1090		Retainer-Brush
513	398003	Clutch-Drive	783		Gear-Starter			

Included in Gasket Set–Part No. 299577. Included in Carburetor Kit–Part No. 398235.

Ø Included in Valve Overhaul Gasket Set-Part No. 498533.

2832-12

Assemblies include all parts shown in frames. 12



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
309A		For Replacement Starter Motor, See Ref 309, Previous Page.	503 510A 513 544A	806000 495878 398003 390837	Drive-Starter	783 801 802A	394856	Gear–Starter Cap–Drive Cap–End (For 3 5/8" Housing
310A	94003	Bolt. (Starter Motor) (For 3 5/8" Housing Length)	697	94773	(For 3 5/8" Housing Length) Screw (Starter Motor	803A	398159	Length) Housing–Starter (For 3 5/8" Housing Length)
311A	395538	Brush Set (For 3 5/8" Housing Lengths)			Mounting)	876 896	495877 94288	Kit-Gear Pin-Roll


[★] Included in Gasket Set-Part No. 299577.


Ø Included in Valve Overhaul Gasket Set-Part No. 498533.


2832-13

Assemblies include all parts shown in frames. 13

Included in Carburetor Kit–Part No. 398235.







REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
3 7 9 12	★ Ø 27803	Seal-Oil Gasket-Cylinder Head Gasket-Breather Gasket-Crankcase (.015" Thick) Note *27876 Gasket- Crankcase (.005" Thick) *27877 Gasket- Crankcase (.009" Thick)	51 51A	*Ø27828 •292681 •27918 •230896 •394681 •398202 •68667 •99525	Seal–Oil Gasket–Intake Gasket–Intake Valve–Idle Adjustment Gasket–Carburetor Body Pin–Float Hinge Valve–Needle Nozzle–Carburetor Gasket–Nozzle Valve–High Speed Carburetor Kit	358 883 978 1095	±⊘272309 ±271736	Gasket Set Gasket-Exhaust Gasket Gasket Set-Valve Overhaul

Included in Gasket Set–Part No. 299577. Included in Carburetor Kit–Part No. 398235.

Ø Included in Valve Overhaul Gasket Set-Part No. 498533.

2832-14

Assemblies include all parts shown in frames. 14