



121A00

Illustrated Parts List

Model Series

121A00

TYPE NUMBERS
0020 through 0323.

TABLE OF CONTENTS

Air Cleaner	5
Blower Housing	6
Camshaft	2
Carburetor	4
Controls	5
Crankcase Cover	2
Crankshaft	2
Cylinder	2
Cylinder Head	3
Exhaust System	5
Flywheel	6
Fuel Supply	5
Governor Spring	5
Ignition	5
Kits/Gaskets – Carburetor	4
Kits/Gaskets – Engine	2
Kits/Gaskets – Valve	3
Lubrication	2
Piston Group	2
Rewind Starter	6

BRIGGS & STRATTON



PRINTED IN U.S.A.


COPYRIGHT by BRIGGS & STRATTON CORPORATION
All rights reserved. No part of this material may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permission in writing from Briggs & Stratton Corporation.

121A00










1019 LABEL KIT

1058 OWNER'S MANUAL

1330 REPAIR MANUAL



287






Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

5711-2

Assemblies include all parts shown in frames.

11/09/2005




Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

5711-3

Assemblies include all parts shown in frames.

11/09/2005

121A00



121 CARBURETOR OVERHAUL KIT					
104	127 0	134	163	276	633
122	51	137	163A	633A	


977 CARBURETOR GASKET SET		
51	163	276
137	163A	633
		633A

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

5711-4

Assemblies include all parts shown in frames.

11/09/2005





Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

5711-5


Assemblies include all parts shown in frames.

11/09/2005

121A00



1036 EMISSION LABEL



Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

5711-6

Assemblies include all parts shown in frames.

11/09/2005

121A00

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	699505	Cylinder Assembly	20	★692550	Seal–Oil (PTO Side)	27	691866	Lock–Piston Pin
2	399269	Kit–Bushing/Seal (Magnetos Side)	21	281658S	Cap–Oil Fill	28	499423	Pin–Piston
3	★299819S	Seal–Oil (Magnetos Side)	22	699478	Screw (Crankcase Cover)	29	690124	Rod–Connecting
5	699486	Head–Cylinder	23	699488	Flywheel	30	692562	Dipper–Connecting Rod
7	★Ø698210	Gasket–Cylinder Head	24	222698S	Key–Flywheel	32	691664	Screw (Connecting Rod)
11A	693647	Tube–Breather (High Mount Air Cleaner)	25	792004	Piston Assembly (Standard) (Used After Code Date 05030800).	32A	695759	Screw (Connecting Rod)
11B	790632	Tube–Breather (Ultra Low Air Cleaner)			----- Note -----	33	499642	Valve–Exhaust
12	★699485	Gasket–Crankcase			499627 Piston	34	499641	Valve–Intake
13	699482	Screw (Cylinder Head)			Assembly (Standard) (Used Before Code Date 05030900).	35	691304	Spring–Valve (Intake)
15	691686	Plug–Oil Drain			791325 Piston	36	691304	Spring–Valve (Exhaust)
15A	691682	Plug–Oil Drain			Assembly (.020" Oversize) (Used After Code Date 05030800).	37	699661	Guard–Flywheel
16	699452	Crankshaft Used on Type No(s). 0028, 0277, 0323. ----- Note -----			692789 Piston	40	692194	Retainer–Valve
		699443 Crankshaft Used on Type No(s). 0101.			Assembly (.020" Oversize) (Used Before Code Date 05030900).	45	690977	Valve–Tappet
		699449 Crankshaft Used on Type No(s). 0022.			791325 Piston	46	696813	Camshaft
		699445 Crankshaft Used on Type No(s). 0020.	26	791969	Ring Set (Standard) (Used After Code Date 05030800).	51★◆	Ø692555	Gasket–Intake (2 Required)
17	692517	Bearing–Ball			----- Note -----	55	691422	Housing–Rewind Starter
18	699804	Cover–Crankcase Used on Type No(s). 0022, 0028, 0277, 0323. ----- Note -----			499631 Ring Set (Standard) (Used Before Code Date 05030900).	58	693389	Rope–Starter
		699696 Cover– Crankcase Used on Type No(s). 0020.			791324 Ring Set (.020" Oversize) (Used After Code Date 05030800).	59	490653	Insert–Grip
18A	699672	Cover–Crankcase Used on Type No(s). 0101.			692786 Ring Set (.020" Oversize) (Used Before Code Date 05030900).	60	490652	Grip–Starter Rope
						65	699228	Screw (Rewind Starter)
						78	699205	Screw (Flywheel Guard)
						95	691636	Screw (Throttle Valve)
						97	690024	Shaft–Throttle
						98	398185	Kit–Idle Speed
						104	◆691242	Pin–Float Hinge
						108	692567	Valve–Choke
						109A	693628	Shaft–Choke
						109C	790624	Shaft–Choke

★ Included in Engine Gasket Set–Ref. No.358.

● Included in Carburetor Overhaul Kit–Ref. No. 121.

◆ Included in Carburetor Gasket Set–Ref. No. 977.

Ø Included in Valve Gasket Set–Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

5711–7

Assemblies include all parts shown in frames.

11/09/2005

121A00

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
117	698344	Jet–Main (Standard) Used on Type No(s). 0028, 0277. ----- Note ----- 690048 Jet–Main (Standard) Used on Type No(s). 0020, 0022, 0101, 0323.	186	692317	Hose–Connector	270	691027	Nut (Control Wire Casing)
118	694176	Jet–Main (High Altitude) Used on Type No(s). 0028, 0277. ----- Note ----- 498976 Jet–Main (High Altitude) Used on Type No(s). 0020, 0022, 0101, 0323.	187	791766	Line–Fuel (Cut to Required Length) (Used After Code Date 05063000). ----- Note ----- 691050 Line–Fuel (Cut to Required Length) (Used Before Code Date 05070100).	271	691028	Lever–Control
121	696998	Kit–Carburetor Overhaul	187A	791867	Line–Fuel (Molded) (Used After Code Date 05063000). ----- Note ----- 692601 Line–Fuel (Molded) (Used Before Code Date 05070100).	271A	694256	Lever–Control
122	♦♦693749	Spacer–Carburetor	187B	791874	Line–Fuel (Molded)	276	271716	Washer–Sealing
125	698475	Carburetor Used on Type No(s). 0028, 0277. ----- Note ----- 698474 Carburetor Used on Type No(s). 0020, 0022, 0101, 0323.	188	699479	Screw (Control Bracket)	281	699639	Plate–Trim
127	♦691739	Plug–Welch	190	699220	Screw (Fuel Tank)	287	699629	Screw (Dipstick Tube)
130	691181	Valve–Throttle	192	694543	Adjustor–Rocker Arm	300	693593	Muffler
133	398187	Float–Carburetor	209	692571	Spring–Governor	304	699598	Housing–Blower
134	398188	Kit–Needle/Seat	209A	691278	Spring–Governor	305	699480	Screw (Blower Housing)
137	♦♦693981	Gasket–Float Bowl	219	693578	Gear–Governor	306	693610	Shield–Cylinder
146	690979	Key–Timing	220	691724	Washer (Governor Gear)	307	699483	Screw (Cylinder Shield)
155	698214	Plate–Cylinder Head	222	699589	Bracket–Control	332	699359	Nut (Flywheel)
161A	790631	Base–Air Cleaner	227	692573	Gear–Governor	333	695711	Armature–Magneto
163★♦♦696024	Gasket–Air Cleaner (Ultra Low Air Cleaner)	238	691300	Cap–Valve	334	699477	Screw (Magneto Armature)	
163A★♦♦696979	Gasket–Air Cleaner (High Mount Air Cleaner)	265	691024	Clamp–Casing	337	491055S	Plug–Spark (Resistor) ----- Note ----- 691043 Plug–Spark (EMS)	
		267	699492	Screw (Casing Clamp)	356	693651	Wire–Stop	
		268	691025	Casing–Control Wire (Cut to Required Length)	356A	692390	Wire–Stop	
		269	691026	Wire–Control (Cut to Required Length)	358	699638	Gasket Set–Engine	
					363	19069	Puller–Flywheel	
					365	692568	Screw (Carburetor)	
					383	19374S	Wrench–Spark Plug	
					415	693463	Plug	
					425A	699492	Screw (Air Cleaner Cover)	
					427	694255	Nut (Control Bracket)	
					445	491588S	Filter–Air Cleaner Cartridge	
					445A	697029	Filter–Air Cleaner Cartridge	
					455	692591	Cup–Flywheel	
					456	692299	Plate–Pawl Friction	

★ Included in Engine Gasket Set–Ref. No.358.

● Included in Carburetor Overhaul Kit–Ref. No. 121.

♦ Included in Carburetor Gasket Set–Ref. No. 977.

⊗ Included in Valve Gasket Set–Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

5711–8

Assemblies include all parts shown in frames.

11/09/2005

121A00

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
459	281505S	Pawl-Ratchet	689	691855	Spring-Friction	968A	693460	Cover-Air Cleaner
467	691668	Knob-Air Cleaner	692	690572	Spring-Detent	968B	791082	Cover-Air Cleaner
504	694254	Washer Set-Friction	717	693462	Bracket-Air Cleaner	971	690370	Screw
505	691251	Nut	718	690959	Pin-Locating			(Air Cleaner Base)
		(Governor Control Lever)	741	695087	Gear-Timing	971A	690349	Screw
			742	692564	Ring-Retaining			(Air Cleaner Base)
522	697689	Plug-Dipstick/Fill	746	692566	Gear-Idler	971B	699629	Screw
523	693618	Dipstick	773	694258	Retainer			(Air Cleaner Base)
524	281370S	Seal-Dipstick Tube	830	694544	Stud-Rocker Arm	972	694260	Tank-Fuel
552	692346	Bushing-Governor Crank	832	693583	Guard-Muffler	975	493640	Bowl-Float
562	691119	Bolt	836	699203	Screw	977	697001	Gasket Set-Carburetor
		(Governor Control Lever)			(Muffler Guard)	993	694088	Gasket-Cylinder Head Plate
597	691696	Screw	836A	699632	Screw	1005	692592	Fan-Flywheel
		(Pawl Friction Plate)			(Muffler Guard)	1019	694852	Kit-Label
615	692576	Retainer-Governor Shaft	842	691031	Seal-O Ring	1022	691890	Gasket-Rocker Cover
601	95162S	Clamp-Hose	847	693617	Dipstick/Tube Assembly	1023	499924	Cover-Rocker
608	693394	Starter-Rewind	851	493880S	Terminal-Spark Plug	1026	790287	Rod-Push
613	699209	Screw	868	692044	Seal-Valve	1029	691230	Arm-Rocker
616	692547	Crank-Governor	875	697030	Base-Air Cleaner	1034	691343	Guide-Push Rod
619	699230	Screw	883	★691893	Gasket-Exhaust	1036		Label-Emission
		(Cylinder Head)	914	699481	Screw			(Available From An Authorized Briggs & Stratton Service Dealer)
621	692310	Switch-Stop			(Rocker Cover)	1058	276355	Owner's Manual
632	693408	Spring/Link-Mechanical Governor			(Bottom)	1070	699201	Screw
633	●693867	Seal-Choke/Throttle Shaft	914A	692557	Screw			(Flywheel Fan)
633A	●691321	Seal-Choke/Throttle Shaft			(Rocker Cover)	1095	698215	Gasket Set-Valve
			914B	697551	Screw	1210	498144	Pulley/Spring Assembly
635	692076	Boot-Spark Plug			(Center)			(Pulley)
663	699206	Screw	951	790630	Lever-Choke	1211	498144	Pulley/Spring Assembly
		(Control Panel)	957	694261	Cap-Fuel Tank			(Spring)
668	694257	Spacer	958	698180	Valve-Fuel Shut Off	1330	272147	Repair Manual
676	393757	Deflector-Muffler	961	698304	Screw			
677	690661	Screw			(Air Cleaner Bracket)			
		(Muffler Deflector)	967	493537S	Filter-Pre Cleaner			
			967A	273356S	Filter-Pre Cleaner			

★ Included in Engine Gasket Set-Ref. No.358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

◆ Included in Carburetor Gasket Set-Ref. No. 977.

Ø Included in Valve Gasket Set-Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

5711-9

Assemblies include all parts shown in frames.

11/09/2005