



12B600

Illustrated Parts List

Model Series

12B600

TYPE NUMBERS
0100 through 0104.

TABLE OF CONTENTS

Air Cleaner	5
Blower Housing/Shrouds	6
Camshaft	2
Carburetor	4
Controls	5
Crankshaft	2
Cylinder	2
Cylinder Head	3
Engine Sump	2
Exhaust System	5
Flywheel	6
Fuel Supply	4
Governor Spring	5
Ignition	5
Lubrication	2
Piston Group	2
Rewind Starter	6


BRIGGS & STRATTON




PRINTED IN U.S.A.

COPYRIGHT by BRIGGS & STRATTON CORPORATION
All rights reserved. No part of this material may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permission in writing from Briggs & Stratton Corporation.

12B600








Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
 6726-2 Assemblies include all parts shown in frames. 10/12/2005




Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
 6726-3 Assemblies include all parts shown in frames. 10/12/2005


12B600



Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
 6726-4 Assemblies include all parts shown in frames. 10/12/2005



12B600



Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
 6726-6 Assemblies include all parts shown in frames. 10/12/2005

12B600

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	692670	Cylinder Assembly	25	791968	Piston Assembly (Standard) (Used After Code Date 04040400).	27	691866	Lock-Piston Pin
2	399269	Kit-Bushing/Seal (Magneto Side)			----- Note -----	28	499423	Pin-Piston
3	★299819	Seal-Oil (Magneto Side)			690021 Piston Assembly (Standard) (Used Before Code Date 04040500).	29	499424	Rod-Connecting
4	493279	Sump-Engine			694167 Piston Assembly (.010" Oversize)	32	691664	Screw (Connecting Rod)
5	695276	Head-Cylinder			791326 Piston Assembly (.020" Oversize) (Used After Code Date 04102100).	32A	695759	Screw (Connecting Rod)
7	★△695166	Gasket-Cylinder Head			694168 Piston Assembly (.020" Oversize) (Used Before Code Date 04102200).	33	499642	Valve-Exhaust
8	495786	Breather Assembly			694169 Piston Assembly (.030" Oversize)	34	499641	Valve-Intake
9	★272481	Gasket-Breather			499631 Ring Set (Standard) (Used Before Code Date 04040500).	35	691304	Spring-Valve (Intake)
10	691125	Screw (Breather Assembly)			692785 Ring Set (.010" Oversize)	36	691304	Spring-Valve (Exhaust)
11	499675	Tube-Breather			791324 Ring Set (.020" Oversize) (Used After Code Date 04102100).	37	694086	Guard-Flywheel
12	★692232	Gasket-Crankcase			692786 Ring Set (.020" Oversize) (Used Before Code Date 04102200).	40	692194	Retainer-Valve
13	691137	Screw (Cylinder Head)			692787 Ring Set (.030" Oversize)	43	691997	Slinger-Governor/Oil
15	691680	Plug-Oil Drain (Square Socket)				45	690977	Tappet-Valve
16	691457	Crankshaft				46	694039	Camshaft
20	★399781	Seal-Oil (PTO Side)	26	791969	Ring Set (Standard) (Used After Code Date 04040400).	51★◆△692668		Gasket-Intake
22	691092	Screw (Crankcase Cover/Sump)			----- Note -----	55	691421	Housing-Rewind Starter
23	692693	Flywheel Used on Type No(s). 0100.			499631 Ring Set (Standard) (Used Before Code Date 04040500).	58	697316	Rope-Starter (Cut To Required Length)
23A	696569	Flywheel Used on Type No(s). 0104.			692785 Ring Set (.010" Oversize)	60	281434	Grip-Starter Rope
24	222698	Key-Flywheel			791324 Ring Set (.020" Oversize) (Used After Code Date 04102100).	65	690837	Screw (Rewind Starter)
					692786 Ring Set (.020" Oversize) (Used Before Code Date 04102200).	78	691108	Screw (Flywheel Guard)
					692787 Ring Set (.030" Oversize)	95	691636	Screw (Throttle Valve)
						97	499682	Shaft-Throttle (Metal)
								----- Note -----
								790121 Shaft-Throttle (Plastic)
						104	◆691242	Pin-Float Hinge

★ Included in Engine Gasket Set-Ref. No.358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

◆ Included in Carburetor Gasket Set-Ref. No. 977.

△Included in Valve Gasket Set-Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.**6726-7**

Assemblies include all parts shown in frames.

10/12/2005

12B600

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
117	498981	Jet–Main (Standard) (Used After Code Date 03110600). ----- Note ----- 498978 Jet–Main (Standard) (Used Before Code Date 03110700).	190	690940	Screw (Fuel Tank)	337	692051	Plug–Spark
118	497466	Jet–Main (High Altitude) (Used After Code Date 03110600). ----- Note ----- 498975 Jet–Main (High Altitude) (Used Before Code Date 03110700).	192	694543	Adjuster–Rocker Arm	356	692390	Wire–Stop
121	692703	Kit–Carburetor Overhaul	202	691303	Link–Mechanical Governor	358	694090	Gasket Set–Engine
122	692799	Spacer–Carburetor	209	691290	Spring–Governor Used on Type No(s). 0100. ----- Note ----- 691291 Spring– Governor Used on Type No(s). 0104.	363	19069	Puller–Flywheel
125	790120	Carburetor	222A	693378	Bracket–Control	365	691136	Screw (Carburetor)
127	694468	Plug–Welch	227	691467	Lever–Governor Control	383	19374	Wrench–Spark Plug
130	691203	Valve–Throttle ----- Note ----- 696564 Valve–Throttle (Used With Plastic Throttle Shaft)	238	691300	Cap–Valve	404	690272	Washer (Governor Crank)
133	398187	Float–Carburetor	265	690798	Clamp–Casing	425	690670	Screw (Air Cleaner Cover)
134	398188	Kit–Needle/Seat	267	691044	Screw (Casing Clamp)	443	691637	Screw (Air Cleaner Primer Base)
137	693981	Gasket–Float Bowl	268	691025	Casing–Control Wire (Cut To Required Length)	443A	692523	Screw (Air Cleaner Primer Base)
146	690979	Key–Timing	269	691026	Wire–Control (Cut To Required Length)	445	491588	Filter–Air Cleaner Cartridge
163A	692667	Gasket–Air Cleaner	270	691027	Nut (Control Wire Casing)	455	695161	Cup–Flywheel
187	791766	Line–Fuel (Cut to Required Length) (Used After Code Date 05063000). ----- Note ----- 691050 Line–Fuel (Cut to Required Length) (Used Before Code Date 05070100).	271	691028	Lever–Control	456	692299	Plate–Pawl Friction
188	691147	Screw (Control Bracket)	276	271716	Washer–Sealing	459	281505	Pawl–Ratchet
			287	690940	Screw (Dipstick Tube)	505	691251	Nut (Governor Control Lever)
			300D	699769	Muffler–Exhaust	523	499621	Dipstick
			304	696527	Housing–Blower	524	692296	Seal–Dipstick Tube
			305	691108	Screw (Blower Housing) ----- Note ----- 691138 Screw (Blower Housing)	525	495265	Tube–Dipstick
			306	691232	Shield–Cylinder	529A	691923	Grommet
			307	690345	Screw (Cylinder Shield)	562	691119	Bolt (Governor–Control Lever)
			332	690662	Nut (Flywheel)	563	691138	Screw (Debris Guard Screen)
			333	802574	Armature–Magneto	564	693808	Screw (Control Cover)
			334	691061	Screw (Magneto Armature)	584	697734	Cover–Breather Passage
						585	691879	Gasket–Breather Passage
						592	690800	Nut (Rewind Starter)
						597	691696	Screw (Pawl Friction Plate)
						601	95162	Clamp–Hose
						604	692669	Cover–Control

★ Included in Engine Gasket Set–Ref. No.358.

● Included in Carburetor Overhaul Kit–Ref. No. 121.

◆ Included in Carburetor Gasket Set–Ref. No. 977.

Δ Included in Valve Gasket Set–Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

6726–8

Assemblies include all parts shown in frames.

10/12/2005

12B600

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
608	497680	Starter-Rewind	830	694544	Stud-Rocker Arm	993	★△694088	Gasket-Cylinder Head Plate
613	691108	Screw (Muffler)	842	★691031	Seal-O Ring (Dipstick Tube)	997	696310	Shield-Debris
613A	691140	Screw (Muffler)	843	691884	Sleeve-Lever	1005	691346	Fan-Flywheel
615	690340	Retainer-Governor Shaft	847	692047	Dipstick/Tube Assembly	1019	696438	Kit-Label
616	698801	Crank-Governor	851	493880	Terminal-Spark Plug	1022	★△691890	Gasket-Rocker Cover
619	691108	Screw (Cylinder Head Plate)	868	★△692044	Seal-Valve	1023	499624	Cover-Rocker Arm
621	692310	Switch-Stop	883	★△691893	Gasket-Exhaust	1026	692045	Rod-Push
633A●	691321	Seal-Choke/Throttle Shaft	886	696268	Gasket Set-Cylinder Head/Plate	1029	691230	Arm-Rocker
		(Throttle Shaft)	914	691108	Screw (Rocker Cover)	1034	691343	Guide-Push Rod
635	66538	Boot-Spark Plug	949	696306	Guard-Debris Screen	1036		Label-Emission (Available From An Authorized Briggs & Stratton Service Dealer)
670	692294	Spacer-Fuel Tank	957	692046	Cap-Fuel Tank (Plastic)	1058	276348	Manual-Owner's
684	690345	Screw (Breather Passage Cover)	966	692673	Base-Air Cleaner Primer	1059	692311	Kit-Screw/Washer
689	691855	Spring-Friction	967	493537	Filter-Pre Cleaner	1095	694091	Gasket Set-Valve
703	696309	Clip	968	692298	Cover-Air Cleaner	1210	498144	Pulley/Spring Assembly (Pulley)
718	690959	Pin-Locating	972	699374	Tank-Fuel (Plastic)	1211	498144	Pulley/Spring Assembly (Spring)
741	790345	Gear-Timing (Use Without Woodruff Key)	975	493640	Bowl-Float	1330	272147	Manual-Repair
		----- Note -----	976	694395	Primer-Carburetor			
		691830 Gear-Timing (Uses Woodruff Key)	977	692704	Gasket Set-Carburetor			

★ Included in Engine Gasket Set-Ref. No.358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

◆ Included in Carburetor Gasket Set-Ref. No. 977.

△Included in Valve Gasket Set-Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

6726-9

Assemblies include all parts shown in frames.

10/12/2005