

12E400

Illustrated Parts List

Model Series

12E400

TYPE NUMBERS
0110.

TABLE OF CONTENTS

Blower Housing/Shrouds	7
Cams	4
Carburetor	5
Controls	6
Crankcase Cover/Sump	2
Crankshaft	4
Cylinder	2
Electric Starter	8
Flywheel	7
Fuel Tank	5
Governor Spring	6
Head	3
Ignition	6
Kits/Gaskets – Carburetor	5
Kits/Gaskets – Engine	2
Muffler	8
Oil Group	2
Piston Group	4
Rewind Starter	8
Valves	3



BRIGGS & STRATTON





PRINTED IN U.S.A.

COPYRIGHT by BRIGGS & STRATTON CORPORATION
All rights reserved. No part of this material may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permission in writing from Briggs & Stratton Corporation.

12E400




Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
 5858-2 Assemblies include all parts shown in frames. 03/01/2004





Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
 5858-3 Assemblies include all parts shown in frames.


03/01/2004

12E400







12E400



Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
5858-6 Assemblies include all parts shown in frames. **03/01/2004**



12E400



Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
5858-8 Assemblies include all parts shown in frames. **03/01/2004**

12E400

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	695713	Cylinder Assembly	25	690021	Piston Assembly (Standard)	35	691304	Spring-Valve (Intake)
2	399269	Kit-Bushing/Seal (Magnetos Side)			----- Note -----	36	691304	Spring-Valve (Exhaust)
3	★299819	Seal-Oil (Magnetos Side)		694167	Piston Assembly	40	692194	Retainer-Valve
5	699486	Head-Cylinder			(.010" Oversize)	45	690977	Tappet-Valve
7	★Ø698210	Gasket-Cylinder Head		694168	Piston Assembly	46	695285	Camshaft
11	695745	Tube-Breather			(.020" Oversize)	51	★♦♦692555	Gasket-Intake (2 Required)
12	★692549	Gasket-Crankcase		694169	Piston Assembly	55	696710	Housing-Rewind Starter
13	691137	Screw (Cylinder Head)			(.030" Oversize)	58	693389	Rope-Starter (Cut To Required Length)
15	691686	Plug-Oil Drain	26	499631	Ring Set (Standard)	60	699334	Grip-Starter Rope (Used After Code Date 03051100).
16	699445	Crankshaft (Used After Code Date 03061200).			----- Note -----			----- Note -----
		----- Note -----		692785	Ring Set (.010" Oversize)			695740 Grip-Starter Rope
		693887 Crankshaft (Used Before Code Date 03061300).		692786	Ring Set (.020" Oversize)			(Used Before Code Date 03051200).
18	790000	Cover-Crankcase		692787	Ring Set (.030" Oversize)	65	697725	Screw (Rewind Starter)
20	★692550	Seal-Oil (PTO Side)	27	691866	Lock-Piston Pin	95	691636	Screw (Throttle Valve)
20A	★691952	Seal-Oil (PTO Side) (Auxiliary Drive)	28	499423	Pin-Piston	97	690024	Shaft-Throttle
21	281658	Cap-Oil Fill	29	690124	Rod-Connecting	98	398185	Kit-Idle Speed
22	692551	Screw (Crankcase Cover/ Sump)	30	692562	Dipper-Connecting Rod	104	♦691242	Pin-Float Hinge
23	695769	Flywheel	32	691664	Screw (Connecting Rod)	108	695807	Valve-Choke
24	222698	Key-Flywheel	32A	695759	Screw (Connecting Rod)	109	695729	Shaft-Choke
			33	499642	Valve-Exhaust			
			34	499641	Valve-Intake			

★ Included in Engine Gasket Set-Ref. No. 358.

Δ Included in Carburetor Overhaul Kit-Ref. No. 121.

■ Included in Carburetor Gasket Set-Ref. No. 977.

♦ Included in Valve Gasket Set-Ref. No. 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.**5858-9**

Assemblies include all parts shown in frames.

03/01/2004

12E400

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
117	690048	Jet–Main (Standard)	268	691072	Control Wire Casing (Cut to Length)	363	19069	Puller–Flywheel
118	498977	Jet–Main (High Altitude)	269	691589	Control Wire (Cut to Length)	365	692568	Screw (Carburetor)
121	695157	Kit–Carburetor Overhaul	270	691027	Nut (Control Wire Casing)	383	19374	Wrench–Spark Plug
122	●693749	Spacer–Carburetor	271	691028	Control Lever	427	694255	Nut (Control Bracket)
125	695727	Carburetor	271A	698038	Lever–Control	449	691693	Screw (Oil Fill Bracket)
127	●694468	Plug–Welch	276	●271716	Washer–Sealing	455	692591	Cup–Flywheel
130	691181	Valve–Throttle	281	697550	Panel–Control	456	692299	Plate–Pawl Friction
133	398187	Float–Carburetor	300	699787	Muffler	459	281505	Pawl–Ratchet
134	●398188	Kit–Needle/Seat	304	696653	Housing–Blower	472	696691	Knob–Choke Shaft
137	●693981	Gasket–Float Bowl	305	691108	Screw (Blower Housing)	474	698314	Alternator
146	690979	Key–Timing	306	695710	Shield–Cylinder	485	695755	Knob–Control
155	698214	Plate–Cylinder Head	307	690345	Screw (Cylinder Shield)	493	695744	Bracket–Mounting
186	692317	Connector–Hose	307A	691003	Screw (Cylinder Shield)	493A	691177	Bracket–Mounting
187	691050	Line–Fuel (Cut to Required Length)	309	696818	Motor–Starter	501	698315	Regulator
187A	692601	Line–Fuel (Molded)	318	690370	Screw (Mounting Bracket)	503	699889	Strap–Starter
188	690877	Screw (Control Bracket)	332	699359	Nut (Flywheel) (Used After Code Date 03060800).	504	694254	Washer Set–Friction
190	692127	Screw (Fuel Tank)			----- Note -----	505	691251	Nut (Governor Control Lever)
192	694543	Adjuster–Rocker Arm			690662 Nut (Flywheel) (Used Before Code Date 03060900).	523	693618	Dipstick
209	692571	Spring–Governor				524	281370	Seal–Dipstick Tube
209A	691278	Spring–Governor				526	690297	Screw (Regulator)
219	693578	Gear–Governor				528	695746	Hose–Primer
220	691724	Washer (Governor Gear)				552	692346	Bushing–Governor Crank
222	698326	Bracket–Control	333	695711	Armature–Magneto	562	691119	Bolt (Governor Control Lever)
227	692573	Lever–Governor Control	334	691061	Screw (Magneto Armature)	564	696685	Screw (Control Cover)
238	691300	Cap–Valve	337	491055	Plug–Spark	597	691696	Screw (Pawl Friction Plate)
			356	695731	Wire–Stop	601	95162	Clamp–Hose
			358	698216	Gasket Set–Engine	604	695749	Cover–Control

★ Included in Engine Gasket Set–Ref. No. 358.

△ Included in Carburetor Overhaul Kit–Ref. No. 121.

■ Included in Carburetor Gasket Set–Ref. No. 977.

◆ Included in Valve Gasket Set–Ref. No. 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

5858–10

Assemblies include all parts shown in frames.

03/01/2004

12E400

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
608	699335	Starter—Rewind (Used After Code Date 03051100). ----- Note ----- 696711 Starter—Re- wind (Used Before Code Date 03051200).	703	698320	Mounting Bracket)	975	493640	Bowl—Float
			718	690959	Pin—Locating	976	695750	Primer—Carburetor
			731	696690	Hood—Snow	977	695156	Gasket Set—Carburetor
			741	695087	Gear—Timing	990	695756	Key Set
			742	692564	Retainer—E Ring	993	★Ø694088	Gasket—Cylinder Head Plate
			746	692566	Gear—Idler	1005	692592	Fan—Flywheel
			773	694258	Retainer	1019	695751	Kit—Label
613	697812	Screw (Muffler)	813	690635	Clamp	1022	★Ø691890	Gasket—Rocker Cover
613A	691108	Screw (Muffler)	819	691685	Screw (Muffler Bracket)	1023	499924	Cover—Rocker Arm
615	692576	Retainer—Governor Shaft	823	691665	Screw (Muffler Adapter)	1026	693517	Rod—Push
616	692547	Crank—Governor	824	696017	Gasket—Heat Shield	1029	691230	Arm—Rocker
619	691108	Screw (Cylinder Head Plate)	830	694544	Stud (Rocker Arm)	1034	691343	Guide—Push Rod
621	692310	Switch—Stop	842	691031	Seal— O Ring (Dipstick/Tube)	1036	697004	Label—Emission
632	692653	Spring/Link— Mechanical Governor	847	693617	Dipstick/Tube Assembly	1054	280275	Tie—Cable
633	◆693867	Seal—Choke/Throttle Shaft (Choke)	851	493880	Terminal—Spark Plug	1058	275697	Owner's Manual
633A	◆691321	Seal—Choke/Throttle Shaft (Throttle)	863	697280	Bracket—Muffler	1070	699201	Screw (Flywheel Fan)
			864	697814	Adapter—Muffler	1095	695289	Gasket Set—Valve
			868	★Ø692044	Seal—Valve	1119	691183	Screw (Alternator)
635	692927	Boot—Spark Plug	883A	★691893	Gasket—Exhaust	1196	696692	Screw (Snow Hood)
663	696685	Screw (Control Panel)	892	★692237	Gasket—Exhaust	1210	498144	Pulley/Spring Assembly (Pulley)
668	694257	Spacer	914	695747	Switch—Key	1211	498144	Pulley/Spring Assembly (Spring)
689	691855	Spring—Friction	914A	697551	Screw (Rocker Cover)	1224	696824	Nut (Carburetor Primer)
692	690572	Spring—Detent (Choke)	930	692557	Screw (Rocker Cover)	1230	695709	Stud (Control Bracket)
697	698418	Screw (Drive Cap) (Starter Motor to	957	696709	Guard—Rewind	1251	696699	Shield—Snow
			958	695737	Cap—Fuel Tank	1330	272147	Repair Manual
			972	692586	Valve—Fuel Shut Off			
				695728	Tank—Fuel			

★ Included in Engine Gasket Set—Ref. No. 358.

Δ Included in Carburetor Overhaul Kit—Ref. No. 121.

■ Included in Carburetor Gasket Set—Ref. No. 977.

◆ Included in Valve Gasket Set—Ref. No. 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.**5858-11**

Assemblies include all parts shown in frames.

03/01/2004