



12L800

Illustrated Parts List

Model Series

12L800

TYPE NUMBERS
0805 through 3104.

TABLE OF CONTENTS

Alternator	7
Air Cleaner	4
Blower Housing/Shrouds	6
Camshaft	2
Carburetor	3
Controls	5
Crankshaft	2
Cylinder	2
Electric Starter	7
Electrical	7
Engine Sump	2
Exhaust System	4
Flywheel	7
Flywheel Brake	7
Fuel Supply	5
Governor Spring	5
Ignition	7
Kits/Gaskets	2 & 3
Lubrication	2
Piston Group	2
Rewind Starter	6
Valves	2


BRIGGS & STRATTON







PRINTED IN U.S.A.

COPYRIGHT by BRIGGS & STRATTON CORPORATION
All rights reserved. No part of this material may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permission in writing from Briggs & Stratton Corporation.









12L800




Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
 2271-2 Assemblies include all parts shown in frames. 09/30/2005




12L800




Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
2271-4 Assemblies include all parts shown in frames. 09/30/2005



12L800



Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
 2271-6 Assemblies include all parts shown in frames. 09/30/2005



12L800

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	697324	Cylinder Assembly	24	222698	Key-Flywheel	27	691866	Lock-Piston Pin
2	399269	Kit-Bushing/Seal (Magneto Side)	25	790358	Piston Assembly (Standard) (Used After Code Date 04031400).	28	499423	Pin-Piston (Standard)
3	★299819	Seal-Oil (Magneto Side)				29	499424	Rod-Connecting (Standard)
4	493279	Sump-Engine			----- Note -----	32	691664	Screw (Connecting Rod)
4A	493365	Sump-Engine (Auxilliary PTO)			499433 Piston Assembly (Standard) (Used Before Code Date 04031500).	32A	695759	Screw (Connecting Rod) (Used After Code Date 00042200).
5	691160	Head-Cylinder			499434 Piston Assembly (.010" Oversize)	33	262651	Valve-Exhaust
7★	Ø692249	Gasket-Cylinder Head			791325 Piston Assembly (.020" Oversize) (Used After Code Date 04102100).	34	262652	Valve-Intake
8	695250	Breather Assembly			499435 Piston Assembly (.020" Oversize) (Used Before Code Date 04102200).	35	691270	Spring-Valve (Intake)
9★	Ø272481	Gasket-Breather			499436 Piston Assembly (.030" Oversize)	36	691270	Spring-Valve (Exhaust)
10	94650	Screw (Breather Assembly)			26 790360 Ring Set (Standard) (Used After Code Date 04031400).	37	694086	Guard-Flywheel
11	691781	Tube-Breather			----- Note -----	40	692194	Retainer-Valve
12	★692232	Gasket-Crankcase			499425 Ring Set (Standard) (Used Before Code Date 04031500).	43	691997	Slinger-Governor/Oil
13	690912	Screw (Cylinder Head)			499426 Ring Set (.010" Oversize)	45	690548	Tappet-Valve
15	691680	Plug-Oil Drain (Square Socket)			791324 Ring Set (.020" Oversize) (Used After Code Date 04102100).	46	691449	Camshaft
15A	691093	Plug-Oil Drain (Hex Socket)			499427 Ring Set (.020" Oversize) (Used Before Code Date 04102200).	46A	691459	Camshaft
16	691454	Crankshaft ----- Note ----- 691451 Crankshaft Used on Type No(s). 0806, 1507, 1508, 1509, 1562. 691452 Crankshaft Used on Type No(s). 0805, 1505, 1506, 2304, 2604, 3104.			499428 Ring Set (.030" Oversize)	45	690548	Tappet-Valve
20	★399781	Seal-Oil (PTO Side)				50	497465	Manifold-Intake
20A	★691952	Seal-Oil (PTO Side) (Auxiliary PTO)				51	★272199	Gasket-Intake
22	691092	Screw (Crankcase Cover/Sump)				54	691650	Screw (Intake Manifold)
23	692315	Flywheel (Rewind Start)				55	691421	Housing-Rewind Starter
23A	691987	Flywheel (Electric Start) ----- Note ----- 691992 Flywheel Used on Type No(s). 0805, 0806.				58	280399	Rope-Starter (Cut To Required Length)
						60	281434	Grip-Starter Rope
						65	690837	Screw (Rewind Starter)
						78	691108	Screw (Flywheel Guard)
						81	691740	Lock-Muffler Screw
						83	691778	Shaft-Auxiliary Drive
						94	●493765	Kit-Idle Mixture
						95	691636	Screw (Throttle Valve)
						97	493267	Shaft-Throttle (Metal) ----- Note ----- 696565 Shaft-Throttle (Plastic)

★ Included in Engine Gasket Set-Ref. No.358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

◆ Included in Carburetor Gasket Set-Ref. No. 977.

Ø Included in Valve Gasket Set-Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

2271-8

Assemblies include all parts shown in frames.

09/30/2005

12L800

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
98	398185	Kit-Idle Speed (Carburetor)	125	698444	Carburetor (Primer System)	187B	791891	Line-Fuel (Includes Filter)
98A	493280	Kit-Idle Speed	125A	498964	Carburetor (Choke System)			(Used After Code Date 05063000).
101	691623	Pin-Shaft			(Used After Code Date 96060200).			----- Note -----
104	691242	Pin-Float Hinge			----- Note -----			692042 Line-Fuel
108	691182	Valve-Choke			497353 Carburetor (Choke System)			(Includes Filter)
109	494218	Shaft-Choke			(Used Before Code Date 96060300).			(Used Before Code Date 05070100).
117	494870	Jet-Main (Standard) (Used After Code Date 02092900).			----- Note -----	188	690877	Screw (Control Bracket)
		----- Note -----	127	694468	Plug-Welch	190	690940	Screw (Fuel Tank)
		498975 Jet-Main (Standard) (Used Before Code Date 02093000).	130	691203	Valve-Throttle	202	691829	Link-Mechanical Governor
		----- Note -----			----- Note -----	209	691292	Spring-Governor
117A	498976	Jet-Main (Standard) (Used After Code Date 96060200).	130A	691181	Valve-Throttle			----- Note -----
		----- Note -----	133	398187	Float-Carburetor			691835 Spring- Governor
		496063 Jet-Main (Standard) (Used Before Code Date 96060300).	134	693981	Kit-Needle/Seal			Used on Type No(s). 0805, 0806, 1505, 1506, 1507, 1508.
		----- Note -----	137	690979	Gasket-Float Bowl			262663 Spring- Governor
		496495 Jet-Main (High Altitude) (Used After Code Date 02092900).	146	691753	Key-Timing			Used on Type No(s). 1509, 1562.
118	497315	Jet-Main (High Altitude) (Used After Code Date 02092900).	159	691753	Bracket-Air Cleaner Primer	217	690354	Spring-Choke Rreturn
		----- Note -----	163	272653	Gasket-Air Cleaner	222	790143	Bracket-Control (Remote/Manual Friction)(Primer)
		496495 Jet-Main (High Altitude) (Used Before Code Date 02093000).	187	791766	Line-Fuel (Cut to Required Length) (Used After Code Date 05063000).	222A	692021	Bracket-Control (Remote Choke A Matic,Non Compliance)
		----- Note -----			----- Note -----	227	690783	Lever-Governor Control
118A	498977	Jet-Main (High Altitude) (Used After Code Date 96060200).	187A	791873	Line-Fuel (Molded) (Used After Code Date 05063000).	240	298090	Filter-Fuel
		----- Note -----			----- Note -----	265	690798	Clamp-Casing
		497315 Jet-Main (High Altitude) (Used Before Code Date 96060300).			691371 Line-Fuel (Molded) (Used Before Code Date 05070100).	267	691044	Screw (Casing Clamp)
121	498260	Kit-Carburetor Overhaul			----- Note -----	268	691072	Casing-Control Wire (Cut to Required Length)

★ Included in Engine Gasket Set-Ref. No.358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

◆ Included in Carburetor Gasket Set-Ref. No. 977.

⊗ Included in Valve Gasket Set-Ref. No 1095.

*Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.***2271-9**

Assemblies include all parts shown in frames.

09/30/2005

12L800

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
269	691026	Wire-Control (Cut to Required Length)	443A	692523	Screw (Air Cleaner Primer Base)	616	698801	Crank-Governor
270	691027	Nut (Control Wire Casing)	445A	491588	Filter-Air Cleaner Cartridge	617★♦270344		Seal-O Ring (Intake Manifold)
271	691028	Lever-Control	455	695161	Cup-Flywheel	621	692310	Switch-Stop
276 ♦♦271716		Washer-Sealing	456	692299	Plate-Pawl Friction	633 ♦♦691321		Seal-Choke/Throttle Shaft
287	690940	Screw (Dipstick Tube)	459	281505	Plate-Ratchet	633A ♦♦693867		Seal-Choke/Throttle Shaft
300	496106	Muffler (Tuned)	474	691991	Alternator	635	66538	Boot-Spark Plug
300B	497681	Muffler (Catalyst)	505	691251	Nut (Governor Control Lever)	651	691660	Screw (Starter Gear Cover)
304	493293	Housing-Blower ----- Note ----- 493294 Housing-Blower Used on Type No(s). 0805, 0806.	510	494147	Drive-Starter	668	★493823	Spacer
305	691108	Screw (Blower Housing)	513	692358	Clutch-Drive	670	692294	Spacer-Fuel Tank
306	690450	Shield-Cylinder	523	495264	Dipstick	676B	397931	Deflector-Muffler (Includes Spark Arrestor)
307	690345	Screw (Cylinder Shield)	524	★692296	Seal-Dipstick Tube	676D	497682	Deflector-Muffler (For TUV)
309	695550	Motor-Starter	525	495265	Tube-Dipstick	677	690661	Screw (Muffler Deflector)
310	692327	Bolt (Starter Motor)	529	691923	Grommet	684	690345	Screw (Breather Passage Cover)
332	690662	Nut (Flywheel)	544	690786	Armature-Starter	689	691855	Spring-Friction
333	802574	Armature-Magneto	545	492919	Washer Set (Starter Motor)	697	691127	Screw (Drive Cap)
334	691061	Screw (Magneto Armature)	562	691119	Bolt (Governor Control Lever)	715	691147	Screw (Shaft Stop)
337	802592	Plug-Spark	564	691132	Screw (Control Cover)	718	690959	Pin-Locating
346	690661	Screw (Spark Arrestor)	564A	691142	Screw (Control Cover)	721	690449	Stop-Shaft
356	692390	Wire-Stop	584	697734	Cover-Breather Passage	741	790345	Gear-Timing (Use Without Woodruff Key)
358	497316	Gasket Set-Engine	585	★691879	Gasket-Breather Passage			----- Note ----- 691830 Gear-Timing (Uses Woodruff Key)
363	19069	Flywheel Puller	592	690800	Nut (Rewind Starter)	742	93941	Retainer-E Ring
365	691688	Screw (Carburetor)	597	691696	Screw (Pawl Friction Plate)	743	691772	Gear-Drive
374	691074	Washer (Camshaft)	601	95162	Clamp-Hose	745	691648	Screw (Brake)
383	89838	Wrench-Spark Plug	601A	691038	Clamp-Hose	783	691918	Gear-Pinion (19 Teeth) (Starter Drive)
404	690272	Washer (Governor Crank)	604	691757	Cover-Control	783A	691269	Gear-Pinion (12 Teeth)
425A	690670	Screw (Air Cleaner Cover)	604A	691344	Cover-Control			
			608	497680	Starter-Rewind			
			613	691340	Screw (Muffler)			
			613B	691114	Screw (Muffler)			
			615	690340	Retainer-Governor Shaft			

★ Included in Engine Gasket Set-Ref. No.358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

♦ Included in Carburetor Gasket Set-Ref. No. 977.

⊗ Included in Valve Gasket Set-Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

2271-10

Assemblies include all parts shown in frames.

09/30/2005

12L800

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
784	692341	Cover-Starter Gear	853	695268	Adapter-Wire	975	493640	Bowl-Float
785	692352	Gasket-Starter Cover	869	691155	Seat-Valve (Intake)	976	694395	Primer-Carburetor
789B	696547	Harness-Wiring	870	690380	Seat-Valve (Exhaust)	977	498261	Gasket Set-Carburetor
801	690782	Cap-Drive	871	262001	Bushing-Valve Guide (Exhaust)	883	691881	Gasket-Exhaust
802	695267	Cap-End (Used After Code Date 00040600).			----- Note -----	910	691094	Stud (Alternator)
		----- Note -----			----- Note -----	921	497233	Cover-Blower Housing
		695975 Cap-End (Used Before Code Date 00040700).			63709 Bushing-Valve Guide (Intake)	921A	695886	Cover-Blower Housing
803	695266	Housing-Starter (Used After Code Date 00040600).	937	691325	Spline-Starter	922	691831	Spring-Brake
		----- Note -----	957	397974	Cap-Fuel Tank (Plastic)	923	691994	Brake
		695975 Housing- Starter (Used Before Code Date 00040700).	958	698183	Valve-Fuel Shut Off (Plastic)	925	690595	Cover-Linkage
832B	497683	Guard-Muffler (Catalyst)	966A	496116	Base-Air Cleaner Primer	930	691919	Guard-Rewind
832D	499034	Guard-Muffler (Tuned)	967A	493537	Filter-Pre Cleaner	930A	691345	Guard-Rewind
836	690664	Screw (Muffler Guard)	968B	692298	Cover-Air Cleaner	994	398067	Arrestor-Spark
836B	691147	Screw (Muffler Guard)	969	690700	Screw (Blower Housing Cover)	1005	691346	Fan-Flywheel
842	691031	Seal-O Ring (Dipstick Tube)	969A	691138	Screw (Blower Housing Cover)	1019	494256	Kit-Label
847	692017	Dipstick/Tube Assembly	970	691669	Screw (Air Cleaner Primer Bracket)	1036		Label-Emission (Available From An Authorized Briggs & Statton Service Dealer)
851	493880	Terminal-Spark Plug	972	699392	Tank-Fuel (Plastic)	1058	276171	Owner's Manual
			972B	699374	Tank-Fuel (Plastic)	1059	692311	Kit-Screw/Washer
						1095	498528	Gasket Set-Valve
						1119	691648	Screw (Alternator)
						1210	498144	Pulley/Spring Assembly (Pulley)
						1211	498144	Pulley/Spring Assembly (Spring)
						1330	270962	Manual-Repair

★ Included in Engine Gasket Set-Ref. No.358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

◆ Included in Carburetor Gasket Set-Ref. No. 977.

⌀ Included in Valve Gasket Set-Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.**2271-11**

Assemblies include all parts shown in frames.

09/30/2005