

201400

Illustrated Parts List

Model Series

201400

TYPE NUMBERS
0035 through 0120.

For Use On Engines Built Before Date Code – 01033100

TABLE OF CONTENTS

Alternator	8
Air Cleaner	5
Blower Housing/Shrouds	6
Cams	2
Carburetor	4
Controls	7
Crankcase Cover/Sump	2
Crankshaft	2
Cylinder Head	3
Electric Starter	8
Electrical	8
Flywheel	6
Fuel Tank	7
Governor Spring	7
Ignition	8
Kits/Gaskets	2 & 4
Muffler	5
Oil	2
Piston Group	2
Rewind	6
Valves	3


BRIGGS & STRATTON



PRINTED IN U.S.A.

COPYRIGHT by BRIGGS & STRATTON CORPORATION
All rights reserved. No part of this material may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permission in writing from Briggs & Stratton Corporation.

201400




Illustrations cover a range of engines. Parts shown without corresponding text are not used on this engine.

6677-2

Assemblies include all parts shown in frames.

3C-4/2001




Illustrations cover a range of engines. Parts shown without corresponding text are not used on this engine.

6677-3


Assemblies include all parts shown in frames.

3C-4/2001

201400



Illustrations cover a range of engines. Parts shown without corresponding text are not used on this engine.
 6677-4 Assemblies include all parts shown in frames. 3C-4/2001




Illustrations cover a range of engines. Parts shown without corresponding text are not used on this engine.

6677-5

Assemblies include all parts shown in frames.

3C-4/2001

201400




Illustrations cover a range of engines. Parts shown without corresponding text are not used on this engine.

6677-6

Assemblies include all parts shown in frames.

3C-4/2001




Illustrations cover a range of engines. Parts shown without corresponding text are not used on this engine.

6677-7

Assemblies include all parts shown in frames.

3C-4/2001

201400



Illustrations cover a range of engines. Parts shown without corresponding text are not used on this engine.

6677-8

Assemblies include all parts shown in frames.

3C-4/2001

201400

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	695464	Cylinder Assembly	25	695457	Piston Assembly (Standard)	79	690614	Case–Gear Reduction
2	495657	Kit–Bushing/Seal			----- Note -----	80	691603	Gasket–Gear Case
3	★391086	Seal–Oil (Magneto Side)		695458	Piston Assembly (.010" Oversize)	81	695400	Lock–Muffler Screw
5	694873	Head–Cylinder		695459	Piston Assembly (.020" Oversize)	82	690287	Screw (Gear Reduction Case)
7	★Δ694872	Gasket–Cylinder Head		695460	Piston Assembly (.030" Oversize)	83	690387	Shaft–Auxiliary Drive
11	694871	Tube–Breather			----- Note -----	84	691121	Plug–Breather
12	★694953	Gasket–Crankcase		694006	Ring Set (.010" Oversize)	85	691076	Screw (Gear Cover to Gear Reduction Case)
13	690360	Screw (Cylinder Head)	26	694004	Ring Set (Standard)	86	690613	Cover–Gear
15	691686	Plug–Oil Drain			----- Note -----	87	391086	Seal–Gear Reduction
15A	691682	Plug–Oil Drain		694008	Ring Set (.020" Oversize)	88	691601	Gasket–Gear Reduction Cover
16	695462	Crankshaft		694010	Ring Set (.030" Oversize)	89	690283	Plug–Oil
		----- Note -----				95A	690718	Screw (Throttle Valve)
		695818 Crankshaft Used on Type No(s). 0035.	27	690975	Lock–Piston Pin	97A	696140	Shaft–Throttle
		696412 Crankshaft Used on Type No(s). 0118.	28	690229	Pin–Piston	98A	●695408	Kit–Idle Speed
		695817 Crankshaft Used on Type No(s). 0049.	29	694691	Rod–Connecting	104A	●694918	Pin–Float Hinge
		694678 Crankshaft Used on Type No(s). 0116.	30	694692	Dipper–Connecting Rod	105A	●696136	Valve–Float Needle
17	695434	Bearing–Ball				108A	696143	Valve–Choke
18	694951	Cover–Crankcase	32	690976	Screw (Connecting Rod)	109C	696145	Shaft–Choke
		----- Note -----				117	●696134	Jet–Main (Strandard)
		695372 Cover–Crankcase Used on Type No(s). 0035, 0036, 0118.	33	499596	Valve–Exhaust	118	696135	Jet–Main (High Altitude)
19	495657	Kit–Bushing/Seal (PTO Side)	34	499597	Valve–Intake	121A	696146	Kit–Carburetor Overhaul
20	★391086	Seal–Oil (PTO Side)	35	694865	Spring–Valve (Intake)			
21	281658	Cap–Oil Fill	36	694865	Spring–Valve (Exhaust)	122★Δ●694876		Spacer–Carburetor
22	695174	Screw (Crankcase Cover)	40	690964	Retainer–Valve	125A	696132	Carburetor
23	694954	Flywheel	42	499586	Keeper–Valve	127A	●690727	Plug–Welch
		----- Note -----	45	690977	Tappet–Valve	130A	696139	Valve–Throttle
		695485 Flywheel Used on Type No(s). 0117.	46	694680	Camshaft	133A	694914	Float–Carburetor
24	222698	Key–Flywheel	51★Δ●694874	Gasket–Intake		135	696142	Tube–Fuel Transfer
			51A★Δ●694875	Gasket–Intake		137A	●◆695426	Gasket–Float Bowl
			53	694869	Stud (Carburetor)	146	690979	Key–Timing
						161	695384	Base–Air Cleaner
			55	695288	Housing–Rewind Starter	163★●◆692277		Gasket–Air Cleaner
			58	693389	Rope–Starter (Cut to Required Length)	185	690958	Nut (Air Cleaner Base)
						187	691050	Line–Fuel
			59	805957	Insert–Grip	187A	695429	Line–Fuel
			60	715257	Grip–Starter Rope	188	690877	Screw (Control Bracket)
			65	690837	Screw (Rewind Starter)	190	692127	Screw (Fuel Tank)
					----- Note -----	192	690083	Adjuster–Rocker Arm
				690759	Screw (Rewind Starter) Used on Type No(s). 0117.			

★ Included in Engine Gasket Set-Ref. No.358.

● Included in Carburetor Overhaul Kit-Ref. No. 121 & 121A.

◆ Included in Carburetor Gasket Set-Ref. No. 977 & 977A.

Δ Included in Valve Gasket Set-Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text are not used on this engine.

6677-9

Assemblies include all parts shown in frames.

3C-4/2001

201400

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
209	694867	Spring–Governor	333	715231	Armature–Magneto	597	691696	Screw
211	695307	Spring–Governor Idle	334	691061	Screw			(Pawl Friction Plate)
212	696059	Link–Throttle	337	491055	Sparkplug	601	95162	Clamp–Hose
219	694950	Gear–Governor			----- Note -----	608	695287	Starter–Rewind
220	691724	Washer			691043 Sparkplug	613	695312	Screw
		(Governor Gear)			Used on Type No(s).			(Muffler)
222	695380	Bracket–Control			0116.	613A	695399	Screw
222A	694866	Bracket–Control	347	693623	Switch–Rocker			(Muffler)
		Used on Type No(s).			Used on Type No(s).	615	694676	Retainer–Governor
		0116.			0116.			Shaft
227	694864	Lever–Governor	347A	692599	Switch–Rocker	616	694675	Crank–Governor
		Control			Used on Type No(s).	621	692310	Switch–Stop
265	691024	Clamp–Casing			0111, 0117.	633B ♦	690998	Seal–Choke/Throttle
267	692577	Screw	356	695366	Wire–Stop			Shaft
		(Casing Clamp)	356A	692390	Wire–Stop	635	710901	Boot–Sparkplug
268	691025	Casing–Control Wire	356B	695815	Wire–Stop			(Alternator)
		(Cut to Required	356C	695295	Wire–Stop	663	692577	Screw
		Length)	356D	692603	Wire–Stop			(Control Panel)
269	691026	Wire–Control	358	695438	Gasket Set–Engine	668	694257	Spacer
		(Cut to Required	364	695365	Terminal–Oil Plug			(Control Bracket)
		Length)	369	695422	Spring–Float Bowl	668A	693604	Spacer
270	691027	Nut	383	19374	Wrench–Sparkplug			(Oil Sensor)
		(Control Wire Casing)	410	695382	Link–Control	689	691855	Spring–Friction
271	691028	Lever–Control	415	691363	Plug	697	690372	Screw
271A	695381	Lever–Control	445	491588	Filter–Air Cleaner			(Drive Cap)
272	691168	Lock–Screw Head			Cartridge	718	690959	Pin–Locating
277	691075	Washer	455	694683	Cup–Flywheel			(Cylinder)
		(Gear Case to Gear	456	692299	Plate–Pawl Friction	718A	695178	Pin–Locating
		Reduction)	459	281505	Pawl–Ratchet			(Head)
281	695294	Panel–Control	493	694861	Bracket–Mounting	727	695480	Cover–Starter Drive
286	695186	Module–Oil Sensor			(Oil Sensor)	732	691097	Screw
287	691693	Screw	503	691532	Strap–Starter			(Starter Drive Cover)
		(Dipstick/Tube	504	695383	Washer Set–Friction	741	691288	Gear–Timing
		Assembly)	505	691251	Nut	742	692564	Retainer–E Ring
300	695311	Muffler			(Governor Control	746	694679	Gear–Idler
304	694687	Housing–Blower			Lever)	773	694258	Retainer
		----- Note -----	510	693699	Drive–Starter	774	695447	Screw
		695481 Housing–	513	692024	Clutch–Drive			(Stop Wire)
		Blower	523	695344	Dipstick	783	693713	Gear–Pinion
		Used on Type No(s).	524	691876	Seal–O Ring	797	693167	Nut
		0117.			(Dipstick Tube)			(Brush Retainer)
305	690960	Screw	525	695343	Tube–Dipstick	798	690967	Screw
		(Blower Housing)	544	692034	Armature–Starter			(Rocker Arm)
306	694677	Shield–Cylinder	552	694674	Bushing–Governor	799	695446	Screw
307	691660	Screw			Crank			(Oil Sensor)
		(Cylinder Shield)	562	691119	Bolt	799A	690297	Screw
309	695479	Motor–Starter			(Governor Control			(Oil Sensor)
310	690323	Bolt			Lever)			
		(Starter Motor)	579	691029	Nut			
311	497608	Brush Set			(Starter Cable)			
332	694685	Nut	592	690800	Nut			
		(Flywheel)			(Rewind Starter)			

★ Included in Engine Gasket Set–Ref. No.358.

● Included in Carburetor Overhaul Kit–Ref. No. 121 & 121A.

♦ Included in Carburetor Gasket Set–Ref. No. 977 & 977A.

△ Included in Valve Gasket Set–Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text are not used on this engine.**6677–10**

Assemblies include all parts shown in frames.

3C–4/2001

201400

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
801	694482	Cap-Drive	968	695385	Cover-Air Cleaner	1095	695440	Gasket Set-Valve
802	691286	Cap-End	972	694260	Tank-Fuel	1100	690973	Pivot-Rocker Arm
803	693757	Housing-Starter	975A	696138	Bowl-Float	1127A	695407	Screw (Float Bowl)
832	695386	Guard-Muffler	977A	696147	Gasket Set-Carburetor	1138	694255	Nut (Control Bracket)
836	690367	Screw (Muffler Guard)	1005	694684	Fan-Flywheel	1161	693649	Nut (Oil Sensor)
842	691031	Seal-O Ring (Dipstick)	1019	695442	Kit-Label	1194	691876	Seal-O Ring (Plug)
843	695588	Sleeve-Lever	1022	★△690971	Gasket-Rocker Cover	1210	498144	Pulley/Spring Assembly (Pulley)
847	695342	Dipstick/Tube Assembly	1023	694690	Cover-Rocker Arm	1211	498144	Pulley/Spring Assembly (Spring)
868	★△690968	Seal-Valve	1026	695177	Rod-Push			
883	★△695398	Gasket-Exhaust	1029	690972	Arm-Rocker			
914	693732	Screw (Rocker Arm Cover)	1036	695703	Label-Emissions			
957	694261	Cap-Fuel	1051	691265	Ring-Retaining			
958	692586	Valve-Fuel Shut Off (Plastic)	1052	694858	Sensor-Oil			
			1052A	693805	Sensor-Oil			
			1058	274788	Owner's Manual			
			1070	691058	Screw (Flywheel Fan)			
			1090	691293	Retainer-Brush			

★ Included in Engine Gasket Set-Ref. No.358.

● Included in Carburetor Overhaul Kit-Ref. No. 121 & 121A.

◆ Included in Carburetor Gasket Set-Ref. No. 977 & 977A.

△ Included in Valve Gasket Set-Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text are not used on this engine.**6677-11**

Assemblies include all parts shown in frames.

3C-4/2001