



Illustrated Parts List

Model Series

21A900

TYPE NUMBERS
0115 through 0176.

TABLE OF CONTENTS

Air Cleaner	6
Alternator	9
Blower Housing	6
Camshaft	3
Carburetor	5
Controls	8
Engine Sump	2
Crankshaft	3
Cylinder	2
Cylinder Head	4
Electric Starter	7
Exhaust System	6
Flywheel	7
Fuel Supply	8
Gasket Set – Engine	4
Gasket Set – Valve	4
Governor Spring	8
Ignition	8
Kit – Carburetor Overhaul	5
Lubrication	3
Piston, Rings, Connecting Rod	3
Rewind Starter	7


BRIGGS & STRATTON




PRINTED IN U.S.A.

COPYRIGHT by BRIGGS & STRATTON CORPORATION
All rights reserved. No part of this material may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permission in writing from Briggs & Stratton Corporation.




21A900



Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
 5069-2 Assemblies include all parts shown in frames. 12/09/2004











21A900




Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
 5069-4 Assemblies include all parts shown in frames. 12/09/2004

21A900





Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
5069-5 Assemblies include all parts shown in frames. **12/09/2004**





21A900




Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
 5069-6 Assemblies include all parts shown in frames. 12/09/2004





DC ONLY		5 – 9 AMP	
DUAL CIRCUIT		10 – 16 AMP	
474A	474B	474C	474D
877A 	877 	877B 	877C 
578 	878 	578 	578 
NOTE: All stators use a No. 1119 mounting screw.  NOTE: The proper flywheel part number and/or the alternator magnet size will determine the alternator type or output. See repair instruction manual for additional information.		526A  501A 	526  501 



21A900

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	697377	Cylinder Assembly	23A	698283	Flywheel (Rewind Starter) Used on Type No(s). 0127, 0134, 0136, 0138, 0139, 0141, 0142, 0144, 0149, 0151, 0161, 0166, 0168, 0170, 0171, 0176. ----- Note ----- 790920 Flywheel (Rewind Starter) Used on Type No(s). 0117, 0171.	28	697099	Pin-Piston
2	399265	Kit-Bushing/Seal (Magnet Side)				29	697364	Rod-Connecting (Standard) ----- Note ----- 697262 Rod-Connecting (.020" Undersize)
3	★391086	Seal-Oil (Magnet Side)				32	692852	Screw (Connecting Rod)
4	697106	Sump-Engine				33	695760	Valve-Exhaust
4A	697188	Sump-Engine Used on Type No(s). 0115, 0119, 0121, 0122, 0129, 0156, 0157, 0165, 0173.				34	695761	Valve-Intake
5	697396	Head-Cylinder				35	691279	Spring-Valve (Intake)
7	★Δ273280	Gasket-Cylinder Head				36	691279	Spring-Valve (Exhaust)
9	★697109	Gasket-Breather	24	222698	Key-Flywheel	37	697352	Guard-Flywheel
10	697157	Screw (Breather Assembly)	25	698371	Piston Assembly (Standard) ----- Note ----- 698372 Piston Assembly (.010" Oversize) 698373 Piston Assembly (.020" Oversize) 698374 Piston Assembly (.030" Oversize)	37A	697626	Guard-Flywheel (Electric Start) Used on Type No(s). 0117, 0127, 0134, 0136, 0138, 0141, 0142, 0144, 0149, 0151, 0161, 0168, 0170, 0171, 0176.
11	697113	Tube-Breather				42	499586	Keeper-Valve
12	★697110	Gasket-Crankcase (.015" Thick)(Standard)				43	691968	Slinger-Governor/Oil
13	690360	Screw (Cylinder Head)				45	690564	Tappet-Valve
14	790560	Stud (Cylinder Head)				46	790392	Camshaft
15	690946	Plug-Oil Drain (3/8" Standard)				50	697361	Manifold-Intake
16A	697390	Crankshaft				51★Δ●	692137	Gasket-Intake
20	★690947	Seal-Oil (PTO Side)	26	698375	Ring Set (Standard) ----- Note ----- 698376 Ring Set (.010" Oversize) 698377 Ring Set (.020" Oversize) 698378 Ring Set (.030" Oversize)	53	690227	Stud (Carburetor)
22	692125	Screw (Crankcase Cover/Sump)				54	691148	Screw (Intake Manifold)
23	698281	Flywheel ----- Note ----- 698282 Flywheel Used on Type No(s). 0115, 0133, 0137, 0146, 0154, 0156, 0157, 0165, 0167. 790922 Flywheel Used on Type No(s). 0104, 0121, 0122, 0152, 0155, 0158, 0172, 0173. 790924 Flywheel Used on Type No(s). 0113, 0157, 0167.				55	695130	Housing-Rewind Starter
			27	698469	Lock-Piston Pin (Pink) (Used After Code Date 02100300) ----- Note ----- 698138 Lock-Piston Pin (Green) (Used Before Code Date 02100400)	56	695129	Pulley-Starter
						57	695131	Spring-Rewind Starter
						58	695132	Rope-Starter
						60	494212	Grip-Starter Rope
						65	697725	Screw (Rewind Starter)

★ Included in Engine Gasket Set-Ref. No.358.

● Included in Carburetor Overhaul Kit-Ref. No. 121 or 121A.

◆ Included in Carburetor Gasket Set-Ref. No. 977 or 977A.

Δ Included in Valve Gasket Set-Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

5069-10

Assemblies include all parts shown in frames.

12/09/2004

21A900

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
73	697133	Screen—Rotating (Used After Code Date 03031600) ----- Note ----- 697384 Screen—Rotating (Used Before Code Date 03031700)	106	●691780	Seat—Inlet (Pump Feed) Used on Type No(s). 0115, 0121, 0122, 0133, 0137, 0140, 0141, 0143, 0144, 0145, 0146, 0147, 0149, 0150, 0151, 0153, 0154, 0157, 0159, 0161, 0162, 0164, 0165, 0169, 0170, 0173. ----- Note ----- ●690577 Seat—Inlet (Gravity Feed) Used on Type No(s). 0104, 0113, 0117, 0119, 0120, 0123, 0124, 0125, 0127, 0128, 0129, 0131, 0134, 0136, 0142, 0152, 0155, 0156, 0158, 0166, 0167, 0168, 0169, 0171, 0172, 0176.	125	790019	Carburetor (Walbro) (Gravity Feed) Used on Type No(s). 0104, 0113, 0117, 0119, 0120, 0123, 0124, 0125, 0127, 0128, 0129, 0131, 0134, 0136, 0138, 0142, 0146, 0152, 0155, 0156, 0158, 0166, 0167, 0168, 0169, 0171, 0172, 0176. ----- Note ----- 790020 Carburetor (Walbro)(Pump Feed) Used on Type No(s). 0115, 0121, 0122, 0133, 0137, 0139, 0140, 0141, 0143, 0144, 0145, 0146, 0147, 0149, 0150, 0151, 0153, 0154, 0157, 0159, 0161, 0162, 0164, 0165, 0170, 0173. 790021 Carburetor Used on Type No(s). 0142.
74	697897	Screw (Rotating Screen)				127	●694524	Plug—Welch
78	691003	Screw (Flywheel Guard)				127A	●690727	Plug—Welch (Nikki)
78A	690364	Screw (Flywheel Guard)(Electric Start) Used on Type No(s). 0117, 0127, 0134, 0136, 0138, 0141, 0142, 0144, 0149, 0151, 0161, 0168, 0170, 0171.	108	691227	Valve—Choke (Walbro)	130	790024	Valve—Throttle (Walbro)
81	691178	Lock—Muffler Screw	108A	698773	Valve—Choke (Nikki)	130A	698774	Valve—Throttle (Nikki)
93	●690602	Bushing—Throttle Shaft	117	●699897	Jet—Main (Standard)	131	790901	Kit—Throttle Shaft (Walbro)
94	498030	Kit—Idle Mixture (Walbro)	118	699898	Jet—Main (High Altitude)			
94A	695425	Kit—Idle Mixture (Nikki)	121	790031	Kit—Carburetor Overhaul (Walbro)			
95	●691636	Screw (Throttle Valve)(Walbro)	121A	698787	Kit—Carburetor Overhaul (Nikki)			
95A	●690718	Screw (Throttle Valve)(Nikki)						
98	495800	Kit—Idle Speed (Walbro)						
98A	695408	Kit—Idle Speed (Nikki)						
104	●690525	Pin—Float Hinge (Walbro)						
104A	●694918	Pin—Float Hinge (Nikki)						
105	●231855	Valve—Float Needle (Walbro)						
105A	●696136	Valve—Float Needle (Nikki)						

★ Included in Engine Gasket Set—Ref. No.358.

● Included in Carburetor Overhaul Kit—Ref. No. 121 or 121A.

◆ Included in Carburetor Gasket Set—Ref. No. 977 or 977A.

△ Included in Valve Gasket Set—Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
5069–11 Assemblies include all parts shown in frames. **12/09/2004**

21A900

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
131A	698776	Kit-Throttle Shaft (Nikki)	187	699331	Line-Fuel (Formed)(Cut To Required Length) Used on Type No(s). 0113, 0115, 0121, 0122, 0123, 0124, 0125, 0128, 0131, 0133, 0137, 0139, 0140, 0141, 0142, 0143, 0144, 0145, 0146, 0147, 0149, 0150, 0151, 0152, 0153, 0154, 0155, 0157, 0158, 0159, 0161, 0162, 0165, 0167, 0169, 0170, 0171, 0172, 0173.	192	691986	Adjuster-Rocker Arm
133	494381	Float-Carburetor (Walbro)				202	691841	Link-Mechanical Governor
133A	694914	Float-Carburetor (Nikki)				209	691789	Spring-Governor Used on Type No(s). 0115, 0117, 0119, 0120, 0121, 0124, 0127, 0128, 0129, 0131, 0134, 0136, 0138, 0139, 0140, 0141, 0142, 0143, 0144, 0145, 0147, 0149, 0153, 0154, 0159, 0162, 0164, 0165, 0166, 0168, 0172, 0173, 0176.
135A	698780	Tube-Fuel Transfer (Nikki)						----- Note -----
137	♦♦281165	Gasket-Float Bowl (Walbro)						692208
137A	♦♦698781	Gasket-Float Bowl (Nikki)	187A	699332	Line-Fuel (Formed)(Cut To Required Length) Used on Type No(s). 0119, 0120, 0134, 0136, 0138, 0168, 0176.			Spring-Governor Used on Type No(s). 0123, 0125, 0137, 0146, 0152, 0155, 0158, 0169.
141	699027	Kit-Choke Shaft (Walbro)						690480
		----- Note ----- 699027 Kit-Choke Shaft (Walbro) (Used After Code Date 03121600) Used on Type No(s). 0142.	187B	691050	Line-Fuel (Cut To Required Length) Used on Type No(s). 0141, 0154, 0159, 0161, 0171.			Spring-Governor Used on Type No(s). 0122, 0133, 0156, 0157, 0170.
141A	698778	Kit-Choke Shaft (Nikki)						691795
141B	699316	Kit-Choke Shaft (Walbro) (Used Before Code Date 03121500) Used on Type No(s). 0142.						Spring-Governor Used on Type No(s). 0113, 0171.
142	♦790025	Nozzle-Carburetor (Standard)(Walbro)						690576
143	790028	Nozzle-Carburetor (High Altitude)(Walbro)						Spring-Governor Used on Type No(s). 0150, 0151.
146	691639	Key-Timing	187C	697907	Line-Fuel (Formed) Used on Type No(s). 0141, 0154, 0159, 0161.	216	691840	Link-Choke
186	698174	Connector-Hose (Straight)				222	694042	Bracket-Control
		----- Note ----- 692317 Connector-Hose (90 Degree)	187D	699883	Line-Fuel (Formed) Used on Type No(s). 0171.	227	691374	Lever-Governor Control
			188	691693	Screw (Control Bracket)	231	691636	Screw (Choke Valve)
			190	790931	Screw (Fuel Tank)	232	691842	Spring-Governor Link
						238	691843	Cap-Valve
						239	491657	Switch-Oil Pressure Used on Type No(s). 0115, 0119, 0121, 0122, 0129, 0172, 0173, 0176.

★ Included in Engine Gasket Set-Ref. No.358.

● Included in Carburetor Overhaul Kit-Ref. No. 121 or 121A.

♦ Included in Carburetor Gasket Set-Ref. No. 977 or 977A.

△ Included in Valve Gasket Set-Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

5069-12

Assemblies include all parts shown in frames.

12/09/2004

21A900

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
240	298090	Filter–Fuel (Red, 150 Microns) Used on Type No(s). 0129. ----- Note ----- 394358 Filter–Fuel (White, 75 Microns) Used on Type No(s). 0113, 0117, 0119, 0120, 0123, 0124, 0125, 0127, 0128, 0131, 0134, 0136, 0138, 0146, 0152, 0155, 0158, 0167, 0168, 0169, 0171, 0172, 0176.	271	691028	Lever–Control	304	698473	Housing–Blower (Black) Used on Type No(s). 0119, 0120, 0123, 0124, 0125, 0127, 0128, 0129, 0131, 0133, 0134, 0136, 0137, 0138, 0139, 0140, 0142, 0143, 0153, 0164, 0166, 0168, 0169, 0170, 0173, 0176. ----- Note ----- 699085
240A	691035	Filter–Fuel (Clear, 40 Microns) Used on Type No(s). 0115, 0121, 0122, 0133, 0137, 0139, 0140, 0141, 0142, 0143, 0144, 0145, 0147, 0149, 0150, 0151, 0153, 0154, 0157, 0159, 0161, 0162, 0164, 0165, 0166, 0170, 0173.	276	692255	Washer–Sealing			Housing–Blower (Red) Used on Type No(s). 0113, 0115, 0117, 0121, 0122, 0141, 0144, 0145, 0146, 0147, 0149, 0150, 0151, 0152, 0154, 0155, 0156, 0157, 0158, 0159, 0161, 0162, 0172.
261	697176	Screw (Control Slide) Used on Type No(s). 0139, 0140, 0142, 0166.	300	697048	Muffler (Lo Tone) Used on Type No(s). 0117, 0119, 0120, 0134, 0139, 0140, 0141, 0143, 0144, 0145, 0147, 0149, 0150, 0151, 0153, 0154, 0159, 0161, 0162, 0164, 0165, 0166, 0168, 0172, 0176.	305	697102	Screw (Blower Housing)
265	691024	Clamp–Casing	300A	697349	Muffler (Lo Tone) Used on Type No(s). 0115, 0133, 0136, 0137, 0138, 0142, 0157, 0170, 0171.	305A	697103	Screw (Blower Housing)
267	690804	Screw (Casing Clamp)	300B	498984	Muffler (Super Lo Tone) Used on Type No(s). 0121, 0122.	306	697359	Shield–Cylinder
267A	695134	Screw (Casing Clamp) Used on Type No(s). 0170.				307	691003	Screw (Cylinder Shield)
268	691025	Casing–Control Wire (Cut To Required Length)				309	693551	Motor–Starter Used on Type No(s). 0113, 0115, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0128, 0129, 0131, 0133, 0137, 0140, 0143, 0145, 0146, 0147, 0150, 0152, 0153, 0154, 0155, 0156, 0157, 0158, 0159, 0162, 0164, 0165, 0169, 0172, 0173, 0176.
269	691026	Wire–Control (Cut To Required Length)				310	690323	Screw (Starter Motor)
270	691027	Nut (Control Wire Casing)						

★ Included in Engine Gasket Set–Ref. No.358.

● Included in Carburetor Overhaul Kit–Ref. No. 121 or 121A.

◆ Included in Carburetor Gasket Set–Ref. No. 977 or 977A.

△ Included in Valve Gasket Set–Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
5069–13 Assemblies include all parts shown in frames. **12/09/2004**

21A900

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
311	497608	Brush Set	383	89838	Wrench—Spark Plug	415	690283	Plug (Sump)
333	492341	Armature—Magneto	385	694476	Screw (Fuel Pump)			Used on Type No(s). 0115, 0119, 0121, 0122, 0129, 0156, 0157, 0172, 0173.
334	691061	Screw (Magneto Armature)			Used on Type No(s). 0115, 0121, 0122, 0133, 0137, 0139, 0140, 0141, 0142, 0143, 0144, 0145, 0147, 0149, 0150, 0151, 0153, 0154, 0157, 0159, 0161, 0162, 0165, 0170, 0172, 0173.	431	697122	Elbow—Intake
337	491055	Plug—Spark				445	698413	Filter—Air Cleaner Cartridge (Non Washable)
		----- Note -----				455	695113	Cup—Flywheel
		691043 Plug—Spark						Used on Type No(s). 0115, 0117, 0123, 0124, 0127, 0133, 0136, 0138, 0139, 0141, 0142, 0144, 0145, 0147, 0149, 0150, 0151, 0153, 0157, 0159, 0161, 0170, 0171, 0176.
		Used on Type No(s). 0113, 0121, 0122, 0131, 0146, 0152, 0155, 0156, 0157, 0158, 0167, 0169, 0171, 0172, 0173.				456	695128	Plate—Pawl Friction
356	697397	Wire—Stop	385A	690297	Screw (Fuel Pump)	459	281505	Pawl—Ratchet
		Used on Type No(s). 0115, 0117, 0121, 0122, 0129, 0131, 0136, 0143, 0152, 0153, 0155, 0158, 0162, 0165, 0171, 0172, 0173.			Used on Type No(s). 0115, 0121, 0122, 0133, 0137, 0139, 0140, 0141, 0142, 0143, 0144, 0145, 0147, 0149, 0150, 0151, 0153, 0154, 0157, 0159, 0161, 0162, 0165, 0170, 0172, 0173.	474A	696578	Alternator (DC Only)
		----- Note -----						Used on Type No(s). 0140, 0143, 0145, 0162.
		690807 Wire—Stop				474B	696459	Alternator (Dual Circuit)
		Used on Type No(s). 0169.	387	697090	Pump—Fuel (Includes Mounting Bracket)			Used on Type No(s). 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0128, 0131, 0147, 0150, 0152, 0153, 0155, 0158, 0159, 0169, 0172, 0173.
356A	398808	Wire—Stop			Used on Type No(s). 0115, 0121, 0122, 0133, 0137, 0139, 0140, 0141, 0142, 0143, 0144, 0145, 0147, 0149, 0150, 0151, 0153, 0154, 0157, 0159, 0161, 0162, 0165, 0170, 0172, 0173.	474C	696457	Alternator (5 To 9 Amp Regulated)
		Used on Type No(s). 0119, 0120, 0123, 0124, 0125, 0127, 0128, 0134, 0138, 0139, 0140, 0141, 0142, 0144, 0145, 0146, 0147, 0149, 0150, 0151, 0154, 0156, 0157, 0159, 0161, 0168, 0176.	387A	808656	Pump—Fuel			Used on Type No(s). 0113, 0129, 0133, 0137, 0146, 0154, 0156, 0157, 0167, 0176.
356B	697089	Wire—Stop			Used on Type No(s). 0115, 0121, 0122, 0133, 0137, 0139, 0140, 0141, 0142, 0143, 0145, 0147, 0149, 0150, 0151, 0153, 0154, 0157, 0159, 0161, 0162, 0165, 0170, 0172, 0173.	474D	696458	Alternator (10 To 16 Amp Regulated)
		Used on Type No(s). 0113, 0115, 0129, 0133, 0137, 0146, 0154, 0156, 0157, 0165, 0167, 0176.						Used on Type No(s). 0115, 0165.
356C	399222	Wire—Stop						
		Used on Type No(s). 0139, 0140, 0142.						
357	691483	Key—Drive Pulley						
		Used on Type No(s). 0156, 0171.						
358	697151	Gasket Set—Engine						
359	691077	Washer (Ground Terminal)						
363	19203	Puller—Flywheel						
373	691612	Nut (Ground Terminal)	404	691691	Washer (Governor Crank)			

★ Included in Engine Gasket Set—Ref. No. 358.

● Included in Carburetor Overhaul Kit—Ref. No. 121 or 121A.

◆ Included in Carburetor Gasket Set—Ref. No. 977 or 977A.

△ Included in Valve Gasket Set—Ref. No. 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

5069-14

Assemblies include all parts shown in frames.

12/09/2004

21A900

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
501	691185	Regulator (10–16 Amp Regulated) Used on Type No(s). 0115, 0165.	523	699908	Dipstick	608	695058	Starter–Rewind Used on Type No(s). 0115, 0117, 0123, 0124, 0127, 0134, 0136, 0138, 0139, 0141, 0142, 0144, 0145, 0147, 0149, 0150, 0151, 0153, 0157, 0159, 0161, 0170, 0171, 0176.
501A	691188	Regulator (5 To 9 Amp Regulated) Used on Type No(s). 0113, 0129, 0133, 0137, 0146, 0154, 0156, 0157, 0161, 0167.			----- Note ----- 697085 Tube–Dipstick Used on Type No(s). 0115, 0121, 0122, 0133, 0137, 0139, 0140, 0141, 0142, 0143, 0144, 0145, 0147, 0149, 0150, 0151, 0153, 0154, 0157, 0159, 0161, 0162, 0165, 0170, 0172, 0173.	613	691416	Screw (Muffler)
		----- Note ----- 698315 Regulator (5 To 9 Amp Regulated) Used on Type No(s). 0176.	526	697348	Screw (Regulator)(10 To 16 Amp Regulated)	613A	691678	Screw (Muffler)
501C	790292	Regulator (Dual Circuit) Used on Type No(s). 0147, 0150.	526A	697088	Screw (Regulator)(5 To 9 Amp Regulated)	613B	690297	Screw (Muffler) Used on Type No(s). 0115, 0133, 0136, 0137, 0138, 0142, 0157, 0170, 0171.
505	691251	Nut (Governor Control Lever)	544	692034	Armature–Starter	614	691620	Pin–Cotter
507	691972	Insulator Used on Type No(s). 0119, 0120, 0123, 0124, 0125, 0127, 0128, 0134, 0138, 0139, 0140, 0141, 0142, 0144, 0145, 0146, 0147, 0149, 0150, 0151, 0154, 0156, 0157, 0159, 0161, 0168, 0176.	552	697144	Bushing–Governor Crank	616	692012	Crank–Governor
510	693699	Drive–Starter	559	697561	Screw (Remote Choke Stop) Used on Type No(s). 0142, 0166, 0170.	617	★692138	Seal–O Ring (Intake Manifold)
513	692024	Clutch–Drive	559A	693675	Screw (Remote Choke Stop) Used on Type No(s). 0170.	621	692310	Switch–Stop Used on Type No(s). 0119, 0120, 0134, 0138, 0139, 0140, 0141, 0142, 0144, 0145, 0147, 0149, 0150, 0151, 0154, 0156, 0157, 0159, 0161, 0168, 0176.
520	691084	Terminal–Ground Used on Type No(s). 0119, 0120, 0123, 0124, 0125, 0127, 0128, 0134, 0138, 0139, 0140, 0141, 0142, 0144, 0145, 0146, 0147, 0149, 0150, 0151, 0154, 0156, 0157, 0159, 0161, 0168, 0176.	562	691119	Bolt (Governor Control Lever)	633	691326	Seal–Choke/Throttle Shaft Used on Type No(s). 0142.
			578	692306	Wire Assembly	634	●690802	Spring/Seal Assembly
			579	691029	Nut (Starter Cable)	634A	●698779	Spring/Seal Assembly (Nikki)
			584	697112	Cover–Breather Passage	635	691909	Boot–Spark Plug
			597	691696	Screw (Pawl Friction Plate)	643	697155	Retainer–Air Filter
			601	95162	Clamp–Hose (Zinc Plate)(Spring Wire) ----- Note ----- 691038 Clamp–Hose (Black)(Spring Steel) Used on Type No(s). 0141, 0144, 0146, 0154, 0159, 0161.	654	690958	Nut (Carburetor)
521	690581	Shield–Cable Used on Type No(s). 0121, 0122, 0123, 0124, 0125, 0127, 0128, 0172.						

★ Included in Engine Gasket Set–Ref. No.358.

● Included in Carburetor Overhaul Kit–Ref. No. 121 or 121A.

◆ Included in Carburetor Gasket Set–Ref. No. 977 or 977A.

△ Included in Valve Gasket Set–Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

5069–15

Assemblies include all parts shown in frames.

12/09/2004

21A900

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
676	393761	Deflector-Muffler (Side Out) Used on Type No(s). 0115, 0117, 0120, 0121, 0122, 0134, 0136, 0137, 0138, 0139, 0140, 0141, 0142, 0144, 0145, 0147, 0149, 0150, 0151, 0153, 0154, 0157, 0159, 0161, 0162, 0168, 0172, 0173.	801	691283	Cap-Drive	877A	393814	Wire/Connector- Alternator (DC Only) Used on Type No(s). 0140, 0143, 0145, 0162.
677	690661	Screw (Muffler Deflector)	802	691286	Cap-End	877B	393537	Wire/Connector- Alternator (5 To 9 Amp Regulated) Used on Type No(s). 0113, 0129, 0133, 0137, 0146, 0154, 0156, 0157, 0167.
687	697175	Slide-Control Used on Type No(s). 0139, 0140, 0142.	803	693757	Housing-Starter	877C	399916	Wire/Connector- Alternator (10 To 16 Amp Regulated) Used on Type No(s). 0115.
688	690395	Cap-Friction Used on Type No(s). 0139, 0140, 0142.	823	698941	Screw (Muffler Adapter)	878	691237	Harness-Alternator Used on Type No(s). 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0128, 0131, 0147, 0150, 0152, 0153, 0155, 0158, 0159, 0169, 0172, 0173, 0176.
689	691855	Spring-Friction	830	691095	Stud-Rocker Arm	883	★692236	Gasket-Exhaust
689A	690529	Spring-Friction Used on Type No(s). 0139, 0140, 0142.	832	790293	Guard-Muffler Used on Type No(s). 0147, 0149, 0150, 0151.	884	691956	Clamp-Muffler Used on Type No(s). 0121, 0122, 0173.
691	★692407	Seal-Governor Shaft	842	★691031	Seal-O Ring (Dipstick Tube)	914	691108	Screw (Rocker Cover)
692	691301	Spring-Detent	843	697158	Sleeve-Lever Used on Type No(s). 0142.	918	697091	Hose-Vacuum (Molded) Used on Type No(s). 0115, 0121, 0122, 0133, 0137, 0139, 0140, 0141, 0142, 0143, 0144, 0145, 0147, 0149, 0150, 0151, 0153, 0154, 0157, 0159, 0161, 0162, 0165, 0170, 0172, 0173.
697	690372	Screw (Drive Cap)	847	790442	Dipstick/Tube Assembly ----- Note ----- 790443 Dipstick/Tube Assembly Used on Type No(s). 0115, 0121, 0122, 0133, 0137, 0139, 0141, 0142, 0143, 0144, 0145, 0147, 0149, 0150, 0151, 0165, 0170, 0172, 0173.	920	691656	Solenoid-Starter Used on Type No(s). 0147, 0150, 0172.
705	790561	Nut (Fuel Tank)	851	692424	Terminal-Spark Plug	943	★690589	Seal-O Ring (Oil Pump Cover)
718	690959	Pin-Locating	864	697346	Adapter-Muffler Used on Type No(s). 0115, 0117, 0119, 0120, 0121, 0122, 0129, 0133, 0134, 0136, 0137, 0138, 0139, 0140, 0141, 0142, 0143, 0144, 0145, 0147, 0149, 0150, 0151, 0153, 0154, 0157, 0159, 0161, 0162, 0165, 0168, 0170, 0171, 0172, 0173, 0176.	950	691657	Screw-Float Bowl (Bottom Of Bowl)
729	691335	Clip-Wire (Wire Retainer)	868	★△690968	Seal-Valve			
729A	691224	Clip-Wire (Starter Motor)	877	393456	Wire/Connector- alternator (Dual Circuit) Used on Type No(s). 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0128, 0131, 0147, 0150, 0152, 0153, 0155, 0158, 0159, 0169, 0172, 0173, 0176.			
729B	694123	Clip-Wire (Regulator) Used on Type No(s). 0113, 0115, 0129, 0133, 0137, 0146, 0154, 0156, 0157, 0165, 0167, 0176.						
741	697128	Gear-Timing						
750	691033	Screw (Oil Pump Cover)						
757	697607	Link-Counterweight						
758	697391	Counterweight						
783	693713	Gear-Pinion						
789	698329	Harness-Wiring Used on Type No(s). 0113, 0133, 0137, 0167.						
797	693167	Nut (Brush Retainer)						

★ Included in Engine Gasket Set-Ref. No.358.

● Included in Carburetor Overhaul Kit-Ref. No. 121 or 121A.

◆ Included in Carburetor Gasket Set-Ref. No. 977 or 977A.

△ Included in Valve Gasket Set-Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

5069-16

Assemblies include all parts shown in frames.

12/09/2004

21A900

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
957	694261	Cap–Fuel Tank (Plastic) Used on Type No(s). 0139, 0140, 0141, 0142, 0144, 0145, 0147, 0149, 0150, 0151, 0154, 0159, 0161, 0162.	1005	699044	Fan–Flywheel (Used After Code Date 03031600) ----- Note ----- 697360 Fan–Flywheel (Used Before Code Date 03031700)	1090	691293	Retainer–Brush
958	698183	Valve–Fuel Shut Off (Plastic) Used on Type No(s). 0141, 0144, 0146, 0154, 0157, 0159, 0161, 0167, 0171, 0172.	1017	690770	Screen–Oil Pump	1091	691333	Cap–Limiter
965	499613	Cover–Oil Pump	1019	699196	Kit–Label ----- Note ----- 695442 Kit–Label	1095	691581	Gasket Set–Valve
967	697292	Filter–Pre Cleaner	1022	★Δ272475	Gasket–Rocker Cover	1119	691183	Screw (Alternator)
968	697420	Cover–Air Cleaner (Black) Used on Type No(s). 0113, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0127, 0128, 0129, 0131, 0133, 0134, 0136, 0137, 0138, 0139, 0140, 0142, 0143, 0145, 0146, 0152, 0153, 0155, 0158, 0162, 0168, 0169, 0170, 0172, 0176. ----- Note ----- 697422 Cover–Air Cleaner (Red) Used on Type No(s). 0115, 0117, 0141, 0144, 0147, 0149, 0150, 0151, 0154, 0156, 0157, 0159, 0161, 0173.	1023	692492	Cover–Rocker	1127	695407	Screw (Float Bowl)
			1024	499054	Pump–Oil	1136	690278	Screw (Control Bracket)(High Speed Control) Used on Type No(s). 0139, 0140, 0142.
			1026	697395	Rod–Push ----- Note ----- 697394 Rod–Push (Intake)	1263	697124	Reed–Breather
			1027	492932	Filter–Oil	1264	697104	Screw (Breather Reed)
			1029	691751	Arm–Rocker	1266	★●691917	Seal–O Ring (Intake Elbow)
			1032	491710	Ball–Oil Pump	1266A	★●697123	Seal–O Ring (Intake Elbow)
			1034	690822	Guide–Push Rod	1267	697424	Latch–Blower Housing (Red) Used on Type No(s). 0115, 0117, 0141, 0144, 0147, 0149, 0150, 0151, 0154, 0156, 0157, 0159, 0161, 0173. ----- Note ----- 697419 Latch–Blower Housing (Black) Used on Type No(s). 0113, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0127, 0128, 0129, 0131, 0133, 0134, 0136, 0137, 0138, 0139, 0140, 0142, 0143, 0145, 0146, 0152, 0153, 0155, 0158, 0162, 0165, 0168, 0169, 0170, 0172, 0176.
			1035	693784	Shaft–Pump			
			1036	790465	Label–Emissions (Used After Code Date 04063000) ----- Note ----- 790186 Label–Emissions (Used After Code Date 03123100 and Before Code Date 04070100). 697221 Label–Emissions (Used Before Code Date 04010100)	1270	697156	Plug–AVS Counterweight
			1040	698368	Plate–Trim Used on Type No(s). 0113, 0121, 0122, 0133, 0137, 0140, 0143, 0146, 0152, 0155, 0158, 0169, 0172, 0173.	1330	272147	Repair Manual
972	699710	Tank–Fuel (Plastic)	1040A	697381	Plate–Trim Used on Type No(s). 0119, 0120, 0129, 0131, 0154, 0156, 0176.	1397	791219	Washer (Blower Housing)
975	495933	Bowl–Float (Walbro)						
975A	698783	Bowl–Float (Nikki)	1044	698139	Screw (Flywheel)			
977	690192	Gasket Set–Carburetor	1051	691265	Ring–Retaining			
977A	790032	Gasket Set–Carburetor (Nikki)	1054	280275	Tie–Cable			
987	●691326	Seal–Throttle Shaft	1058	275935	Operator's Manual			
987A	●698777	Seal–Throttle Shaft (Nikki)	1070	690372	Screw (Flywheel Fan)			

★ Included in Engine Gasket Set–Ref. No.358.

● Included in Carburetor Overhaul Kit–Ref. No. 121 or 121A.

◆ Included in Carburetor Gasket Set–Ref. No. 977 or 977A.

Δ Included in Valve Gasket Set–Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
5069–17 Assemblies include all parts shown in frames. **12/09/2004**