



28CH00

Illustrated Parts List

Model Series

28CH00

TYPE NUMBERS
0036, 0110, 0111, 0112.

TABLE OF CONTENTS


Air Cleaner	5
Alternator	7
Blower Housing	5
Camshaft	2
Carburetor	4
Controls	7
Crankshaft	2
Cylinder	2
Cylinder Head	3
Electric Starter	7
Engine Sump	2
Exhaust System	5
Flywheel	6
Fuel Supply	4
Gasket Set - Engine	2
Gasket Set - Valve	3
Governor Spring	7
Ignition	7
Intake Manifold	3
Kit - Carburetor Overhaul.	4
Lubrication	3
Piston, Rings, Connecting Rod	2
Rewind Starter	6
Valves	3

PRINTED IN U.S.A.




COPYRIGHT by BRIGGS & STRATTON CORPORATION
All rights reserved. No part of this material may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permission in writing from Briggs & Stratton Corporation.

28CH00














Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine. 5330-2 Assemblies include all parts shown in frames. 12/05/2005




Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
 5330-3 Assemblies include all parts shown in frames. 12/05/2005





28CH00




Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.





1036 EMISSION LABEL







28CH00





NOTE: All stators use a No. 1119 mounting screw. 

NOTE: The proper flywheel part number and/or the alternator magnet size will determine the alternator type or output. See repair instruction manual for additional information.



Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
 5330-7 Assemblies include all parts shown in frames. 12/05/2005

28CH00

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	697132	Cylinder Assembly	26	792308	Ring Set (Standard) (Used After Code Date 05102900).	37	697108	Guard-Flywheel Used on Type No(s). 0036, 0110, 0112.
2	399265	Kit-Bushing/Seal (Magneto Side)						----- Note -----
3	★391086S	Seal-Oil (Magneto Side)						697352
4A	697188	Sump-Engine						Guard-Flywheel Used on Type No(s). 0111.
5	698404	Head-Cylinder						
7	★Δ273280S	Gasket-Cylinder Head						
9	★697109	Gasket-Breather				42	499586	Keeper-Valve
10	697157	Screw (Breather Assembly)				43	691968	Slinger-Governor/Oil
11	697113	Tube-Breather				45	690564	Tappet-Valve
12	★697110	Gasket-Crankcase				46	790400	Camshaft
13	690360	Screw (Cylinder Head)				50	690193	Manifold-Intake
15	690946	Plug-Oil Drain				51	★Δ●692137	Gasket-Intake
16	697516	Crankshaft				53	690227	Stud (Carburetor)
20	★690947	Seal-Oil (PTO Side)				54	691148	Screw (Intake Manifold)
22	692125	Screw (Crankcase Cover/Sump)	27	698469	Lock-Piston Pin	55	695130	Housing-Rewind Starter
23	693556	Flywheel Used on Type No(s). 0036, 0110, 0112. ----- Note ----- 693557 Flywheel Used on Type No(s). 0111.	28	697099	Pin-Piston	56	695129	Pulley-Starter
24	222698S	Key-Flywheel	29	791632	Rod-Connecting (Standard) (Used After Code Date 05040300). ----- Note ----- 697518 Rod- Connecting (Standard) (Used Before Code Date 05040400).	57	695131	Spring-Rewind Starter
25	792307	Piston Assembly (Standard) (Used After Code Date 05102900). ----- Note ----- 698390 Piston Assembly (Standard) (Used Before Code Date 05103100). 698394 Piston Assembly (.020" Oversize) (Used Before Code Date 05103000).				58	695132	Rope-Starter
						60	494212	Grip-Starter Rope
						65	697725	Screw (Rewind Starter)
						73A	494439	Screen-Rotating Used on Type No(s). 0110, 0112.
						74	691674	Screw (Rotating Screen)
						78	691003	Screw (Flywheel Guard)
						81	691178	Lock-Muffler Screw
						93	●690602	Bushing-Throttle Shaft
						94	498030	Kit-Idle Mixture
						94A	695425	Kit-Idle Mixture
						95	●691636	Screw (Throttle Valve)
						95A	●690718	Screw (Throttle Valve)

★ Included in Engine Gasket Set-Ref. No.358.

● Included in Carburetor Overhaul Kit-Ref. No. 121 or 121A.

● Included in Carburetor Gasket Set-Ref. No. 977.

Δ Included in Valve Gasket Set-Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

5330-8

Assemblies include all parts shown in frames.

12/05/2005

28CH00

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
98	495800	Kit-Idle Speed	141B	698778	Kit-Choke Shaft	271	691028	Lever-Control
98A	695408	Kit-Idle Speed	142	●697140	Nozzle-Carburetor (Standard)	276	●692255	Washer-Sealing
104	●690525	Pin-Float Hinge	146	691639	Key-Timing	276A	695410	Washer-Sealing
104A	●694918	Pin-Float Hinge	187	791766	Line-Fuel (Cut To Required Length)	300	697349	Muffler Used on Type No(s). 0036, 0112.
105	●231855S	Valve-Float Needle	187B	791805	Line-Fuel (Formed)(10-1/4 Inches Long)(Cut to Required Length) Used on Type No(s). 0036.	300A	698356	Muffler Used on Type No(s). 0111.
105A	●696136	Valve-Float Needle	188	691693	Screw (Control Bracket)	304	790009	Housing-Blower (Black) Used on Type No(s). 0036, 0110, 0112.
106	●690577	Seat-Inlet (Gravity Feed)	192	691986	Adjuster-Rocker Arm	----- Note -----		
		----- Note -----	202	691841	Link-Mechanical Governor	699704		
		●691780 Seat-Inlet (Pump Feed)	209	692208	Spring-Governor (Green)	Housing-Blower (Black) Used on Type No(s). 0111.		
108	690464	Valve-Choke (Walbro Carburetor Part No. 697204)	216	691840	Link-Choke	305	697102	Screw (Blower Housing)
108A	692344	Valve-Choke (CARBURETOR PART NUMBERS 696179, 696181, 697202, 697203, 697206)	222	694042	Bracket-Control	305A	697103	Screw (Blower Housing)
108B	695419	Valve-Choke	227	691374	Lever-Governor Control	306	697107	Shield-Cylinder
117	●694352	Jet-Main (Standard)	232	691842	Spring-Governor Link	307	691003	Screw (Cylinder Shield)
117A	●699457	Jet-Main (Standard)	238	691843	Cap-Valve	309	693551	Motor-Starter
118	697228	Jet-Main (High Altitude)	240	394358S	Filter-Fuel (White, 75 Microns) Used on Type No(s). 0110, 0111.	310	690323	Screw (Starter Motor)
118A	699458	Jet-Main (High Altitude)	240B	695666	Filter-Fuel (Includes 30 Micron Paper Element) Used on Type No(s). 0036, 0112.	311	497608	Brush Set
121	697241	Kit-Carburetor Overhaul	265	691024	Clamp-Casing	333	492341	Armature-Magneto
121A	699521	Kit-Carburetor Overhaul (Nikki Carburetor)	267	690804	Screw (Casing Clamp)	334	691061	Screw (Magneto Armature)
125	698445	Carburetor (Gravity Feed)	268	691025	Casing-Control Wire (Cut To Required Length)	337	491055S	Plug-Spark
127	695005	Plug-Welch	269	691026	Wire-Control (Cut To Required Length)	356	697089	Wire-Stop
127A	●690727	Plug-Welch	270	●691027	Nut (Control Wire Casing)	358	697151	Gasket Set-Engine
130	691750	Valve-Throttle				363	19203	Puller-Flywheel
130A	699500	Valve-Throttle				383	89838S	Wrench-Spark Plug
131	494379	Kit-Throttle Shaft				385	694476	Screw (Fuel Pump)
131A	699501	Kit-Throttle Shaft				385A	690297	Screw (Fuel Pump)
133	494381	Float-Carburetor				387	697090	Pump-Fuel (Includes Mounting Bracket)
133A	694914	Float-Carburetor				387A	808656	Pump-Fuel
135	698780	Tube-Fuel Transfer				404	691691	Washer (Governor Crank)
137●●281165S		Gasket-Float Bowl				415	690283	Plug (Square Head)
137A	●698781	Gasket-Float Bowl				431	697122	Elbow-Intake
141	495097	Kit-Choke Shaft (CARBURETOR PART NO. 697204)				445	697153	Filter-Air Cleaner Cartridge (Washable)
141A	495931	Kit-Choke Shaft (CARBURETOR PART NUMBERS 696179, 696181, 697202, 697203, 697206)						

★ Included in Engine Gasket Set-Ref. No.358.

● Included in Carburetor Overhaul Kit-Ref. No. 121, or 121A.

◆ Included in Carburetor Gasket Set-Ref. No. 977.

△ Included in Valve Gasket Set-Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

28CH00

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
455	695113	Cup-Flywheel	613B	691678	Screw (Muffler)	847	790443	Dipstick/Tube Assembly
456	695128	Plate-Pawl Friction	614	691620	Pin-Cotter			Used on Type No(s). 0036, 0112.
459	281505S	Pawl-Ratchet	616	692012	Crank-Governor			----- Note -----
462	691261	Washer (Starter Cable)	617	★692138	Seal-O Ring (Intake Manifold)			790442 Dipstick/Tube Assembly
474	696578	Alternator (DC Only) Used on Type No(s). 0111.	634	●690801	Spring/Seal Assembly (CARBURETOR PART NO. 697204)			Used on Type No(s). 0110, 0111.
474B	696457	Alternator (Tri Circuit) Used on Type No(s). 0036, 0110, 0112.	634A	●690802	Spring/Seal Assembly (CARBURETOR PART NUMBERS 696179, 696181, 697202, 697203, 697206)	851	692424	Terminal-Spark Plug
493	695450	Bracket-Mounting	634B	●698779	Spring/Seal Assembly	864	697346	Adapter-Muffler
501	691188	Regulator Used on Type No(s). 0036, 0110, 0112.	635	691909	Boot-Spark Plug	868	★△690968	Seal-Valve
503	691532	Strap-Starter	643	698401	Retainer-Air Filter	877A	393814	Wire/Connector-Alternator
505	691251	Nut (Governor Control Lever)	654	690958	Nut (Carburetor)	877B	393537	Wire/Connector-Alternator
510	693699	Drive-Starter	668	691500	Spacer	878A	691955	Harness-Alternator
513	692024	Clutch-Drive	676	393761	Deflector-Muffler	883	★692236	Gasket-Exhaust
523	699908	Dipstick	677	690661	Screw (Muffler Deflector)	914	691108	Screw (Rocker Cover)
524	★691032	Seal-Dipstick Tube	689	691855	Spring-Friction	918	791851	Hose-Vacuum Used on Type No(s). 0036, 0112.
525	697085	Tube-Dipstick Used on Type No(s). 0036, 0112.	691	★692407	Seal-Governor Shaft	943	★690589	Seal-O Ring (Oil Pump Cover)
		----- Note -----	692	690572	Spring-Detent	947	694393	Solenoid-Fuel
		697184 Tube-Dipstick Used on Type No(s). 0110, 0111.	697	690372	Screw (Drive Cap)	947A	699915	Solenoid-Fuel
526	697088	Screw (Regulator)	718	690959	Pin-Locating	949	697729	Guard-Debris Screen Used on Type No(s). 0036.
544	692034	Armature-Starter	729	691335	Clip-Wire (Wire Saddle)	949A	695448	Guard-Debris Screen
552	697144	Bushing-Governor Crank	729A	691224	Clip-Wire (Aluminum Coated Steel)	950	695407	Screw-Float Bowl (Bottom Of Bowl)
559	697561	Screw (Remote Choke Stop)	741	697128	Gear-Timing	965	499613	Cover-Oil Pump
562	691119	Bolt (Governor Control Lever)	750	691033	Screw (Oil Pump Cover)	967	697015	Filter-Pre Cleaner
563	695449	Screw (Debris Screen Guard)	757	697607	Link-Counterweight	968	697574	Cover-Air Cleaner Used on Type No(s). 0036, 0110, 0112.
578	692306	Wire Assembly	758	697134	Counterweight			----- Note -----
579	691029	Nut (Starter Cable)	759	697392	Pin-Counterweight			698403 Cover-Air Cleaner
584	697112	Cover-Breather Passage	783	693713	Gear-Pinion			Used on Type No(s). 0111.
597	691696	Screw (Pawl Friction Plate)	789	692037	Harness-Wiring			
601	791850	Clamp-Hose	797	693167	Nut (Brush Retainer)			
608	695058	Starter-Rewind	801	691283	Cap-Drive			
613	691416	Screw (Muffler)	802	691286	Cap-End			
613A	690297	Screw (Muffler)	803	693757	Housing-Starter			
			823	698941	Screw (Muffler Adapter)			
			830	691095	Stud-Rocker Arm			
			842	★691031	Seal-O Ring (Dipstick Tube)			

★ Included in Engine Gasket Set-Ref. No.358.

● Included in Carburetor Overhaul Kit-Ref. No. 121 or 121A.

● Included in Carburetor Gasket Set-Ref. No. 977.

△ Included in Valve Gasket Set-Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

5330-10

Assemblies include all parts shown in frames.

12/05/2005

28CH00

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
975	495933	Bowl-Float	1027	696854	Filter-Oil	1127	695407	Screw
975A	699502	Bowl-Float	1029	691751	Arm-Rocker			(Float Bowl)
977	690192	Gasket Set-Carburetor	1032	491710	Ball-Oil Pump	1263	697124	Reed-Breather
987	●691326	Seal-Throttle Shaft	1034	690822	Guide-Push Rod	1264	697104	Screw
987A	●698777	Seal-Throttle Shaft	1035	693784	Shaft-Pump			(Breather Reed)
1005	697546	Fan-Flywheel	1036		Label-Emissions	1265	697125	Support-Blower
		Used on Type No(s). 0036.			(Available from an Authorized Briggs & Stratton Service Dealer)			Housing
		----- Note -----	1040A	698470	Plate-Trim	1266	★●691917	Seal-O Ring
		697111 Fan-Flywheel			Used on Type No(s). 0110, 0112.			(Intake Elbow)
		Used on Type No(s). 0110, 0112.				1266A	●697123	Seal-O Ring
		697853 Fan-Flywheel	1044	698139	Screw			(Intake Elbow)
		Used on Type No(s). 0111.			(Flywheel)	1267	697575	Latch-Blower Housing
1017	690770	Screen-Oil Pump	1051	691265	Ring-Retaining			Used on Type No(s). 0036, 0110, 0112.
		(Push In)	1054	280275	Tie-Cable			----- Note -----
1019	698414	Kit-Label	1058	276344	Operator's Manual			697419 Latch-Blower
1022★△272475S		Gasket-Rocker Cover	1059	698516	Kit-Screw/Washer			Housing
1023	791079	Cover-Rocker	1070	690372	Screw			Used on Type No(s). 0111.
		(Used After Code Date 05013100).			(Flywheel Fan)	1270	697156	Plug-AVS
		----- Note -----	1090	691293	Retainer-Brush			Counterweight
		692492 Cover-Rocker	1091	691333	Cap-Limiter	1279	691108	Screw
		(Used Before Code Date 05020100).	1095	691581	Gasket Set-Valve			(Blower Housing
			1119	691183	Screw			Support)
					(Alternator)	1330	272147	Repair Manual
1024	499054	Pump-Oil						
1026	692003	Rod-Push						
		(Intake)						
		----- Note -----						
		692011 Rod-Push						
		(Exhaust)						

★ Included in Engine Gasket Set-Ref. No.358.

● Included in Carburetor Overhaul Kit-Ref. No. 121, or 121A.

◆ Included in Carburetor Gasket Set-Ref. No. 977.

△ Included in Valve Gasket Set-Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.