



541400

Illustrated Parts List

Model Series

541400

TYPE NUMBERS
0110 Through 0114.

TABLE OF CONTENTS

Air Cleaner	7
Alternator	11
Blower Housing	10
Camshaft	2
Carburetor	6
Controls	9
Crankcase Cover	4
Crankshaft	2
Cylinder	2
Cylinder Head/Valves	3
Electric Starter	11
Exhaust System	8
Flywheel	10
Fuel Pump	6
Governor Springs	9
Intake Manifold	4
Kit/Gasket Valve Set	5
Kit/Gasket Engine Set	5
Pistons	2
Valves	3

BRIGGS & STRATTON



PRINTED IN U.S.A.


COPYRIGHT by BRIGGS & STRATTON CORPORATION
All rights reserved. No part of this material may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permission in writing from Briggs & Stratton Corporation.

541400

1058 OPERATOR'S MANUAL

1019 LABEL KIT


1036 LABEL EMISSIONS




276

615


691



616




46



16


741

146




29

32



28


27



25

26

27



1013

1027




1338

1339

239


415

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
3333-2 Assemblies include all parts shown in frames. 11/29/2004





Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
 3333-3 Assemblies include all parts shown in frames. 11/29/2004




541400



Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
3333-4 Assemblies include all parts shown in frames. **11/29/2004**




541400




Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
3333-6 Assemblies include all parts shown in frames. **11/29/2004**

541400




Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
3333-7 Assemblies include all parts shown in frames. **11/29/2004**

541400




Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
3333-8 Assemblies include all parts shown in frames. **11/29/2004**

541400



Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
3333-9 Assemblies include all parts shown in frames. **11/29/2004**

541400



Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
3333-10 Assemblies include all parts shown in frames. 11/29/2004

NOTE: All stators use a No. 1119 mounting screw. 

NOTE: The proper flywheel part number and/or the alternator magnet size will determine the alternator type or output. See repair instruction manual for additional information.

20 AMP

474E

877D



526B


501B




1054





789



789A



1336



703



344



587




527




920

309



1009



334 

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

3333-11

Assemblies include all parts shown in frames.

11/29/2004

541400

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	809971	Cylinder Assembly	35	809374	Spring-Valve (Intake)	121	841548	Kit-Carburetor Overhaul
3	★841596	Seal-Oil (Magnet Side)	36	809374	Spring-Valve (Exhaust)	122	809880	Spacer-Carburetor
5	841666	Head-Cylinder ----- Note ----- 841667 Head-Cylinder	40	807492	Retainer-Valve	125	841109	Carburetor
7	★Δ809730	Gasket-Cylinder Head	45	809785	Tappet-Valve	131	841551	Kit-Throttle Shaft
11	809736	Tube-Breather	46	809879	Camshaft	133	●841545	Float-Carburetor
12	★809727	Gasket-Crankcase	50	841591	Manifold-Intake	135	●841646	Tube-Fuel Transfer
13	809784	Screw (Cylinder Head)	51	★Δ841592	Gasket-Intake	137	●841651	Gasket-Float Bowl
15	807392	Plug-Oil Drain	51A	●★Δ809910	Gasket-Intake	141	841549	Kit-Choke Shaft
16	809982	Crankshaft ----- Note ----- 841529 Crankshaft Used on Type No(s). 0113, 0114.	62	841524	Screw (Speed Adjustor Lever)	142	●841648	Nozzle-Carburetor (Standard)
18	842458	Cover-Crankcase	73	841840	Screen-Rotating	146	691639	Key-Timing
20	★841596	Seal-Oil (PTO Side)	74	809947	Screw (Rotating Screen)	150	●841649	Gasket-Nozzle
21	809895	Cap-Oil Fill	75	691056	Washer (Flywheel)	156	841522	Lever-Speed Adjuster
22	807362	Screw (Crankcase Cover/Sump)	75A	842548	Washer (Flywheel)	161	841851	Base-Air Cleaner (Metal)
23	841998	Flywheel	95	690718	Screw (Throttle Valve)	163	●★807375	Gasket-Air Cleaner
24	222698	Key-Flywheel	98	841842	Kit-Idle Speed	167	841855	Seal-Air Cleaner Nut
25	809790	Piston Assembly ----- Note ----- 841931 Piston Assembly (.020" Oversize)	104	●690882	Pin-Float Hinge	187	791745	Line-Fuel
26	809972	Ring Set ----- Note ----- 841932 Ring Set (.020" Oversize)	105	●698537	Valve-Float Needle	187A	809921	Line-Fuel
27	807351	Lock-Piston Pin	117A	842633	Jet-Main (Standard)	192	807623	Adjuster-Rocker Arm
28	807361	Pin-Piston	117B	842634	Jet-Main (Standard)	197	692539	Screw (Back Plate)
29	809275	Rod-Connecting	118A	842139	Jet-Main (High Altitude) (5000 Ft.)	202	841322	Link-Mechanical Governor
32	807363	Screw (Connecting Rod)			----- Note ----- 842627 Jet-Main (High Altitude) (9000 Ft.)	209	841012	Spring-Governor Used on Type No(s). 0100, 0111, 0112, 0113, 0114.
33	809901	Valve-Exhaust	118B	842629	Jet-Main (High Altitude) (5000 Ft.)	211	809875	Spring-Governed Idle
34	809902	Valve-Intake			----- Note ----- 842585 Jet-Main (High Altitude) (9000 Ft.)	215	809728	Guide-Air (Cylinder 1)
						215A	809737	Guide-Air (Cylinder 2)
						215B	809897	Guide-Air (Cylinder 2)
						215C	809738	Guide-Air (Cylinder 1)
						215D	809739	Guide-Air (Valley)

★ Included in Engine Gasket Set-Ref. No.358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

◆ Included in Carburetor Gasket Set-Ref. No. 977.

Δ Included in Valve Gasket Set-Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

541400

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
216	809788	Link-Choke	300	809983	Muffler	437	809743	Screw
216A	841671	Link-Choke	300A	841530	Muffler			(Exhaust Manifold)
219	809426	Gear-Governor	300B	841680	Muffler	439	692154	Seal-O Ring
220	841608	Washer			(Lo Mount) (Oil Filter Side)			(Crankcase Cover/Sump)
		(Governor Gear)	300C	841836	Muffler	445	841497	Filter-Air Cleaner
221	841026	Cup-Governor	300D	842262	Muffler			Cartridge
222	841492	Bracket-Control			(Lo Mount) (Starter Motor Side)	445A	821136	Filter-Air Cleaner
		Used on Type No(s). 0100, 0113, 0114.	301	841518	Pipe-Exhaust			Cartridge
222A	841527	Bracket-Control	304	809959	Housing-Blower	445B	692519	Filter-Air Cleaner
		Used on Type No(s). 0111, 0112.	309	807383	Motor-Starter			Cartridge
227	809984	Lever-Governor			(DC)(10-16 AMP)	466	841301	Seal-O Ring
		Control	332	807356	Nut			(Breather Assembly)
231	690728	Screw			(Flywheel)	467	841846	Knob-Air Cleaner
		(Choke Valve)	332A	842222	Nut	468	★690690	Seal-O Ring
232	690545	Spring-Governor Link			(Flywheel)			(Oil Pump Screen)
235	841848	Shield-Fuel Spray	333	841279	Armature-Magneto	474E	696579	Alternator
239	841281	Switch-Oil Pressure	334	692066	Screw			(20 Amp)
240	691035	Filter-Fuel			(Magneto Armature)	479	807084	Screw
265	691024	Clamp-Casing	337	491055	Plug-Spark			(Oil Pump Screen)
265A	841673	Clamp-Casing			----- Note -----	500	691086	Washer
		Used on Type No(s). 0100, 0111, 0112, 0113, 0114.			792015 Plug-Spark			(Key Switch)
					Used on Type No(s). 0113, 0114.	501B	691573	Regulator
266	841521	Control-Throttle	344	692539	Screw			(20 Amp)
267	692539	Screw			(Cable Clamp)	506	809957	Screw
		(Casing Clamp)	358	841122	Gasket Set-Engine			(Carburetor Cover)
267A	841672	Screw	363	19203	Puller-Flywheel	523	841007	Dipstick
		(Casing Clamp)	365	807437	Screw			(Standard)
268	691025	Casing-Control Wire			(Carburetor)	526B	691547	Screw
269	691026	Wire-Control	365B	841853	Screw			(Regulator)(20 Amp)
270	691027	Nut			(Carburetor)	527	690423	Clamp-Tube
		(Control Wire Casing)	383	19374	Wrench-Spark Plug	534	692062	Screw
271	692541	Lever-Control	385	809876	Screw			(Air Cleaner)
276	841654	Washer-Sealing			(Fuel Pump)	536	809670	Cleaner-Air
		----- Note -----	387	809669	Pump-Fuel	541	841525	Washer
		809436	415	690283	Plug			(Speed Adjuster Lever)
		Washer-Sealing	431	841539	Elbow-Intake	541A	841526	Washer
		(Governor Control Lever)	431B	841854	Elbow-Intake			(Speed Adjuster Lever)
290	809911	Screw	436B	841681	Manifold-Exhaust	573	809956	Plate-Back
		(Intake Elbow)			(Lo Mount)	580	★△809894	Seal-O Ring
290A	807421	Screw			(Oil Filter Side)			(Oil Fill Cap)
		(Intake Elbow)	436D	842263	Manifold-Exhaust	582	809878	Clamp-Air Cleaner
297	690939	Nut			(Lo Mount)	587	807386	Clamp-Cable
		(Air Filter Retainer)			(Starter Motor Side)	596	691492	Screw
								(Oil Pump)

★ Included in Engine Gasket Set-Ref. No.358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

◆ Included in Carburetor Gasket Set-Ref. No. 977.

△ Included in Valve Gasket Set-Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

3333-13

Assemblies include all parts shown in frames.

11/29/2005

541400

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
601	841499	Clamp-Hose	855	809896	Adapter-Air Cleaner	1027	492932	Filter-Oil
601C	691038	Clamp-Hose	862	841886	Strap/Stud-Air Cleaner			(2 1/4" Long)
607	692539	Screw			Mounting	1029	807323	Arm-Rocker
		(Air Cleaner Brace)	868	★△691963	Seal-Valve	1036		Label-Emissions
613	692062	Screw	871	692057	Bushing-Valve Guide			(Available from an
		(Muffler)	877D	698092	Wire/Connector-			Authorized Briggs &
615	809533	Retainer-Governor			Alternator			Stratton Service
		Shaft	879	809955	Cover-Carburetor			Dealer)
616	809433	Crank-Governor	883	★△809872	Gasket-Exhaust	1054	807340	Tie-Cable
633	●808183	Seal-Choke/Throttle	884	841968	Clamp-Muffler	1058	275723	Operator's Manual
		Shaft	890	809987	Bracket-Support	1070	807435	Screw
635	692076	Boot-Spark Plug	890A	841614	Bracket-Support			(Flywheel Fan)
643	841850	Retainer-Air Filter	892	692318	Switch-Key	1077	809729	Bracket-Lifting
646	841849	Brace-Air Cleaner	906	690707	Spring-Torsion	1095	841123	Gasket Set-Valve
664	691087	Nut	914	807357	Screw	1100	690973	Pivot-Rocker Arm
		(Key Switch)			(Rocker Cover)	1119	691552	Screw
668	841974	Spacer	920	825418	Solenoid-Starter			(Alternator)
672	●841655	Gasket-Carburetor	943	★690681	Seal-O Ring	1123	●841653	Seal-O Ring
		Plate			(Oil Pump Cover)			(Solenoid Retainer)
691	★809287	Seal-Governor Shaft	947	841546	Solenoid-Fuel	1124	●841647	Seal-O Ring
703	★807116	Clip	965	809422	Cover-Oil Pump			(Fuel Transfer Tube)
711	691492	Screw	967	692520	Filter-Pre Cleaner	1126	841619	Screw
		(Carburetor Shield)	968	841847	Cover-Air Cleaner			(Fuel Transfer Tube)
725	841132	Shield-Heat	975	841650	Bowl-Float	1127	841621	Screw
728	692067	Screw	987	●808183	Seal-Throttle Shaft			(Float Bowl)
		(Heat Shield)	990	691959	Key Set	1128	841620	Screw
741	809432	Gear-Timing	1005	809950	Fan-Flywheel			(Carburetor Nozzle)
750	692539	Screw	1006	809999	Retainer-Fan	1130	841590	Stud
		(Oil Pump Cover)	1009	690711	Screw			(Intake Manifold)
789	809906	Harness-Wiring			(Starter Motor)	1169	841620	Screw
789A	809967	Harness-Wiring	1013	809505	Nipple-Oil Filter			(Carburetor Cover
798	691492	Screw	1017	809421	Screen-Oil Pump			Plate)
		(Rocker Arm)	1019	841305	Kit-Label	1174	842067	Nut
806	692062	Screw	1022	★△809732	Gasket-Rocker Cover			(Intake Manifold)
		(Lifting Bracket)	1023	809789	Cover-Rocker	1209	692539	Screw
813	807376	Clamp			(Cylinder 2)			(Speed Control Panel)
832	841682	Guard-Muffler	1023A	809731	Cover-Rocker	1212	809958	Stud
836	692539	Screw			(Cylinder 1)			(Blower Housing)
		(Guard-Muffler)	1024	841291	Pump-Oil	1263	841324	Reed-Breather
843	842745	Sleeve-Lever	1026	809783	Rod-Push	1315	809905	Hose-Air Cleaner
851	493880	Terminal-Spark Plug			(Aluminum)			

★ Included in Engine Gasket Set-Ref. No.358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

◆ Included in Carburetor Gasket Set-Ref. No. 977.

△ Included in Valve Gasket Set-Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

541400

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1328	809907	Cap-A/C Rain	1336	841015	Shield-Wire Protective	1371	841537	Nut
1331	809934	Seal-O Ring (Fuel Pump)	1337	807382	Screw (Air Cleaner Bracket)			(Flywheel Fan Guard)
1332	806647	Washer (Rotating Screen)	1338	809334	Tray-Oil Drip	1372	809946	Stud (Rotating Screen)
1334	807435	Screw (Air Guide)	1339	807435	Screw (Oil Drip Tray)	1375	841550	Cover-Breather Reed
1334A	841233	Screw (Air Guide)	1344	841613	Cable-Choke Used on Type No(s). 0111, 0112.	1376	806421	Screw (Breather/Reed Cover)
1334B	692062	Screw (Air Guide)	1369	841612	Guard-Flywheel Fan	1378	841615	Washer/Nut Set Used on Type No(s). 0111, 0112.
1334C	690677	Screw (Air Guide)	1370	692539	Screw (Flywheel Fan Guard)			
1335	690939	Nut (Blower Housing)						

★ Included in Engine Gasket Set-Ref. No.358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

◆ Included in Carburetor Gasket Set-Ref. No. 977.

△ Included in Valve Gasket Set-Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.**3333-15**

Assemblies include all parts shown in frames.

11/29/2005