

**132200 to 132299**

**SERVICE ENGINE**  **SALES MANUAL**

**MODEL 132200 SERIES ENGINES REPLACED WITH  
 STANDARD SERVICE ENGINES**

In most cases, the Original Type numbers shown may be replaced by a Service Type Number without making any changes. Necessary changes of engine parts such as crankshafts, reduction parts, blower housings, etc., are noted. Other differences, such as mufflers, elbows, deflectors, etc., are not listed but are very important for safety and engine performance. Be sure the exhaust system on the replacement engine duplicates the system originally selected by the equipment manufacturer. Parts that are suitable for additional use should be transferred. Before making any conversion, check the data shown in the column labeled "REMOVE, ADD and NOTE." See if the changes, which are shown, are actually necessary on the application in question. Often a standard service engine will be a WORKABLE replacement without converting to such things as a special fuel tank or starter position.

If the crankshaft number does not appear in the "Original Engine" column, consult the Illustrated Parts List for the correct service replacement crankshaft number.

**Engine Replacement Notes:**

- NOTE 15:** For all Go-Karts use only a Model 136200 series engine as a replacement, regardless of the original Model.
- NOTE 16:** Gear Red. @ 12 o'clock.
- NOTE 17:** Gear Red. @ 3 o'clock.
- NOTE 22:** If the gear reduction parts are suitable for additional service, use model 121412 type no. 0014 and transfer the reduction parts from the original engine.
- NOTE 25:** If the replacement engine supersedes to or is a Model 120000 series engine, refer to the illustrations located after the conversion data for this model series. the overall dimensions that differ, are shown in the illustrations. If after making a visual inspection and it is determined the Model 120000 series engine cannot be used because of equipment interference, the original engine should be repaired with individual parts.

**Short Block Notes:**

The SHORT BLOCK part number shown, is the assembly which can be used to rebuild the Original Type Number. If a letter appears after the short block number, it indicates the short block must be modified. The change denoted by each letter is as follows:

**132200 to 132299**

Original Engine			Make From		Remove		Add		Note	Change to Type	Trim	RPM	Short Block	
Type	Model	Crank	Model	Type #	Qty	Part #	Qty	Part #					Part #	Notes
0111	132232	493898	121332	0036					15 25		All	3600		
0115	132232	397090	121332	0033					15 25		All	3800	694196	
0116	132252	493770	121352	0049					15 22 25		All	3600		
0117	132292	397084	No Replacement Repair With Individual Parts.						15		All	3600		
0121	132232	492089	121332	0035					15 25		All	3300	694195	
0130	132235	397099	No Replacement Repair With Individual Parts.						15		All	3000		
0131	132232	397090	121332	0033					15 25		All	3750	694196	
0132	132232	492089	121332	0035					15 25		All	3600	694195	
0133	132232	493898	No Replacement Repair With Individual Parts.						15		All	4000		
0134	132232	493898	121332	0036					15 25		All	3600		
0135	132232	493898	121332	0036					15 25		All	3000		
0136	132232	397090	121332	0033	1	693206	1	692571	15 25		All	3100	694196	
0137	132252	493770	121352	0049					15 17 22 25		All	3600		

132200 to 132299

Original Engine			Make From		Remove		Add		Note	Change to Type	Trim	RPM	Short Block	
Type	Model	Crank	Model	Type #	Qty	Part #	Qty	Part #					Part #	Notes
0138	132232	493898	121332	0036					15 25		All	3200		
0139	132232	493898	121332	0036					15 25		All	3600		
0140	132232	397090	121332	0033					15 25		All	3600	694196	
0141	132232	493898	121332	0036					15 25		All	3600		
0142	132212	398318	121312	0060					15 25		All	4000		
0143	132232	493898	121332	0036					15 25		All	3600		
0144	132232	493898	121332	0036					15 25		All	4000		
0145	132232	397088	No Replacement Repair With Individual Parts.						15		All	4000		
0146	132232	492089	121332	0035					15 25		All	4000	694195	
0147	132252	493770	121352	0049					15 22 25		All	4000		
0200	132232	397090	121332	0033					15 25		All	3750	694196	
0201	132232	397090	121332	0033	1	693206	1	692571	15 25		All	3100	694196	
0202	132232	493898	121332	0036					15 25		All	4000		
0203	132252	493770	121352	0049					15 22 25		All	4000		
0204	132232	493898	121332	0036					15 25		All	3200		
0205	132232	492089	121332	0033					15 25		All	4000		
0206	132232	492089	No Replacement Repair With Individual Parts.						15		All	4000		
0207	132232	492089	121332	0035					15 25		All	3600	694195	
0208	132232	493898	121332	0036					15 25		All	3600		
0209	132232	397090	121332	0033					15 25		All	3100	694196	
0210	132232	397090	121332	0033					15 25		All	3100	694196	
0211	132232	492089	121332	0035					15 25		All	3600	694195	
0212	132232	493898	121332	0036					15 25		All	3400		
0213	132232	493898	121332	0036					15 25		All	4000		
0214	132232	493898	121332	0036					15 25		All	3600		
0215	132232	493898	121332	0036					15 25		All	3600		
0216	132235	397099	121337	0050					15 25		All	3000		
0217	132232	493898	121332	0036					15 25		All	3500		
0219	132232	397090	121332	0033					15 25		All	3600	694196	

132200 to 132299

Original Engine			Make From		Remove		Add		Note	Change to Type	Trim	RPM	Short Block	
Type	Model	Crank	Model	Type #	Qty	Part #	Qty	Part #					Part #	Notes
0220	132232	492089	121332	0035					15 25		All	4000	694195	
0221	132232	493898	121332	0036					15 25		All	3200		
0222	132232	493898	121332	0036					15 25		All	3600		
0223	132232	493898	121332	0036					15 25		All	3800		
0224	132232	493898	121332	0036					15 25		All	3000		
0225	132232	492089	121332	0035					15 25		All	3300	694195	
0226	132232	493898	121332	0036					15 25		All	3200		
0227	132232	493898	121332	0036					15 25		All	3600		
0228	132232	493898	121332	0036					15 25		All	3800		
0229	132232	493898	121332	0036					15 25		All	4000		
0230	132232	397090	121332	0033					15 25		All	3700	694196	
0231	132232	492089	121332	0035					15 25		All	4000	694195	
0232	132232	398318	121312	0060					15 25		All	4000		
0233	132252	493770	121352	0049					15 22 25		All	3600		
0234	132252	493770	121352	0049					15 22 25		All	3600		
0235	132232	397090	121332	0033	1	693206	1	692571	15 25		All	3100	694196	
0236	132232	493898	121332	0036					15 25		All	3600		
0237	132232	492089	121332	0035					15 25		All	4000	694195	
0238	132292	397084	No Replacement Repair With Individual Parts.						15		All	3600		
0239	132212	397084	No Replacement Repair With Individual Parts.						15		All	3600		
0240	132232	397088	No Replacement Repair With Individual Parts.						15		All	4000		
0241	132212	493770	121312	0014					15 25		All	2800		
0242	132212	493770	121312	0014					15 25		All	2800		
0243	132232	493898	121332	0036					15 25		All	3600		
0244	132212	398318	121312	0060					15 25		All	4000		
0245	132232	493898	121332	0036					15 25		All	3600		
0246	132232	493898	121332	0036					15 25		All	3800		
0247	132292	397084	No Replacement Repair With Individual Parts.						15		All	3600		
0248	132232	493898	121332	0036					15 25		All	3900		
0249	132232	493898	121332	0036					15 25		All	3900		

132200 to 132299

Original Engine			Make From		Remove		Add		Note	Change to Type	Trim	RPM	Short Block	
Type	Model	Crank	Model	Type #	Qty	Part #	Qty	Part #					Part #	Notes
0250	132232	397090	121332	0033					15 25		All	3100	694196	
0251	132232	493898	121332	0036					15 25		All	3600		
0252	132232	493898	121332	0036					15 25		All	3200		
0253	132232	397090	121332	0033					15 25		All	3150	694196	
0254	132232	493898	121332	0036					15 25		All	3800		
0255	132252	493770	121352	0049					15 16 22 25		All	3400		
0256	132232	397101	No Replacement Repair With Individual Parts.						15		All	4000		
0257	132232	493898	No Replacement Repair With Individual Parts.						15		All	4000		
0258	132232	397090	121332	0033					15 25		All	3750	694196	
0259	132232	493898	121332	0036					15 25		All	3200		
0260	132232	493898	121332	0036					15 25		All	3600		
0261	132232	493898	121332	0036					15 25		All	3500		
0262	132232	397090	121332	0033					15 25		All	3150	694196	
0263	132231	492089	121332	0035					15 25		All	3600	694195	
0264	132232	493898	121332	0036					15 25		All	3600		
0265	132232	492089	121332	0035					15 25		All	4000	694195	
0266	132235	397099	121337	0050					15 25		All	3000		
0267	132252	493770	121352	0049					15 17 22 25		All	4000		
0268	132232	493898	121332	0036					15 25		All	3500		
0269	132232	397090	121332	0033					15 25		All	3800	694196	
0301	132232	493898	121332	0036					15 25		All	3600		
0302	132252	493770	121352	0049					15 22 25		All	3600		
0303	132292	397094	No Replacement Repair With Individual Parts.						15		All	3600		
0311	132232	493898	121332	0036					15 25		All	3600		
0312	132232	492089	121332	0035					15 25		All	4000	694195	
0313	132232	492089	121332	0035					15 25		All	3600	694195	
0314	132232	493898	121332	0036					15 25		All	3800		
0315	132232	492089	No Replacement Repair With Individual Parts.						15		All	4000		
0316	132232	493898	121332	0036					15 25		All	3600		

132200 to 132299

Original Engine			Make From		Remove		Add		Note	Change to Type	Trim	RPM	Short Block		
Type	Model	Crank	Model	Type #	Qty	Part #	Qty	Part #					Part #	Notes	
0317	132232	492089	121332	0035					15 25		All	4250	694195		
0318	132232	493898	121332	0036					15 25		All	4000			
0319	132212	493770	121312	0014					15 25		All	2800			
0320	132232	493898	121332	0036					15 25		All	3000			
0321	132232	397090	121332	0033					15 25		All	3150	694196		
0322	132232	493898	121332	0036					15 25		All	3800			
0323	132232	493898	121332	0036					15 25		All	3600			
0324	132232	492089	121332	0035					15 25		All	4000	694195		
0325	132232	397090	121332	0033					15 25		All	3800	694196		
0326	132232	493898	121332	0036					15 25		All	4000			
0327	132232	397090	121332	0033					15 25		All	3750	694196		
0328	132232	397090	121332	0033	1	693206	1	692571	15 25		All	3150	694196		
0329	132232	397088	No Replacement Repair With Individual Parts.							15		All	4000		
0330	132232	492089	121332	0035					15 25		All	4250	694195		
0331	132252	493898	121332	0036					15 25		All	4000			
0332	132232	493770	121352	0049					15 22 25		All	4000			
0333	132232	493898	121332	0036					15 25		All	4000			
0334	132232	493898	121332	0036					15 25		All	3500			
0335	132232	492089	121332	0035					15 25		All	4250	694195		
0336	132232	397090	121332	0033					15 25		All	3150	694196		
0337	132231	492089	121332	0035					15 25		All	3600	694195		
0338	132232	493898	121332	0036					15 25		All	33400			
0339	132232	397101	No Replacement Repair With Individual Parts.							15		All	4000		
0340	132292	397084	No Replacement Repair With Individual Parts.							15		All	3600		
0341	132232	397090	121332	0033					15 25		All	3150	694196		
0342	132232	493898	121332	0036					15 25		All	3600			
0343	132232	493898	121332	0036					15 25		All	3600			
0344	132232	493898	121332	0036					15 25		All	3600			
0345	132232	397101	No Replacement Repair With Individual Parts.							15		All	4000		
0346	132232	492089	121332	0035					15 25		All	4000	694195		

132200 to 132299

Original Engine			Make From		Remove		Add		Note	Change to Type	Trim	RPM	Short Block	
Type	Model	Crank	Model	Type #	Qty	Part #	Qty	Part #					Part #	Notes
0347	132232	493898	121332	0036					15 25		All	4000		
0348	132232	493898	121332	0036					15 25		All	3600		
0349	132232	493898	121332	0036					15 25		All	3600		
0350	132232	397090	121332	0033					15 25		All	3150	694196	
0351	132232	397090	121332	0033					15 25		All	3750	694196	
0352	132251	493770	121352	0049					15 22 25		All	4000		
0353	132231	493898	121332	0036					15 25		All	4000		
0354	132232	397090	121332	0033					15 25		All	3150	649196	
0355	132232	492089	121332	0035					15 25		All	3600	694195	
0356	132292	397084	No Replacement Repair With Individual Parts.						15		All	3600		
0357	132232	397090	121332	0033					15 25		All	3150	694196	
0358	132232	493898	121332	0036					15 25		All	3500		
0359	132212	398318	121312	0060					15 25		All	4000		
0360	132232	493898	121332	0036					15 25		All	3300		
0361	132237	397099	121337	0050					15 25		All	3600		
0362	132212	398318	121312	0060					15 25		All	4000		
0363	132232	397090	121332	0033					15 25		All	3150	694196	
0364	132232	397101	No Replacement Repair With Individual Parts.						15		All	4000		
0365	132232	397090	121332	0033					15 25		All	3150	694196	
0366	132232	493898	121332	0036					15 25		All	3600		
0367	132232	397101	No Replacement Repair With Individual Parts.						15		All	3600		
0368	132292	397084	No Replacement Repair With Individual Parts.						15		All	3600		
0369	132232	493898	121332	0036					15 25		All	3600		
0370	132232	493898	121332	0036					15 25		All	3600		
0371	132232	493898	121332	0036					15 25		All	3600		
0372	132212	397084	No Replacement Repair With Individual Parts.						15		All	3500		
0373	132252	493770	121352	0049					15 17 22 25		All	4000		
0374	132232	397090	121332	0033					15 25		All	3750	694196	
0375	132232	492089	121332	0035					15 25		All	4250	694195	
0376	132232	493898	No Replacement Repair With Individual Parts.						15		All	4000		

132200 to 132299

Original Engine			Make From		Remove		Add		Note	Change to Type	Trim	RPM	Short Block	
Type	Model	Crank	Model	Type #	Qty	Part #	Qty	Part #					Part #	Notes
0377	132232	492089	121332	0035					15 25		All	4000	694195	
0378	132232	493898	121332	0036					15 25		All	4000		
0379	132252	493770	121352	0049					15 22 25		All	4000		
0380	132232	397090	121332	0033					15 25		All	3150	694196	
0381	132232	397101	No Replacement Repair With Individual Parts.						15		All	4000		
0382	132232	493898	121332	0036					15 25		All	3600		
0385	132232	493898	121332	0036					15 25		All	4000		
0386	132232	397101	No Replacement Repair With Individual Parts.						15		All	3600		
0387	132232	397101	No Replacement Repair With Individual Parts.						15		All	3600		
0388	132232	397090	121332	0033					15 25		All	3150	694196	
0389	132252	493770	121352	0049					15 17 22 25		All	3600		
0390	132232	493898	121332	0036					15 25		All	3600		
0391	132232	397090	121332	0033					15 25		All	3150	694196	
0392	132232	493898	121332	0036					15 25		All	3600		
0393	132232	493898	121332	0036					15 25		All	3600		
0394	132232	493898	121332	0036					15 25		All	4000		
0395	132232	493898	121332	0036					15 25		All	3600		
0396	132292	397084	No Replacement Repair With Individual Parts.						15		All	3600		
0397	132232	493898	121332	0036					15 25		All	3200		
0398	132232	397090	121332	0033					15 25		All	3150	694196	
0399	132231	493898	121332	0036					15 25		All	3600		
0400	132232	493898	121332	0036					15 25		All	3600		
0401	132232	397090	121332	0033					15 25		All	3150	694196	
0402	132232	492089	121332	0035					15 25		All	4000	694195	
0403	132232	493770	121352	0049					15 22 25		All	3600		
0404	132232	397090	121332	0033					15 25		All	3150	694196	
0405	132232	397090	121332	0033					15 25		All	3750	694196	
0406	132232	492089	121332	0035					15 25		All	4250	694195	
0407	132232	397090	121332	0033					15 25		All	3150	694196	

132200 to 132299

Original Engine			Make From		Remove		Add		Note	Change to Type	Trim	RPM	Short Block	
Type	Model	Crank	Model	Type #	Qty	Part #	Qty	Part #					Part #	Notes
0408	132292	397084	No Replacement Repair With Individual Parts.						15		All	3600		
0409	132232	493898	121332	0036					15 25		All	3150		
0410	132232	493898	121332	0036					15 25		All	3150		
0411	132232	397090	121332	0033					15 25		All	3750	694196	
0412	132232	493898	121332	0036					15 25		All	3600		
0413	132232	397090	121332	0033					15 25		All	3150	694196	
0414	132212	398318	121312	0060					15 25		All	4000		
0415	132232	397090	121332	0033					15 25		All	3150	694196	
0416	132232	397090	121332	0033					15 25		All	3150	694196	
0417	132212	493980	No Replacement Repair With Individual Parts.						15		All	3750	496821	
0418	132232	493898	121332	0036					15 25		All	4000		
0419	132252	493770	121352	0049					15 22 25		All	4000		
0420	132232	493898	121332	0036					15 25		All	3600		
0421	132232	493898	121332	0036					15 25		All	3600		
0422	132232	492089	121332	0035					15 25		All	3600	694195	
0423	132232	397090	121332	0033					15 25		All	3750	694196	
0424	132297	493855	No Replacement Repair With Individual Parts.						15		All	3600		
0425	132212	493953	121332	0033					15 25		All	3750	496821	
0426	132212	493953	121332	0033					15 25		All	3750	496821	
0427	132232	492089	121332	0035					15 25		All	4000	694195	
0428	132213	494391	No Replacement Repair With Individual Parts.						15		All	4000		
0429	132232	493898	121332	0036					15 25		All	3200		
0430	132212	494391	No Replacement Repair With Individual Parts.						15		All	4000		
0431	132232	397090	121332	0033					15 25		All	3600	694196	
0432	132252	493770	121352	0049					15 22 25		All	3600		
0433	132232	492089	121332	0035					15 25		All	4000	694195	
0434	132292	397084	No Replacement Repair With Individual Parts.						15		All	3600		
0435	132232	493898	121332	0036					15 25		All	3400		
0436	132212	493980	No Replacement Repair With Individual Parts.						15		All	3750	496821	
0437	132232	397090	121332	0033					15 25		All	3150	694196	
0438	132232	493898	121332	0036					15 25		All	4000		



132200 to 132299

Original Engine			Make From		Remove		Add		Note	Change to Type	Trim	RPM	Short Block		
Type	Model	Crank	Model	Type #	Qty	Part #	Qty	Part #					Part #	Notes	
0439	132232	493898	121332	0036					15 25		All	3600			
0440	132212	398318	121312	0060					15 25		All	3700			
0441	132232	397090	121332	0033					15 25		All	3150	694196		
0442	132232	397090	121332	0033					15 25		All	3150	694196		
0443	132212	494035	121332	0033					15 25		All	3750	496821		
0444	132232	493898	121332	0036					15 25		All	3200			
0445	132232	493290	121332	0036					15 25		All	3600			
0446	132232	493290	121332	0036					15 25		All	3600			
0447	132212	492926	121312	0060					15 25		All	4000			
0448	132232	492090	121332	0033					15 25		All	3150	694196		
0449	132232	493290	121332	0036					15 25		All	3800			
0450	132212	492926	121312	0060					15 25		All	3500			
0451	132212	397103	No Replacement Repair With Individual Parts.							15		All	3500		
0452	132232	493015	No Replacement Repair With Individual Parts.							15		All	4000		
0453	132232	492926	121312	0036					15 25		All	3600			
2035	132232	397086	121332	0035					15 25		All	4000	694195		
2036	132232	493898	121332	0036					15 25		All	4000			
2038	132232	492090	121332	0033					15 25		All	3750	694196		
2049	132252	493770	121352	0049					15 25		All	4000			
2130	132232	492089	121332	0035					15 25		All	4000	694195		
2135	132232	492089	121332	0035					15 25		All	4000	694195		
2136	132232	493898	121332	0036					15 25		All	4000			
2137	132232	493898	121332	0036					15 25		All	4000			
2138	132232	397090	121332	0033					15 25		All	3800	694196		
2139	132232	397090	121332	0033					15 25		All	3750	694196		
2143	132232	493898	121332	0036					15 25		All	4000			
2149	132252	493770	121352	0049					15 22 25		All	4000			
2150	132237	397099	121337	0050					15 25		All	4000			
2175	132232	492089	121332	0035					15 25		All	4000	694195		

132200 to 132299

Original Engine			Make From		Remove		Add		Note	Change to Type	Trim	RPM	Short Block		
Type	Model	Crank	Model	Type #	Qty	Part #	Qty	Part #					Part #	Notes	
2224	132212	493770	121312	0014					15 25		All	4000			
2230	132232	492089	121332	0035					15 25		All	4000	694195		
2235	132232	492089	121332	0035					15 25		All	4000	694195		
2236	132232	493898	121332	0036					15 25		All	3600			
2237	132232	493898	121332	0036					15 25		All	3600			
2238	132232	397090	121332	0033					15 25		All	3750	694196		
2239	132232	397090	121332	0033					15 25		All	3750	694196		
2243	132232	493898	121332	0036					15 25		All	4000			
2249	132252	493770	121352	0049					15 25		All	3600			
2250	132237	397099	121337	0050					15 25		All	4000			
2253	132232	492089	121332	0035					15 25		All	4000	694195		
2254	132232	493898	121332	0036					15 25		All	4000			
2255	132252	493770	121352	0049					15 22 25		All	4000			
2256	132232	397090	121332	0033					15 25		All	3150	694196		
2260	132212	398318	121312	0060					15 25		All	4000			
2266	132232	493898	121332	0036					15 25		All	4000			
4001	132212	493770	121312	0014	1	693206	1	692571	15 25		All	2800			
4002	132232	493898	121332	0036					15 25		All	3600			
4003	132232	493898	121332	0036					15 25		All	3600			
4005	132232	493898	121332	0036					15 25		All	4000			
4006	132232	492089	121332	0035					15 25		All	3850	694195		
4007	132232	397090	121332	0033					15 25		All	3150	694196		
4008	132232	397101	No Replacement Repair With Individual Parts.							15		All	4000		
4009	132252	493770	121352	0049					15 22 25		All	3600			
4010	132232	493898	121332	0036					15 25		All	3600			
4011	132232	492089	121332	0035					15 25		All	4000	694195		
4013	132232	493898	121332	0036					15 25		All	3600			
4014	132232	397090	No Replacement Repair With Individual Parts.							15		All	3150		
4015	132252	493770	121352	0049					15 22 25		All	3600			

132200 to 132299

Original Engine			Make From		Remove		Add		Note	Change to Type	Trim	RPM	Short Block	
Type	Model	Crank	Model	Type #	Qty	Part #	Qty	Part #					Part #	Notes
4016	132237	397099	121337	0050					15 25		All	3200		
4017	132237	396820	No Replacement Repair With Individual Parts.						15		All	3150		
4019	132292	397084	No Replacement Repair With Individual Parts.						15		All	3600		
4020	132237	397099	121337	0050					15 25		All	2900		
4021	132252	493770	121352	0049					15 16 22 25		All	3600		
4022	132232	493898	121332	0036					15 25		All	3600		
4023	132232	493898	121332	0036					15 25		All	3600		
4024	132212	493770	121312	0014					15 25		All	3600		
4025	132232	397090	121332	0033					15 25		All	3150	694196	
4026	132232	493898	121332	0036					15 25		All	3800		
4027	132252	493770	121352	0049					15 22 25		All	3600		
4035	132232	492089	121332	0035					15 25		All	4000	694195	
4036	132232	493898	121332	0036					15 25		01 02 03 04 05 06 07 08 09 10 11	3600 3600 3600 3600 3600 3600 3600 4000 3600 3750		
4038	132232	397090	121332	0033					15 25		All	3750	694196	
4039	132232	493898	121332	0036					15 25		All	3300		
4040	132232	493898	121332	0036					15 25		All	4000		
4049	132252	493770	121352	0049					15 22 25		All	3600		
4050	132237	397099	121337	0050					15 25		All	3600		
4060	132212	398318	121312	0060					15 25		01 02 03	4000 4000 3600		
4061	132232	397090	121332	0033					15 25		All	3150	694196	
4062	132232	492089	121332	0035					15 25		All	4000	694195	
4063	132252	493770	121352	0049					15 22 25		All	3600		
4064	132232	493898	121332	0036					15 25		All	3600		

**132200 to 132299**

Original Engine			Make From		Remove		Add		Note	Change to Type	Trim	RPM	Short Block	
Type	Model	Crank	Model	Type #	Qty	Part #	Qty	Part #					Part #	Notes
4065	132232	493898	121332	0036					15 25		All	3600		
4066	132232	493898	121332	0036					15 25		All	3600		
4070	132232	492089	121332	0035					15 25		All	4250	694195	
4071	132232	397101	No Replacement Repair With Individual Parts.						15		All	4000		
4072	132232	492089	121332	0035					15 25		All	4250	694195	
4090	132232	493898	121332	0036					15 25		All	3600		
4091	132232	492089	121332	0035					15 25		All	4000	694195	

**MODEL 132200**

**MODEL 120000**

