FORM MS-6228-7/04 REPLACES FORM MS-6228-4/02 FILE IN SECT. 2B OF SERVICE ENGINE SALES MANUAL

461700 to 461799



## MODEL 461700 SERIES ENGINES REPLACED WITH STANDARD SERVICE ENGINES

In most cases, the Original Type numbers shown may be replaced by a Service Type Number without making any changes. Necessary changes of engine parts such as crankshafts, reduction parts, blower housings, etc., are noted. Other differences, such as mufflers, elbows, deflectors, etc., are not listed but are very important for safety and engine performance. Be sure the exhaust system on the replacement engine duplicates the system originally selected by the equipment manufacturer. Parts that are suitable for additional use should be transferred. Before making any conversion, check the data shown in the column labeled "REMOVE, ADD and NOTE." See if the changes, which are shown, are actually necessary on the application in question. Often a standard service engine will be a WORKABLE replacement without converting to such things as a special fuel tank or starter position.

If the crankshaft number does not appear in the "Original Engine" column, consult the Illustrated Parts List for the correct service replacement crankshaft number.

## **Engine Replacement Notes:**

## **Short Block Notes:**

The SHORT BLOCK part number shown, is the assembly which can be used to rebuild the Original Type Number. If a letter appears after the short block number, it indicates the short block must be modified. The change denoted by each letter is as follows:

## 461700 to 461799

Original Engine			Make From		Remove		Add			Change			Short Block	
Type	Model	Crank	Model	Type #	Qty	Part #	Qty	Part #	Note	to Type	Trim	RPM	Part #	Notes
0115	461777	498129	No Re	placemen	Repa	ir With In	dividu	al Parts.			All	3400		
0116	461707	690666	No Re	placemen	Repa	ir With In	dividua	al Parts.			All	3400		
0137	461777	498129	No Re	placemen	Repa	ir With In	dividu	al Parts.			All	3300		
0143	461707	690666	No Re	placemen	Repa	ir With In	dividua	al Parts.			All	3300		
0145	461707	690666	No Re	placemen	Repa	ir With In	dividua	al Parts.			All	3300		
0147	461707	690666	No Re	placemen	Repa	ir With In	dividua	al Parts.			E1	3300		
0149	461707	690666	No Re	placemen	Repa	ir With In	dividu	al Parts.			All	3300		