





1110
Air Cleaner

Page 2 of 71

Ref #	Part Number	Qty	S/P/F	Description
1	BS-393749	1		Air Cleaner Assembly
2	BS-93911	1		Screw, Air Cleaner
3	BS-396966	1		Cover, Air Cleaner (Includes Ref No. 5)
4	BS-93913	1		Screw, Air Cleaner
5	BS-397971	1		Gasket, Air Cleaner Cover
6	BS-93910	1		Screw, Air Cleaner
7	BS-270978	1		Washer, Air Cleaner
8	BS-393725	1		Cartridge, Air Cleaner
9	BS-94018	1	S	Screw Sem
10	BS-270853	1	/P	Gasket, Air Cleaner
11	BS-397321	1		Body, Air Cleaner
12	BS-222898	1		Plate, Air Cleaner Cartridge




1110
Battery & Mounting

Page 4 of 71

Ref #	Part Number	Qty	S/P/F	Description
1	725-3061	1	S	Battery, 12 Volt
	710-0451	2	/P	Bolt, Carr. 5/16-18 X .75 Long
	712-3010	2	S	Nut, 5/16-18
2	759-3193	1		Cover W/Graphic, Battery
	777-4491	1		Graphic
3	703-1144	1		Tray, Battery
	710-3008	4	/P	Bolt, 5/16 X 3/4 GR 5
	736-0119	4	S	Washer, 5/16 Lock
	736-3007	4		Washer, 5/16 Ext-Int Tooth Lock
	712-3010	4	S	Nut, 5/16 GR 5
4	711-3142	1		Rod, Battery Cover LH
5	711-0222	1	S	Rod, Battery Cover RH
6	736-0142	2	S	Washer, .281 X .500 X .056
7	712-3044	2		Nut, 1/4 Wing
8	735-3027	1		Hose, Battery Drain 48 in. Long

1110
Brake Assembly

Page 5 of 71



1110
Brake Assembly

Page 6 of 71

Ref #	Part Number	Qty	S/P/F	Description
	761-3000	1		Brake Assy, Caliper
1	HH-9908225	1	S	Plate Assy, Stud
2	HH-0303017	1		Washer, Thrust
3	HH-1802434	1		Cam
4	HH-1403286	1		Plate, Actuator
5	HH-0603031	1		Spring, Compression
6	HH-0703275	1	S	Ring, Retaining
7	HH-0103443	2	S	Screw, 1/4-20 X 2 Phc Hex-Hd Cap
	712-0107	2	S	Nut, 1/4-20 Hex Patch Lock
8	HH-1108979	2		Bushing
9	HH-0603314B	2		Spring, Return
10	HH-9908229	1	S	Side Assy, Carrier
11	HH-0307700	1		Washer

1110


Page 8 of 71

Brake Pedal & Connections

Ref #	Part Number	Qty	S/P/F	Description
1	703-1243	1		Pedal, Brake
2	748-0151	2	S	Bearing, Flanged
3	735-0189	1		Pad, Foot
4	703-1176	1		Control, Brake Link
5	715-3028	2		Pin, 1/4 X 1-1/4 Pln Slit-Spr
6	703-1226	1		Lever, Parking Brake
7	703-1224	1		Handle, Brake Lock
	712-0998	1	/P	Nut, No. 10 Cad P/T Lock GR 5
8	720-3016	1		Knob, Brake Lock Handle
9	703-1120	1		Bracket, Brake
	710-3000	2	S	Bolt, 3/8 X 3/4 GR 5
	712-3000	2	S	Nut, 3/8 GR 5
10	761-3010	1		Disc & Hub
11	714-0126	1	S	Key, No. 9 Hi-Pro
12	761-3000	1		Brake Assy, Caliper For Components See Brake Assembly
	736-0463	2	S	Washer, .281 X .625 X .051
	712-0107	2	S	Nut, 1/4-20 Hex Patch Lock
13	747-3099	1		Rod, Brake
	714-0474	1	S	Pin, 1/8 X 3/4 Pln Cot
	736-0185	1	S	Washer, .406 X .812 X .065 Hdn
	712-0130	1	/P	Nut, 3/8 Cad P/T Lock GR 5
14	732-3045	1		Spring, Brake Pedal Return
15	703-1316	1		Cam, Hydro
16	750-0262	1		Spacer, .375 X .50 X 1.42
17	738-0258	1	S	Screw, Shoulder
18	736-0232	2	S	Washer, Wave
19	715-0119	2	/P	Pin, 5/32 X 3/4 Slit-Spg
20	736-3028	1		Washer, .781 X 1.25 X .054

1110
Carburetor

Page 9 of 71




1110
Carburetor

Page 10 of 71

Ref #	Part Number	Qty	S/P/F	Description
1	BS-396784	1		Carburetor Assembly
2	BS-299647	1		Shaft & Lever, Manual Choke
3	BS-222010	1	/P	Valve, Choke
4	BS-93499	1	S	Screw, Throttle & Choke Valve Mtg. Stem
5	BS-211712	1	S	Stop, Throttle
6	BS-26157	1	S	Spring, Throttle Adjustment
7	BS-91920	1		Screw, Machine Fill Hd 8/32 X 5/8 in.
8	BS-93043	1		Pin, Throttle Stop
9	BS-299740	1		Nozzle, Carburetor
10	BS-292681	1	/P	Valve Assy, Carburetor Idle
11	BS-396813	1		Body Assy, Carburetor
	BS-221997	1		Plug, Welch
12	BS-490017	1	S	Shaft & Lever, Throttle
13	BS-398970	1	S	Seal, Throttle Shaft
14	BS-93357	1		Screw, Carburetor Mtg
15	BS-270872	1	S	Gasket, Carburetor Mtg
16	BS-222433	1	/P	Valve, Throttle
17	BS-270511	1	/P	Gasket, Float Bowl
18	BS-299707	1	/P	Float, Carburetor
19	BS-221995	1	/P	Bowl, Float
20	BS-231323	1		Screw, Nozzle
21	BS-222014	1	S	Washer, Float Bowl
22	BS-396568	1		Valve, Needle
23	BS-230896	1		Pin, Float Hinge
24	BS-394683	1		Valve, Fuel Inlet
25	BS-222311	1		Bracket, Carburetor
26	710-0432	1	/P	Screw
27	BS-93543	1	S	Screw
28	BS-211960	1		Venturi, Carburetor
29	BS-220899	1		Washer, Choke Lever
30	BS-23270	1		Screw, Choke Lever
	BS-394698	1	/P	Carburetor Overhaul Kit
	BS-299740	1		Nozzle, Carburetor
	BS-292681	1	/P	Valve Assy, Carburetor Idle
	BS-270511	1	/P	Gasket, Float Bowl
	BS-231323	1		Screw, Nozzle
	BS-222014	1	S	Washer, Float Bowl
	BS-396568	1		Valve, Needle
	BS-230896	1		Pin, Float Hinge
	BS-394683	1		Valve, Fuel Inlet

1110
Drive

Page 11 of 71




1110
Drive

Page 12 of 71

Ref #	Part Number	Qty	S/P/F	Description
1	703-1225	1		Support, Transaxle
	710-3000	2	S	Bolt, 3/8 X 3 GR 5
	736-0169	2	S	Washer, 3/8 Lock
	712-3017	2	S	Nut, 3/8 GR 5
2	710-3046	2		U-Bolt, Axle to Frame
	712-3009	4	S	Nut, 5/16 Cad P/T Lock GR 5
	736-0242	4	/P	Washer, .345 X .88 X .06 Belleville
3	703-1147	2		Spacer, Transmission
4	756-3034	1		Pulley, Engine 4.75 OD
5	714-0119	1	S	Key, 1/4 X 5/8 Sq Parallel
6	756-0166	1	S	Pulley, Idler 2.62 OD
7	726-3008	1	/P	Clamp, Cable
8	710-0539	1	/P	Bolt, 3/8 X 1-3/4 GR 5
9	711-3187	1		Bushing, .385 X 1.0 X .474
10	748-3015	1		Spacer, .385 X 1.0 X 3.06 Idler
11	703-1396	1	S	Arm, Idler
12	750-0252	1	S	Bushing, .375 X .60 X .830
13	736-0247	1	/P	Washer, .400 X 1.25 X .157 Belleville
14	736-0169	1	S	Washer, 3/8 Lock
15	710-3153	1		Bolt, 3/8 X 5 GR 5
16	756-0217	1	S	Pulley, Flat Idler 2.75 OD
17	710-3022	1	/P	Bolt, 3/8 X 2-3/4 GR 5
18	736-0140	1	S	Washer, .385 X .62 X .063
19	736-0260	1	S	Washer, .385 X .87 X .06 Hdn
20	750-0497	1		Spacer, .375 X .625 X .445
21	736-0169	1	S	Washer, 3/8 Lock
22	712-3008	1	S	Nut, 3/8 Jam GR 5
23	712-0266	1	S	Nut, 3/8 Cad P/T Lock GR 5
24	756-0225	1	/P	Pulley, Idler 3.12 OD X .75 Wide
	710-3037	1	S	Bolt, 3/8 X 1-3/4 GR 5
	736-0331	1	/P	Washer, .39 X 1.13 X .062 Belleville
	736-0169	1	S	Washer, 3/8 Lock
	712-3017	1	S	Nut, 3/8 GR 5
25	756-3014	1	/P	Pulley, Transmission
26	714-3024	1		Key, 1/8 X 1/2 Hi-Pro No. 3
27	731-3016	1	S	Fan, Hydrostatic (10 Blade)
	710-0751	5	/P	Bolt, 1/4-20 X .62 GR 5
	736-0222	3	S	Washer, 1/4 Ext Tooth Lock
28	703-0302	1		Retainer, Bolt
29	754-3025	1	S	Belt, Drive
30	732-3044	1	S	Spring, .41 OD X 6.0
31	737-3000	1	S	Fitting, Lube 3/16 Drive
32	703-1415	1		Spacer, Fan

1110
Engine -11 HP B&S- -Electric Start

Page 13 of 71



1110

Page 14 of 71

Engine -11 HP B&S- -Electric Start

Ref #	Part Number	Qty	S/P/F	Description
	BS-253707-017101	1		Engine Assembly 11 HP For Units w/ S/N 107,999 and Below (Non- Regulated Tri-Circuit)
	BS-253707-024601	1		Engine Assembly 11 HP For Units w/ S/N 108,000 and Above (Regulated)
	710-0624	4	/P	Bolt, 5/16 NF X 1-1/2 GR 5
	712-3057	4	S	Nut, 5/16 NF GR 5
	736-0119	4	S	Washer, 5/16 Lock
	BS-396610	1		Short Block
1	BS-395705	1		Cylinder Assembly (Includes Ref No. 2, 55, 70, 71 & 72)
2	BS-399265	1	/P	Bushing, Cylinder
3	BS-212914	1		Head, Cylinder
4	BS-271075	1	S	Gasket, Cylinder Head
5	BS-394217	1	S	Breather Assembly
6	BS-27803	1	S	Gasket, Valve Cover
7	BS-93394	2	S	Screw Sem
8	BS-280100	1	S	Tube, Breather
9	BS-270808	1	S	Gasket, Crankcase Cover 1/64 in. thick
	BS-270915	1		Gasket, Crankcase Cover .005 in. thick
	BS-270916	1		Gasket, Crankcase Cover .009 in. thick
10	BS-93723	10		Screw, Cylinder Head 3 in. Lg
11	BS-392299	1		Crankshaft
	BS-94196	1		Gear Key
12	BS-391784	1		Base, Engine (Includes Ref No. 9 & 13)
13	BS-291675	1	S	Seal, Oil
14	BS-93585	8		Screw, Base Mounting Sem
15	BS-222698	1	S	Key, Flywheel
16	BS-394661	1	S	Piston Assembly Std (Includes Ref No. 17 & 18)
	BS-394662	1	S	Piston Assembly .010 in. O.S.
	BS-394663	1		Piston Assembly .020 in. O.S.
	BS-394664	1		Piston Assembly .030 in. O.S.
17	BS-394665	1	S	Piston Ring Set Std
	BS-392331	1		Chrome Piston Ring Set Std
	BS-391781	1		Piston Ring Set .010 in. O.S.
	BS-391782	1		Piston Ring Set .020 in. O.S.
	BS-391783	1	S	Piston Ring Set .030 in. O.S.
18	BS-260924	2	S	Lock, Piston Pin
19	BS-299691	1	/P	Pin Assembly, Piston Std (Includes Ref No. 18)
	BS-391286	1		Pin Assembly, Piston .005 in. O.S.
20	BS-391775	1	S	Connecting Rod Assembly (Includes Ref No. 21 & 22)
	BS-393712	1		Connecting Rod Assembly .020 in. U.S. Crankpin Bore
21	BS-222299	1		Lock, Connecting Rod Screw
22	BS-92909	2		Screw, Connecting Rod
23	BS-261185	1		Valve, Exhaust

1110

Page 15 of 71

Engine -11 HP B&S- -Electric Start

Ref #	Part Number	Qty	S/P/F	Description
24	BS-261462	1		Valve, Intake
25	BS-65906	1	/P	Spring, Intake Valve
26	BS-26828	1	S	Spring, Exhaust Valve
27	BS-221596	1	S	Retainer, Intake Valve
28	BS-292260	1	S	Rotocoil, Exhaust Valve
29	BS-93630	2	S	Retainer, Exhaust Valve Rotocoil
30	BS-261183	2		Tappet, Valve
31	BS-212897	1		Gear, Cam
32	BS-67218	1		Connector, Fuel Pipe
33	BS-261609	1		Link, Governor
34	BS-261306	1	S	Spring, Governor
35	BS-391764	1	S	Oil Slinger, Governor Gear & Bracket Assy
36	BS-390746	1		Plate, Governor Control
37	BS-231058	1	S	Crank, Governor 1/4 in. dia.
38	BS-391733	1		Lever Assy, Governor for 1/4 in. dia. Crank (Includes Ref No. 56 & 57)
39	BS-222450	1	S	Washer, Governor Lever 1/4 in. ID
40	BS-261911	1		Spring, Governor Link
41	BS-221535	1	S	Clamp, Casing
42	710-0432	1	/P	Screw, Clamp Mounting
43	BS-222774	1		Shield, Cylinder
44	BS-93163	4		Screw, Cylinder Shield Mounting Sem
45	BS-222725	1		Cover, Cylinder Head Motor Starting
46	BS-92791	2	S	Washer, Lock, Shakeproof
47	712-0142	2	/P	Nut, Hex 8-32
48	BS-390818	1	S	Pump, Impulse
	BS-394462	1		Pump Repair Kit
49	BS-222502	1	S	Clamp, Oil Filler Tube
50	BS-93722	1	S	Terminal, Spade
51	BS-391841	1		Cap & Dipstick, Oil Filler
52	BS-68838	1	S	Seal, Filler Tube
53	BS-280134	1		Tube, Oil Filler
54	BS-393815	1		Pipe, Vent (Includes Ref No. 58)
55	BS-231055	1	S	Bushing, Governor Crank 1/4 in. I.D.
56	BS-92613	1	/P	Bolt, Governor Lever
57	BS-231082	1		Nut, Hex 10-24
58	BS-93053	2	S	Clamp, Fuel Pipe
59	BS-93306	1	/P	Cotter, Hair Pin
60	BS-93307	1	/P	Retainer, E-Ring
61	BS-66538	1	S	Elbow, Spark Plug
62	BS-93496	1	S	Screw Sem
63	BS-262135	1	S	Gear, Timing (Uses key for installation)
	BS-261196	1		Gear, Timing (Uses pin for installation)
64	BS-212359	1		Link, Counterweight
65	BS-391373	1	S	Counterweight Assy (Includes Ref No. 66)
66	BS-298909	1	/P	Pin, Counterweight
67	BS-93875	1		Screw, Counterweight
68	BS-270920	1	S	Seal, Filler Cap
69	BS-392067	1		Filler Group, Oil (Includes Ref No. 42, 49, 51, 52, 53 & 68)
70	BS-261463	1		Seat, Intake Valve Std
71	BS-210940	1	S	Seat, Exhaust Valve Std

1110


Page 16 of 71

Engine -11 HP B&S- -Electric Start

Ref #	Part Number	Qty	S/P/F	Description
72	BS-261961	1		Guide, Exhaust Valve
	BS-231218	1		Guide, Intake Valve (Brass) See Repair Manual
73	BS-398525	1	S	Insulator Assy
74	751-3058	1		Tube, Oil Drain
75	751-3001	1	/P	Plug, 3/8-18 Znp H/Hd Auto Pipe Oil Drain
76	BS-93380	1		Screw Sem
	BS-393411	1	/P	Overhaul Gasket Kit
	BS-271075	1	S	Gasket, Cylinder Head
	BS-27803	1	S	Gasket, Valve Cover
	BS-270808	1	S	Gasket, Crankcase Cover 1/64 in.
	BS-270915	1		Gasket, Crankcase Cover .005 in.
	BS-270916	1		Gasket, Crankcase Cover .009 in.
	BS-270872	1	S	Gasket, Carburetor Mtg

1110
Engine Electrical

Page 17 of 71



1110
Engine Electrical


Page 18 of 71

Ref #	Part Number	Qty	S/P/F	Description
1	BS-392595	1	S/F	Stator, Alternator (Tri-Circuit System)
	BS-393295	1	S/F	Stator, Alternator (Regulated System)
2	BS-393537	1		Connector Assy (Tri-Circuit System)
3	BS-93621	1	/P	Screw, Stator Mounting
4	BS-93343	1	S	Screw, Regulator Mounting
5	BS-394890	1	S	Regulator, Alternator
6	BS-222934	1	S	Bracket, Regulator
7	BS-393514	1		Clamp, Regulator
8	759-3331	1	/P	Spark Plug
9	BS-398811	1	/P	Armature Assy, Magneto (Includes Ref No. 11)
10	BS-221798	1	S	Terminal, Ignition Cable
11	BS-93381	1		Screw, Armature Mounting
	759-3276	1		Regulator Service Kit (To update the charging system to a fully regulated system on units w/ S/N
	BS-222934	1	S	Regulator Mounting Bracket
	BS-392366	1	S	Flywheel
	BS-393295	1	S	Stator
	BS-393514	1		Clamp
	BS-394890	1	S	Regulator
	BS-93343	2	S	Regulator Mounting Screw
	726-0215	1		Cable Tie
	729-0124	1		Fuse Holder
	725-3120	1	S	Fuse
	759-3281	1		Diode Assembly Replacement Harness
	759-3282	1	/P	"PTO ON" Indicator Light Diode Assy
	779-3340	1		Label, "Always Mow at Full Throttle"
	772-3721	1		Instruction Sheet

1110

Page 19 of 71

Engine Flywheel, Ring Gear, Blower Housing & Screens



1110


Page 20 of 71

Engine Flywheel, Ring Gear, Blower Housing & Screens

Ref #	Part Number	Qty	S/P/F	Description
1	BS-398857	1		Guard, Debris
	BS-223379	1		Bracket, Guard Mounting
2	BS-94018	1	S	Screw, Hex Washer Hd
3	BS-93067	1		Screw, Hex Head Sem
4	BS-393997	1		Housing, Blower
5	BS-92284	1	S	Nut, Hex
6	BS-220865	1		Washer, Spring
7	BS-391988	1		Flywheel & Ring Gear Assy, Magneto (For Units w/ S/N 107,999 & Below)
	BS-392366	1	S	Flywheel & Ring Gear Assy, Magneto (For Units w/ S/N 108,000 & Above)
8	BS-392134	1	S	Gear Ring for Tri-Circuit System (Includes Mounting Hardware)
	BS-399676	1	S	Gear Ring for Regulated System (Includes Mounting Hardware)
9	BS-93535	1		Screw Sem
10	BS-395405	1	/P	Cover, Starter (Includes Ref No. 11)
11	BS-93984	1		Screw Sem
12	BS-93158	1		Screw, Blower Housing Mounting Sem
13		1		Starter Motor (See Starter Motor Group)

1110
Fenders & Foot Rests

Page 21 of 71



1110


Page 22 of 71

Fenders & Foot Rests

Ref #	Part Number	Qty	S/P/F	Description
1	703-1234	1		Fender w/Hole
	710-3092	4		Screw, 5/16 X 3/4 Flange Lock
	710-3093	2		Screw, 5/16 X 1-1/4 Flange Lock
	712-0158	6	S	Nut, 5/16 Center Lock
	710-3000	2	S	Bolt, 3/8 X 3/4
	736-0169	2	S	Washer, 3/8 Lock
	726-3009	1		Clip, Cable
	726-0215	1		Tie, Cable
2	703-0993	1		Support, Fender Front
	710-3008	2	/P	Bolt, 5/16 X 3/4
	736-0242	2	/P	Washer, .348 X .88 X .06 Belleville
3	703-0995	1	/P	Support, Fender Rear LH
	710-3008	2	/P	Bolt, 5/16 X 3/4
	736-0242	2	/P	Washer, .348 X .88 X .06 Belleville
4	703-0996	1		Support, Fender Rear RH
	710-3008	2	/P	Bolt, 5/16 X 3/4
	736-0242	2	/P	Washer, .348 X .88 X .06 Belleville
5	731-3046	1		Cover, Shift
	710-0351	4	/P	Screw, No. 10 X 1/2 Truss-Hd "B" Tap
	736-3034	3		Washer, .219 X .56 X .06 Flat
	12894	1		Clip, Cable
6	723-3006	1	/P	Tread, Platform LH
7	723-3007	1	/P	Tread, Platform RH
8	730-3000	2	S	Reflector
9	703-1202	1		Support, Fender LH
10	703-1201	1		Support, Fender RH
	710-3008	4	/P	Bolt, 5/16 X 3/4 GR 5
	736-0119	4	S	Washer, 5/16 Lock
11	703-1346	1		Strip, Trim -39.38 in. Long
12	723-3042	1	/P	Bushing, Snap
13	759-3214	1		Kit, Chassis Label

1110
Frame & Drawbar

Page 23 of 71



1110


Page 24 of 71

Frame & Drawbar

Ref #	Part Number	Qty	S/P/F	Description
1	703-1203	1		Frame
2	703-1119	1	S	Drawbar
	710-3000	4	S	Bolt, 3/8 X 3/4 GR 5
	736-0169	4	S	Washer, 3/8 Lock
3	759-3194	1		Cover w/Graphic
	779-3237	1		Graphic, Caution (Tractors w/ Internal Dump Valve S/N 108,348 & Below)
	779-3299	1		Graphic, Caution (Tractors w/ External Dump Valve S/N 108,349 & Above)
	710-3149	2		Screw, #10-16 X 1 PHC O/Hdcr Tap
	726-3039	2		Nut, Speed
	710-3000	1	S	Bolt, 3/8 X 3/4 GR 5
	736-3032	1		Washer, .406 X 1 X .054 Flat
	736-0169	1	S	Washer, 3/8 Lock
4	726-3008	2	/P	Clip, Cable
	710-3000	1	S	Bolt, 3/8 X 3/4 GR 5
	712-3004	2	S	Nut, 3/8 Lock
5	703-1288	1	S	Front Mower Support
	710-3000	3	S	Bolt 3/8-16 X 3/4 Lg GR 5
	736-0169	3	S	Lock Washer 3/8 Dia
6	703-1297	1		Deck Support Rod
	714-0149	3	S	Internal Cotter Pin
7	703-1441	1		Rear Deck Bracket Assy RH
8	703-1442	1		Rear Deck Bracket Assy LH
9	747-3106	2		Link Retaining Rod
	736-0206	4	S	Flat Washer 3/8 ID X 1.0 OD
	712-3005	4	S	Nut, Flange 3/8-16

1110
Front Axle & Connections

Page 25 of 71



1110


Page 26 of 71

Front Axle & Connections

Ref #	Part Number	Qty	S/P/F	Description
1	719-3019	1	S/F	Axle, Front (Pivot ID .842)
	737-3000	3	S	Fitting, Lube 3/16 Drive Type
2	710-3161	1		Bolt, 1/2-20 X 4.0 Long GR 5
	712-3021	1	S	Nut, 1/2-20 Castle
	714-0470	1	S	Pin, 1/8 X 1-1/4 Cotter
3	711-3063	1	S	Bushing, Axle Pivot (Pivot OD .840)
4	703-1252	1	S	Knuckle Assy, LH
5	703-1253	1	/P	Knuckle Assy, RH
6	710-3000	2	S	Bolt, 3/8-16 X 3/4 Long GR 5
7	711-3205	1		Link, Drag
	712-3001	2	S	Nut, 3/8-24 Jam GR 5
8	711-3153	1		Link, Drag
	712-3001	2	S	Nut, 3/8-24 Jam GR 5
9	723-3018	4	S	Joint, 3/8-24 Ball Type G
	712-3001	4	S	Nut, 3/8-24 Jam GR 5
10	736-3039	1	S	Washer, .406 X 1.50 X 11 ga.

1110
Front Axle Kit: 759-3268

Page 27 of 71



1110


Page 28 of 71

Front Axle Kit: 759-3268

Ref #	Part Number	Qty	S/P/F	Description
	759-3268	1	/P	Front Axle Kit
1	759-3269	1	S	Axle, Front (Pivot ID 1.12)
	737-3000	3	S	Fitting, Lube 3/16 Drive
2	711-3220	1		Bushing, Pivot Axle (Pivot OD 1.10)
3	712-3017	2	S	Nut, 3/8-16
4	710-3179	2		Bolt, 3/8-16 X 1.25 GR 5
5	736-0188	2	/P	Washer, .79 X 1.49 X .06 Hdn

1110
Front Wheel

Page 29 of 71



1110
Front Wheel

Page 30 of 71

Ref #	Part Number	Qty	S/P/F	Description
	734-3061	2	S	Tire, Soft Trac 15 X 6
1	734-0961	2		Wheel Assy, Front (Includes Ref No. 2 & 9)
2	737-0224	2		Fitting, 1/4 Lub
3	734-3068	2	S	Valve, Tubeless Type
4	748-3007	4	S	Bushing, Bronze Flange
5	736-3040	2	/P	Washer, .406 X 1.92 X .06
6	710-3119	2	/P	Bolt, 3/8 X 3/4 GR 5
7	731-3020	2	S	Cap, Hub
8	736-3036	2		Washer, .406 X 1.5 X .125
9	777-5883	2		Label, Inflation

1110


Page 32 of 71

Fuel Tank & Related Parts

Ref #	Part Number	Qty	S/P/F	Description
1	759-3195	1		Tank Assy, Fuel (Includes Ref No. 2 & 3)
2	751-0171	1	S	Valve w/Screen, Shut-off
3	751-3008	1	S	Bushing
4	751-3044	1	/P	Cap w/Gauge, Fuel Tank
5	723-3003	1	/P	Gasket, Fuel Tank Cap
6		1		Line, Fuel Tank To Filter, 56 in. Long (Order Bulk Fuel Line Part No. 759-3330, 10 ft. Long)
7	751-3013	1	S	Filter, Fuel
8		1		Line, Fuel Filter To Engine, 25 in. Long (Order Bulk Fuel Line Part No. 759-3330, 10 ft. Long)
9	726-0205	4	/P	Clamp, 1/2 OD Tube Hose
10	703-1349	2		Strip, Foam Gasket Sealing 12 in. Long
11	703-1348	2		Strip, Foam Gasket Sealing 5 in. Long
12	703-1368	2		Seal, Edge, 4 in. Long
13	723-3051	2		Strip, Foam Gasket Sealing 3 in. Long

1110
Gas Spring Kit

Page 33 of 71




1110
Gas Spring Kit

Page 34 of 71

Ref #	Part Number	Qty	S/P/F	Description
1	703-1384	1		Spring Assy, Gas
2	703-1382	1		Bracket, Spring
	736-0119	2	S	Washer, Lock 5/16
	710-3038	2	/P	Bolt, 5/16-18 X 7/8 Long GR 5
	712-3010	2	S	Nut, 5/16-18 GR 5
3	736-0119	2	S	Washer, Lock 5/16
4	712-3010	2	S	Nut, 5/16-18 GR 5

1110
Hood & Grille

Page 35 of 71




1110
Hood & Grille

Page 36 of 71

Ref #	Part Number	Qty	S/P/F	Description
1	759-3234	1		Hood & Grille Assy w/Product Graphic (Includes Ref No. 9)
2	732-3048	2		Spring, Extension
3	703-1215	1		Plate, Hood LH
	710-3008	2	/P	Bolt, 3/8 X 3/4 GR 5
4	703-1216	1		Plate, Hood RH
	710-3008	2	/P	Bolt, 3/8 X 3/4 GR 5
5	703-1158	1		Screen, Grille
	710-0227	8	/P	Screw, No. 8 X 1/2 Hex- Washer-Hd Tap
6	731-3051	1		Insert, Grille
	726-3040	4	/P	Nut, No. 10 C-Z Stamped
7	759-3173	1	F	Graphic, Hood Decal Set (Model 1110)
8	731-3053	2	S	Graphic, Cub Cadet Script w/Adhesive
9	731-3059	1		Ornament, Hood (Included w/Ref No. 1)

1110
Hydro Dump Valves & Mounting Part 1

Page 37 of 71




1110

Page 38 of 71

Hydro Dump Valves & Mounting Part 1

Ref #	Part Number	Qty	S/P/F	Description
1	717-3016	1	S	Transmission, Hydro
	710-3022	2	/P	Bolt, 3/8-16 X 2.75 GR 5
	710-0521	2	/P	Bolt, 3/8-16 X 3.0 GR 8
2	703-1225	1		Support, Transaxle
3	703-0310	1	/P	Lever, Dump
	715-3008	1	/P	Pin, 1/8 X 3/4 Hvy Spring
4	703-1328	1		Rod, Dump Valve
5	703-1170	1		Bracket, Dump Valve
	710-3008	2	/P	Bolt, 5/16-18 X .75 Long GR 5
	712-3010	2	S	Nut, 5/16-18 GR 5
	736-0242	2	/P	Washer, .345 X .88 X .06
	736-0119	2	S	Washer, Lock 5/16
6	736-0159	1	S	Washer, .344 X .88 X .06
7	732-0306	1	S	Spring, .47 OD X 1.93
8	714-0145	1	S	Pin, 1/2 Int. Cotter
9	721-3006	1	/P	Gasket, Hydro Transmission



1110


Page 40 of 71

Hydro Dump Valves & Mounting Part 2

Ref #	Part Number	Qty	S/P/F	Description
1	717-3016	1	S	Transmission, Hydro
	710-3022	2	/P	Bolt, 3/8-16 X 2.75 GR 5
	710-0521	2	/P	Bolt, 3/8-16 X 3.0 GR 8
2	703-1225	1		Support, Transaxle
3	703-0310	1	/P	Lever, Dump
	715-3008	1	/P	Pin, 1/8 X 3/4 Hvy Spring
4	703-1373	1		Lever, Dump
5	736-0159	1	S	Washer, .344 X .88 X .06
6	714-0145	1	S	Pin, 1/2 Int. Cotter
7	720-3017	1	/P	Knob, Ball
8	721-3006	1	/P	Gasket, Hydro Transmission

1110
Hydro Pump

Page 41 of 71



1110
Hydro Pump

Page 42 of 71

Ref #	Part Number	Qty	S/P/F	Description
	717-3016	1	S	Pump, Hydro
1	ET-990077-000	1		Reservoir Kit (Includes Ref No. 2)
2	ET-008771-130	1		Ring, Square Cut Seal
3	ET-990102-000	1		Cover Service Kit (Includes Ref No. 4, 5, 6, 22, 26, & 27)
4	ET-096098-062	1		Ring, External Retaining
5	ET-095060-000	1		Washer, Control Shaft
6	ET-093881-000	1		Dowel, Pivot Pin
7	ET-024234-000	1		O-Ring Fitting Guide Kit, (Includes Ref No. 8)
8	ET-008761-010	1		O-Ring
9	ET-024166-000	1		Bracket, Pin
10	ET-072149-000	2		Spring, Valve
11	ET-008771-162	1		Ring, Square Cut Seal
12	ET-022712-000	1		Pump Rotor Ball Kit
13	ET-040520-000	1		Race, Pump
14	ET-101901-000	1		Cam Ring Kit
15	ET-098294-075	1		Pin, Coil, 5/16 Dia X 3/4 Long
16	ET-024465-000	1		Pintle Kit [Includes Ref No. 15, 29 (Qty 2), 30 (Qty 2), & 31 (Qty 2)]
17	ET-022711-000	1	S	Motor Rotor Ball Kit, [Includes Ref No. 32 (Qty 2)]
18	ET-101680-156	1		Ring, Retaining
19	ET-097121-000	1		Ring, Snap
20	ET-090797-000	1	/P	Bearing, Ball
21	ET-990067-000	1		Kit, Input Shaft (Includes Ref No. 18, 19, 20, & 22)
22	721-0100	1	S	Seal, Oil
23	ET-008761-010	1		O-Ring
24	ET-024234-000	1		Nut Assy
25	ET-062240-000	1		Shaft, Dump Valve
26	ET-093895-000	1	S	Seal, Oil
27	ET-990083-000	1		Kit, Control Shaft
28	ET-095203-000	1		Insert, Cam Ring
29	ET-070130-000	2		Body, Check Valve
30	ET-095881-031	2		Ball, 5/16 Dia
31	ET-095214-000	2	/P	Ring, Retaining
32	ET-070044-000	1		Spring, Piston
33	ET-025083-006	2		O-Ring Plug Kit, (Includes Ref No. 34)
34	ET-008785-006	2		O-Ring
35	ET-032278-000	1		Body
36	721-0100	1	S	Seal, Oil
37	ET-090797-000	1	/P	Bearing, Ball
38	ET-101680-156	1		Ring, Retaining
39	ET-095202-000	1		Spacer
40	ET-040511-000	1		Gear, Drive
41	ET-096098-066	1		Ring, External Retaining
42	ET-022892-000	1		Output Shaft Kit
43	714-0156	1		Key, Woodruff
44	ET-040519-000	1		Race, Motor
45	ET-095912-125	2		Screw, Socket Head Cap


1110
Hydro Pump

Page 43 of 71

Ref #	Part Number	Qty	S/P/F	Description
	ET-990314-000	1	/P	Overhaul Sealing Kit, [Includes Ref No. 2, 7, 11, 22, 23, 24, 26, 34 (Qty 2), & 36]

1110
Implement Lift Handle


Page 44 of 71



1110
Implement Lift Handle

Page 45 of 71

Ref #	Part Number	Qty	S/P/F	Description
1	738-3054	1		Shaft, Lift
2	703-1199	1		Lever, Lift
3	715-3029	1		Pin, 3/8 X 1-3/4 PIn SlT-Spr
4	720-3002	1		Pointer, Lift
5	720-3007	1	S	Grip, Lift Handle
6	711-3015	1	/P	Pin, Release
7	732-3005	1	S	Spring, Lift Handle
8	736-3009	1	/P	Washer, .344 X .532 X .06 Hdn Flat
9	747-3098	1		Rod, Handle
10	711-3016	1		Rod, Handle Release
11	715-3030	1		Pin, 5/16 X 1-3/8 Hvy PIn Cld Spr
12	726-3005	1		Plug, 1.0 Button
13	703-1126	1		Ratchet, Handle
14	715-3025	1		Pin, 3/16 X 3 Slotted Roll Spr
15	703-0828	1		Bracket, Height Indicator
	728-0141	2		Rivet, .156 dia. X .250
16	715-3028	2		Pin, 1/4 X 1-1/2 Slotted Roll
17	710-0514	1	/P	Bolt, 3/8 X 1 GR 5
18	710-0514	1	/P	Bolt, 3/8 X 1 GR 5
19	712-3000	2	S	Nut, 3/8 Center L GR 5
20	779-3233	1		Label, 5 Position



1110


Page 47 of 71

Lift Arms & Links

Ref #	Part Number	Qty	S/P/F	Description
1	738-3054	1		Shaft, Lift
2	703-1186	2		Arm, Lift
3	703-1199	1		Lever, Lift
4	703-1277	1		Bracket, Lift
5	703-1287	1		Link, Lift
6	715-3028	2		Pin, 1/4 X 1.5 Long Slotted Roll
7	747-3046	1		Rod, Lift Link
8	712-0206	1	S	Nut, 1/2-13
9	711-0332	1	S	Pin, Lift Bracket
10	736-0272	4	S	Washer, .510 X 1.0 X .06
11	714-0149	4	S	Pin, Internal Cotter

1110
Lift Links (for SN 109,000 & Up)

Page 48 of 71



1110


Page 49 of 71

Lift Links (for SN 109,000 & Up)

Ref #	Part Number	Qty	S/P/F	Description
1	738-3054	1		Shaft, Lift
2	703-1378	1		Arm Assy, Lift LH
3	703-1377	1		Arm Assy, Lift RH
4	703-1199	1		Lever, Lift
5	703-1383	2		Bracket, Lift
6	715-3028	2		Pin, 1/4 X 1.5 Long Slotted Roll
7	711-3216	2		Bolt, Eye
8	711-0332	2	S	Pin, Lift Bracket
9	712-0206	2	S	Nut, 1/2-13
10	736-0272	4	S	Washer, .510 X 1.0 X .06
11	714-0149	4	S	Pin, Internal Cotter

1110
Muffler


Page 50 of 71



1110
Muffler

Page 51 of 71

Ref #	Part Number	Qty	S/P/F	Description
1	751-3060	1		Muffler & Shield
2	721-0208	1	S	Gasket, Muffler
3	738-0636	2	S	Bolts, Muffler Shield 7/16 dia X 3-5/8 Lg



1110


Page 53 of 71

Pedestal, Engine Controls & Instrument Panel

Ref #	Part Number	Qty	S/P/F	Description
1	710-3009	4	/P	Screw, 10-24 X 3/4 Pan-Hd. Cutting
2	725-3023	1	S	Indicator, Charge
3	731-3049	1		Bezel, Light
4	779-3266	1	S	Label, Indicator
5	703-1167	1		Plate, Indicator
6	725-3104	6		Lamp, Indicator
7	735-0640	4		Washer, .18 X .50 X. 06 Rubber
8	712-3060	4		Nut, Self-Threading Pal
9	731-3047	1		Panel, Instrument
10	703-1194	1		Pedestal
	710-3005	4	/P	Bolt, 3/8-16 X 1.25 GR 5
	726-3028	4	S	Retainer, Push-on Bolt
11	779-3296	1	/P	Label, Battery Booster
12	746-3017	1		Control, Choke
13	720-3018	1	S	Knob, Throttle Control
14	746-3015	1	S	Control, Throttle (Includes Ref. No. 13)
	710-3009	2	/P	Screw, 10-24 X 3/4 Pan-Hd. Cutting

1110
PTO Clutch

Page 54 of 71




1110
PTO Clutch

Page 55 of 71

Ref #	Part Number	Qty	S/P/F	Description
1	711-3179	1	S	Spacer, Engine Pulley
2	756-3034	1		Pulley, Engine (A sec. X 4.75 OD) 04
3	714-0119	1	S	Key, 1/4 X .75 Sq.
4	711-3183	1		Bushing, 1.2 X 1.5 X .620
5	703-1146	1	S	Bracket, Torque
	736-0105	2	/P	Washer, Belleville .400 X .88 X .06
	710-0514	2	/P	Bolt, 3/8-16 X 1.0 GR 5
6	736-3082	1	S	Washer, .445 X 1.5 X .172
7	736-0171	1	S	Washer, Lock 7/16
8	710-3157	1	S	Bolt, 7/16-20 X 3.25 GR 5
9	717-3036	1	S	Clutch Assy, PTO
10	759-3229	1	S	Armature
11	759-3231	1		Rotor
12	759-3230	1		Field
13	759-3228	1		Mounting Accessories Hex Nuts Springs

1110
Rear Wheel

Page 56 of 71



1110
Rear Wheel


Page 57 of 71

Ref #	Part Number	Qty	S/P/F	Description
	734-1065	2	S	Tire, Soft Trac 20 X 10 X 8
1	734-0764	2	S	Wheel Assy, Rear (Includes Ref No. 8)
2	734-3068	2	S	Valve, Tubeless Type
3	736-0242	2	/P	Washer, .345 X .88 Belleville
4	736-0231	2	S	Washer, .344 X 1.125 X .125
5	736-3040	2	/P	Washer, .406 X 1.92 X .06
6	710-3166	2	S	Bolt, 5/16 X 1 GR 5
7	731-3020	2	S	Cap, Hub
8	777-5883	2		Label, Inflation

1110

Page 58 of 71

Relays, Switches, Circuit Breaker & Wiring-Instrmnt Pnl & Btt




1110

Page 59 of 71

Relays, Switches, Circuit Breaker & Wiring-Instrmnt Pnl & Btt

Ref #	Part Number	Qty	S/P/F	Description
1	725-0267	1	S	Switch, Key
	712-3013	1	/P	Nut, Mounting
2	703-1345	1	S	Key, Ignition (Set of 2)
3	725-0459	1	S	Breaker, Circuit (For Units w/ S/N 107,999 & Below)
	712-0147	2	/P	Nut, 10-24 Speed
	710-0351	2	/P	Screw, 10-24 X 1/2 "B" Tap
4	725-0893	1	S	Switch, PTO
	712-3014	1	/P	Nut, Mounting
5	725-3102	1	S	Switch, Solenoid
	710-0751	2	/P	Screw, 1/4-20 X .62 GR 5
	712-3006	2	/P	Nut, 1/4-20 GR 5
	736-3006	2	/P	Washer, 1/4 Ext-Int Tooth Lock
6	725-0894	2	S	Relay
	710-0751	4	/P	Screw, 1/4-20 X .62 GR 5
	712-3006	4	/P	Nut, 1/4-20 GR 5
	736-3006	4	/P	Washer, 1/4 Ext-Int Tooth Lock
7	725-3112	1		Harness, Battery Tray
8	725-3105	1		Harness, Main Wiring (For Units w/ S/N 107,999 & Below)
	725-3116	1		Diode Assy
	725-3121	1		Harness, Main Wiring (For Units w/ S/N 108,000 & Above)
9	703-1194	1		Pedestal
10	703-1144	1		Tray, Battery
	710-3008	4	/P	Bolt, 5/16-18 X 3/4 GR 5
	710-3010	4	/P	Nut, 5/16-18 GR 5
	736-0119	4	S	Washer, 5/16 Lock
	736-3007	4		Washer, 5/16 Ext-Int Tooth Lock
11	725-3115	1	S	Harness, Indicator
12	726-3008	1	/P	Clip, Cable
	710-3039	1	/P	Bolt, 5/16-18 X 1/2 GR 5
	712-3004	1	S	Nut, 5/16-18 Flange Lock
13	725-3120	1	S	Fuse (For Units w/ S/N 108,000 & Above)
14	729-0124	1		Fuse Holder (For Units w/ S/N 108,000 & Above)
15	726-0215	1		Cable Tie (For Units w/ S/N 108,000 & Above)




1110
Seat & Support

Page 61 of 71

Ref #	Part Number	Qty	S/P/F	Description
1	759-3148	1	/P	Seat w/Graphic
	710-3008	4	/P	Bolt, 5/16 X 3/4 GR 5
	736-0242	4	/P	Washer, .345 X .88 X .06 Belleville
	779-3349	1	/P	Graphic
2	703-0068	2	/P	Spring, Seat
	710-3002	4	S	Bolt, 5/16 X 1 GR 5
	736-3070	4	/P	Washer, .344 X 1.500 X .105
	712-3010	4	S	Nut, 5/16 GR 5
	736-0242	4	/P	Washer, .345 X .88 X .06 Belleville
3	703-0069	1		Cover, Seat Support
4	735-3005	2		Bumper Adhesive, Locktite #495
5	703-0070	1		Bracket Assy, Pivot LH
6	703-0072	1		Bracket, Assy, Pivot RH
	710-3000	4	S	Bolt, 3/8 X 3/4 GR 5
	736-0169	4	S	Washer, 3/8 Lock
7	723-3045	1		Bushing, Snap (1.0 ID)
8	725-3039	1		Switch Assy, Beam

1110
Starter Motor

Page 62 of 71



1110
Starter Motor

Page 63 of 71

Ref #	Part Number	Qty	S/P/F	Description
1	BS-394805	1	S	Motor Assy, Starter
	BS-93523	2		Bolt, Starter Mtg
2	BS-94003	2		Bolt
3	BS-395537	1		Cap Assy Commutator (Includes Ref No. 4)
4	BS-395538	1		Brush Assy
5	BS-394856	1	S	Cap, Drive End
6	BS-393825	1	S	Housing
7	BS-396865	1	S	Drive Assy (Includes Ref No. 8 & 10)
8	BS-391135	1	S	Clutch, Starter
9	BS-280104	1	S	Gear
10	BS-393254	1	S	Retainer Kit (Includes Ref No. 9 & 11)
11	BS-93754	1		Roll Pin

1110
Steering


Page 65 of 71

Ref #	Part Number	Qty	S/P/F	Description
1	731-0220	1	S	Cap, Steering Wheel
2	731-0356	1	F	Wheel, Steering (Non-Serrated)
	731-0806	1	S/F	Wheel, Steering (Serrated End)
	712-0158	1	S	Nut, Hex Cent-L 5/16-18
	736-0242	1	/P	Washer, .344 X .88 X .060
3	759-3272	1	F	Shaft Kit, Steering (Non-Serrated)
	738-3057	1		Shaft, Steering Wheel (For units w/ S/N 110213 & above)
4	741-3025	1		Bearing, Flange
	710-3105	2	/P	Bolt, 5/16 X 7/8 Sq-Nk Crg
	736-0119	2	S	Washer, 5/16 Lock
	712-3010	2	S	Nut, 5/16 GR 5
5	703-1242	1		Housing, Steering Gear (Includes Ref No. 6 & 7)
	710-0805	4	/P	Bolt, 5/16 X 1-1/2 GR 5
	736-0119	4	S	Washer, 5/16 Lock
	712-3010	4	S	Nut, 5/16 GR 5
	712-3043	4		Retainer, Bolt Push-on
6	748-3010	1	S	Bearing
7	748-3012	2		Bearing
8	736-3080	1		Washer, .63 X 1.13 X .09 Hdn
9	748-0237	1	S	Gear, Pinion
10	737-3001	1	/P	Fitting, 1/4 45D Taper Drive Thd Lub
11	703-1162	1		Plate, Back-Up
	710-0601	2	S	Bolt, 5/16 X 3/4 GR 5
12	703-1353	1	S	Gear, Side
13	711-3206	1		Spacer
	710-0539	1	/P	Bolt, 3/8-NF X 1-3/4 GR 5
	712-0241	1	/P	Washer, 3/8 Lock
	736-0169	1	S	Nut, 3/8-NF GR 5
14	703-1352	1		Shaft, Steering
15	710-0670	1	/P	Bolt, Nylon
	712-0798	1	/P	Nut, 3/8 GR 5
16	712-0237	1	S	Nut, 5/16-24 Hex Ctr Lock
17	736-0264	1	S	Washer, .344 X .62 X .063
18	736-0237	1	/P	Washer, .64 X 1.25 X .100
19	712-0204	1		Nut, 1/2-13 Insert Lock
20	779-3077	1		Label, Steering Cap
21	726-3008	1	/P	Clip, Cable

1110

Switches & Wiring -Seat & Fenders

Page 66 of 71



1110


Page 67 of 71

Switches & Wiring -Seat & Fenders

Ref #	Part Number	Qty	S/P/F	Description
1	725-3039	1		Switch, Seat
2	725-3119	2	S	Switch, Transmission Shift Lever
	710-3150	2		Screw, #4 X 1-1/2 Znp P/Hds Mach
	712-3052	2	/P	Nut, No. 4 Mach Screw
3	725-3119	1	S	Switch, Shift Cover
	710-3152	2		Screw, #4 X 3/4 Phc P/Hds Mach
	712-3052	2	/P	Nut, No. 4 Mach Screw
4	703-1165	1		Bracket, Switch Mounting
5	703-1164	1		Plate, Switch
	710-0751	2	/P	Bolt, 1/4 X 5/8
	736-0463	2	S	Washer, .281 X .62 X .06
6	703-1163	1		Plate, Shift Cover Switch
	710-3148	2		Screw, #8 X .43 Hex-Washer Hd
7	725-3105	1		Harness, Main Wiring (For Units w/ S/N 107,999 & Below)
	725-3121	1		Harness, Main Wiring (For Units w/ S/N 108,000 & Above)
8	731-3061	1		Cover, Switch

1110
Transaxle

Page 68 of 71




1110
Transaxle

Page 69 of 71

Ref #	Part Number	Qty	S/P/F	Description
	TC-1331	1		Transaxle Assy
1	TC-778197	2		Gear, Bevel Pinion
2	TC-778198	2		Gear, Bevel
3	TC-786019	1		Pin, Drive
4	TC-786027	2		Block, Drive
5	TC-774028A	1		Carrier, Differential
6	TC-774029A	1		Carrier, Differential
7	TC-778033A	1		Gear, Ring
8	TC-774588	1		Axle, 13-5/32 Long
9	TC-774587	1		Axle, 16-3/8 Long
10	TC-780107	2	/P	Washer
11	TC-780042	4		Washer, Thrust
12	TC-792018	2	S	Ring, Snap
13	TC-792020	4	S	Screw, Hex Hd Cap, 1/4-20 X 2-1/4
14	TC-792006	4		Lockwasher, 1/4
15	TC-770059	1		Case Assy (Includes Ref No. 16 & 17)
16	TC-780013	2	S	Bearing, Needle
17	TC-780088	1		Bearing, Needle
18	TC-772091	1		Cover Assy (Includes Ref No. 16 & 19)
19	TC-780089	1	/P	Bearing, Needle
20	TC-782041A	1		Housing & Bushing Assy, 6-5/8 Long (Includes Ref No. 21)
21	TC-780054	4	/P	Bushing
22	TC-782042A	1		Housing & Bushing Assy, 8-5/8 Long (Includes Ref No. 21)
23	TC-776093	1		Shaft, Brake
24	TC-788044	1	S	Gasket, Case-to-Cover
25	TC-778036	1		Gear, Output
26	TC-778037	1		Gear, Idler
27	TC-778041	1		Shaft, Output
28	TC-786017	1		Spacer
29	TC-780001	2		Washer
30	TC-780090	1		Washer
31	TC-788008	3	/P	Seal, Oil
32	TC-786026	2	/P	Pin, Dowel
33	TC-792046	10		Screw, Hex Hd Self-Tapping, 1/4-20 X 1
34	TC-792010	2		Plug, Pipe

1110
Transmission Controls

Page 70 of 71



1110

Page 71 of 71

Transmission Controls

Ref #	Part Number	Qty	S/P/F	Description
1	703-1267	1		Handle, Shifter Control (Includes Ref No. 24)
2	720-0175	1	S	Knob, Shifter
3	703-1220	1		Lever, Shifter
4	715-3032	1		Pin, 3/16 X 1 Pln Slit-Spr
5	723-3047	2		Bearing, Nyliner
6	723-3013	1	S	Washer, Friction
7	736-3022	3	S	Washer, .760 X 1.50 X .06 Belleville
8	712-3059	1	/P	Nut, 1/2 Cad P/T Lock GR 5
9	703-1176	1		Control, Brake Link See Brake & Connections, Ref No. 4
10	703-1191	1		Link, Actuator
	710-3000	1	S	Bolt, 3/8 X 3/4 GR 5
	712-3000	1	S	Nut, 3/8 Cad P/T Lock GR 5
11	711-3185	1		Bearing
12	703-1175	1		Shaft, Hydro Control
	710-3155	1		Bolt, 5/16 X 1 GR 5
	736-0231	1	S	Washer, .344 X 1.125 X .125
13	703-1118	1		Plate, Cam
	710-3154	2		Bolt, 3/8 X 2-5/8 Pln GR 5
	712-3000	2	S	Nut, 3/8 GR 5
14	719-3018	1		Clevis, 5/16-24 X 2-1/4 Pln Lt Adj
	712-3025	1		Nut, 5/16 NF Jam GR 5
	711-3060	1	/P	Pin, 5/16 X .940 Pln Clevis
	714-0507	1	S	Pin, 3/32 X 3/4 Cot
15	747-3101	1		Rod, Control
	714-0507	2	S	Pin, 3/32 X 3/4 Pln Cot
16	732-3022	2		Spring, Compression
17	703-0307	1		Arm Assy, Control Shaft
	736-0185	1	S	Washer, .406 X .750 X .060
	712-3000	1	S	Nut, 3/8 Cad P/T Lock GR 5
18	714-0112	1	S	Key, 1/8 X 1/2 SAE 3 Woodruff
19	719-3013	1	/P	Clevis, 3/8-24 X 2-1/2 C-Z Lt Adj
	712-3001	1	S	Nut, 3/8 NF Jam GR 5
	711-3010	1	S	Pin, 3/8 X 1.060 Clevis
	736-0185	1	S	Washer, .406 X .812 X .051
	714-0507	1	S	Pin, 3/32 X 3/4 Pln Cot
20	747-3100	1		Rod, Control
	714-0507	1	S	Pin, 3/32 X 3/4 Pln Cot
	736-0185	1	S	Washer, .406 X .812 X .051
21	711-3189	2		Spacer, .385 X .88 X 1.88
22	736-0140	2	S	Washer, .385 X .62 X .063
23	711-3192	1		Spacer, .635 X .88 X .40
24	710-3069	1	/P	Screw, 1/4 X 1/2 Hex-Soc-Hd