





SLT1554 Tractor Command Engine
Adjustable Seat Rev00

Page 2 of 62


Ref #	Part Number	Qty	S/P/F	Description
1	783-0739A	1	S	Lever, Seat, Adjustment
2	710-1268	2	/P	Screw, #10-16, 0.375
3	712-04063	2	/P	Nut, Nylon Lock, 5/16-18, Gr5
4	712-3027	1	S	Nut, Nylon Lock, 1/4-20
5	720-0433	1		Grip, Seat, Adjustment (Yellow)
6	726-0201	2		Nut, Speed,.3125 ID
7	731-04074	4		Spacer, Seat, Adjustment
8	732-0499	1		Spring, Compression.41 OD x 1.50
9	732-1184	1	/P	Spring, Extension,.80 Dia x 4.6 Lg.
10	783-0738B	1	S	Seat Pivot Bracket
11	757-04035	1		Seat, Mid-back, V-1480
12	783-0753	1		Selector, Seat, Adjustment
13	736-0275	3	S	Washer, Flat,.344 x.688 x.065
14	736-3019	2		Washer, Flat,.531 x 1.062 x.134
15	738-0137A	1	S	Screw, Shoulder,.340 x.285, 1/4-20
16	738-0296	2	S	Shoulder, Screw.437 x.286 Lg
17	738-0966	4	S	Screw, Shoulder,.50 x.925, 3/8-16
18	783-0209C	1	S	Bracket, Seat Lift
19	783-0611	1		Stop, Seat, Adjustment
20	710-0227	2	/P	Screw, #8-18 x.50
21	726-0279	2		Plate, Insulator
22	725-1303	1	S	Spring Switch, Outer
23	725-1439	1		Spring Switch, Inner
24	726-0278	1		Plate, Insulator Boss



SLT1554 Tractor Command Engine
Adjustable Seat Rev01

Page 4 of 62


Ref #	Part Number	Qty	S/P/F	Description
1	710-1268	2	/P	Screw Hex Wash Hd., #10-16, 0.375
2	712-04063	2	/P	Nut, Flange Insert Lck, 5/16-18,Gr5
3	712-3027	1	S	Nut, Flange Lock, 1/4-20
4	720-0433	1		Grip, Seat Adjustment (Yellow)
5	726-0201	2		Nut, Speed, .3125 ID
6	731-04074	4		Spacer, Seat, Adjustment
7	732-0499	1		Spring, Compression .41 OD x 1.5
8	732-1184	1	/P	Spring, Extension, .84 Dia x 4.6 Lg
9	736-0275	3	S	Washer, Flat, .344 x .688 x .065
10	736-3019	2		Washer, Flat, .531 x 1.062 x .134
11	738-0137A	1	S	Screw, Shoulder, .34 x .285, 1/4-20
12	738-0296	2	S	Shoulder, Screw .437 x .286 Lg
13	738-0966A	4	/P	Screw, Shoulder, .50 x.925:3/8-16
14	783-0209D	1	/P	Bracket, Seat Lift
15	783-0611	1		Stop, Seat, Adjustment
16	783-0738B	1	S	Bracket, Pivot, Seat
17	783-0739A	1	S	Lever, Seat, Adjustment
18	783-0753	1		Selector, Seat, Adjustment
19	757-04035	1		Seat, Mid-back, V-1480
19	777D06883	1	/P	Graphic, Made in USA
19	777D01782	1	/P	Graphic, Cub Cadet
20	17239D	1		Bracket, Seat Lift
21	710-0227	2	/P	Screw, #8-18 x.50
22	726-0279	2		Plate, Insulator
23	725-1303	1	S	Spring Switch, Outer
24	725-1439	1		Spring Switch, Inner
25	726-0278	1		Plate, Insulator Boss
26	757-04039	1	S	Arm Rest (If Equipped)
27	732-04309	1		Spring, Extension, .815 x 4.775



SLT1554 Tractor Command Engine
Air Intake Filtration

Page 6 of 62


Ref #	Part Number	Qty	S/P/F	Description
1	KH-M-0545010	2	/P	Screw, Hx Flange, M5-0.8 x 10
2	KH-24-126-130-S	1		Bracket, Air Cleaner Base
3	KH-M-651040-S	4		Screw, Hx Flange, M6-1.0 x 40
4	KH-24-164-51-S	1	S	Manifold, Intake
5	KH-24-153-27-S	2	/P	O-Ring, Intake Port
6	KH-24-041-52-S	1	/P	Gasket, Intake Manifold
7	KH-24-041-14	1	/P	Gasket, Air Cleaner Base
8	KH-24-094-34-S	1		Base, Air Cleaner
9	KH-24-041-13-S	1		Gasket, Fuel Spit-back Cup
10	KH-24-109-25-S	1	/P	Cup, Spit-back w/Stud
11	KH-24-083-03-S	1	S	Element, Air Cleaner
12	KH-24-083-05-S	1	S	Element, Precleaner
13	KH-231032	1	/P	Seal, Breather
14	KH-24-096-01	1	/P	Cover, Inner Air Cleaner
15	KH-12-100-01	1	/P	Nut, Wing
16	KH-24-096-67-S	1	/P	Cover, Air Cleaner
17	KH-54-755-01-S	1	/P	Kit, Knob w/Seal
18	KH-24-153-20-S	1		O-Ring
19	KH-25-341-04-S	1	/P	Knob, Cover
20	KH-24-063-51-S	1		Baffle, Fuel Spit-back



SLT1554 Tractor Command Engine
Blower Housing

Page 8 of 62


Ref #	Part Number	Qty	S/P/F	Description
1	KH-24-027-114-S	1		Housing, Blower
2	KH-24-100-01	2		Nut, Plastic
3	KH-M-0545020	4	/P	Screw, Hx Flange, M5-0.8 x 20
4	KH-M-545016-S	2	/P	Screw, Hx Flange, M5-0.8 x 16
5	KH-M-551016-S	1		Screw, Hx Flange, M5-0.8 x 16
6	KH-M-645016-S	6	/P	Screw, Hx Flange, M6-1.0 x 16
7	KH-24-146-18-S	1		Plate, Backing, #2 Side
8	KH-24-146-20-S	1	/P	Plate, Backing, #1 Side
9	KH-24-063-39-S	1	S	Baffle, Cylinder Barrel, #2 Side
10	KH-24-063-69-S	1		Baffle, Valley, #2 Side
11	KH-M-545010	2	S	Screw, Hx Flange, M5-0.8 x 10
12	KH-24-063-58-S	1	S	Baffle, Cylinder Barrel, #1 Side
13	KH-24-063-60-S	1		Baffle Valley, #1 Side
	KH-24-096-85-S	1		Cover, Blower Housing (Not Shown)
	KH-25-086-91-S	1	/P	Screw, Tapping (Not Shown)



SLT1554 Tractor Command Engine
Carburetor Fuel System

Page 10 of 62

Ref #	Part Number	Qty	S/P/F	Description
1	KH-24-853-102-S	1	/P	Kit, Carburetor w/Gaskets
2	KH-24-041-52-S	1	/P	Gasket, Carburetor
3	KH-24-041-14	1	/P	Gasket, Air Cleaner Base
4	KH-M-629095-S	2		Stud, Intake Manifold
5	KH-M-641060-S	2	/P	Nut, Hex Flange, M6-1.0
6	KH-25-237-14-S	6	/P	Clamp, Hose
7	KH-24-353-12	1		Line, Fuel, 11"
8	KH-24-086-12	2		Screw, Hex Cap, M6-1.7 x 18
9	KH-24-393-16	1	/P	Pump, Pulse Fuel
10	KH-24-100-01	2		Nut, Plastic
11	KH-15-353-04	1		Line, Fuel, 11-1/2
12	KH-25-353-03-S	2		Line, Fuel, 13-3/4
13	KH-24-050-10-S	1	S	Filter, Fuel
14	KH-47-154-01-S	1	/P	Clip, Cable
	KH-25-153-05-S	1		O-Ring, Heavy Duty Air Cleaner (Not Shown)
	KH-24-234-02-S	1		Chamber, Float (Not Shown)
	KH-24-431-01-S	1		Sleeve, Insulating (Not Shown)
	KH-24-757-18-S	1	/P	Kit, Overhaul w/Gaskets (Not Shown)
	KH-24-757-19	1	/P	Kit, Choke Repair w/Gaskets (Not Shown)
	KH-24-757-20	1		Kit, Gasket (Not Shown)
	KH-24-757-21-S	1	/P	Kit, Accelerator Pump, w/Gaskets (Not Shown)
	KH-24-757-22	1	/P	Kit, Solenoid, w/Gaskets (Not Shown)




SLT1554 Tractor Command Engine
Dash Panel

Page 12 of 62

Ref #	Part Number	Qty	S/P/F	Description
1	710-0192	2	/P	Screw, #10-24 X .375
2	710-04471	2		Screw, Ball, 5/16-18
3	710-0599	6	/P	Screw, Self-tapping, 1/4-20, 0.500
4	710-0642	2	/P	Screw, Hx. Wash. Hd, Tapp. 1/4-20 x .75
5	710-0726	8	/P	Screw, Hx. Wash. Hd, Tapp, 5/16-12 x .75
6	710-0837	1		Screw, Oval Cntrsnsk, #10-16 x .625
7	710-0895	3		Screw, 1/4-15, 0.750
8	710-1611B	6	/P	Screw, Torx Hd. Tapp. 5/16-18 x .75
9	710-3217	1	/P	Screw, Truss Mach., #8-32 x .375
10	712-0142	1	/P	Nut, Hex, #8-32 GrA
11	712-0324	1	/P	Nut, Hex Insert Lock, 1/4-20 GR8
12	712-3004A	2	/P	Nut, Hex Flange Lock, 5/16-18 GR5
13	714-0104	1	S	Internal Cotter Pin, .072 x 1.13
14	725-0157	1	/P	Cable Tie
15	727-3194	2		Cylinder, Gas
16	731-04293A	1	/P	Lever, Dash, Brake
17	731-04294A	1		Lever, Dash, Cruise
18	731-05077	1	S	Dash
18	777I22459	1		Graphic, Dash Insert
19	731-3161	1	S	Knob, Throttle Control
20	736-0173	3	/P	Washer, Flat, .28 x .74 x .063
21	736-0362	2	/P	Washer, Flat, .33 x 1.25 x .06 HT
22	741-0587	1		Bearing, Steering Column
23	747-04215	1	S	Strap, Batter
24	747-1323A	1		Rod, .25 x 4.55
25	783-04285B	1	S	Plate, Dash Support RH
26	783-04323B	1	S	Plate, Dash Support, LH
27	783-04475	1	S	Bracket, Steering Support
28	783-04506A	1	S	Plate, Dash Support
29	783-0462	1	/P	Bracket, PTO Switch Retainer
30	783-1447A	1	S	Bracket, Support, Battery
31	783-1499	1	S	Bracket, Rod, Dash
32	746-1100	1	S	Cable, Throttle, 38.0 Lg
33	746-04120	1		Cable, Choke, 40.5 Lg.
34	925-1707D	1	/P	Battery, 235 CCA, Dry
35	710-0703	1	/P	Screw, Carriage, 1/4-20, .75,
36	712-0271	1	/P	Nut, Hex, 1/4-20, Sems
37	712-3087	1	/P	Nut, Wing, 1/4-20
38	738-1132	1		Screw, Shoulder, 1/4-20, .25 x .15
	629-04139	1		Harness Assembly (shown with Electrical System including Switches)

SLT1554 Tractor Command Engine
Drive System

Page 13 of 62




Ref #	Part Number	Qty	S/P/F	Description
1	17840	2	S	Bracket, Mounting, Transaxle
2	618-04228	2	S	Hub Assembly, Wheel
3	618-04270	1	S	Transmission, Hydrostatic
4	629-04124	1		Harness Assembly, Ground & Reverse
5	783-04442	1		Bracket Assembly, Idler, Center Dbl
6	710-1266	4	/P	Hex Cap Screw, 5/16-18,3.5, Gr5
7	710-0227	2	/P	Screw, #8-18, 0.500
8	710-0344	1	/P	Hex Cap Screw, 3/8-16, 1.50, Gr5
9	710-0726	4	/P	Screw, 5/16-12, 0.75
10	710-0599	1	/P	Screw, 1/4-20, 0.5
11	710-3007	3	/P	Screw, #12-24, 0.375
12	710-3011	1	/P	Hex Cap Screw, 3/8-16, 2.25, Gr5
13	710-0809	1		Hex Cap Screw, 5/16-18, 1.25, Gr5
14	710-0627	2	/P	Hex Cap Screw, 5/16-24 x.750
15	711-0832	1	S	Ferrule, 3/8-24 x.375 Dia
16	712-0291	1	S	Nut, Hex Lock, 1/4-20
17	712-3066	1	S	Nut, Hex Lock, 1/2-20, Gr2
18	712-04065	1	/P	Nut, Nylon Lock, 3/8-16
19	731-05130	2		Sleeve, 2.4"
20	712-04063	4	/P	Nut, Flange Lock, 5/16-18, Gr5
21	750-0566A	1	/P	Spacer, 1"
22	712-3017	2	S	Nut, Hex, 3/8-16, Gr8
23	714-0104	1	S	Pin, Cotter,.072 Dia. x 1.13 Lg
24	714-0111	2	S	Pin, Cotter, 3/32, 1.0
25	725-0157	2	/P	Cable, Tie, 3/16 x.05 x 7.4
26	725-1644	1		Switch, Spring, Short
27	726-0154	1	S	Tie, Cable, Push Mount 7.5 Lg
28	726-0320	1	S	Plate, Insulator Nut
29	731-1449A	1	S	Fan, Blade, 10"
30	732-0209	1	S	Spring,.48 OD x 2.03 Extension
31	732-0429A	1	S	Spring, Extension,.50 Dia x 3.97 Lg
32	732-0716	1	S	Spring, Extension,.59 OD x 4.00 Lg
33	732-0729	1	/P	Ring, Wire
34	732-0994	1		Spring, Extension,.500 Dia x 7.0
35	732-3118	1		Spring, Extension, 3/8 OD x 1.44
36	710-0502A	1	/P	Screw, 3/8-16, 1.25
37	736-0169	1	S	Washer, Lock, 3/8, Regular Duty
38	736-0866	2		Washer, Flat,.755 x 1.92 x.060
39	736-0242	2	/P	Belle Washer
40	736-3010	1	/P	Washer, Flat,.407 x.812 x.135
41	738-0372B	1	/P	Spacer, Shoulder, 1.00 x.38 x.38
42	747-1149	1		Rod, Hydro Bypass
43	747-04139	1		Rod, Brake, Hydro
44	747-1151	1		Rod, Control, Hydro
45	756-0978A	1	S	Pulley, Engine, 3.56 Dia.
46	754-0461	1	S	Belt, V Type, Poly
47	756-0116A	2	S	Pulley, Idler, V Type x 3.06 Dia
48	756-0981B	1	S	Pulley, Idler, Flat 2.75 OD
49	756-04111	1		Pulley, Engine, 4.11Dia.
50	783-0810B	1	S	Bracket, Transmission, Torque Hydro
51	783-1019	1	S	Bracket, Actuator, Switch
52	736-0320	1	/P	Washer, Flat,.38 x 1.92 x.060
53	750-0535	1	S	Spacer,.380 ID x.625 OD x.21

SLT1554 Tractor Command Engine
Drive System

Page 15 of 62


Ref #	Part Number	Qty	S/P/F	Description
54	710-1007	1	/P	Screw, 3/8-16 x 1.500
55	748-0334	2	S	Transaxle Spacer
56	736-0921	1	S	Washer, Lock, 1/2"




SLT1554 Tractor Command Engine
Electrical System

Page 17 of 62

Ref #	Part Number	Qty	S/P/F	Description
1	17962	1		Plate, Switch
2	629-04139	1		Harness Assembly
3	629-04142	1	S	Harness Assembly, Headlight
4	710-0224	2	S	Screw, Hx. Wash. Hd. Tapp, 10-16 x .5
5	710-0227	2	/P	Screw, Hx. Wash. Hd. Tapp, 8-18 x .5
6	725-04022	1	S	Indicator/ Meter Hour
7	725-04039	1	S	Switch, Interlock
8	725-04175	1	S	Switch, Electric PTO, Yellow Knob
9	725-1303	1	S	Switch, Outer Seat Spring
10	725-1439	1		Switch, Inner Seat Spring
11	725-2054	2	S	Key, Switch, Plastic
12	726-0278	1		Plate, Insulator Boss
13	726-0279	2		Plate, Insulator
14	725-04227	1	S	Switch, Key/Module
15	725-1648	1	S	Relay
16	725-1381	1	S	Fuse, 20 Amp
17	725-04008	1		Fuse, 5 Amp
18	725-2003	1		Receptacle, Power 12V




Ref #	Part Number	Qty	S/P/F	Description
1	710-0227	4	/P	Screw, #8-18, 0.500
2	710-0599	4	/P	Screw, Hex, 1/4-20, 0.500
3	710-0726	2	/P	Screw, Hex, 5/16-12 x.75
4	710-1315	4	/P	Screw, Hex, 3/8-16 x 1.25
5	751-0805	1	S	Muffler, Dual Inlet
6	725-0157	2	/P	Cable, Tie, 3/16 x.05 x 7.4
7	751-0645A	1	/P	Pipe, Exhaust, RH
8	712-3005	1	S	Flange Lock Nut, 3/8-16
9	736-0300	1	S	Flat Washer,.406 x.875 x.059
10	751-0644B	1	/P	Pipe, Exhaust, LH
11	751-0564A	1	S	Deflector, Muffler
12	783-0615D	1	S	Bracket, Muffler
13	751-3142	1		Cap, Oil Drain
14	751-3140	1	S	Drain, Oil
15	751-3141	1	S	Extension Hose, Oil Drain



SLT1554 Tractor Command Engine
Engine Controls

Page 21 of 62


Ref #	Part Number	Qty	S/P/F	Description
1	KH-24-211-03-S	1		Bolt, Round Hd, M6-1.0 x 25
2	KH-24-090-33-S	1	S	Lever, Governor
3	KH-M-641060-S	1	/P	Nut, Hex Flange, M6-1.0
4	KH-24-089-01	1		Spring, Linkage
5	KH-25-158-08	1	/P	Bushing, Linkage Retaining
6	KH-24-079-04	1		Linkage, Throttle
7	KH-25-158-11	2	/P	Bushing, Throttle Linkage
8	KH-M-547050-S	1		Nut, Hex Lock
9	KH-24-089-03	1		Spring, Choke Return
10	KH-24-126-56	1	S	Bracket, Control
11	KH-M-645016-S	4	/P	Screw, Hex Flange
12	KH-47-237-02	1	S	Clamp, Bowden
13	KH-24-086-43-S	1		Screw, Thread Forming
14	KH-24-112-27-S	1		Spacer, Control Assembly
15	KH-24-090-47-S	1		Lever, Throttle Actuator
16	KH-24-468-20-S	1		Washer, Plain
17	KH-M-446030-S	1	/P	Nut, Hex M4 x 0.7
18	KH-M-403025	1		Screw, Hex. Hd, M4-0.7 x 25
19	KH-24-090-13	1		Lever, Throttle Control
20	KH-24-468-01	1		Washer, Plain
21	KH-24-090-05	1		Lever, Choke
22	KH-41-468-03	1		Washer, Wave
23	KH-M-545020-S	1		Screw, Hx Flange, M5-0.8 x 20
24	KH-24-079-22-S	1		Linkage, Choke
25	KH-24-089-55-S	1		Spring, Governor
26	KH-24-089-25-S	1	/P	Spring, Governor



SLT1554 Tractor Command Engine
Engine Crankcase

Page 23 of 62


Ref #	Part Number	Qty	S/P/F	Description
	KH-CV740-0026	1	/P	Complete Engine
1	KH-24-014-42	1	S	Crankshaft
2	KH-52-139-09	2	S	Plug, Cup
3	KH-24-032-01	1	S	Seal, Front Oil
4	KH-24-782-23	1		Crankcase, (Use Miniblock)
5	KH-24-294-13	1	/P	Fitting
6	KH-24-380-13-S	6	S	Pin, Locating Dowel
7	KH-24-067-13	2	S	Rod, Connecting, Std
	KH-24-067-14	2		Rod, Connection, .010 / .25mm
8	KH-24-874-08-S	2	S	Piston w/Ring Set, Std
	KH-24-874-20-S	2	S	Piston w/Ring Set, .010 / .25mm
	KH-24-874-21-S	2		Piston w/Ring Set, .020 / .50mm
	KH-24-874-16-S	2	S	Piston w/Ring Set, .08mm
9	KH-24-108-04-S	2	/P	Ring Set, Std., .08
10	KH-24-018-01	4	S	Retainer, Piston Pin
11	KH-12-422-09	AR	S	Shim, Camshaft, .0320 (Red)
	KH-12-422-13	AR	S	Shim, Camshaft, .0400 (Black)
	KH-12-422-07	AR	S	Shim, Camshaft, .0280 (White)
	KH-12-422-08	AR	S	Shim, Camshaft, .0300 (Blue)
	KH-12-422-10	AR	S	Shim, Camshaft, .0340 (Yellow)
	KH-12-422-11	AR	S	Shim, Camshaft, .0360 (Green)
	KH-12-422-12	AR	S	Shim, Camshaft, .0380 (Gray)
12	KH-24-012-18-S	1		Camshaft Assembly
13	KH-M-0545010	1	/P	Screw, Hex Flng, M5 x 0.8 x 10
14	KH-24-018-04	1		Retainer, Breather Reed
15	KH-24-402-05-S	1	/P	Reed, Breather
16	KH-12-153-01-S	1	/P	O-Ring
17	KH-24-126-19	1		Bracket, Oil Fill Tube
18	KH-12-123-04	1	S	Tube, Oil Fill
19	KH-M-545016-S	1	/P	Screw, Hex Flange, M5 x .8 x 16
20	KH-12-153-02-S	1	/P	O-Ring, Upper Oil Fill Tube
21	KH-24-038-04-S	1	/P	Dipstick Assembly
22	KH-24-755-46	1	/P	Kit, Oil Fill Cap
23	KH-25-153-02-S	1		O-Ring, Dipstick
24	KH-24-018-09-S	1		Ring, Retainer
25	KH-M-931010-S	1		Washer, Nylon
26	KH-28-032-09-S	1		Seal, Governor Cross Shaft
27	KH-24-468-15-S	1		Washer, Plain
28	KH-24-144-38-S	1	/P	Shaft, Governor Cross
	KH-24-755-113-S	1	S	Gasket Set



SLT1554 Tractor Command Engine
Fender & Fuel Tank

Page 25 of 62

Ref #	Part Number	Qty	S/P/F	Description
1	710-0451	2	/P	Bolt, Carriage, 5/16-18 x .75 Lg
2	710-0599	2	/P	Screw, Hex Wash Hd Tap, 1/4-20 x .5
3	710-0726	8	/P	Screw, Hex Wash Hd Tap, 5/16-12, 0.75
4	710-0895	6		Screw, 1/4-15, 0.750
5	712-04063	2	/P	Nut, Flange Insert Lock, 5/16-18 GRF
6	731-2616A	1	S	Cover, Fender, RH
7	731-2617	1		Cover, Fender, LH
8	736-0607	1	/P	Washer, External Tooth Lock, 5/16
9	736-3078	2	/P	Washer, Flat, .349 x 1.00 x .063
10	783-04398A	1	S	Fender
	777D08309	1	S	Graphic, Rear of Fender
	777S32484	1		Graphic, Warning/Instruction
11	783-0677	1	S	Bracket, Lift, Adjustment
12	783-1489A	2	/P	Bracket, Seat, Mount
13	726-3046	12	/P	Clip, Ratchet, .250 Dia
14	735-0697A	1		Pad, Foot, LH
15	735-0698B	1		Pad, Foot, RH
16	751-0819B	1	S	Tank, Fuel
17	751-3124B	1	S	Cap, Fuel




SLT1554 Tractor Command Engine
Frame

Page 27 of 62

Ref #	Part Number	Qty	S/P/F	Description
1	17962	1		Plate, Switch
2	683-04173	1	S	Frame Assembly, Lower
3	726-0205	2	/P	Clamp, Hose,.490 Dia.
4	710-0224	2	S	Screw, Hex Wash. Hd. Tapp, 10-16 x.5
5	710-0726	13	/P	Screw, Self-tapping, 5/16-18, 0.75
6	751-0535	1		Fuel Line
7	710-1652	1	/P	Screw, Hex Wash. Hd. Tapp, 1/4-20 x 0.625
8	725-04039	1	S	Switch, Interlock
9	712-04065	4	/P	Nut, Nylon Lock, 3/8-16
10	710-0607	1	/P	Screw, Hex Wash. Tapp, 5/16-18 x.5
11	783-04329A	1		Bracket, Frame, Seat
12	741-04092	1		Snap Bushing
13	732-04035	2		Spring, Compression, 1.28 OD x 3.125 Lg
14	736-0222	1	S	Washer, Lock, Ext 1/4
16	738-04058	2		Shoulder Spacer
17	738-0143	2	/P	Shoulder Screw, 3/8-16
18	710-3005	2	/P	Hex Screw 3/8-16 x 1.25
19	783-0726D	1	/P	Bracket, Pivot, Support RH
20	783-0727C	1	/P	Bracket, Pivot, Support LH
21	783-0728	1		Bracket, Pivot, Bar
22	783-04330A	1	S	Frame, Upper

SLT1554 Tractor Command Engine
Head Valve Breather

Page 28 of 62




SLT1554 Tractor Command Engine
Head Valve Breather

Page 29 of 62

Ref #	Part Number	Qty	S/P/F	Description
1	KH-24-033-03	1		Kit, Breather Cover
2	KH-24-041-51-S	1	S	Gasket, Breather
3	KH-24-096-87-S	1		Cover, Breather
4	KH-M-645020-S	4	/P	Screw, Hx Flange, M6-1.0 x 20
5	KH-25-351-01	4	S	Lifter, Valve
6	KH-24-755-66	1	/P	Kit, Valve Train
7	KH-24-411-05	4	/P	Rod, Push
8	KH-24-841-03-S	2	/P	Kit, Cylinder Hd Gasket (Includes Head Mtg. Hardware)
9	KH-24-318-72-S	1		Head Assembly, #2 Cylinder
10	KH-25-186-01	4	/P	Arm, Rocker
11	KH-24-599-01	4	S	Pivot, Rocker Arm
12	KH-12-086-16	8	S	Screw, Hex Flange
13	KH-66-086-07-S	4	S	Screw, Hex Flange, M6-1.0 x 34
14	KH-24-755-141-S	1	/P	Kit, Valve Cover
15	KH-24-153-28-S	1	S	O-Ring
16	KH-M-651030-S	4		Screw, Hex Flange, M6-1.0 x 30
17	KH-24-445-01	1	S	Strap, Lifting
18	KH-24-016-01	2	/P	Valve, Exhaust, Std
	KH-24-016-02	2		Valve, Exhaust, .010 (25mm)
19	KH-24-017-01	2	/P	Valve, Intake, Std.
	KH-24-017-02	2		Valve, Intake, .010 (25mm)
20	KH-66-032-05-S	2	/P	Seal, Valve Stem
21	KH-235011-S	4	/P	Retainer, Spring
22	KH-24-089-02	4	/P	Spring, Valve
23	KH-12-173-01	4	/P	Cap, Valve Spring
24	KH-12-755-03	4	/P	Kit, Retainer
25	KH-24-318-69-S	1	/P	Head, Cylinder, #1
26	KH-24-755-142-S	1	/P	Kit, Valve Cover
27	KH-25-313-03-S	1	/P	Grommet, Rubber
28	KH-24-755-57-S	1	/P	Kit, Breather Separator
29	KH-24-326-74-S	1	S	Hose, Breather
30	KH-25-072-04	4	/P	Stud, M8-1.25 x 33
31	KH-24-041-49-S	2	/P	Gasket, Exhaust
32	KH-M-0841080	4	S	Nut, Muffler Mtg., M8-1.25
	KH-24-755-147-S	1		Kit, Cylinder Head Hardware (Not Shown)

SLT1554 Tractor Command Engine
Hood & Grille


Page 30 of 62



SLT1554 Tractor Command Engine
Hood & Grille

Page 31 of 62

Ref #	Part Number	Qty	S/P/F	Description
1	710-0726	4	/P	Screw, 5/16-12 x.750
2	710-0895	12		Screw, 1/4-15 x.750
3	710-1276	4	/P	Screw, Self Tapp, 1/4-20 x.750
4	710-3170	2		Screw, Ball, 5/16-18 x.56
5	711-0332	2	S	Pin, Clevis,.50 Dia. x.78 Lg.
6	712-3004A	2	/P	Nut, Flange Lock, 5/16-18
7	714-0104	1	S	Pin, Cotter,.072 Dia. x 1.13 Lg.
8	714-0145	2	S	Pin, Click,.092 x 1.64 Lg.
	759-04209	1	/P	Hood, Service Kit (contains 931-06887, 726-0233, 710-1242 and installation instructions)
9	931-06887	1	S	Hood Replaces 731-05053
9	726-0233	4	/P	Push Nut .25ID x .50 OD
9	710-1242	4	/P	Screw, Hi Low 5/16-14 x .75
10	731-05103	1	S	Grill
11	731-05111	1	S	Lens
12	731-05129	1		Hood Plenum
13	732-04281	1	S	Latch Spring
14	747-04354	1	S	Hood Pivot Rod
15	747-04368	1	/P	Hood Latch Rod
16	747-1323A	1		Rod,.250 Dia. x 4.55 Lg.
17	749-04207	1	S	Bumper
	731-05368	1		Cap, Bumper
18	783-04662	1	S	Hood Hinge Bracket
19	783-04714	1	S	Latch Plate
20	783-04717	1	S	Latch Pivot Bracket
21	783-04724	2	S	Upper Pivot Bracket
22	783-04725	2		Hood Pivot Bracket
23	725-0963	2	S	Miniature Lamp, 12V
24	725-1649	2	S	Lamp Socket
	629-04142	1	S	Headlight Harness (Not Shown)




SLT1554 Tractor Command Engine
Ignition Electrical

Page 33 of 62

Ref #	Part Number	Qty	S/P/F	Description
1	KH-24-755-79	1	/P	Kit, Grass Screen
2	KH-25-086-117-S	4		Screw, Hex Sems
3	KH-25-086-47	4	/P	Bolt, Shoulder
4	KH-24-157-08-S	1		Fan
5	KH-12-086-14	1		Screw, Hx Flange, M10-1.5 x 46
6	KH-12-468-03	1	/P	Washer, Plain, 3/8
7	KH-X-42-15	1	/P	Key
8	KH-24-025-15-S	1	S	Flywheel
9	KH-41-403-09	1	S	Rectifier-Regulator
10	KH-X-25-92	2		Washer, Plain, 3/16
11	KH-24-086-18	2		Screw, Phillips Hd, 11-16 x 7/8
12	KH-236602-S	1	S	Connector
13	759-3336	2	/P	Spark Plug
14	KH-M-548025-S	2	/P	Screw, Hx Cap, M5-0.8 x 25
15	KH-54-755-09-S	1	S	Kit, 15 Amp Stator
16	KH-24-126-139-S	1		Bracket, Stator Wire
17	KH-47-154-01	2	S	Clip, Cable
18	KH-48-154-02	1		Clip, Cable
19	KH-X-25-63	1	/P	Washer, Plain, 1/4
20	KH-24-584-36-S	2	/P	Module, Ignition
21	KH-M-0545020	4	/P	Screw, Hx Flange, M5-0.8 x 20
22	KH-24-584-31-S	1	S	Module, Speed Advance
23	KH-M-448010	2		Screw, M4 x 0.7 x 10
	KH-24-176-81-S	1		Harness, Wire (Not Shown)
	KH-24-126-137-S	1		Bracket, Ground Strap (Not Shown)
	KH-25-454-03-S	3		Tie, Wire (Not Shown)

SLT1554 Tractor Command Engine Label Map


Page 34 of 62



SLT1554 Tractor Command Engine
Label Map

Page 35 of 62

Ref #	Part Number	Qty	S/P/F	Description
777D06883	777D06883	1	/P	LABEL-SEAT BACK
777X40182	777X40182	1		LABEL-80 DBA
777I22459	777I22459	1		LABEL-DASH PANEL
777S30503	777S30503	1	/P	LABEL-DANGER CHUTE
777D09508	777D09508	1		LABEL-CYCLO CUT
777D07875	777D07875	1		LABEL-54" CUT
777S30015	777S30015	1		LBL.RIDER DNGR.STRAIGHT
777D08735	777D08735	1		LABEL-RH SIDE LT1554
777D08734	777D08734	1		LABEL-LH SIDE LT1554
777D07559	777D07559	1		LABEL-LFT SIDE HOOD
777D07558	777D07558	1		LABEL-RGT SIDE HOOD
777X42027	777X42027	1		LABEL-GRILLE REFLECTOR
777S32484	777S32484	1		LABEL-FRAME COVER
777X42036	777X42036	1		LABEL: CUB RIDER
777I20310	777I20310	1		LABEL-SEAT ADJUSTER
777I22241	777I22241	1		LABEL-FUEL LEVEL
777D08309	977D08309	1	/P	LABEL-1500 FENDER
777I22240	777I22240	1		LABEL-HYDRO ENGAGE
777X42064	777X42064	1	/P	LABEL-PARTS LIST
777I22280	977I22280	1	/P	LABEL-THROTTLE




SLT1554 Tractor Command Engine
Lift Assembly

Page 37 of 62

Ref #	Part Number	Qty	S/P/F	Description
1	683-04118	1	S	Shaft Assembly, Lift
2	711-0332	2	S	Pin, Clevis, .50 Dia x .78 Lg
3	712-0206	2	S	Nut, Hex, 1/2-13, Gr5
4	712-04065	2	/P	Nut, Flange Insert Lock, 3/8-16 GrF
5	712-04063	2	/P	Nut, Flange Insert Lock, 5/16-18, GrF
6	712-3083	2	/P	Nut, Hex Lock, 1/2-13, Gr8, Nylon
7	714-0104	2	S	Pin, Cotter, .072 Dia. x 1.13 Lg
8	714-0111	2	S	Pin, Cotter, 3/32, 1.0
9	714-04023	2	S	Pin, Internal Cotter, .080 x 1.56 Lg
10	716-0106A	2		E-ring, .625 Dia. Shaft
11	720-0311	1		Grip, Handle
12	732-0874	1	/P	Spring, Torsion
13	738-0138A	2	/P	Screw, Hex Cap, 5/16-18x.620 Gr2
14	738-0380	2	S	Shoulder Screw, .5 x .27:3/8-16
15	741-0225	2	S	Bearing, Hex Flange
16	746-0968	2		Cable, Lift, 16.16 Lg
17	747-04155	1		Handle, Lift
18	747-1324	1		Rod, Deck, Front Adjustment .5" Dia
19	756-1154	2		Pulley, Roller
20	783-0678A	2	S	Lift, Arm
21	783-0720A	1	S	Bracket, Adjustment, Front Deck Rod

SLT1554 Tractor Command Engine
Mower Deck

Page 38 of 62



SLT1554 Tractor Command Engine
Mower Deck

Page 39 of 62

Ref #	Part Number	Qty	S/P/F	Description
1	16606	1	S	Hook, Retainer Bracket
2	618-04129B	3	S	Spindle Assembly Complete
3	618-04217	3	S	Housing Assembly, Spindle
4	683-0254B	1	/P	Hanger Bracket Assembly
5	683-04180	1	S	54" Deck Assembly
6	683-04182	1	S	Idler Arm Assembly
7	703-2093	1		Inner Rear Baffle
8	703-3279	1		Chute Deflector Stop
9	710-0216	2	/P	Screw, 3/8-16 x.75
10	710-0347	2	/P	Screw, 3/8-16 x 1.75 GR5
11	710-0528	1	/P	Screw, 5/16-18 x 1.25
12	710-0599	1	/P	Screw, 1/4-20 x.500
13	710-0623	3	/P	Screw, TT, 3/8-16 x.750
14	710-0726	1	/P	Screw, 5/16-12 x.750
15	710-1260A	12	/P	Screw, 5/16-18 x.750
16	710-3103	1	/P	Screw, 5/16-18 x 2.00
17	710-04095	1		Screw, Spec. Hex Cap, 3/8-16 x 1.0
18	710-3178	2	/P	Bolt, Carriage, 3/8-16 x.750
19	710-0607	14	/P	Screw, Hx. Wash Hd Tapp, 5/16-18 x .5 GR1
20	711-1737	1		Pin, Roller,.5" Dia. x 10.06 Lg.
21	712-0229	2		Push Nut, 3/8
22	712-04063	1	/P	Nut, Flange Lock, 5/16-18
23	712-04065	9	/P	Nut, Flange Lock, 3/8-16
24	712-0431	4	S	Nut, Flange Lock, 3/8-16
25	712-0641	2	S	Nut, Hex, M16-1.5
26	712-3010	1	S	Nut, Hex, 5/16-18
27	712-3022	1	/P	Nut, Hex Lock, 1/2-13
28	710-3168	1	/P	Screw, Carriage, 3/8-16 x 1.0
29	714-0111	1	S	Pin, Cotter, 3/32 x 1.00
30	714-0470	2	S	Pin, Cotter, 1/8 x 1.25
31	717-04074	1	S	Deck Adjustment Gear
32	721-04041	1	S	Water Nozzle Adapter
33	731-3005	1	/P	Front Roller
34	732-0306A	2	S	Sprg, Compr, .531 x 1.75 Lg.
35	732-04247	1		Spring, Extension, .85 x 6.415 Lg.
36	732-0971	1		Spring, Extension, 1.01 x 6.5 Lg.
37	734-04155	4		Deck Wheel
38	736-0119	1	S	Washer, Lock, 5/16
39	736-0300	2	S	Washer, Flat,.406 x.875 x.059
40	736-0760	2	S	Washer, Lock
41	736-0921	1	S	Washer, Lock, 1/2
43	737-04003C	2	S	Deck Water Nozzle
44	738-3056	4	S	Screw,.5 x 2.5:3/8-16
45	738-1229A	1	/P	Screw,.625 x 2.50 x 1/2-13
46	759-3820	3	/P	Blade, High Lift, 18.5 Lg.
47	747-04384	1		Rod, Upstop
48	747-1116	2	/P	Rod, Handle, Deck Release
49	710-0650	1	/P	Screw, Hx. Tapp, 5/16-18 x .875
50	750-0151	2	S	Spacer,.550 ID x.755 OD x 1.1
51	754-0642	1	S	Belt, V, B Sec, 138.0
52	756-04129	2	S	Pulley, Idler, 4.25" Dia.
53	783-04013A	1		Bracket, Stabilizer, Pulley
54	783-04462	1		Bracket, Lift


SLT1554 Tractor Command Engine
Mower Deck

Page 40 of 62

Ref #	Part Number	Qty	S/P/F	Description
55	783-04690	2	S	Skirt, Deck
56	783-04691	1		Cover, Belt, RH
57	783-04692	1		Cover, Belt, LH
58	783-04726	1		Bracket, Idler, Stationary
59	631-04070	1	S	Chute Assembly, Side Discharge
60	783-04470	1	/P	Chute Mounting Bracket
61	732-3070	1	S	Torsion Spring
62	931-3131A	1	/P	Deflector Chute
63	711-1762	1		Hinge Pin
64	736-0275	1	S	Washer, Flat, .344 x .688 x .065
65	736-3010	1	/P	Washer, Flat, .407 x .812 x 1.35 HT
66	710-04226	3	/P	Bolt, Spindle, 3/4-16 x 5.85
67	712-3078	3	/P	Nut, Hx Flange Lock, 3/4-16 GR8
68	737-3000	3	S	Fitting, Lube, 3/16 Drive
69	748-0433	3		Spacer, .82 x 1.15 x .73
70	748-3065A	6	/P	Spacer, Deck Spindle
71	748-3101	6		Spacer, Blade
72	756-3096	3	/P	Pulley, Spindle
73	721-3018A	6	S	Seal, Oil, Single Lip
74	741-04129	6	S	Bearing, Cone
75	741-04130	6	S	Cup, Bearing
76	750-3190A	3	/P	Spacer, Bearing, .780 x 1.000 x

SLT1554 Tractor Command Engine
Oil Pan Lubrication

Page 41 of 62




SLT1554 Tractor Command Engine
Oil Pan Lubrication

Page 42 of 62

Ref #	Part Number	Qty	S/P/F	Description
1	KH-24-199-21-S	1		Kit, Oil Pan, Includes 2-13
2	KH-M-645025-S	2	/P	Screw, Hx Flange, M6 -1.0 x 25
3	KH-M-631005	2	/P	Washer, 6mm
4	KH-24-393-37-S	1	S	Oil Pump Ass'y., Includes 5, 6
5	KH-24-153-01	1	/P	O-Ring,
6	KH-24-381-11-S	1		Tube, Oil Pick-up
7	KH-24-162-26-S	1		Screen, Oil
8	KH-24-043-12	1	/P	Kit, Governor Gear
9	KH-12-380-01	1	/P	Pin, Governor Regulating
10	KH-24-448-02-S	1		Tab, Locking
11	KH-12-144-02	1		Shaft, Governor Gear
12	KH-24-041-54-S	1	/P	Gasket, Oil Pan
13	KH-52-032-08	1	S	Seal, Oil
14	KH-24-422-03-S	1		Shim, Thrust
15	KH-25-139-62-S	1	/P	Plug, 3/8 Hex Ctsk
16	KH-24-755-52	1		Kit, Oil Cooler
17	KH-24-136-05-S	1		Nipple, Oil Filter
18	KH-24-594-24-S	1		Cooler, Oil
19	KH-24-041-29	1		Gasket, Oil Filter Adapter
20	KH-12-050-08	1	S	Filter, Oil
21	KH-24-086-16	9	S	Screw, Hx Flange, M8-1.25 x 45
22	KH-24-086-17	1	S	Screw, Hx Flange, M8-1.25 x 45
23	KH-25-139-57-S	1	/P	Plug, Pipe, 3/8

SLT1554 Tractor Command Engine Pedal Assembly


Page 43 of 62



SLT1554 Tractor Command Engine
Pedal Assembly

Page 44 of 62

Ref #	Part Number	Qty	S/P/F	Description
1	647-0031B	1	S	Control Assembly, Brake
2	647-0049A	1	S	Control Assembly, Hydro
3	710-0726	4	/P	Screw, Self-tapping, 5/16-12, 0.75
4	710-0650	1	/P	Screw, Self-tapping, 5/16-18, 0.875
5	736-0119	1	S	Washer, Lock, 5/16
6	783-0773A	1		Pedal, Brake
7	711-04159B	1		Pin, 3/8-16, 3/8 x 2.68
8	712-04065	2	/P	Nut, Nylon Lock, 3/8-16
9	712-3004A	1	/P	Nut, Flange Lock, 5/16-18, Gr5
10	714-0104	4	S	Pin, Cotter,.072 Dia. x 1.13 Lg
11	714-0111	2	S	Pin, Cotter, 3/32, 1.0
12	719-0584A	1	S	Pedal, Hydro Control
13	732-0335	1		Spring, Compression,.405 x 1.17
14	732-0955	1		Spring, Extension,.50 OD x 1.41 Lg
15	732-0963	1		Spring, Extension,.50 Dia x 6.37 Lg
16	735-3049	1	S	Pad, Brake, Control
17	783-0663E	1	/P	Bracket, Lockout, Hydro
18	710-1611B	3	/P	Screw, Torx Hd. Tapp. 5/16-18 x.75
19	736-0187	2	/P	Washer, Flat.64 ID x 1.24 x.06
20	736-3008	1	S	Washer, Flat,.344 x.750 x.120
21	738-0155	1	S	Shoulder, Screw.437
22	738-0380	1	S	Shoulder, Screw 3/8-16
23	741-0225	2	S	Bearing, Hex Flange
24	741-3065B	2	/P	Bearing, Hex Flange,.628 ID, Split
25	747-04096	1		Rod, Control, Cruise
26	747-04093	1		Rod, Control, Brake Lock
27	748-04039B	1	/P	Latch, Cruise
28	783-04612	1	S	Bracket, Support, Steering



SLT1554 Tractor Command Engine
Power Take Off System

Page 46 of 62


Ref #	Part Number	Qty	S/P/F	Description
1	710-0859	1	/P	Screw, 3/8-16 x 2.5 GR5
2	710-0726	3	/P	Screw, 5/16-12,.75
3	783-04419A	1	S	Bracket, Clutch
4	710-3157A	1	/P	Screw, Hex Cap, 7/16-20 x 3.25 GR5
5	783-04467	1		Deck Stop
6	717-1774B	1	S	Clutch, Electric PTO
7	712-04065	1	/P	Nut, Hx. Nylon Lock, 3/8-16
8	736-0277	1		Washer, Flat, 1.031 x 1.62 x.095
9	748-0415B	1	/P	Spacer, 3/8 x 1.54



SLT1554 Tractor Command Engine
Quick Reference

Page 48 of 62

Ref #	Part Number	Qty	S/P/F	Description
	759-3336	1	/P	Spark Plug
	KH-24-083-03-S	1	S	Air Filter
	KH-24-083-05-S	1	S	Pre-Cleaner
	KH-12-050-01-S	1	/P	Oil Filter
	KH-24-050-13-S	1	/P	Fuel Filter
	KH-24-584-36-S	1	/P	Ignition Module
	KH-41-403-09	1	S	Voltage Regulator
	KH-24-393-16	1	/P	Fuel Pump
	KH-24-757-18-S	1	/P	Carb Kit
	KH-24-757-22	1	/P	Carburetor Solenoid
	954-0461	1	/P	Drive Belt (Trans)
	954-0642	1	/P	P.T.O. / Deck Belt
	759-3820	1	/P	Blades (742-3013) (3 used)
	712-3078	1	/P	Blade Nut
	918-04129B	1	/P	Spindle Assy. w/Pulley
	734-04155	1		Deck Wheels (Front)
	734-04155	1		Deck Wheels (Back)
	737-04003D	1	/P	Water Nozzle Adapter
	923-0448A	1	/P	Ball Joints
	925-04039	1	/P	Brake Switch
	951-3124D	1	S	Fuel Cap
	725-2054A	1	S	Ignition Keys
	925-04227B	1	/P	Ignition Switch Module
	KH-25-435-06-S	1	/P	Solenoid, Starter
	925-04175	1	/P	P.T.O. Switch
	917-1774C	1	/P	P.T.O. Clutch
	KH-25-357-05-S	1	S	Engine Oil
	737-3121	1	/P	Transmission Fluid, Gallon
	490-900-0041	1		Deck Leveling Gauge Accessory




SLT1554 Tractor Command Engine
Starter

Page 50 of 62

Ref #	Part Number	Qty	S/P/F	Description
1	KH-M-839080	2	S	Screw, Hx Flange, M8-1.25 x 80
2	KH-25-098-09-S	1	S	Starter, Solenoid Shift
3	KH-25-086-113-S	3		Screw, Torx Hd
4	KH-25-435-05-S	1	S	Kit, Solenoid
5	KH-25-755-33-S	1		Kit, Starter Pinion
6	KH-25-141-05-S	1		Ring
7	KH-25-221-01-S	1		Kit, Brush

SLT1554 Tractor Command Engine
Steering


Page 51 of 62



SLT1554 Tractor Command Engine
Steering

Page 52 of 62

Ref #	Part Number	Qty	S/P/F	Description
1	710-0514	1	/P	Hex Cap Screw, 3/8-16, 1.00, Gr5, Std
2	711-1408	1		Link, Drag, RH
3	711-1409A	1	/P	Link, Drag, LH
4	710-1260	1	S	Self-tapping Screw, 5/16-18 x.75
5	712-0240	2	S	Nut, Jam, 7/16-20, Gr2
6	712-0214	2	S	Nut, Hex, 3/8-24, Gr5
7	712-04065	4	/P	Nut, Nylon Lock, 3/8-16
8	712-0459	1	/P	Nut, Flange Lock, 7/16-20
9	712-3004A	2	/P	Nut, Flange Lock, 5/16-18
10	717-1550E	1	S	Gear, Steering, 11/90 Ratio
11	717-1554	1		Gear, Pinion, Steering
12	723-0448A	2	S	Ball Joint, 7/16-20
13	710-04095	1		Hex Cap Screw, 3/8-16, 1.00
14	736-3004	1	S	Washer, Flat,.406 x.875 x.105
15	736-3084	1	/P	Washer, Flat,.510 x 1.120 x.060
16	737-3007	1		Grease, Alvania Ep 2
17	738-04154	2		Spacer, Shoulder, 1.00 x.38 x.38
18	759-04186	1	/P	Shaft, Steering,.625 OD x 25.00 Lg
19	741-0475	2	S	Bushing, Plastic,.380 ID
20	741-0656A	1	S	Bearing, Hex Flange, 5/8
21	683-04101	1	S	Axle Assembly, LH.750 Dia
22	683-04102	1	S	Axle Assembly, RH.750 Dia
23	712-0417A	2	/P	Nut, Hex, Flange, 5/8-18
24	714-04039	2		Pin, Cot, 5/32, 1.25
25	719-04105	1	/P	Axle, Pivot, Cast.750 Dia
26	736-0866	2		Washer, Flat,.755 x 1.92 x.060
27	738-1011A	2	/P	Screw, Shoulder,.500 x 2.230, 3/8-16
28	631-04008	1	S	Wheel, Steering, Three Spoke
29	731-04532	1	S	Cover, Steering Wheel



SLT1554 Tractor Command Engine
Transmission 618-04270

Page 54 of 62

Ref #	Part Number	Qty	S/P/F	Description
1	HG-71275	1		Main Housing, Assembly
		1		Main Housing, Machined Drain
		1		Bushing, .865 X .985 X .790
2	HG-70483	1	/P	Side Housing, Assembly
		1		Side Housing
		1		Bushing, .865 X .985 X .790
		1		Bushing, .624 X .719 X .562
3	HG-70477	1		Center Section, Assembly
		1		Center Section
		1		Bushing, .707 X .788 X .591
4	HG-51048	1	/P	Swashplate, Trunnion Machined
5	HG-70331	1	/P	Block - Assembly
		1		Block - Cylinder
		5		Piston
		5		Spring, Compression
		5		Washer - Thrust
7	HG-51190	14	/P	Hex Flange Screw 1/4-20 X 1.25
9	HG-51062	1	/P	Shaft, Input
10	HG-2000022	1	/P	Ring, Retaining
11	HG-50951	1	/P	Spacer
12	HG-50329	3	/P	Ring, Retaining
13	HG-51161	1	/P	Seal, Lip .67 X 1.58 X .276
14	HG-50315	1		Ball, Bearing 17mm ID X 40mm OD X12mm
16	HG-51064	1		Bolt, Hex Flange Head 5/16-24 X .94 (Patch)
17	HG-51140	1	/P	Lip Seal 18 X 32 X 7
18	HG-51119	1	/P	Arm, Control
19	HG-50551	2	S	Bearing, 30 X 52 X 13 Thrust
24	HG-50966	1		Shaft, Motor
27	HG-51767	1		Gear - Pinion, 12T
28	HG-51766	1		10T/49T Gear
29	HG-51043	1	/P	Gear, LDT Jackshaft
30	HG-51044	1		60T Bull Gear
31	HG-51088	2	/P	Sleeve Bearing .75 X 1.750 X .625
32	HG-51089	2	/P	Sleeve Bearing (Outboard) .75 X 1.575 X .625
33	HG-44875	2	/P	Washer, 3/4 X 1 1/2 X .13 THK
34	HG-51066	2	/P	Lip Seal Axle Seal
35	HG-52209	1	S	Shaft, Axle (R.H.)
36	HG-52210	1	S	Shaft, Axle (L.H.)
37	HG-51769	2	/P	Miter Gear 12T (Splined)
38	HG-51768	2		Miter Gear 12T
39	HG-50146	1		Shaft
40	HG-44871	2	/P	Ring, Spiral Retaining
41	HG-51083	1		Pin, Jackshaft
42	HG-51100	1		Magnet, Ring
44	HG-50016	2		Bolt, Hex Flange 3/8-24 X 2.5
48	HG-51098	1		Rod, Bypass Actuator
49	HG-51135	1		Arm, Bypass
50	HG-51116	1	/P	Retaining Ring, 250 External
51	HG-51081	1	/P	Seal, Lip .741 X .250 X 250 TC
52	HG-44371	1	/P	Flat Washer
53	HG-44145	1		Retaining Ring
54	HG-51071	1		Bearing, Center Block
55	HG-2003014	1	/P	Spring, Helical Compression

SLT1554 Tractor Command Engine
Transmission 618-04270

Page 55 of 62

Ref #	Part Number	Qty	S/P/F	Description
56	HG-2003017	1	/P	Washer
58	HG-62589	1	/P	Brake, Yoke
59	HG-51072	1	/P	Rotor, Brake
60	HG-44132	2	S	Brake, Puck
61	HG-44134	1	S	Puck Plate
62	HG-44127	2	S	Brake Actuating Pin
63	HG-51146	2		HFHCS 1/4-20 X 2 w/Patch SPECIAL FLANGE
65	HG-23711	1		Spacer
66	HG-51607	1		Spring, Brake ARM BIAS
68	HG-44094	1	/P	Arm, Brake
69	HG-44142	1	S	Slotted Hex Nut, 5/16-24
70	HG-44101	1	S	Cotter Pin, 3/32 X 3/4
71	HG-50919	1	/P	Compression Spring Anti-Drag
72	HG-50132	3	/P	Washer
73	HG-44130	2	S	Flat, Washer 11/32 I.D. X 7/9 O.D
74	HG-70719	1	/P	Seal, Kit
84	HG-51143	1	/P	Fitting, 5/16 SAE 5/32 Tube
85	HG-51147	1		Hose, Expansion Tank
94	HG-44147	1		Bearing, Ball .62 ID X 1.39 .44
95	HG-50837	1		Screw, Socket Head Cap 5/16-24 X 1 1/2
96	HG-51200	1		Spacer, Locating
97	HG-50870	1		Screw, SFHCS 5/16-18 X 1
98	HG-51120	1		Arm, Return
99	HG-51097	1		Puck, Adjusting
100	HG-52493	1		Washer
101	HG-51131	1	/P	Spring, Extension
102	HG-51123	1		Spacer, .260 ID X .560 OD X .870
103	HG-51223	1		Bracket, Torque
108	HG-51069	1		Washer, Motor Shaft .71 ID X 1.15 OD X .030 THK
109	HG-9005110-5600	2	/P	Plug, SAE #6
110	HG-50868	1		Screw, Torx Head 5/16-18 T.F.
111	HG-51144	1		O-Ring .103 X .299 ID
114	HG-51184	1	/P	Spring, Guide
124	HG-71315	1		Center Section - Filter - Bypass Assembly
		1		Center Section
		1		Base, Filter,w/Poppet
		1		Check Plug Assembly, .027 Washer
		1		Shock Valve Assembly
		1		Spring, Bypass
		1		Actuator, Bypass
		1		Deflector
		1		Bottom, Filter
		1		Bushing, .707 X .788 X .591
125	HG-70756	1	/P	Filter Assembly
		1		Bottom, Filter
		1		Spring, Bypass
		1		Deflector
		1		Base, Filter,w/Poppet
128	HG-70503	1	/P	Kit, Expansion Tank
		1		Tank, Expansion Assembly
		1		Cap, Vent

SLT1554 Tractor Command Engine
Transmission 618-04270

Page 56 of 62

Ref #	Part Number	Qty	S/P/F	Description
		1		VS Bolt, Self Tapping 10/32 X 1/2
		1		Bracket, Support Expansion Tank
	HG-70463	1	/P	Seal - O-Ring Kit not shown
		1		Seal, Lip .67 X 1.58 X .276
		1		Lip Seal 18 X 32 X 7
		2		Lip Seal .706 X 1.584 .25
		1		Seal, Lip .741 X .250 X .250 TC
		1		Oil Seal .625 X .25
		1		O-Ring
	737-3121	1	/P	Drive System Fluid not shown
	HG-50928	1	/P	Sealant 10.5 oz. not shown

SLT1554 Tractor Command Engine
Transmission 618-04270A

Page 58 of 62

Ref #	Part Number	Qty	S/P/F	Description
1	HG-70467	1		Main Housing, Assembly
		1		Main Housing, Machined Drain
		1		Bushing, .865 X .985 X .790
2	HG-71389	1		Side Housing, Assembly
		1		Side Housing, Machined
		1		Bushing, .865 X .985 X .790
		1		Bushing, .624 X .719 X .562
3	HG-70477	1		Center Section, Assembly
		1		Center Section, 5 Piston
		1		Bushing, .707 X .788 X .591
4	HG-51046	1		Swashplate, Trunnion Machined
5	HG-70331	1	/P	Block - Assembly
		1		Block - Cylinder
		5		Piston
		5		Spring, Compression
		5		Washer - Thrust
7	HG-51190	14	/P	Hex Flange Screw 1/4-20 X 1.25
9	HG-51062	1	/P	Shaft, Input
10	HG-2000022	1	/P	Ring, Retaining
11	HG-50951	1	/P	Spacer
12	HG-50329	3	/P	Ring, Retaining
13	HG-51161	1	/P	Seal, Lip .67 X 1.58 X .276
14	HG-50315	1		Ball, Bearing 17mm ID X 40mm OD X12mm
16	HG-51064	1		Bolt, Hex Flange Head 5/16-24 X .94 (Patch)
17	HG-51140	1	/P	Lip Seal 18 X 32 X 7
18	HG-51119	1	/P	Arm, Control
19	HG-50551	2	S	Bearing, 30 X 52 X 13 Thrust
24	HG-50966	1		Shaft, Motor
27	HG-51767	1		Gear - Pinion, 12T
28	HG-51766	1		10T/49T Gear
29	HG-51043	1	/P	Gear, LDT Jackshaft
30	HG-51044	1		60T Bull Gear
31	HG-51088	2	/P	Sleeve Bushing, Inboard
32	HG-51089	2	/P	Sleeve Bushing .75 x 1.575 x .625
33	HG-44875	2	/P	Washer, 3/4 X 1 1/2 X .13 THK
34	HG-51066	2	/P	Lip Seal Axle Seal
35	HG-51079	1	/P	Shaft, Axle (R.H.) DD
36	HG-51078	1	/P	Shaft, Axle (L.H.) DD
37	HG-51769	2	/P	Miter Gear 12T (Splined)
38	HG-51769	2	/P	Miter Gear 12T
39	HG-50146	1		Shaft
40	HG-44871	2	/P	Ring, Spiral Retaining
41	HG-51083	1		Pin, Jackshaft
42	HG-51100	1		Magnet, Ring
44	HG-50016	2		Bolt, Hex Flange 3/8-24 X 2.5
48	HG-51098	1		Rod, Bypass Actuator
49	HG-51135	1		Arm, Bypass
50	HG-51116	1	/P	Retaining Ring, 250 External
51	HG-51081	1	/P	Seal, Lip .741 X .250 X 250 TC
52	HG-44371	1	/P	Flat Washer, 5/9 ID X 1.0 OD X .05THK
53	HG-44145	1		Retaining Ring
54	HG-51071	1		Bearing, Center Block
55	HG-2003014	1	/P	Spring, Helical Compression

SLT1554 Tractor Command Engine
Transmission 618-04270A


Page 59 of 62

Ref #	Part Number	Qty	S/P/F	Description
56	HG-2003017	1	/P	Washer
58	HG-62589	1	/P	Brake, Yoke Kit
59	HG-51072	1	/P	Rotor, Brake
60	HG-44132	2	S	Brake, Puck
61	HG-44134	1	S	Puck Plate
62	HG-44127	2	S	Brake Actuating Pin
63	HG-51146	2		HFHCS 1/4-20 X 2 w/Patch SPECIAL FLANGE
65	HG-23711	1		Spacer
66	HG-51607	1		Spring, Brake ARM BIAS
68	HG-44094	1	/P	Arm, Brake
69	HG-44142	1	S	Slotted Hex Nut, 5/16-24
70	HG-44101	1	S	Cotter Pin, 3/32 X 3/4
71	HG-50919	1	/P	Compression Spring Anti-Drag
72	HG-50132	3	/P	Washer,
73	HG-41130	2		Flat, Washer 11/32 I.D. X 7/9 O.D
74	HG-70719	1	/P	Seal, Kit
84	HG-51143	1	/P	Fitting, 5/16 SAE 5/32 Tube
85	HG-51147	1		Hose, Expansion Tank
94	HG-44147	1		Bearing, Ball .62 ID X 1.39 .44
95	HG-50837	1		Screw, Socket Head Cap 5/16-24 X 1 1/2
96	HG-51200	1		Spacer, Locating
97	HG-50870	1		Screw, SFHCS 5/16-18 X 1
98	HG-51120	1		Arm, Return
99	HG-51097	1		Puck, Adjusting
100	HG-52493	1		Washer, Flat
101	HG-51131	1	/P	Spring, Extension
102	HG-51123	1		Spacer, .260 ID X .560 OD X .870
103	HG-51223	1		Bracket, Torque
108	HG-51069	1		Washer, Motor Shaft .71 ID X 1.15 OD X .030 THK
109	HG-9005110-5600	2	/P	Plug, SAE #6
110	HG-50868	1		Screw, Torx Head 5/16-18 T.F.
111	HG-51144	1		O-Ring .103 X .299 ID
114	HG-51184	1	/P	Spring, Guide
124	HG-71315	1		Center Section - Filter - Bypass Assembly
		1		Center Section
		1		Base, Filter,w/Poppet
		1		Check Plug Assembly, .027 Washer
		1		Shock Valve Assembly
		1		Spring, Bypass
		1		Actuator, Bypass
		1		Deflector
		1		Bottom, Filter
		1		Bushing, .707 X .788 X .591
125	HG-70756	1	/P	Filter Assembly
		1		Bottom, Filter
		1		Spring, Bypass
		1		Deflector
		1		Base, Filter,w/Poppet
128	HG-70503	1	/P	Kit, Expansion Tank
		1		Tank, Expansion Assembly
		1		Cap, Vent

SLT1554 Tractor Command Engine
Transmission 618-04270A

Page 60 of 62

Ref #	Part Number	Qty	S/P/F	Description
		1		VS Bolt, Self Tapping 10/32 X 1/2
		1		Bracket, Support Expansion Tank
	HG-70463	1	/P	Seal - O-Ring Kit not shown
		1		Seal, Lip .67 X 1.58 X .276
		1		Lip Seal 18 X 32 X 7
		2		Lip Seal .706 X 1.584 .25
		1		Seal, Lip .741 X .250 X .250 TC
		1		Oil Seal .625 X .25
		1		O-Ring
	737-3121	1	/P	Drive System Fluid not shown
	HG-50928	1	/P	Sealant 10.5 oz. not shown



SLT1554 Tractor Command Engine
Wheels

Page 62 of 62

Ref #	Part Number	Qty	S/P/F	Description
1	734-04174	2		Tire, Turf, Cub Cadet 22 x 9.5 x 12
2	634-04238-0499	2	/P	Rim Assembly, 12 x 7 (4-Lug)
3	712-3050	8	/P	Lug Nut, 7/16-14
4	741-0516B	2	/P	Bearing, Flange .760 X 1.00 X 1.20LG
4	741-0990B	2	/P	Bearing, Flange .760 ID w/grease fitting
5	634-04405-0499	2		Rim Assembly, 6 x 4.5 (Included, Bearings, Spacer and Valve)
6	931-3020	2	/P	Hub Cap
7	734-1731-0901	2	/P	Tire, Turf, Cub Cadet 15 x 6 x 6
	737-0224	2		Grease Fitting (Not Shown)
	934-0255	4	/P	Valve, Tubeless Air (Not Shown)