


SLT1554 Tractor Courage Engine (2007 & before)
Adjustable Seat

Page 1 of 74




SLT1554 Tractor Courage Engine (2007 & before)
Adjustable Seat

Page 2 of 74

Ref #	Part Number	Qty	S/P/F	Description
1	783-0739A	1	S	Lever, Seat, Adjustment
2	710-1268	2	/P	Screw, #10-16, 0.375
3	712-04063	2	/P	Nut, Nylon Lock, 5/16-18, Gr5
4	712-3027	1	S	Nut, Nylon Lock, 1/4-20
5	720-0433	1		Grip, Seat, Adjustment (Yellow)
6	726-0201	2		Nut, Speed, .3125 ID
7	731-04074	4		Spacer, Seat, Adjustment
8	732-0499	1		Spring, Compression .41 OD x 1.50
9	732-1184	1	/P	Spring, Extension, .80 Dia x 4.6
10	783-0738C	1	S	Pivot Bracket, Seat
11	757-04035	1		Seat, Cub Cadet, High Back
12	783-0753	1		Selector, Seat, Adjustment
13	736-0275	2	S	Washer, Flat, .344 x .688 x .065
14	736-3019	2		Washer, Flat, .531 x 1.062 x .134
15	738-0137A	1	S	Screw, Shoulder, .340 x .285, 1/4-
16	738-0296	2	S	Shoulder, Screw .437 x .286 Lg
17	738-0966A	4	/P	Screw, Shoulder, .50 x .925, 3/8-16
18	783-0209D	1	/P	LH Bracket, Seat Lift
18	17239D	1		RH Bracket, Seat Lift
19	783-0611	1		Stop, Seat, Adjustment
20	710-0227	2	/P	Screw, #8-18 x .50
21	726-0279	2		Plate, Insulator
22	725-1303	1	S	Spring Switch, Inner
23	725-1439	1		Spring Switch, Outer
24	726-0278	1		Plate, Insulator Boss
25	757-04039	1	S	Armrests (Includes two armrests)
26	710-1260A	6	/P	Screw, 5/16-18, .75

SLT1554 Tractor Courage Engine (2007 & before)
Dash Panel 1K016 & after

Page 3 of 74



SLT1554 Tractor Courage Engine (2007 & before)
Dash Panel 1K016 & after

Page 4 of 74

Ref #	Part Number	Qty	S/P/F	Description
1	710-0351	1	/P	Screw, #10-18 x.5
2	710-0192	2	/P	Screw, #10-24 x.375
3	710-0599	6	/P	Screw, Self-tapping, 1/4-20, 0.500
4	710-0642	3	/P	Screw, Hex. 1/4-20 x.75
5	736-0362	2	/P	Flat Washer,.330 x 1.25 x.06
6	710-04666	1		Screw, Hex Flange, 1/4-20,.75,
7	710-0726	12	/P	Screw, Hex, 5/16-12 x.75
8	710-0895	2		Screw, 1/4-15, 0.750
9	710-1611B	4	/P	Screw, Torx Hd. Tapp. 5/16-18 x.75
10	710-3217	1	/P	Screw, Machine, #8-32, 0.375, Trus Phillips
11	712-0142	1	/P	Nut, 8-32
12	712-0324	1	/P	Nut, Nylon Lock, 1/4-20
13	747-04215	1	S	Hold-down Rod, Battery
14	746-04352	1		Control, Throttle, 38.0
15	714-0104	1	S	Internal Cotter Pin,.072 x 1.13
16	710-04187	1	/P	Screw, 1/4-15 x.50
17	731-05077B	1	S	Dash
18	731-04294A	1		Lever, Dash, Cruise
19	731-04293A	1	/P	Lever, Dash, Brake
20	731-3161A	1	S	Knob, Throttle Control
21	683-04232	1	S	Dash Support, RH
22	710-04471	2		Ball Screw, 5/16-18 x.48
23	725-2054	2	S	Ignition Key, Plastic
24	683-04231	1	S	Dash Support, LH
25	746-04120	1		Control, Choke
26	747-1323A	1		Rod,.250 Dia x 4.25
27	783-04475	1	S	Bracket, Steering Support
28	783-04506C	1	S	Plate, Dash Support
29	741-0587	1		Steering Column Bearing
30	725-04022A	1	S	Monitor, Systems Indicator / Hour Meter
31	783-1447C	1		Bracket, Support, Battery
32	712-3004A	2	/P	Flange Lock Nut,5/16-18
33	727-04142	2		Gas Spring Cylinder, 3.62 Stroke
34	783-1499	1	S	Bracket, Rod, Dash
35	725-1750A	1	S	Battery, 235 CCA
36	712-0271	1	/P	Nut, Sems, 1/4-20
37	725-04227	1	S	Switch Module, Ignition
38	725-04175	1	S	Switch, PTO, Yellow
39	736-0173	2	/P	Flat Washer,.28 x.74 x.063
40	725-1426A	1	S	Solenoid, 12V, 100 Amp
41	736-0222	2	S	Washer, External Lock, 1/4
42	710-0607	2	/P	Screw, Hex, 5/16-12 x .50
	725-2003	1		Power Receptacle, 12 V not shown
	725-04405	1	S	Wire Harness not shown


SLT1554 Tractor Courage Engine (2007 & before)
Dash Panel 1K016 & before

Page 6 of 74

Ref #	Part Number	Qty	S/P/F	Description
1	710-0351	1	/P	Screw, #10-18 x.50
2	710-0192	2	/P	Screw, #10-24 x.375
3	710-0599	6	/P	Screw, Self-tapping, 1/4-20, 0.500
4	710-0642	3	/P	Screw, Hex. 1/4-20 x.75
5	736-0362	2	/P	Flat Washer,.330 x 1.25 x.06
6	710-0703	1	/P	Screw, Carriage, 1/4-20,.75,
7	710-0726	12	/P	Screw, Hex, 5/16-12 x.75
8	710-0895	2		Screw, 1/4-15, 0.750
9	710-1611B	2	/P	Screw, Torx Hd. Tapp. 5/16-18 x.75
10	710-3217	1	/P	Screw, Machine, #8-32, 0.375, Trus Phillips
11	712-0142	1	/P	Nut, 8-32
12	712-0324	1	/P	Nut, Nylon Lock, 1/4-20
13	747-04215	1	S	Hold-down Rod, Battery
14	746-1100	1	S	Control, Throttle, 38.0
15	714-0104	1	S	Internal Cotter Pin,.072 x 1.13
16	710-04187	1	/P	Screw, 1/4-15 x.50
17	731-05077	1	S	Dash
18	731-04294A	1		Lever, Dash, Cruise
19	731-04293A	1	/P	Lever, Dash, Brake
20	731-3161	1	S	Knob, Throttle Control
21	683-04232	1	S	Dash Support, RH
22	710-04471	2		Ball Screw, 5/16-18 x.48
23	725-2054	2	S	Ignition Key, Plastic
24	683-04231	1	S	Dash Support, LH
25	746-04120	1		Control, Choke
26	747-1323A	1		Rod,.250 Dia x 4.25
27	783-04475	1	S	Bracket, Steering Support
28	783-04506A	1	S	Plate, Dash Support
29	741-0587	1		Steering Column Bearing
30	725-04022A	1	S	Monitor, Systems Indicator / Hour Meter
31	783-1447A	1	S	Bracket, Support, Battery
32	712-3004A	2	/P	Flange Lock Nut,5/16-18
33	727-04142	2		Gas Spring Cylinder, 3.62 Stroke
34	783-1499	1	S	Bracket, Rod, Dash
35	725-1750A	1	S	Battery, 235 CCA
36	712-0271	1	/P	Nut, Sems, 1/4-20
37	725-04227	1	S	Switch Module, Ignition
38	725-04175	1	S	Switch, PTO, Yellow
39	736-0173	2	/P	Flat Washer,.28 x.74 x.063
40	725-1426A	1	S	Solenoid, 12V, 100 Amp
41	736-0222	2	S	Washer, External Lock, 1/4
	725-2003	1		Receptacle, 12 V
	725-04338	1	S	Wire Harness

SLT1554 Tractor Courage Engine (2007 & before)
Deck Chute Assembly

Page 7 of 74




SLT1554 Tractor Courage Engine (2007 & before)
Deck Chute Assembly

Page 8 of 74

Ref #	Part Number	Qty	S/P/F	Description
	631-04070	1	S	Chute Assembly, Complete
1	711-1762	1		Pin, Hinge, .375 Dia x 14.06
2	731-3131A	1	S	Deflector, Chute
3	732-3070A	1	/P	Spring, Torsion
4	777S30145	1	S	Graphic, Danger
5	783-04470	1	/P	Bracket, Mounting

SLT1554 Tractor Courage Engine (2007 & before)
Drive System

Page 9 of 74



SLT1554 Tractor Courage Engine (2007 & before)
Drive System


Page 10 of 74

Ref #	Part Number	Qty	S/P/F	Description
1	17840	2	S	Bracket, Mounting, Transaxle
2	618-04228	2	S	Hub Assembly, Wheel
3	618-04270A	1	S	Transmission, Hydrostatic
4	629-04124	1		Harness Assembly, Ground & Reverse
5	783-04442	1		Bracket Assembly, Idler, Center Dbl
6	710-1266	4	/P	Hex Cap Screw, 5/16-18,3.5, Gr5
7	710-0227	2	/P	Screw, #8-18, 0.500
8	710-0344	3	/P	Hex Cap Screw, 3/8-16, 1.50, Gr5
9	710-0726	6	/P	Screw, 5/16-12, 0.75
10	710-0599	1	/P	Screw, 1/4-20, 0.5
11	710-3007	3	/P	Screw, #12-24, 0.375
12	710-3011	1	/P	Hex Cap Screw, 3/8-16, 2.25, Gr5
13	710-0778	1	/P	Hex Cap Screw, 1/4-20, 1.5, Gr5
14	710-0627	2	/P	Hex Cap Screw, 5/16-24 x .750
15	711-0832	1	S	Ferrule, 3/8-24 x .375 Dia
16	712-0291	1	S	Nut, Hex Lock, 1/4-20
17	712-3066	1	S	Nut, Hex, 1/2-20, Gr5
18	712-04065	4	/P	Nut, Nylon Lock, 3/8-16
19	731-05300	2		Sleeve, 2.4"
20	712-04052	5		Nut, Nylon Lock, 5/16-18, Gr5
21	750-0566A	1	/P	Spacer, 1"
22	712-3017	3	S	Nut, Hex, 3/8-16, Gr8
23	714-0104	2	S	Pin, Cotter, .072 Dia. x 1.13 Lg
24	714-0111	1	S	Pin, Cotter, 3/32, 1.0
25	725-0157	2	/P	Cable, Tie, 3/16 x .05 x 7.4
26	725-1644	1		Switch, Spring, Short
27	726-0154	2	S	Tie, Cable, Push Mount 7.5 Lg
28	726-0320	1	S	Plate, Insulator Nut
29	731-1449A	1	S	Fan, Blade, 10"
30	732-0209	1	S	Spring, .48 OD x 2.03 Extension
31	732-04323A	1	S	Spring, Extension, .563 Dia x 3.72 Lg
32	732-0716	1	S	Spring, Extension, .59 OD x 4.00 Lg
33	732-0729	1	/P	Ring, Wire
34	732-0994	1		Spring, Extension, .500 Dia x 7.0
35	732-3118	1		Spring, Extension, 3/8 OD x 1.44
36	710-0502A	1	/P	Screw, 3/8-16, 1.25
37	736-0169	1	S	Washer, Lock, 3/8, Regular Duty
38	736-0921	1	S	Washer, Lock, 1/2
39	736-0242	2	/P	Bell Washer
40	736-3010	3	/P	Washer, Flat, .407 x .812 x .135
41	738-0372B	1	/P	Spacer, Shoulder, 1.00 x .38 x .38
42	747-1149	1		Rod, Hydro Bypass
43	747-04139	1		Rod, Brake, Hydro
44	747-1151	1		Rod, Control, Hydro
45	756-0978A	1	S	Pulley, Engine, 3.56 Dia.
46	754-0461	1	S	Belt, V Type, Poly
47	756-0116A	2	S	Pulley, Idler, V Type x 3.06 Dia
48	756-04224	1	/P	Pulley, Idler, Flat 2.75 OD
49	756-04111	1		Pulley, Engine, 4.11Dia.
50	783-0810B	1	S	Bracket, Transmission, Torque Hydro
51	783-1019	1	S	Bracket, Actuator, Switch
52	736-0320	1	/P	Washer, Flat, .38 x 1.92 x .060
53	714-0507	1	S	Pin, Cotter, 3/32, .750

SLT1554 Tractor Courage Engine (2007 & before)
Drive System

Page 11 of 74

Ref #	Part Number	Qty	S/P/F	Description
54	750-0535	1	S	Spacer, .38 x .625 x .21




SLT1554 Tractor Courage Engine (2007 & before)
Engine Accessories 1K016 & after

Page 13 of 74

Ref #	Part Number	Qty	S/P/F	Description
1	710-0227	4	/P	Screw, #8-18, 0.500
2	710-0599	8	/P	Screw, Hex, 1/4-20, 0.500
3	710-0726	2	/P	Screw, Hex, 5/16-12 x .75
4	710-1315	4	/P	Screw, Hex, 3/8-16 x 1.25
5	751-10161	1		Muffler, Dual Inlet
6	725-0157	2	/P	Cable, Tie, 3/16 x .05 x 7.4
7	712-3004A	2	/P	Nut, Flange Lock, 5/16-18
8	712-3005	1	S	Hex Flange Nut, 3/8-16
9	736-0300	1	S	Lock Washer, .406 x .875 x .059
10	751-0564A	1	S	Deflector, Muffler
11	783-04573	1		Muffler Bracket, LH
12	783-04574	1		Muffler Bracket, RH
13	710-1314A	4	/P	Screw, 5/16-18, 0.75
14	751-10517	1	S	Drain, Oil
15	751-3141	1	S	Extension Hose, Oil Drain
16	783-05410	1		Heat Shield, Lower
17	683-04256-0637	1	/P	Shield, Muffler
18	751-10007	1		Pipe, Exhaust, LH
19	751-10006	1		Pipe, Exhaust, RH
20	783-04783	1	S	Heat Shield, Upper
21	728-04000	1		Rivet, Pop, .188 x .325
22	710-0642	4	/P	Screw, Hex, 1/4-20, 0.750
23	751-10353	1		Extension, Deflector

SLT1554 Tractor Courage Engine (2007 & before)
Engine Accessories 1K016 & before

Page 14 of 74




SLT1554 Tractor Courage Engine (2007 & before)
 Engine Accessories 1K016 & before

Page 15 of 74

Ref #	Part Number	Qty	S/P/F	Description
1	710-0227	4	/P	Screw, #8-18, 0.500
2	710-0599	4	/P	Screw, Hex, 1/4-20, 0.500
3	710-0726	2	/P	Screw, Hex, 5/16-12 x .75
4	710-1315	4	/P	Screw, Hex, 3/8-16 x 1.25
5	751-10161	1		Muffler, Dual Inlet
6	725-0157	2	/P	Cable, Tie, 3/16 x .05 x 7.4
7	712-3004A	2	/P	Nut, Flange Lock, 5/16-18
8	712-3005	1	S	Hex Flange Nut, 3/8-16
9	736-0300	1	S	Lock Washer, .406 x .875 x .059
10	751-0564A	1	S	Deflector, Muffler
11	783-04573	1		Muffler Bracket, LH
12	783-04574	1		Muffler Bracket, RH
13	783-04783	1	S	Heat Shield
14	751-3140	1	S	Drain, Oil
15	751-3141	1	S	Extension Hose, Oil Drain
16	751-3142	1		Cap, Oil Drain
17	783-04576	1		Shield, Muffler
18	751-10007	1		Pipe, Exhaust, LH
19	751-10006	1		Pipe, Exhaust, RH

SLT1554 Tractor Courage Engine (2007 & before)
Engine Air Intake Filtration


Page 16 of 74



SLT1554 Tractor Courage Engine (2007 & before)
Engine Air Intake Filtration

Page 17 of 74

Ref #	Part Number	Qty	S/P/F	Description
1	KH-24-164-51-S	1	S	Manifold, intake (Includes 2,3)
2	KH-24-041-52-S	1	/P	Gasket, carburetor
3	KH-24-153-27-S	2	/P	O-Ring, intake port
4	KH-32-094-03-S	1	S	Base, air cleaner (Includes 5,6)
5	KH-24-041-14	1	/P	Gasket, air cleaner base
6	KH-32-344-02-S	1		Latch, air cleaner element
7	KH-32-083-03-S	1	S	Element, air cleaner
8	KH-M-651040-S	4		Screw, hex. flange M6x1.0x40
9	KH-32-083-05-S	1	S	Pre-cleaner, element




SLT1554 Tractor Courage Engine (2007 & before)
Engine Blower Housing & Baffles

Page 19 of 74

Ref #	Part Number	Qty	S/P/F	Description
1	KH-32-027-03-S	1		Housing, blower
2	KH-32-096-08-S	1		Cover, air cleaner
3	KH-M-545016-S	4	/P	Screw, hex. flange M5x0.8x16
4	KH-M-645016-S	8	/P	Screw, hex. flange M6x1.0x16
5	KH-32-146-05-S	1		Plate, backing w/rectifier-regulator opening
6	KH-32-063-05-S	1		Baffle, cylinder barrel - #2 side
7	KH-32-063-02-S	1		Baffle, valley - #2 side
8	KH-M-545010	4	S	Screw, hex. flange M5x0.8x10
9	KH-32-063-03-S	1		Baffle, valley - #1 side
10	KH-32-063-04-S	1		Baffle, cylinder barrel-#1 side (SLT 1554)
10	KH-32-063-06-S	1		Baffle, cylinder barrel-#1 side (SLT 1550)
11	KH-M-545020-S	2		Screw, hex. flange M5x0.8x20
12	KH-24-086-12	2		Screw, hex. cap M6x1.7x18

SLT1554 Tractor Courage Engine (2007 & before)
Engine Crankcase

Page 20 of 74




SLT1554 Tractor Courage Engine (2007 & before)
Engine Crankcase

Page 21 of 74

Ref #	Part Number	Qty	S/P/F	Description
1	KH-32-038-01-S	1	S	Kit, dipstick (Includes 2)
2	KH-12-153-03	1		O-Ring
3	KH-M-545016-S	1	/P	Screw, hex. flange thread forming
4	KH-12-123-04	1	S	Tube, oil fill (Includes 5,6)
5	KH-12-153-02-S	1	/P	O-Ring, upper oil fill tube
6	KH-12-153-01-S	1	/P	O-Ring, lower oil fill tube
7	KH-24-126-19	1		Bracket, oil fill tube
8	KH-24-032-01-S	1	S	Seal, oil
9	N/A	1		Crankcase See below
10	KH-25-237-14-S	1	/P	Clamp, hose
11	KH-32-326-04-S	1		Hose, breather
12	KH-M-547050-S	1		Nut, hex. lock M5x0.8
13	KH-32-468-01-S	1		Washer, sealing
14	KH-32-081-02-S	1		Housing, breather
15	KH-32-072-02-S	2		Stud, breather cover
16	KH-24-018-04	2		Retainer, breather reed
17	KH-24-402-05-S	2	/P	Reed, breather
18	KH-24-380-16-S	6	/P	Pin, locating
19	KH-24-067-13-S	2	S	Connecting Rod (Std.)
20	KH-32-874-06-S	2		Piston w/Ring Set (Std.) (Includes 20,21)
20		2		Piston w/Ring Set (.25) (TBD)
21	KH-24-018-01	4	S	Retainer, piston pin
22	KH-24-108-05-S	2	/P	Ring Set (Std.)
22	KH-24-108-06-S	2	S	Ring Set (.25)
23	KH-12-422-10	1	S	Shim, camshaft (yellow) A.R.
23	KH-12-422-09	1	S	Shim, camshaft (red) A.R.
23	KH-12-422-13	1	S	Shim, camshaft (black) A.R.
23	KH-12-422-07	1	S	Shim, camshaft (white) A.R.
23	KH-12-422-08	1	S	Shim, camshaft (blue) A.R.
23	KH-12-422-11	1	S	Shim, camshaft (green) A.R.
23	KH-12-422-12	1	S	Shim, camshaft (gray) A.R.
24	KH-32-012-01-S	1		Kit, camshaft
25	KH-M-645016-S	1	/P	Screw, hex. flange thread forming
26	KH-32-096-04-S	1		Cover, breather
27	KH-32-041-01-S	1		Gasket, breather cover
28	KH-32-050-01-S	1		Filter, breather
29	KH-28-032-09-S	1		Seal, governor cross shaft
30	KH-24-018-09-S	1		Ring, retainer
31	KH-M-931010-S	1		Washer, plain 8 mm
32	KH-24-468-15-S	1		Washer, flat 1/4"
33	KH-24-144-38-S	1	/P	Shaft, governor cross
34	KH-32-014-04-S	1	S	Crankshaft (Includes 2)
35	KH-52-139-09-	1		Plug, cup
	KH-32-782-01	1		Miniblock Not shown
	KH-32-522-03	1		Short Block Not shown
	KH-SV730-0011	1		Complete Engine (SLT1550) Not shown
	KH-SV740-0010	1		Complete Engine (SLT1554) Not shown

SLT1554 Tractor Courage Engine (2007 & before)
Engine Cylinder Head

Page 22 of 74




SLT1554 Tractor Courage Engine (2007 & before)
Engine Cylinder Head

Page 23 of 74

Ref #	Part Number	Qty	S/P/F	Description
1	KH-24-755-141-S	1	/P	Kit, valve cover (Includes 2,3)
2	KH-24-153-28-S	1	S	O-Ring
3	KH-M-651030-S	4		Screw, hex. flange M6x1.0x30
4	KH-32-318-01-S	1	S	Head assembly, #1 cylinder
5	KH-12-755-03	4	/P	Kit, retainer
6	KH-12-173-01	2	/P	Cap, valve spring
7	KH-24-089-02	2	/P	Spring, valve
8	KH-235011-S	2	/P	Retainer, spring
9	KH-66-032-05-S	1	/P	Seal, valve stem
10	KH-24-017-01	1	/P	Valve, intake (Std.)
10	KH-24-017-02	1		Valve, intake (.25)
11	KH-24-016-01	1	/P	Valve, exhaust (Std.)
11	KH-24-016-02	1		Valve, exhaust (.25)
12	KH-32-019-01-S	4	S	Tappet
13	KH-32-411-02-S	2	/P	Rod, push
14	KH-24-841-03-S	2	/P	Kit, cylinder head gasket (Includes Head Mtg. Hardware)
15	KH-32-318-02-S	1	S	Head assembly, #2 cylinder
16	KH-32-186-02-S	2	S	Arm, rocker
17	KH-32-100-04-S	4		Nut, hex. M10x0.75
18	KH-32-086-03-S	4		Screw, set
19	KH-32-599-02-S	2	S	Pivot, rocker arm
20	KH-12-086-16	4	S	Screw, hex. flange M10x1.5x90
21	KH-M-651045-S	4	S	Screw, hex. flange M6x1.0x45
22	KH-32-096-06-S	1		Kit, valve cover - breather (Includes 2)
23	KH-24-445-01	1	S	Strap, lifting
	KH-24-041-49-S	1	/P	Exhaust Gasket
	KH-24-153-27-S	1	/P	O-Ring (intake port)

SLT1554 Tractor Courage Engine (2007 & before)
Engine Engine Controls


Page 24 of 74



SLT1554 Tractor Courage Engine (2007 & before)
Engine Engine Controls

Page 25 of 74

Ref #	Part Number	Qty	S/P/F	Description
1	KH-24-211-03-S	1		Bolt, round head square neck
2	KH-24-090-33-S	1	S	Lever, governor
3	KH-M-641060-S	1	/P	Nut, hex. flange M6x1.0
4	KH-24-089-01	1		Spring, linkage
5	KH-25-158-08	1	/P	Bushing, linkage retaining
6	KH-24-079-04	1		Linkage, throttle
7	KH-25-158-11	1	/P	Bushing, throttle linkage
8	KH-M-545016-S	1	/P	Screw, hex. flange M5x0.8x16
9	KH-M-547050-S	1		Nut, hex. lock M5x0.8
10	KH-24-089-03	1		Spring, choke return
11	KH-24-126-161-S	1	S	Bracket, control
12	KH-M-645016-S	4	/P	Screw, hex. flange M6x1.0x16
13	KH-47-237-02	1	S	Clamp, dual conduit
14	KH-24-086-43-S	1		Screw, thread forming
15	KH-24-079-22-S	1		Linkage, choke
16	KH-24-112-27-S	1		Spacer, control assembly
17	KH-24-090-47-S	1		Lever, throttle actuator
18	KH-24-090-13	1		Lever, throttle control
19	KH-24-468-01	1		Washer, plain 5.5 mm
20	KH-M-545020-S	1		Screw, hex. flange M5x0.8x20
21	KH-41-468-03	1		Washer, spring 1/4"
22	KH-24-090-05	1		Lever, choke
23	KH-M-403025	1		Screw, hex. head cap M4x0.7x25
24	KH-M-446030-S	1	/P	Nut, hex. M4x0.7
25	KH-24-468-20-S	1		Washer, plain
26	KH-24-089-25-S	1	/P	Spring, governor
27	KH-24-089-55-S	1		Spring, governor




SLT1554 Tractor Courage Engine (2007 & before)
Engine Exhaust

Page 27 of 74

Ref #	Part Number	Qty	S/P/F	Description
1	KH-25-072-04	4	/P	Stud, M8x1.25x33
2	KH-24-041-49-S	1	/P	Gasket, exhaust manifold
3	KH-M-841080	4	S	Nut, hex. flange M8x1.25

SLT1554 Tractor Courage Engine (2007 & before)
Engine Fuel System


Page 28 of 74



SLT1554 Tractor Courage Engine (2007 & before)
Engine Fuel System

Page 29 of 74


Ref #	Part Number	Qty	S/P/F	Description
1	KH-32-853-12-S	1	/P	Kit, carburetor w/gaskets (Includes 2,3)
2	KH-24-041-52-S	1	/P	Gasket, carburetor
3	KH-24-041-14	1	/P	Gasket, air cleaner base
4	KH-M-629105-S	2		Stud, carburetor
5	KH-M-641060-S	2	/P	Nut, hex. flange M6x1.0
6	KH-25-237-14-S	4	/P	Clamp, hose
7	KH-25-111-34-S	2		Line, fuel (Fuel line comes in lengths of 24")
8	KH-24-100-01	2		Nut, plastic
9	KH-25-237-01-S	1		Clamp, hose
10	KH-32-326-02-S	1	S	Hose, fuel pump
11	KH-24-086-12	2		Screw, hex. cap M6x1.7x18
12	KH-24-393-16	1	/P	Pump, pulse fuel
13	KH-25-050-22-S	1	S	Filter, fuel
14	KH-47-154-01-S	1	/P	Clip, cable
	KH-24-757-36-S	1		Kit, service choke repair
	KH-24-757-38-S	1		Kit, service gasket repair
	KH-24-757-44-S	1		Kit, float w/gaskets
	KH-24-757-45-S	1	/P	Kit, solenoid valve w/gaskets
	KH-24-757-46-S	1	/P	Kit, overhaul w/gaskets



SLT1554 Tractor Courage Engine (2007 & before)
Engine Ignition and Electrical

Page 31 of 74

Ref #	Part Number	Qty	S/P/F	Description
1	KH-32-162-03-S	1		Screen, grass
2	KH-12-086-14	1		Screw, hex. flange M10x1.5x45
3	KH-12-468-03	1	/P	Washer, plain 3/8"
4	KH-20-146-02-S	1	S	Plate, fan mounting
5	KH-32-157-01-S	1		Fan
6	KH-32-025-05-S	1	S	Flywheel (SLT 1554)
6	KH-32-025-06-S	1	S	Flywheel (SLT 1550)
7	KH-X-42-15	1	/P	Key
8	KH-236602-S	1	S	Connector (3 contact)
9	KH-M-551016-S	2		Screw, heavy hex. flange M5x0.8x16
10	KH-41-403-09	1	S	Rectifier-regulator
11	KH-54-755-09-S	1	S	Kit, 15 amp stator
12	KH-47-154-01-S	1	/P	Clip, cable (SLT 1554)
12	KH-235173	1		Clip, cable (SLT 1550)
13	KH-M-548025-S	2	/P	Screw, hex. head thread forming M5x0.8x25
14	759-3336	2	/P	Spark plug
15	KH-24-584-36-S	2	/P	Module, ignition (SLT 1554)
15	KH-24-584-01	2	S	Module, ignition (SLT 1550)
16	KH-M-545020-S	4		Screw, hex. flange thread forming M5x0.8x20
17	KH-24-584-31-S	1	S	Module, speed advance (SLT 1554 only)
18	KH-M-448010-S	2		Screw, hex. flange thread forming (SLT 1554 only)
	KH-32-176-02-S	1	S	Wiring Harness (SLT 1550) Not shown
	KH-32-176-05-S	1		Wiring Harness (SLT 1554) Not shown
	KH-25-454-03-S	1		Wire Tie Not shown




SLT1554 Tractor Courage Engine (2007 & before)
Engine Oil Pan Lubrication

Page 33 of 74

Ref #	Part Number	Qty	S/P/F	Description
1	KH-32-199-02-S	1	S	Pan assembly, oil (Includes 2-15)
2	KH-32-086-01-S	2		Screw, hex. flange thread forming shoulder
3	KH-32-393-08-S	1	S	Oil pump assembly
4	KH-24-043-12	1	/P	Kit, governor gear w/pin (Includes 5)
5	KH-12-380-01	1	/P	Pin, governor regulating
6	KH-24-448-02-S	1		Tab, locking
7	KH-12-144-02	1		Shaft, governor gear
8	KH-52-032-08-S	1	S	Seal, oil (PTO end)
9	KH-32-123-01-S	1		Tube, oil feed - filter to oil pan
10	KH-32-123-03-S	1		Tube, oil feed - oil pan to filter
11	KH-24-153-01	2	/P	O-Ring
12	KH-32-029-10-S	1	S	Adapter, oil filter (Includes 13,14)
13	KH-25-139-60-S	1	/P	Plug, hex. ctsk. 1/8"
14	KH-32-153-02-S	1		O-Ring, oil filter adapter
15	KH-32-136-03-S	1		Nipple, oil filter
16	KH-25-099-24-S	1	S	Switch, pressure
17	KH-52-050-02	1	S	Filter, oil
18	KH-24-086-17-S	1	/P	Screw, hex. flange M8x1.25x45
19	KH-24-086-16-S	9	S	Screw, hex. flange M8x1.25x45
20	KH-25-139-57-S	1	/P	Plug, sq. hd. solid 3/8"

SLT1554 Tractor Courage Engine (2007 & before)
Engine Starting System


Page 34 of 74



SLT1554 Tractor Courage Engine (2007 & before)
Engine Starting System

Page 35 of 74

Ref #	Part Number	Qty	S/P/F	Description
1	KH-M-839080	2	S	Screw, hex. flange M8x1.25x70
2	KH-32-098-01-S	1	S	Starter assembly (Includes 3-5)
3	KH-12-755-39-S	1		Kit, drive
4	KH-12-755-38-S	1		Kit, drive parts
5	KH-12-243-04-S	1		Commutator, end cap




SLT1554 Tractor Courage Engine (2007 & before)
Fender and Fuel Tank

Page 37 of 74

Ref #	Part Number	Qty	S/P/F	Description
1	710-0528	2	/P	Screw, 5/16-18 x 1.25
2	710-0726	8	/P	Screw, 5/16-12, 0.75
3	710-0895	9		Screw, 1/4-15, 0.750
4	712-04063	2	/P	Nut, Nylon Lock, 5/16-18
5	731-2616A	1	S	Cover, Fender, RH
6	731-2617	1		Cover, Fender, LH
7	736-3078	2	/P	Washer, Flat, .349 x 1.00 x .063
8	783-0677B	1		Bracket, Lift, Adjustment
9	783-1489A	2	/P	Bracket, Seat, Mount
10	783-04477	1	S	Fender
11	726-3046	12	/P	Clip, Ratchet, .250 Dia
12	735-0697A	1		Pad, Foot, LH
13	735-0698B	1		Pad, Foot, RH
14	751-0819B	1	S	Tank, Fuel
15	751-3124B	1	S	Cap, Fuel
16	710-0599	2	/P	Screw, Self-tapping, 1/4-20, 0.500
17	736-0607	1	/P	Washer, Lock, 5/16 External Tooth
18	735-0690	2		Grommet
19	750-3310	2		Flange Spacer, .3125 x .4375 x .625

SLT1554 Tractor Courage Engine (2007 & before)
Frame

Page 38 of 74




SLT1554 Tractor Courage Engine (2007 & before)
Frame

Page 39 of 74

Ref #	Part Number	Qty	S/P/F	Description
1	17962	1		Plate, Switch
2	683-04173	1	S	Frame Assembly, Lower
3	710-1260A	6	/P	Screw, Self-tapping, 5/16-12, 0.75
4	710-0224	2	S	Screw, Hex Wash. Hd. Tapp, 10-16 x .5
5	710-0726	7	/P	Screw, Self-tapping, 5/16-18, 0.75
6	726-0205	2	/P	Clamp, Hose, .490 Dia.
7	710-1652	1	/P	Screw, Hex Wash. 1/4-20 x 0.625
8	751-10349	1		Fuel Line, Low Permeation, 29"
9	712-04065	2	/P	Nut, Nylon Lock, 3/8-16
10	710-0607	1	/P	Screw, Hex Wash. Tapp, 5/16-18 x .5
11	725-04039	1	S	Switch, Interlock
12	741-04092	1		Snap Bushing
13	732-04035	2		Spring, Compression, 1.28 OD x 3.125
14	736-0222	2	S	Washer, Lock, Ext 1/4
16	738-04058	2		Shoulder Spacer
17	738-0143	2	/P	Shoulder Screw, 3/8-16
18	710-3005	2	/P	Hex Screw 3/8-16 x 1.25
19	783-0726E	1	/P	Bracket, Pivot, Support RH
20	783-0727D	1		Bracket, Pivot, Support LH
21	783-0728	1		Bracket, Pivot, Bar
22	783-04810	1	S	Frame, Upper
23	783-04746	1		Bracket, Frame, Seat

SLT1554 Tractor Courage Engine (2007 & before)
Hood and Grille 1K016 & after

Page 40 of 74




SLT1554 Tractor Courage Engine (2007 & before)
Hood and Grille 1K016 & after

Page 41 of 74

Ref #	Part Number	Qty	S/P/F	Description
1	710-0726	2	/P	Screw, 5/16-12 x.750
2	710-0895	8		Screw, 1/4-15 x.750
3	710-0642	6	/P	Screw, Self Tapp, 1/4-20 x.750
4	738-04091	2	S	Screw, Shoulder, 5/16-18
5	738-0143	2	/P	Bolt, Shoulder, 3/8-16
6	712-04063	2	/P	Nut, Flange Lock, 5/16-18
7	714-0104	1	S	Pin, Cotter, .072 Dia. x 1.13
8	712-04065	2	/P	Nut, Nylon Lock, 3/8-16
9	759-04209	1	/P	Hood, Service Kit (contains 931-06887, 726-0233, 710-1242 and installation instructions)
9	931-06887	1	S	Hood Replaces 731-05053B
9	726-0233	4	/P	Push Nut .25ID x .50 OD
9	710-1242	4	/P	Screw, Hi Low 5/16-14 x .75
10	731-05103	1	S	Grill
11	731-05111	1	S	Lens
12	731-05129	1		Hood Plenum
13	732-04281A	1	/P	Latch Spring
14	783-05028	1	S	Hood Pivot Rod
15	747-04494	1		Hood Latch Rod
16	747-1323A	1		Rod, .250 Dia. x 4.55
17	683-04218	1	S	Bumper
18	783-05029	1	S	Hood Hinge Bracket
19	783-04848	1		Latch Plate
20	783-04717A	1	/P	Latch Pivot Bracket
21	710-0607	4	/P	Screw, 5/16-18 x.50
22	731-05291	1	S	Vinyl Strip, 2.5"
23	725-0963	2	S	Miniature Lamp, 12V
24	725-1649	2	S	Lamp Socket
25	731-05368	4		Cap, Bumper
	629-04142A	1	/P	Headlight Harness not shown

SLT1554 Tractor Courage Engine (2007 & before)
Hood and Grille 1K016 & before

Page 42 of 74




SLT1554 Tractor Courage Engine (2007 & before)
Hood and Grille 1K016 & before

Page 43 of 74

Ref #	Part Number	Qty	S/P/F	Description
1	710-0726	4	/P	Screw, 5/16-12 x.750
2	710-0895	12		Screw, 1/4-15 x.750
3	710-1276	4	/P	Screw, Self Tapp, 1/4-20 x.750
4	710-3170	2		Screw, Ball, 5/16-18 x.56
5	711-0332	2	S	Pin, Clevis,.50 Dia. x.78
6	712-04063	2	/P	Nut, Flange Lock, 5/16-18
7	714-0104	1	S	Pin, Cotter,.072 Dia. x 1.13
8	714-0145	2	S	Pin, Click,.092 x 1.64
9	759-04209	1	/P	Hood, Service Kit (contains 931-06887, 726-0233, 710-1242 and installation instructions)
9	931-06887	1	S	Hood Replaces 731-05053B
9	726-0233	4	/P	Push Nut .25ID x .50 OD
9	710-1242	4	/P	Screw, Hi Low 5/16-14 x .75
10	731-05103	1	S	Grill
11	731-05111	1	S	Lens
12	731-05129	1		Hood Plenum
13	732-04281A	1	/P	Latch Spring
14	747-04354B	1	/P	Hood Pivot Rod
15	747-04494	1		Hood Latch Rod
16	747-1323A	1		Rod,.250 Dia. x 4.55
17	683-04218	1	S	Bumper
18	783-04971	1		Hood Hinge Bracket
19	783-04714	1	S	Latch Plate
20	783-04717A	1	/P	Latch Pivot Bracket
21	783-04724A	2	/P	Upper Pivot Bracket
22	783-04725A	2		Hood Pivot Bracket
23	725-0963	2	S	Miniature Lamp, 12V
24	725-1649	2	S	Lamp Socket
25	731-05368	4		Cap, Bumper
26	731-05291	1	S	Vinyl Strip, 2.5"
	629-04142A	1	/P	Headlight Harness

SLT1554 Tractor Courage Engine (2007 & before)
Label Map SLT1554

Page 44 of 74




SLT1554 Tractor Courage Engine (2007 & before)
Label Map SLT1554

Page 45 of 74

Ref #	Part Number	Qty	S/P/F	Description
777X42179	777X42179	1		LABEL-CUB HOTLINE
777I22679	777I22679	1		LABEL-CHECK ENG OIL
777D10633	777D10633	1		LABEL-CYCLO CUT
777S30015	777S30015	1		LBL.RIDER DNGR.STRAIGHT
777I22265	777I22265	1		LABEL-BELT ROUTE
777D10781	777D10781	1		LABEL-54" CUT
777S30503	777S30503	1	/P	LABEL-DANGER CHUTE
777S30284	977S30145	1	/P	LABEL
777D10624	777D10624	1		LABEL-RIDER:DECK WASH CUB
777D08735	777D08735	1		LABEL-RH SIDE LT1554
777D08734	777D08734	1		LABEL-LH SIDE LT1554
777D09639	777D09639	1		LABEL-LFT SIDE HOOD
777D09638	777D09638	1		LABEL-RGT SIDE HOOD
777X42072	777X42072	1		LABEL-GRILLE RIB
777X42027	777X42027	1		LABEL-GRILLE REFLECTOR
777X42036	777X42036	1		LABEL: CUB RIDER
777X42535	777X42535	1		LABEL-PARTS LIST SLT1554
777I22280	977I22280	1	/P	LABEL-THROTTLE
777I22459	777I22459	1		LABEL-DASH PANEL
777I20310	777I20310	1		LABEL-SEAT ADJUSTE
777I22241	777I22241	1		LABEL-FUEL LEVEL
777S32484	777S32484	1		LABEL-FRAME COVER
777D10279	777D10279	1		LABEL-REAR FENDER
777I22240	777I22240	1		LABEL-HYDRO ENGAGE

SLT1554 Tractor Courage Engine (2007 & before)
Lift Assembly 1K016 & after

Page 46 of 74




SLT1554 Tractor Courage Engine (2007 & before)
Lift Assembly 1K016 & after

Page 47 of 74

Ref #	Part Number	Qty	S/P/F	Description
1	683-04223	1	S	Shaft Assembly, Lift (Model SLT 1550)
1	683-04301	1	S	Shaft Assembly, Lift (Model SLT 1554)
2	711-0332	2	S	Pin, Clevis, .50 Dia x .78 Lg
3	783-0720A	1	S	Bracket, Deck
4	712-04065	2	/P	Nut, Nylon Lock, 3/8-16
5	712-04063	2	/P	Nut, Nylon Lock, 5/16-18, Gr5
6	712-3083	2	/P	Nut, Hex Lock, 1/2-13, Gr8, Nylon
7	714-0104	2	S	Pin, Cotter, .072 Dia. x 1.13 Lg
8	714-0111	2	S	Pin, Cotter, 3/32, 1.0
9	714-04023	2	S	Pin, Click, .092 x 1.64 Lg
10	716-0106A	2		E-ring, .625 Dia. Shaft
11	720-0311	1		Grip, Handle
12	732-0874	1	/P	Spring, Torsion
18	738-0138A	2	/P	Screw, Shoulder, 5/16-18x.620 Gr2
19	738-0143	2	/P	Shoulder Screw, 3/8-16
20	741-0225	2	S	Bearing, Hex Flange
22	746-0968	2		Cable, Lift, 16.16 Lg
23	747-04447	1		Handle, Lift
24	747-1324	1		Rod, Deck .5" Dia.
25	756-1154	2		Pulley, Roller
26	783-04963A	2		Arm, Lift (Model SLT 1550)
26	783-05546	2	S	Arm, Lift (Model SLT 1554)
27	712-0206	2	S	Nut, Hex, 1/2-13
28	710-0726	1	/P	Screw, Self-tapping, 5/16-12, 0.75
29	732-0791	1		Spring, 1.01 x 6.5
30	783-04462	1		Bracket, Lift

SLT1554 Tractor Courage Engine (2007 & before)
Lift Assembly 1K016 & before

Page 48 of 74




SLT1554 Tractor Courage Engine (2007 & before)
Lift Assembly 1K016 & before

Page 49 of 74

Ref #	Part Number	Qty	S/P/F	Description
1	753-06260	1	/P	Shaft Assembly, Lift (Model SLT 1550) Replaces 683-04079
1	683-04118	1	S	Shaft Assembly, Lift (Model SLT 1554)
2	711-0332	2	S	Pin, Clevis, .50 Dia x .78 Lg
3	783-0720A	1	S	Bracket, Deck
4	712-04065	2	/P	Nut, Nylon Lock, 3/8-16
5	712-04063	2	/P	Nut, Nylon Lock, 5/16-18, Gr5
6	712-3083	2	/P	Nut, Hex Lock, 1/2-13, Gr8, Nylon
7	714-0104	2	S	Pin, Cotter, .072 Dia. x 1.13 Lg
8	714-0111	2	S	Pin, Cotter, 3/32, 1.0
9	714-04023	2	S	Pin, Click, .092 x 1.64 Lg
10	716-0106A	2		E-ring, .625 Dia. Shaft
11	720-0311	1		Grip, Handle
12	732-0874	1	/P	Spring, Torsion
18	738-0138A	2	/P	Screw, Hex Cap, 5/16-18x.620 Gr2
19	738-0143	2	/P	Shoulder Screw, 3/8-16
20	741-0225	2	S	Bearing, Hex Flange
22	746-0968	2		Cable, Lift, 16.16 Lg
23	747-04155	1		Handle, Lift
24	747-1324	1		Rod, Deck .5" Dia.
25	756-1154	2		Pulley, Roller
26	783-04963	2		Arm, Lift (Model SLT 1550)
26	783-0678A	2	S	Arm, Lift (Model SLT 1554)
27	712-0206	2	S	Nut, Hex, 1/2-13
28	710-0726	1	/P	Screw, Self-tapping, 5/16-12, 0.75
29	732-0934	1		Spring, 1.01 x 6.5 (Model SLT 1554)
30	783-04462	1		Bracket, Lift (Model SLT 1554)

SLT1554 Tractor Courage Engine (2007 & before)
Mower Deck 54 inch

Page 50 of 74



SLT1554 Tractor Courage Engine (2007 & before)
Mower Deck 54 inch

Page 51 of 74

Ref #	Part Number	Qty	S/P/F	Description
1	16606	1	S	Hook, Retainer Bracket
2	618-04126	3	S	Spindle Assembly
3	683-0254B	1	/P	Hanger Bracket Assembly
4	738-1010A	3	/P	Shaft, Spindle, 5.75
5	683-04180	1	S	54" Deck Weldment
6	683-04182	1	S	Idler Arm Assembly
7	703-2093	1		Inner Rear Baffle
8	703-3279	1		Chute Deflector Stop
9	710-0216	2	/P	Screw, 3/8-16 x.75
10	710-0520	2	/P	Screw, 3/8-16 x 1.50
11	710-0528	1	/P	Screw, 5/16-18 x 1.25
12	710-0599	1	/P	Screw, 1/4-20 x.500
13	710-0623	4	/P	Screw, 3/8-16 x.750
14	710-0726	14	/P	Screw, 5/16-12 x.750
15	710-1260A	12	/P	Screw, 5/16-18 x.750
16	710-3103	1	/P	Screw, 5/16-18 x 2.00
17	710-04095	1		Screw, 3/8-16 x 1.0
18	710-3178	2	/P	Bolt, Carriage, 3/8-16 x.750
19	711-1737	1		Pin, Roller,.5" Dia. x 10.06
20	712-0417A	2	/P	Nut, Hex, Flange, 5/8-18
21	712-0229	2		Push Nut, 3/8
22	712-04063	1	/P	Nut, Flange Lock, 5/16-18
23	712-04065	9	/P	Nut, Flange Lock, 3/8-16
24	712-0431	2	S	Nut, Flange Lock, 3/8-16
25	712-0641	2	S	Nut, Hex, M16-1.5
26	712-3010	1	S	Nut, Hex, 5/16-18
27	712-3022	1	/P	Nut, Hex Lock, 1/2-13
28	736-0315	3	/P	Washer, Flat, .760 x 1.5 x .120
29	714-0111	1	S	Pin, Cotter, 3/32 x 1.00
30	714-0470	2	S	Pin, Cotter, 1/8 x 1.25
31	717-04074	1	S	Deck Adjustment Gear
32	721-04041	1	S	Hose Coupler
33	731-3005	1	/P	Front Roller
34	732-0306A	2	S	Spring,.531OD x 1.75
35	732-0459B	1	S	Spring, Ext.,.94 Dia. x 6.74
36	750-1349	3	S	Spacer, 79 x 1.84 x .55
37	734-04155	4		Deck Wheel
38	736-0119	1	S	Washer, Lock, 5/16
39	736-0300	2	S	Washer, Flat,.406 x.875 x.059
40	736-0760	2	S	Washer, Lock
41	736-0921	1	S	Washer, Lock, 1/2
43	737-04003B	2	S	Port, Water
44	738-0373	4	S	Screw,.498 x 1.53 x 3/8-16
45	738-1229A	1	/P	Screw,.625 x 2.50 x 1/2-13
46	742-0677	3	S	Blade, 18.5"
47	756-1171	3		Pulley, 5.39"
48	747-1116	2	/P	Rod, Deck Release Handle
49	750-1000	6		Spacer, .800 x 1.10 x 1.322
50	750-0151	2	S	Spacer,.550 ID x.755 OD x 1.1
51	754-0642	1	S	V-Belt
52	756-04129	2	S	Pulley, Idler, 4.25" Dia.
53	783-04013A	1		Bracket, Stabilizer, Pulley
54	737-3000	3	S	Lube Fitting, 3/16


SLT1554 Tractor Courage Engine (2007 & before)
Mower Deck 54 inch

Page 52 of 74

Ref #	Part Number	Qty	S/P/F	Description
55	783-04690	2	S	Skirt, Deck
56	783-04691	1		Cover, Belt, RH
57	783-04692	1		Cover, Belt, LH
58	783-04726	1		Bracket, Idler, Stationary
59	631-04070	1	S	Chute Assembly, Side Discharge
60	783-04470	1	/P	Chute Mounting Bracket
61	732-3070	1	S	Torsion Spring
62	731-3131A	1	S	Deflector Chute
63	711-1762	1		Hinge Pin
64	741-0919	6	S	Ball Bearing, .787 x 1.85 x .551

SLT1554 Tractor Courage Engine (2007 & before)
Pedal Assembly 1K016 & after

Page 53 of 74




SLT1554 Tractor Courage Engine (2007 & before)
Pedal Assembly 1K016 & after

Page 54 of 74

Ref #	Part Number	Qty	S/P/F	Description
1	647-04100	1	S	Control Assembly, Brake
2	647-0049A	1	S	Control Assembly, Hydro
3	710-0726	4	/P	Screw, Self-tapping, 5/16-12, 0.75
4	710-1260A	1	/P	Screw, Self-tapping, 5/16-18, 0.75
5	736-0119	1	S	Washer, Lock, 5/16
6	783-04641	1	S	Pedal, Brake
7	711-04159B	1		Pin, 3/8-16, 3/8 x 2.68
8	712-04065	2	/P	Nut, Nylon Lock, 3/8-16
9	712-3004A	1	/P	Nut, Flange Lock, 5/16-18, Gr5
10	714-0104	5	S	Pin, Cotter, .072 Dia. x 1.13 Lg
11	714-0111	2	S	Pin, Cotter, 3/32, 1.0
12	719-0584B	1	S	Pedal, Hydro Control
13	732-0335	1		Spring, Compression, .405 x 1.17
14	732-0955	1		Spring, Extension, .50 OD x 1.41 Lg
15	732-0963	1		Spring, Extension, .50 Dia x 6.37 Lg
16	735-3049A	1	/P	Pad, Brake, Control
17	783-0663E	1	/P	Bracket, Lockout, Hydro
18	783-04612	1	S	Bracket, Support, Stearing
19	736-0187	2	/P	Washer, Flat .64 x 1.24 x .06
20	736-0262	1	/P	Washer, Flat, .385 x .870 x .092
21	738-0155	1	S	Shoulder, Screw .437
22	738-0380	1	S	Shoulder, Screw 3/8-16
23	741-0225	2	S	Bearing, Hex Flange
24	741-3065B	2	/P	Bearing, Hex Flange, .628 ID, Split
25	747-04096	1		Rod, Control, Cruise
26	747-04093A	1		Rod, Control, Brake Lock
27	748-04039C	1		Latch, Cruise

SLT1554 Tractor Courage Engine (2007 & before)
Pedal Assembly 1K016 & before


Page 55 of 74



SLT1554 Tractor Courage Engine (2007 & before)
Pedal Assembly 1K016 & before

Page 56 of 74

Ref #	Part Number	Qty	S/P/F	Description
1	647-0031B	1	S	Control Assembly, Brake
2	647-0049A	1	S	Control Assembly, Hydro
3	710-0726	4	/P	Screw, Self-tapping, 5/16-12, 0.75
4	710-0650	1	/P	Screw, Self-tapping, 5/16-18,
5	736-0119	1	S	Washer, Lock, 5/16
6	783-0773A	1		Pedal, Brake
7	711-04159B	1		Pin, 3/8-16, 3/8 x 2.68
8	712-04065	2	/P	Nut, Nylon Lock, 3/8-16
9	712-3004A	1	/P	Nut, Flange Lock, 5/16-18, Gr5
10	714-0104	5	S	Pin, Cotter, .072 Dia. x 1.13 Lg
11	714-0111	2	S	Pin, Cotter, 3/32, 1.0
12	719-0584B	1	S	Pedal, Hydro Control
13	732-0335	1		Spring, Compression, .405 x 1.17
14	732-0955	1		Spring, Extension, .50 OD x 1.41
15	732-0963	1		Spring, Extension, .50 Dia x 6.37
16	735-3049	1	S	Pad, Brake, Control
17	783-0663E	1	/P	Bracket, Lockout, Hydro
18	710-1611B	3	/P	Screw, Torx Hd. Tapp. 5/16-18 x
19	736-0187	2	/P	Washer, Flat .64 ID x 1.24 x .06
20	736-3008	1	S	Washer, Flat, .344 x .750 x .120
21	738-0155	1	S	Shoulder, Screw .437
22	738-0380	1	S	Shoulder, Screw 3/8-16
23	741-0225	2	S	Bearing, Hex Flange
24	741-3065B	2	/P	Bearing, Hex Flange, .628 ID, Split
25	747-04096	1		Rod, Control, Cruise
26	747-04093	1		Rod, Control, Brake Lock
27	748-04039B	1	/P	Latch, Cruise
28	783-04612	1	S	Bracket, Support, Stearing
29	736-0300	1	S	Lock Washer,.406 x.875 x.059



SLT1554 Tractor Courage Engine (2007 & before)
PTO System

Page 58 of 74

Ref #	Part Number	Qty	S/P/F	Description
1	710-0859	1	/P	Screw, 3/8-16 x 2.5 GR5
2	710-0726	3	/P	Screw, 5/16-12, .75
3	710-1260A	1	/P	Screw, 5/16-18, .75
4	710-3157	1	S	Screw, Hex Cap, 7/16-20 x 3.25 GR5
5	710-0607	1	/P	Screw, Hex, 5/16-18 x .5 (Model SLT 1550)
6	717-04174	1	S	Clutch, PTO (Model SLT 1550)
6	717-1774B	1	S	Clutch, PTO (Model SLT 1554)
7	712-04065	1	/P	Nut, Hex. Nylon Lock, 3/8-16
8	736-0171	1	S	Washer, Lock, 7/16, Regular Duty
9	783-04975	2	S	Deck Stop (Model SLT 1550)
10	748-0415B	1	/P	Spacer, 3/8 x 1.54
11	736-0277	1		Washer, Flat, 1.031 x 1.62 x .095
12	783-04467	1		Deck Stop (Model SLT 1554)
13	783-04419B	1	S	Bracket, Clutch
14	736-0277	1		Washer, Flat, 1.031 x 1.62 x .095
15	747-04384	1		Deck Stop Rod (Model SLT 1554)



SLT1554 Tractor Courage Engine (2007 & before)
Quick Reference SLT1554

Page 60 of 74

Ref #	Part Number	Qty	S/P/F	Description
	759-3336	1	/P	Spark Plug
	KH-32-883-03-S1	1	/P	Air Filter & Pre-Cleaner
	KH-52-050-02-S	1	/P	Oil Filter
	KH-25-050-22-S1	1	/P	Fuel Filter
	KH-24-584-36-S	1	/P	Ignition Module
	KH-41-403-10-S	1	/P	Voltage Regulator
	KH-24-393-16	1	/P	Fuel Pump
	KH-24-757-46-S	1	/P	Carb Kit
	KH-24-757-45-S	1	/P	Carburetor Solenoid
	754-0461	1	S	Drive Belt (Trans)
	754-0642	1	S	P.T.O. / Deck Belt
	742-0677	1	S	Blades
	712-0417A	1	/P	Blade Nut
	618-04126A	1	S	Spindle Assy. w/Pulley
	734-04155	1		Deck Wheels (Front)
	734-04155	1		Deck Wheels (Back)
	721-04041	1	S	Water Nozzle Adapter
	723-0448A	1	S	Ball Joints
	725-04039	1	S	Brake Switch
	751-3124D	1	S	Fuel Cap
	725-04439	1		Solenoid
	725-2054	1	S	Ignition Keys
	725-04227B	1	S	Ignition Switch Module
	725-04175	1	S	P.T.O. Switch
	717-1774B	1	S	P.T.O. Clutch
	KH-25-357-05-S	1	S	Engine Oil
	737-3121	1	/P	Transmission Fluid
	490-900-0041	1		Deck Leveling Guage


SLT1554 Tractor Courage Engine (2007 & before)
Steering

Page 62 of 74

Ref #	Part Number	Qty	S/P/F	Description
1	710-0514	1	/P	Hex Cap Screw, 3/8-16, 1.00, Gr5, Std
2	711-1408	1		Link, Drag, RH
3	711-1409A	1	/P	Link, Drag, LH
4	710-1260	1	S	Self-tapping Screw, 5/16-18 x .75
5	712-0240	2	S	Nut, Jam, 7/16-20, Gr2
6	712-0214	2	S	Nut, Hex, 3/8-24, Gr5
7	712-04065	4	/P	Nut, Nylon Lock, 3/8-16
8	712-0459	1	/P	Nut, Flange Lock, 7/16-20
9	712-3004A	2	/P	Nut, Flange Lock, 5/16-18
10	717-1550E	1	S	Gear, Steering, 11/90 Ratio
11	717-1554	1		Gear, Pinion, Steering
12	723-0448A	2	S	Ball Joint, 7/16-20
13	710-04095	1		Hex Cap Screw, 3/8-16, 1.00
14	736-3004	1	S	Washer, Flat, .406 x .875 x .105
15	736-3084	1	/P	Washer, Flat, .510 x 1.120 x .060
16	731-04532	1	S	Cover, Steering Wheel
17	738-04154	2		Spacer, Shoulder, 1.00 x .38 x .38
18	759-04186	1	/P	Shaft, Steering, .625 OD x 25.00 Lg
19	741-0475	2	S	Bushing, Plastic, .380 ID
20	741-0656A	1	S	Bearing, Hex Flange, 5/8
21	638-04003A	1	S	Axle Ass'y, LH .750 Dia
22	638-04004A	1	S	Axle Ass'y, RH .750 Dia
23	726-0341	2	/P	Push Cap, .75
24	714-04039	2		Pin, Cot, 5/32, 1.25
25	719-04105	1	/P	Axle, Pivot, Cast .750 Dia
26	736-0866	2		Washer, Flat, .755 x 1.92 x .060
27	738-1011A	2	/P	Screw, Shoulder, .500 x 2.230, 3/8-16
28	631-04008A	1	/P	Wheel, Steering, Three Spoke

SLT1554 Tractor Courage Engine (2007 & before)
Transmission 618-04270

Page 63 of 74



SLT1554 Tractor Courage Engine (2007 & before)
Transmission 618-04270

Page 64 of 74

Ref #	Part Number	Qty	S/P/F	Description
1	HG-71275	1		Main Housing, Assembly
		1		Main Housing, Machined Drain
		1		Bushing, .865 X .985 X .790
2	HG-70483	1	/P	Side Housing, Assembly
		1		Side Housing
		1		Bushing, .865 X .985 X .790
		1		Bushing, .624 X .719 X .562
3	HG-70477	1		Center Section, Assembly
		1		Center Section
		1		Bushing, .707 X .788 X .591
4	HG-51048	1	/P	Swashplate, Trunnion Machined
5	HG-70331	1	/P	Block - Assembly
		1		Block - Cylinder
		5		Piston
		5		Spring, Compression
		5		Washer - Thrust
7	HG-51190	14	/P	Hex Flange Screw 1/4-20 X 1.25
9	HG-51062	1	/P	Shaft, Input
10	HG-2000022	1	/P	Ring, Retaining
11	HG-50951	1	/P	Spacer
12	HG-50329	3	/P	Ring, Retaining
13	HG-51161	1	/P	Seal, Lip .67 X 1.58 X .276
14	HG-50315	1		Ball, Bearing 17mm ID X 40mm OD X12mm
16	HG-51064	1		Bolt, Hex Flange Head 5/16-24 X .94 (Patch)
17	HG-51140	1	/P	Lip Seal 18 X 32 X 7
18	HG-51119	1	/P	Arm, Control
19	HG-50551	2	S	Bearing, 30 X 52 X 13 Thrust
24	HG-50966	1		Shaft, Motor
27	HG-51767	1		Gear - Pinion, 12T
28	HG-51766	1		10T/49T Gear
29	HG-51043	1	/P	Gear, LDT Jackshaft
30	HG-51044	1		60T Bull Gear
31	HG-51088	2	/P	Sleeve Bearing .75 X 1.750 X .625
32	HG-51089	2	/P	Sleeve Bearing (Outboard) .75 X 1.575 X .625
33	HG-44875	2	/P	Washer, 3/4 X 1 1/2 X .13 THK
34	HG-51066	2	/P	Lip Seal Axle Seal
35	HG-52209	1	S	Shaft, Axle (R.H.)
36	HG-52210	1	S	Shaft, Axle (L.H.)
37	HG-51769	2	/P	Miter Gear 12T (Splined)
38	HG-51768	2		Miter Gear 12T
39	HG-50146	1		Shaft
40	HG-44871	2	/P	Ring, Spiral Retaining
41	HG-51083	1		Pin, Jackshaft
42	HG-51100	1		Magnet, Ring
44	HG-50016	2		Bolt, Hex Flange 3/8-24 X 2.5
48	HG-51098	1		Rod, Bypass Actuator
49	HG-51135	1		Arm, Bypass
50	HG-51116	1	/P	Retaining Ring, 250 External
51	HG-51081	1	/P	Seal, Lip .741 X .250 X 250 TC
52	HG-44371	1	/P	Flat Washer
53	HG-44145	1		Retaining Ring
54	HG-51071	1		Bearing, Center Block
55	HG-2003014	1	/P	Spring, Helical Compression

SLT1554 Tractor Courage Engine (2007 & before)
Transmission 618-04270


Page 65 of 74

Ref #	Part Number	Qty	S/P/F	Description
56	HG-2003017	1	/P	Washer
58	HG-62589	1	/P	Brake, Yoke
59	HG-51072	1	/P	Rotor, Brake
60	HG-44132	2	S	Brake, Puck
61	HG-44134	1	S	Puck Plate
62	HG-44127	2	S	Brake Actuating Pin
63	HG-51146	2		HFHCS 1/4-20 X 2 w/Patch SPECIAL FLANGE
65	HG-23711	1		Spacer
66	HG-51607	1		Spring, Brake ARM BIAS
68	HG-44094	1	/P	Arm, Brake
69	HG-44142	1	S	Slotted Hex Nut, 5/16-24
70	HG-44101	1	S	Cotter Pin, 3/32 X 3/4
71	HG-50919	1	/P	Compression Spring Anti-Drag
72	HG-50132	3	/P	Washer
73	HG-44130	2	S	Flat, Washer 11/32 I.D. X 7/9 O.D
74	HG-70719	1	/P	Seal, Kit
84	HG-51143	1	/P	Fitting, 5/16 SAE 5/32 Tube
85	HG-51147	1		Hose, Expansion Tank
94	HG-44147	1		Bearing, Ball .62 ID X 1.39 .44
95	HG-50837	1		Screw, Socket Head Cap 5/16-24 X 1 1/2
96	HG-51200	1		Spacer, Locating
97	HG-50870	1		Screw, SFHCS 5/16-18 X 1
98	HG-51120	1		Arm, Return
99	HG-51097	1		Puck, Adjusting
100	HG-52493	1		Washer
101	HG-51131	1	/P	Spring, Extension
102	HG-51123	1		Spacer, .260 ID X .560 OD X .870
103	HG-51223	1		Bracket, Torque
108	HG-51069	1		Washer, Motor Shaft .71 ID X 1.15 OD X .030 THK
109	HG-9005110-5600	2	/P	Plug, SAE #6
110	HG-50868	1		Screw, Torx Head 5/16-18 T.F.
111	HG-51144	1		O-Ring .103 X .299 ID
114	HG-51184	1	/P	Spring, Guide
124	HG-71315	1		Center Section - Filter - Bypass Assembly
		1		Center Section
		1		Base, Filter,w/Poppet
		1		Check Plug Assembly, .027 Washer
		1		Shock Valve Assembly
		1		Spring, Bypass
		1		Actuator, Bypass
		1		Deflector
		1		Bottom, Filter
		1		Bushing, .707 X .788 X .591
125	HG-70756	1	/P	Filter Assembly
		1		Bottom, Filter
		1		Spring, Bypass
		1		Deflector
		1		Base, Filter,w/Poppet
128	HG-70503	1	/P	Kit, Expansion Tank
		1		Tank, Expansion Assembly
		1		Cap, Vent

SLT1554 Tractor Courage Engine (2007 & before)
Transmission 618-04270

Page 66 of 74

Ref #	Part Number	Qty	S/P/F	Description
		1		VSBolt, Self Tapping 10/32 X 1/2
		1		Bracket, Support Expansion Tank
	HG-70463	1	/P	Seal - O-Ring Kit not shown
		1		Seal, Lip .67 X 1.58 X .276
		1		Lip Seal 18 X 32 X 7
		2		Lip Seal .706 X 1.584 .25
		1		Seal, Lip .741 X .250 X .250 TC
		1		Oil Seal .625 X .25
		1		O-Ring
	737-3121	1	/P	Drive System Fluid not shown
	HG-50928	1	/P	Sealant 10.5 oz. not shown



SLT1554 Tractor Courage Engine (2007 & before)
Transmission 618-04270A

Page 68 of 74

Ref #	Part Number	Qty	S/P/F	Description
1	HG-70467	1		Main Housing, Assembly
		1		Main Housing, Machined Drain
		1		Bushing, .865 X .985 X .790
2	HG-71389	1		Side Housing, Assembly
		1		Side Housing, Machined
		1		Bushing, .865 X .985 X .790
		1		Bushing, .624 X .719 X .562
3	HG-70477	1		Center Section, Assembly
		1		Center Section, 5 Piston
		1		Bushing, .707 X .788 X .591
4	HG-51046	1		Swashplate, Trunnion Machined
5	HG-70331	1	/P	Block - Assembly
		1		Block - Cylinder
		5		Piston
		5		Spring, Compression
		5		Washer - Thrust
7	HG-51190	14	/P	Hex Flange Screw 1/4-20 X 1.25
9	HG-51062	1	/P	Shaft, Input
10	HG-2000022	1	/P	Ring, Retaining
11	HG-50951	1	/P	Spacer
12	HG-50329	3	/P	Ring, Retaining
13	HG-51161	1	/P	Seal, Lip .67 X 1.58 X .276
14	HG-50315	1		Ball, Bearing 17mm ID X 40mm OD X12mm
16	HG-51064	1		Bolt, Hex Flange Head 5/16-24 X .94 (Patch)
17	HG-51140	1	/P	Lip Seal 18 X 32 X 7
18	HG-51119	1	/P	Arm, Control
19	HG-50551	2	S	Bearing, 30 X 52 X 13 Thrust
24	HG-50966	1		Shaft, Motor
27	HG-51767	1		Gear - Pinion, 12T
28	HG-51766	1		10T/49T Gear
29	HG-51043	1	/P	Gear, LDT Jackshaft
30	HG-51044	1		60T Bull Gear
31	HG-51088	2	/P	Sleeve Bushing, Inboard
32	HG-51089	2	/P	Sleeve Bushing .75 x 1.575 x .625
33	HG-44875	2	/P	Washer, 3/4 X 1 1/2 X .13 THK
34	HG-51066	2	/P	Lip Seal Axle Seal
35	HG-51079	1	/P	Shaft, Axle (R.H.) DD
36	HG-51078	1	/P	Shaft, Axle (L.H.) DD
37	HG-51769	2	/P	Miter Gear 12T (Splined)
38	HG-51769	2	/P	Miter Gear 12T
39	HG-50146	1		Shaft
40	HG-44871	2	/P	Ring, Spiral Retaining
41	HG-51083	1		Pin, Jackshaft
42	HG-51100	1		Magnet, Ring
44	HG-50016	2		Bolt, Hex Flange 3/8-24 X 2.5
48	HG-51098	1		Rod, Bypass Actuator
49	HG-51135	1		Arm, Bypass
50	HG-51116	1	/P	Retaining Ring, 250 External
51	HG-51081	1	/P	Seal, Lip .741 X .250 X 250 TC
52	HG-44371	1	/P	Flat Washer, 5/9 ID X 1.0 OD X .05THK
53	HG-44145	1		Retaining Ring
54	HG-51071	1		Bearing, Center Block
55	HG-2003014	1	/P	Spring, Helical Compression

SLT1554 Tractor Courage Engine (2007 & before)
Transmission 618-04270A

Page 69 of 74

Ref #	Part Number	Qty	S/P/F	Description
56	HG-2003017	1	/P	Washer
58	HG-62589	1	/P	Brake, Yoke Kit
59	HG-51072	1	/P	Rotor, Brake
60	HG-44132	2	S	Brake, Puck
61	HG-44134	1	S	Puck Plate
62	HG-44127	2	S	Brake Actuating Pin
63	HG-51146	2		HFHCS 1/4-20 X 2 w/Patch SPECIAL FLANGE
65	HG-23711	1		Spacer
66	HG-51607	1		Spring, Brake ARM BIAS
68	HG-44094	1	/P	Arm, Brake
69	HG-44142	1	S	Slotted Hex Nut, 5/16-24
70	HG-44101	1	S	Cotter Pin, 3/32 X 3/4
71	HG-50919	1	/P	Compression Spring Anti-Drag
72	HG-50132	3	/P	Washer,
73	HG-41130	2		Flat, Washer 11/32 I.D. X 7/9 O.D
74	HG-70719	1	/P	Seal, Kit
84	HG-51143	1	/P	Fitting, 5/16 SAE 5/32 Tube
85	HG-51147	1		Hose, Expansion Tank
94	HG-44147	1		Bearing, Ball .62 ID X 1.39 .44
95	HG-50837	1		Screw, Socket Head Cap 5/16-24 X 1 1/2
96	HG-51200	1		Spacer, Locating
97	HG-50870	1		Screw, SFHCS 5/16-18 X 1
98	HG-51120	1		Arm, Return
99	HG-51097	1		Puck, Adjusting
100	HG-52493	1		Washer, Flat
101	HG-51131	1	/P	Spring, Extension
102	HG-51123	1		Spacer, .260 ID X .560 OD X .870
103	HG-51223	1		Bracket, Torque
108	HG-51069	1		Washer, Motor Shaft .71 ID X 1.15 OD X .030 THK
109	HG-9005110-5600	2	/P	Plug, SAE #6
110	HG-50868	1		Screw, Torx Head 5/16-18 T.F.
111	HG-51144	1		O-Ring .103 X .299 ID
114	HG-51184	1	/P	Spring, Guide
124	HG-71315	1		Center Section - Filter - Bypass Assembly
		1		Center Section
		1		Base, Filter,w/Poppet
		1		Check Plug Assembly, .027 Washer
		1		Shock Valve Assembly
		1		Spring, Bypass
		1		Actuator, Bypass
		1		Deflector
		1		Bottom, Filter
		1		Bushing, .707 X .788 X .591
125	HG-70756	1	/P	Filter Assembly
		1		Bottom, Filter
		1		Spring, Bypass
		1		Deflector
		1		Base, Filter,w/Poppet
128	HG-70503	1	/P	Kit, Expansion Tank
		1		Tank, Expansion Assembly
		1		Cap, Vent


SLT1554 Tractor Courage Engine (2007 & before)
Transmission 618-04270A

Page 70 of 74

Ref #	Part Number	Qty	S/P/F	Description
		1		VS Bolt, Self Tapping 10/32 X 1/2
		1		Bracket, Support Expansion Tank
	HG-70463	1	/P	Seal - O-Ring Kit not shown
		1		Seal, Lip .67 X 1.58 X .276
		1		Lip Seal 18 X 32 X 7
		2		Lip Seal .706 X 1.584 .25
		1		Seal, Lip .741 X .250 X .250 TC
		1		Oil Seal .625 X .25
		1		O-Ring
	737-3121	1	/P	Drive System Fluid not shown
	HG-50928	1	/P	Sealant 10.5 oz. not shown

SLT1554 Tractor Courage Engine (2007 & before)
Wheels 1K016 & after

Page 71 of 74




SLT1554 Tractor Courage Engine (2007 & before)
Wheels 1K016 & after

Page 72 of 74

Ref #	Part Number	Qty	S/P/F	Description
1	734-04174	2		Tire, Turf, 22 x 9.5 x 12
2	634-04238	2	/P	Rim Assembly, 12 x 7 (4-Lug)
2	734-0255	2	S	Valve, Tubeless Air not shown
3	712-3050	2	/P	Lug Nut, 7/16-14
4	734-1731	2		Tire, Turf, 15 x 6 x 6
5	634-04081	2	S	Rim Assembly, 6 x 4.5 Includes Flange Bearings and Valve
5	741-04137	4	S	Bearing, Flange not shown
5	734-0255	2	S	Valve, Tubeless Air not shown
6	731-05674	2	/P	Hub Cap

SLT1554 Tractor Courage Engine (2007 & before)
Wheels 1K016 & before

Page 73 of 74



SLT1554 Tractor Courage Engine (2007 & before)
Wheels 1K016 & before

Page 74 of 74

Ref #	Part Number	Qty	S/P/F	Description
1	734-04174	2		Tire, Turf, 22 x 9.5 x 12
2	634-04238	2	/P	Rim Assembly, 12 x 7
3	712-3050	8	/P	Lug Nut, 7/16-14
4	741-3032	4	S	Bearing, Ball,.75 ID x 1.75 OD
5	634-04104A	2	S	Rim Assembly, 6 x 4.5 (Included, Bearings, Spacer and Valve)
6	731-3020	2	S	Hub Cap
7	734-1731	2		Tire, Turf, 15 x 6 x 6
	737-0224	2		Grease Fitting
	734-0255	4	S	Valve, Tubeless Air