


3235 Tractor S/N 1K010G & After
Air Intake KH 76524

Page 1 of 82




3235 Tractor S/N 1K010G & After
Air Intake KH 76524

Page 2 of 82

Ref #	Part Number	Qty	S/P/F	Description
1	KH-54-755-01	1	S	Kit, Knob w/Seal (Includes 2,3)
2	KH-25-341-03	1	/P	Knob, Cover
3	KH-24-153-20-S	1		Seal, Air Cleaner Cover Knob
4	KH-24-096-69-S	1	/P	Cover, Air Cleaner
5	KH-12-100-01	1	/P	Wing Nut
6	KH-24-096-01	1	/P	Cover, Inner Air Cleaner
7	KH-24-032-03	1	/P	Seal, Inner Air Cleaner
8	KH-24-083-02	1	S	Precleaner, Element
9	KH-47-083-03	1	S	Element, Air Cleaner
10	KH-M-0639016	3	S	Screw, Hex Flange M6 x 1.0 x 16
11	KH-24-126-21	1		Bracket, Air Cleaner Base
12	KH-24-094-03	1	S	Base, Air Cleaner
13	KH-M-0651055	4		Screw, Hex Flange M6 x 1.0 x 55
14	KH-25-155-11	1		Connector, Hose 45°.
15	KH-25-237-14-S	2	/P	Clamp, Hose
16	KH-15-353-02-S	1		Line, Fuel 17"
17	KH-24-164-29	1		Manifold, Intake
18	KH-24-041-01	2	/P	Gasket, Intake Manifold
19	KH-24-041-06	1	/P	Gasket, Air Cleaner Base
20	KH-24-743-08	1		Kit, Air Cleaner Cover (Includes 1-4, 11)

3235 Tractor S/N 1K010G & After
Air Intake KH-730104

Page 3 of 82




3235 Tractor S/N 1K010G & After
Air Intake KH-730104

Page 4 of 82

Ref #	Part Number	Qty	S/P/F	Description
1	KH-54-755-01	1	S	Kit, Knob w/Seal (Incl. Ref #2,3)
2	KH-25-341-03	1	/P	Knob, Cover
3	KH-24-153-20-S	1		Seal, Air Cleaner Cover Knob
4	KH-24-096-69-S	1	/P	Cover, Air Cleaner
5	KH-12-100-01	1	/P	Wing Nut
6	KH-24-096-01	1	/P	Cover, Inner Air Cleaner
7	KH-24-032-03	1	/P	Seal, Inner Air Cleaner
8	KH-24-083-02	1	S	Precleaner, Element
9	KH-47-083-03	1	S	Element, Air Cleaner
10	KH-M-0639016	3	S	Screw, Hex Flange, M6 x 1.0 x16
11	KH-24-126-21	1		Bracket, Air Cleaner Base
12	KH-24-094-24-S	1	S	Base, Air Cleaner
13	KH-24-041-06	1	/P	Gasket, Air Cleaner Base
14	KH-M-0651040-S	4		Screw, Hex Flange, M6 x 1.0 x 40
15	KH-24-164-55-S	1	S	Manifold, Intake (Includes Carb Gasket KH-24-041-53-S and (2) O-Rings KH-24-153-27-S)
16	KH-24-153-27-S	2	/P	O-Ring, Intake Manifold
17	KH-24-743-08	1		Kit, Air Cleaner Cover (Incl 1-4, 11)
18	KH-24-041-53-S	1		Gasket, Carburetor
19	KH-M-0545010	2	/P	Screw, Hex Flng, M5 x 0.8 x 10
20	KH-24-126-130-S	1		Bracket, Air Cleaner Base
21	KH-25-155-11-S	1		Connector, Hose 45°.
22	KH-25-237-14-S	2	/P	Clamp, Hose
23	KH-15-353-02-S	1		Line, Fuel 17"

3235 Tractor S/N 1K010G & After
Blower Housing And Baffles KH-730104

Page 5 of 82




3235 Tractor S/N 1K010G & After
Blower Housing And Baffles KH-730104

Page 6 of 82

Ref #	Part Number	Qty	S/P/F	Description
1	KH-24-027-163-S	1		Housing, Blower (Includes Grommet KH-25-313-06-S)
5	KH-M-0551016	1		Screw, Hex Flange M5 x 0.8 x 16
6	KH-M-0545016	3	S	Screw, Hex Flange M5 x 0.8 x 16
7	KH-M-0545020	4	/P	Screw, Hex Flange M5 x 0.8 x 20
8	KH-24-146-16	1	S	Plate, Backing #2 Side
9	KH-M-0645016	6	S	Screw, Hex Flange M6 x 1.0 x 16
10	KH-24-063-20	1	/P	Baffle, Cyl. Barrel #2 Side
11	KH-24-063-17	1	/P	Baffle, Valley #2 Side
12	KH-M-0545010	2	/P	Screw, Hex Flange M5 x 0.8 x 10
13	KH-24-063-59-S	1		Baffle, Valley #1 Side
14	KH-24-063-58-S	1	S	Baffle, Cyl. Barrel #1 Side
15	KH-24-146-20	1	S	Plate, Backing #1 Side

3235 Tractor S/N 1K010G & After
Blower Housing And Baffles KH-76524

Page 7 of 82




3235 Tractor S/N 1K010G & After
Blower Housing And Baffles KH-76524

Page 8 of 82

Ref #	Part Number	Qty	S/P/F	Description
1	KH-24-027-20	1	S	Housing, Blower (Includes 2-4)
2	KH-24-100-02	2		Nut, Plastic
3	KH-25-139-16	1		Plug, Button 9/16"
4	KH-24-100-01	3		Nut, Plastic
5	KH-M-0551016	1		Screw, Hex Flange M5 x 0.8 x 16
6	KH-M-0545016	3	S	Screw, Hex Flange M5 x 0.8 x 16
7	KH-M-0545020	4	/P	Screw, Hex Flange M5 x 0.8 x 20
8	KH-24-146-16	1	S	Plate, Backing #2 Side
9	KH-M-0645016	6	S	Screw, Hex Flange M6 x 1.0 x 16
10	KH-24-063-20	1	/P	Baffle, Cyl. Barrel #2 Side
11	KH-24-063-17	1	/P	Baffle, Valley #2 Side
12	KH-M-0545010	2	/P	Screw, Hex Flange M5 x 0.8 x 10
13	KH-24-063-24	1	S	Baffle, Valley #1 Side
14	KH-24-063-58-S	1	S	Baffle, Cyl. Barrel #1 Side
15	KH-24-146-20	1	S	Plate, Backing #1 Side

3235 Tractor S/N 1K010G & After
Brake And Control Pedals

Page 9 of 82



3235 Tractor S/N 1K010G & After
Brake And Control Pedals


Page 10 of 82

Ref #	Part Number	Qty	S/P/F	Description
1	603-0379	1		Shaft Assembly, Pedal
2	603-0421A	1	/P	Plate, Disengagement
3	603-0437-0637	1	/P	Cam, Clutch
4	603-0445A	1		Shaft Assembly, Brake.
5	603-0449A	1	S	Shaft Assembly, Reverse.
6	603-0634	1		Rod Assembly, Cruise
7	703-3012-0716	1		Link, Pedal Mounting
8	703-3020-0637	1		Bracket, Rod Adjust
9	703-3152-0637	2		Bracket, Switch
10	603-0733-0716	1		Lever, Brake Diff Lock
11	703-3156-0716	1	S	Link, Brake Pedal
12	710-0106	1	/P	Screw, Hex Cap, 1/4-20 x 1.25 GR5
13	710-0599	5	/P	Screw, Hex Wash. Hd. Tapp 1/4-20 x .5
14	710-0623	2	/P	Screw, Hex Wash. Hd. Tapp 3/8-16 x .75
15	710-0642	6	/P	Screw, Hex Wash. Hd. Tapp 1/4-20 x .75
16	710-1315	2	/P	Screw, Hex Wash. Hd. Tapp 3/8-16 x 1.25
17	711-0679A	1	/P	Pin, Clevis, 3/8 x 2.015
18	711-1530	1		Ferrule, Adjust
19	711-04035	1		Stud, Actuator
20	712-3004A	2	/P	Nut, Hex Flange Lock, 5/16-18
21	712-3027	1	S	Nut, Hex Flange Lock, 1/4-20
22	712-3058	3	S	Nut, Hex Insert Lock, 1/2-20
23	712-0429	1	S	Nut, Hex Insert Lock, 5/16-18
24	714-0104	7	S	Pin, Internal Cotter
25	714-0145	2	S	Pin, Internal Cotter
26	714-0147	5	/P	Pin, Internal Cotter
27	715-0114	1	S	Pin, Spiral Spring, .25 x 1.5
28	731-3247	1		Pedal, Forward
29	731-3248	1		Pedal, Reverse
30	731-3249	1	S	Pedal, Brake
31	732-0324	1		Spring, Compression
32	732-0859	1	S	Spring, No Cut Reverse
33	732-0871	1		Spring, Torsion
34	732-3118	2		Spring, Extension, .380 OD x 1.44
35	736-0275	2	S	Washer, Flat, .344 x .688 x .065
36	736-0287	1	S	Washer, Flat, .79 x 1.24 x .060
37	736-0463	1	S	Washer, Flat, .25 x .62
38	736-0621	1		Washer, Wave, .785 x 1.0 x .012
39	736-3019	3		Washer, Flat, .531 x 1.06 x .134
40	741-0598	4	S	Bearing, Hex Flange
41	741-3073	3	S	Bearing, Flange
42	741-3074	2		Bearing, Flange
43	741-3084	1		Bearing, Flange
44	747-3319	1		Rod, Rear Control
45	747-3320	1		Rod, Front Control
46	747-3324	1		Rod, Rear Connecting
47	747-3353	1		Rod, Front Connecting
48	747-3422	1		Rod, Brake
49	748-04001	1		Cruise Latch
50	748-3080A	1	/P	Plate, Cruise
51	603-0738	1	S	Link Assembly, Brake
52	736-0418A	1	/P	Washer, Flat, .341 x 2.25 x .10
53	736-0160	1	S	Washer, Flat, .53 x .93 x .050

3235 Tractor S/N 1K010G & After
Brake And Control Pedals

Page 11 of 82

Ref #	Part Number	Qty	S/P/F	Description
754	736-0262	2	/P	Washer, Flat, .385 x .870 x .092



3235 Tractor S/N 1K010G & After
Center Hydraulic Lift Linkage


Page 13 of 82

Ref #	Part Number	Qty	S/P/F	Description
1	603-0434-0716	1	/P	Link, LH Lift
2	603-0435A	1	/P	Shaft Assembly, Lift
3	603-0456-0716	1		Link, RH Lift
4	603-0803	1		Bracket, Downstop
5	703-3426	1		Stop Bracket, Lift Rod
6	703-3797	1		Arm, Downstop
7	748-3103	1		Disk, Detent
8	710-3178	2	/P	Bolt, Carriage, 3/8-16 x .75
9	710-3013	2	/P	Screw, Hex Cap, 1/4-20 x .5 GR5
10	711-1206	1		Pin, Clevis, .5 x 3.75
11	711-1553	1		Ferrule, Adjustment
12	711-1561	1		Pin, Detent Plunger
13	712-0431	2	S	Nut, Flange Lock, 3/8-16 GR5
14	712-3083	3	/P	Nut, Hex Lock, 1/2-13
15	714-0147	2	/P	Pin, Internal Cotter
16	716-0102	2	S	Snap Ring, 1.0 Dia. Shaft
17	716-0104	1	S	Ring, 'E' Retaining, .5 Dia
18	716-0111	1	/P	Snap Ring, .875 Dia. Shaft
19	717-3518	1		Cylinder, Center Lift
20	720-0236	1	S	Knob
	777I20243	1		Graphic, Height Adjust.
21	727-3135	2		Hose, Lift
	725-0157	1	/P	Tie, Cable
22	731-3215A	1	S	Indicator, Lift Position
23	732-0437	1		Spring, Compression
24	732-0870A	1	/P	Spring, Compression
25	736-0142	2	S	Washer, Flat, .281 x .5 x .063
26	736-0160	1	S	Washer, Flat, .536 x .93 x .050
27	736-0250	1	/P	Washer. Flat, 1.0 x 1.7 x .10
28	738-0744A	2	S	Shoulder Screw
29	741-0170	2	S	Bearing, Flange w/Flats
30	747-3330	1		Rod, RH Lift
31	747-3331A	1		Rod, LH Lift
32	747-3437	1		Screw, Adjustment

3235 Tractor S/N 1K010G & After
Crankcase And Crankshaft KH-730104

Page 15 of 82

Ref #	Part Number	Qty	S/P/F	Description
1	KH-730104	1		Engine, Complete
	KH-24-782-32	1		Miniblock
2	KH-24-014-06	1	S	Crankshaft (Includes 3)
3	KH-52-139-09	2	S	Plug, Cup
4	KH-25-139-57-S	2	/P	Plug, Hex Head, 3/8 NPTF
5	KH-24-032-01	1	S	Seal, Oil
6	KH-24-380-13-S	6	S	Pin, Dowel Locating
7	KH-24-067-13	2	S	Rod, Connecting, Std
	KH-24-067-14	2		Rod, Connecting, .010
8	KH-24-874-08-S	2	S	Piston w/Ring Set, Std
	KH-24-874-16-S	2	S	Piston w/Ring Set, .003
9	KH-24-018-01	4	S	Retainer, Piston Pin
10	KH-24-108-05-S	1	/P	Ring Set, Std & .003
11	KH-24-012-16-S	1		Camshaft
12	KH-24-018-09-S	1		Ring, Retainer
13	KH-12-422-09	A/R	S	Shim, Camshaft, .0320
	KH-12-422-13	A/R	S	Shim, Camshaft, .0400
	KH-12-422-07	A/R	S	Shim, Camshaft, .0280
	KH-12-422-08	A/R	S	Shim, Camshaft, .0300
	KH-12-422-10	1	S	Shim, Camshaft, .0340
	KH-12-422-11	A/R	S	Shim, Camshaft, .0360
	KH-12-422-12	A/R	S	Shim, Camshaft, .0380
14	KH-M-931010-S	1		Washer, Nylon
15	KH-28-032-09-S	1		Seal, Governor Cross Shaft
16	KH-24-468-15-S	1		Washer, Plain
17	KH-24-144-38-S	1	/P	Shaft, Governor Cross
18	751-3141-12	12 in.	S	Hose, Oil Drain
19	751-3140	1	S	Drain, Oil
	751-3142	1		Cap, Oil Drain
20	737-0199	1	S	Pipe, Straight
21	737-0272	1		Elbow, 90°.
	KH-24-755-113-S	1	S	Gasket Set




3235 Tractor S/N 1K010G & After
Crankcase And Crankshaft KH-76524

Page 17 of 82

Ref #	Part Number	Qty	S/P/F	Description
1	KH-76524	1	S	Engine, Complete
	KH-24-522-249	1		Short Block
	KH-24-782-27	1		Miniblock
2	KH-24-014-06	1	S	Crankshaft (Includes 3)
3	KH-52-139-09	2	S	Plug, Cup
4	KH-27-139-57-S	2		Plug, Hex Head, 3/8 NPTF
5	KH-24-032-01	1	S	Seal, Oil
6	KH-24-380-13-S	6	S	Pin, Dowel Locating
7	KH-24-067-13	2	S	Rod, Connecting, Std
	KH-24-067-14	2		Rod, Connecting, .010
8	KH-24-874-09	2	S	Piston w/Ring Set, Std
	KH-24-874-10	2	S	Piston w/Ring Set, .010
	KH-24-874-11	2		Piston w/Ring Set, .020
	KH-24-874-15	2		Piston w/Ring Set, .003
9	KH-24-018-01	4	S	Retainer, Piston Pin
10	KH-24-108-08	1		Ring Set, Std
	KH-24-108-09	1		Ring Set, .010
	KH-24-108-10	1		Ring Set, .020
11	KH-12-422-09	A/R	S	Shim, Camshaft, .0320
	KH-12-422-13	A/R	S	Shim, Camshaft, .0400
	KH-12-422-07	A/R	S	Shim, Camshaft, .0280
	KH-12-422-08	A/R	S	Shim, Camshaft, .0300
	KH-12-422-10	1	S	Shim, Camshaft, .0340
	KH-12-422-11	A/R	S	Shim, Camshaft, .0360
	KH-12-422-12	A/R	S	Shim, Camshaft, .0380
12	KH-24-012-10	1	S	Camshaft
13	KH-24-018-09-S	1		Ring, Retainer
14	KH-M-931010-S	1		Washer, Nylon
15	KH-28-032-09-S	1		Seal, Governor Cross Shaft
16	KH-24-468-15-S	1		Washer, Plain
17	KH-24-144-33-S	1	S	Shaft, Governor Cross
18	751-3141-12	12 in.	S	Hose, Oil Drain
19	751-3140	1	S	Drain, Oil
	751-3142	1		Cap, Oil Drain
20	737-0199	1	S	Pipe, Straight
21	737-0272	1		Elbow, 90°.
	KH-24-755-108-S	1		Gasket Set

3235 Tractor S/N 1K010G & After
Cylinder Head, Valves And Breather KH-730104

Page 18 of 82




3235 Tractor S/N 1K010G & After
Cylinder Head, Valves And Breather KH-730104

Page 19 of 82

Ref #	Part Number	Qty	S/P/F	Description
1	KH-24-755-74	1	S	Kit, Valve Cover (Includes 2-3)
2	KH-24-086-32	4		Screw, Shoulder
3	KH-24-153-23-S	1	/P	O-Ring, Valve Cover
4	KH-24-445-01	1	S	Strap, Lifting
5	KH-12-755-03	4	/P	Kit, Retainer
6	KH-12-173-01	4	/P	Cap, Valve Spring
7	KH-24-089-02	4	/P	Spring, Valve
8	KH-235011	4	S	Retainer, Spring
9	KH-66-032-05	2		Seal, Valve Stem
10	KH-24-318-65-S	1	S	Head Assembly, #1 Cylinder
11	KH-24-017-01	2	/P	Valve, Intake (Std.)
	KH-24-017-02	2		Valve, Intake (.25mm)
12	KH-24-016-01	2	/P	Valve, Exhaust (Std.)
	KH-24-016-02	2		Valve, Exhaust (.25mm)
13	KH-24-755-66	1	/P	Kit, Valve Train (Includes 15,18,19)
14	KH-25-351-01	4	S	Lifter, Valve
15	KH-24-411-05	4	/P	Rod, Push
16	KH-24-041-37-S	2	S	Gasket, Cylinder Head
17	KH-24-318-66-S	1	S	Head Assembly, #2 Cylinder
18	KH-25-186-01	4	/P	Arm, Rocker
19	KH-24-599-01	4	S	Pivot, Rocker Arm
20	KH-M-0640034	4	/P	Screw, Hex Flange M6 x 1 x 34
21	KH-24-072-09-S	8		Stud, Cyl. Hd.
22	KH-24-153-23-S	1	/P	O-Ring, Valve Cover
23	KH-24-393-14	1	S	Cover, Fuel Pump Valve (Includes 24)
24	KH-25-155-02	2	/P	Connector 90°.
25	KH-24-086-34	4	/P	Screw, Shoulder
26	KH-24-227-02	1	S	Cap Assembly, Oil Fill (Includes 27)
27	KH-24-153-09	1	S	O-Ring
28	KH-24-402-03	1	/P	Reed, Breather
29	KH-12-018-01	1	S	Retainer, Breather Reed
30	KH-M-0545010	1	/P	Screw, Hex Flange M5 x 0.8 x 10
31	KH-24-050-01	1	S	Filter, Breather
32	KH-24-033-01	1	/P	Kit, Breather (Includes 34, 35)
34	KH-24-041-23	1	S	Gasket, Breather
35	KH-24-096-86-S	1	S	Cover, Breather
36	KH-M0645020	4		Screw, Hex Flange M6 x 1.0 x 20
37	KH-25-237-14-S	1	/P	Clamp, Breather
38	KH-24-326-26	1	S	Hose, Breather
39	KH-24-468-16-S	8		Washer, Flat, 8mm
40	KH-24-100-10-S	8		Nut, Hex Flange, M8 x 1.25

3235 Tractor S/N 1K010G & After
Cylinder Head, Valves And Breather KH-76524

Page 20 of 82




3235 Tractor S/N 1K010G & After
Cylinder Head, Valves And Breather KH-76524

Page 21 of 82

Ref #	Part Number	Qty	S/P/F	Description
1	KH-24-755-74	1	S	Kit, Valve Cover (Includes 2-3)
2	KH-24-086-32	4		Screw, Shoulder
3	KH-24-153-16	1	S	O-Ring, Valve Cover
4	KH-24-445-01	1	S	Strap, Lifting
5	KH-12-755-03	4	/P	Kit, Retainer
6	KH-12-173-01	4	/P	Cap, Valve Spring
7	KH-24-089-02	4	/P	Spring, Valve
8	KH-235011	4	S	Retainer, Spring
9	KH-24-032-05	2	S	Seal, Valve Stem
10	KH-24-318-68-S	1	S	Head Assembly, #1 Cylinder
11	KH-24-017-01	2	/P	Valve, Intake (Std.)
	KH-24-017-02	2		Valve, Intake (.25mm)
12	KH-24-016-01	2	/P	Valve, Exhaust (Std.)
	KH-24-016-02	2		Valve, Exhaust (.25mm)
13	KH-24-755-66	1	/P	Kit, Valve Train (Includes 15,18,19)
14	KH-25-351-01	4	S	Lifter, Valve
15	KH-24-411-05	4	/P	Rod, Push
16	KH-24-041-40-S	2	S	Gasket, Cylinder Head
17	KH-24-318-70-S	1	S	Head Assembly, #2 Cylinder
18	KH-25-186-01	4	/P	Arm, Rocker
19	KH-24-599-01	4	S	Pivot, Rocker Arm
20	KH-M-0640034	4	/P	Screw, Hex Flange M6 x 1 x 34
21	KH-24-072-09-S	8		Stud, Cyl. Hd.
22	KH-24-153-16	1	S	O-Ring, Valve Cover
23	KH-24-393-14	1	S	Cover, Fuel Pump Valve (Includes 24)
24	KH-25-155-02	2	/P	Connector 90°.
25	KH-24-086-34	4	/P	Screw, Shoulder
26	KH-24-227-02	1	S	Cap Assembly, Oil Fill (Includes 27)
27	KH-24-153-09	1	S	O-Ring
28	KH-24-402-03	1	/P	Reed, Breather
29	KH-12-018-01	1	S	Retainer, Breather Reed
30	KH-M-0545010	1	/P	Screw, Hex Flange M5 x 0.8 x 10
31	KH-24-050-01	1	S	Filter, Breather
32	KH-24-033-01	1	/P	Kit, Breather (Includes 33-35)
33	KH-25-139-60-S	1	/P	Plug, Allen Head 1/8 NPTF
34	KH-24-041-23	1	S	Gasket, Breather
35	KH-24-096-58	1		Cover, Breather
36	KH-M0645020	4		Screw, Hex Flange M6 x 1.0 x 20
37	KH-25-237-14-S	1	/P	Clamp, Breather
38	KH-24-326-26	1	S	Hose, Breather
39	KH-24-468-16-S	8		Washer, Flat, 8mm
40	KH-24-100-10-S	8		Nut, Hex Flange, M8 x 1.25

3235 Tractor S/N 1K010G & After
Dash Panel

Page 22 of 82




3235 Tractor S/N 1K010G & After
Dash Panel

Page 23 of 82

Ref #	Part Number	Qty	S/P/F	Description
1	603-0586	1		Control Assembly, Throttle/Choke
2	631-0076	1		Boot, Tilt Steer
3	631-3014A	1	/P	Dash Panel
	777I20183	1		Graphic, Monitor Light Cover
4	759-3476A	1	S	Key, Ignition (Set of 2)
5	703-3072	1	/P	Screen, Dash
6	703-3162	1		Plate, PTO Handle
7	710-0134	4	/P	Carriage Bolt, 1/4-20 x .62
8	710-0294	2		Screw, Hex Cap 1/4-20 x .375 GR5
9	710-1260A	2	/P	Screw, Hex Wash. Hd. Tapp 5/16-18 x .75
10	710-3013	3	/P	Screw, Hex Cap 1/4-20 x .50 GR5
11	712-0237	1	S	Nut, Hex Lock, 5/16-24
12	712-0397	4	S	Wing Nut, 1/4-20 w/Bell Washer
13	723-0511-37	2		Seal, Screen Cut to fit screen
14	725-1346	1	S	Nut, Ignition Switch, 5/8-32
15	725-1347	1	/P	Cap, Ignition Switch
16	725-3159	1	S	Hour Meter
17	725-3256	1	S	Switch, PTO
18	726-0233	4	/P	Nut, Push
19	731-3209	1		Steering Wheel
20	731-3210	1		Cover, Steering Wheel
21	731-3241	1		Handle, PTO Switch
22	736-04062	1	S	Washer, Flat, .34 x 1.5 x .10
23	783-0462	1	/P	Bracket, PTO Switch Retainer
24	629-3079	1	S	Harness, PTO Adapter

3235 Tractor S/N 1K010G & After
Driveshaft And Engine Connections

Page 24 of 82



3235 Tractor S/N 1K010G & After
Driveshaft And Engine Connections

Page 25 of 82

Ref #	Part Number	Qty	S/P/F	Description
1	629-3074A	1	S	Harness, Wire
1	726-0154	4	S	Tie, Pushmount
1	726-3055	2		Clip, Cable
2	651-3003	1		Muffler Assembly
3	703-2909-0716	1	/P	Plate, Engine Mounting
4	703-2999	1		Shield, Muffler Heat
5	710-0539	4	/P	Screw, Hex Cap, 3/8-24 x 1.75 GR5
6	710-0607	4	/P	Screw, Hex Wash. Hd. Tapp 5/16-18 x .5
7	710-0757	1	/P	Screw, Hex Cap, 7/16-20 x 1.5 GR5
8	710-1062	4		Screw, Hex Cap Lock 1/4-20 x 1.25 GR5
9	710-3038	6	/P	Screw, Hex Cap, 5/16-18 x .875 GR5
10	710-0237	1	/P	Screw, Hex Cap, M8 - 1.25 x 16MM GR5 (Use with KH-730104 engine)
11	710-3209	4		Screw, Hex Cap, M6 - 1.0 x 10MM
12	710-3288	4		Screw, Hex Cap, Lock 1/4-20 x 1.62 GR5
13	712-0429	6	S	Nut, Hex Insert Lock, 5/16-18
14	712-3054	4	/P	Nut, Hex Lock, 3/8-24
15	718-3093	1	S	Shaft, Drive, 27.125 Long
15	759-3765	2		Drive Barrels Kit Not shown (2 used per tractor)
16	725-3163	1	S	Switch, Key, w/Ground
17	725-3164A	1	S	Switch, Plunger (Reverse)
18	725-3166	1	S	Switch, Snap Mount (Seat)
19	726-0205	2	/P	Clamp, Hose
20	731-3166	1		Boot, Intake
21	731-3221A	1	/P	Baffle, Lower Air
22	731-3231	1	S	Baffle, Upper Air
23	736-0142	4	S	Washer, Flat, .281 x .50 x .06
24	703-3398	1		Shield, Lower Exhaust
25	736-3017	1	/P	Washer, Flat, .417 x 1.5 x .225
26	746-3075	1		Cable, Throttle Control
27	746-3077	1		Cable, Choke Control
28	750-3201	1		Spacer, Crankshaft (Use with KH-730104 engine)
29	751-0535-60	1	S	Hose, Fuel Line 60in.
30	751-3154	1		Pipe, Exhaust RH
31	751-3155	1		Pipe, Exhaust LH
32	756-3091A	2	/P	Pulley Half
33	756-3099	1		Pulley, Center
34	KH-25-072-04	4	/P	Stud, M8 - 1.25 x 33MM
35	KH-24-041-02	2	S	Gasket, Exhaust
36	712-3086	4	/P	Nut, Hex, M8 x 1.25
37	725-1365	2	S	Bulb, Indicator
38	725-3243	2		Fuse, 25 Amp
39	721-0342	1	S	Gasket, Silicone
40	725-1648	1	S	Relay
41	736-0171	1	S	Washer, Lock, 7/16
42	759-3868	1	S	Cover, Fuse Box
43	759-3869	1	S	Box, Fuse
44	710-3007	3	/P	Screw, Hex Wash. Hd. Tapp, #12-24 x .38
45	725-3191A	1	S	Switch, Plunger (Brake)
46	719-3096	1	/P	Adapter, Drive Shaft


3235 Tractor S/N 1K010G & After
Driveshaft And Engine Connections

Page 26 of 82

Ref #	Part Number	Qty	S/P/F	Description
47	KH-24-086-16	2	S	Screw, Hex Flange, M10 x 1.5 x 90
48	751-3199	1		Hose, Vacuum
49		1		Not used

3235 Tractor S/N 1K010G & After
Engine Controls KH 76524

Page 27 of 82




3235 Tractor S/N 1K010G & After
Engine Controls KH 76524

Page 28 of 82

Ref #	Part Number	Qty	S/P/F	Description
1	KH-M-0547050	1	/P	Nut, Hex Lock M5 x 0.8
2	KH-24-089-03	1		Spring, Choke Return
3	KH-M-0645016	4	S	Screw, Hex Flange M6 x 1.0 x 16
4	KH-24-126-56	1	S	Bracket, Control
5	KH-24-468-01	3		Washer, Plain 5.5 mm
6	KH-24-090-07	1	/P	Lever, Throttle Actuator
7	KH-12-237-01	2		Clamp,Cable,
8	KH-M-0545016	3	S	Screw, Hex Flange M5 x 0.8 x 16
9	KH-24-090-13	1		Lever, Throttle Control
10	KH-M-0446030	1	S	Nut, Hex M4 x 0.7.
11	KH-M-0401030	1	S	Screw, Hex Cap M4 x 0.7 x 30
12	KH-24-079-02	1	S	Linkage,Choke
13	KH-24-090-05	1		Lever, Choke
14	KH-41-468-03	1		Washer, Spring 1/4"
15	KH-M-0545020	1	/P	Screw, Hex Flange M5 x 0.8 x 20
16	KH-24-089-51-S	1	/P	Spring, Throttle Limiter
17	KH-24-089-46-S	1		Spring, Governor
18	KH-24-211-03-S	1		Screw, Carriage
19	KH-24-090-33-S	1	S	Lever, Governor
20	KH-M-0641060	1	S	Nut, Hex Flange M6 x 1.0"
21	KH-24-089-01	1		Spring, Linkage
22	KH-25-158-08	1	/P	Bushing, Linkage Retaining
23	KH-24-079-01	1		Linkage, Throttle
24	KH-25-158-11	1	/P	Bushing, Linkage Retaining
25	KH-24-126-04	2	S	Bracket Support

3235 Tractor S/N 1K010G & After
Engine Controls KH-730104

Page 29 of 82




3235 Tractor S/N 1K010G & After
Engine Controls KH-730104

Page 30 of 82

Ref #	Part Number	Qty	S/P/F	Description
1	KH-M-0547050	1	/P	Nut, Hex Lock M5 x 0.8
2	KH-24-089-03	1		Spring, Choke Return
3	KH-M-645016-S	4	/P	Screw, Hex Flange M6 x 1.0 x 16
4	KH-24-126-56	1	S	Bracket, Control
5	KH-24-468-01	3		Washer , Plain 5.5mm
6	KH-24-090-07	1	/P	Lever, Throttle Actuator
7	KH-12-237-01	2		Clamp, Cable
8	KH-M-545016-S	3	/P	Screw, Hex Flange M5 x 0.8 x 16
9	KH-24-090-13	1		Lever, Throttle Control
10	KH-M-446030-S	1	/P	Nut, Hex M4 x 0.7
11	KH-M-401030-S	1		Screw, Hex Cap M4 x 0.7 x30
12	KH-24-079-21-S	1	/P	Linkage, Choke
13	KH-24-090-05	1		Lever, Choke
14	KH-41-468-03	1		Washer, Spring 1/4"
15	KH-M-0545020	1	/P	Screw, Hex Flange M5 x 0,.8 x 20
16	KH-24-089-51-S	1	/P	Spring, Throttle Limiter
17	KH-24-089-48-S	1		Spring, Governor
18	KH-24-211-03-S	1		Screw, Round Hd. Square Neck
19	KH-24-090-33-S	1	S	Lever, Governor
20	KH-M-0641060	1	S	Nut, Hex Flange M6 x 1.0
21	KH-24-089-01	1		Spring, Linkage
22	KH-25-158-08	1	/P	Bushing, Linkage Retaining
23	KH-24-079-01	1		Linkage, Throttle
24	KH-25-158-11	1	/P	Bushing, Linkage Retaining
25	KH-X-20-1-S	1		Washer
26	KH-M-541050-S	1		Nut, Hex

3235 Tractor S/N 1K010G & After
Fender And Running Board


Page 31 of 82



3235 Tractor S/N 1K010G & After
Fender And Running Board

Page 32 of 82

Ref #	Part Number	Qty	S/P/F	Description
1	625-0023A	1	S	Light Assembly, Rear RH
	725-3262	1	S	Bulb Only, Tail Light
	725-3263	1	S	Bulb Only, Reverse Indicator Light
	629-3059	1		Harness, Tail Light
2	625-0024A	1	S	Light Assembly, Rear LH
	725-3262	1	S	Bulb Only, Tail Light
	725-3263	1	S	Bulb Only, Reverse Indicator Light
	629-3059	1		Harness, Tail Light
3	703-3622-0716	1		Running Board
	777D04383	2		Graphic, All Shaft Drive
	777I20860	1		Graphic, Starting Instructions
	777I20859	1		Graphic, Height Adjustment
	777S30017	1		Graphic, Warning
4	703-2978-0716	1	/P	Fender
	777D04715	1	S	Graphic, 3000 Series
5	710-0602	4	/P	Screw, Hex Wash. Hd. Tapp 5/16-18 x 1.0
6	710-3013	14	/P	Screw, Hex Cap, 1/4-20 x .5 GR5
7	712-0324	6	/P	Nut, Hex Lock, 1/4-20
8	726-3057	4	S	Clip, Tail Light
9	731-3239	1		Cover, Lift Lever
10	731-3253	1		Flap, Lift Lever
11	735-0275	1		Pad. Floor LH
12	735-0276	1		Pad. Floor RH





3235 Tractor S/N 1K010G & After
Frame And Hitch Plate

Page 34 of 82

Ref #	Part Number	Qty	S/P/F	Description
1	603-0446B-0716	1	/P	Frame Assembly
2	603-0463A-0716	1	S	Bumper, Front
	777D00585	1		Graphic
3	703-3546-0716	1		Hitch Plate
	777I20773	1		Graphic, Trans. Release
	777S30265	1		Graphic, Trans. Oil
4	710-0623	4	/P	Screw, Hex Wash. Hd. Tapp 3/8-16 x .75
5	710-0599	3	/P	Screw, Hex Wash. Hd. Tapp 1/4-20 x .5
6	710-0617	2		Screw, Round Hd., 3/8-24
7	710-3131	2	/P	Screw, Hex Cap 1/2-13 x 1.0 GR5
8	710-1260A	4	/P	Screw, Hex Wash. Hd. Tapp 5/16-18 x .75
9	712-3027	2	S	Nut, Hex Flange Lock, 1/4-20
10	712-3083	2	/P	Nut, Hex Lock, 1/2-13
11	726-0211	8	S	Speed Nut, U-Type, 5/16-18
12	732-3002	1	S	Spring, Extension
13	735-0653	1		Flap, Intk.
14	736-0342	3		Washer, Flat, .283 x .75 x .030
15	738-0704	2	S	Shoulder Screw, .312 x .18
16	747-3336	1		Rod, Front Latch
17	710-3038	2	/P	Screw, Hex Cap, 5/16-18 x .875 August 25, 2002 and prior
17	710-3015	2	/P	Screw, Hex Cap, 1/4-20 x .75 GR5 August 26, 2002 & after
18	711-1333	1		Shaft, Frame Brace August 25, 2002 and prior
18	647-04010	1		Shaft, tank constraint August 26, 2002 & after
19	736-3008	2	S	Washer, Flat, .344 x .75 x .12 August 25, 2002 and prior
19	736-0329	2	S	Washer, lock, 1/4 August 26, 2002 & after
20	703-3417-0716	1		Bracket, Running Board LH
21	703-3418-0716	1		Bracket, Running Board RH

3235 Tractor S/N 1K010G & After
Front Axle

Page 35 of 82




3235 Tractor S/N 1K010G & After
Front Axle

Page 36 of 82

Ref #	Part Number	Qty	S/P/F	Description
1	603-0426-0637	1	S	Axle, RH Steering
2	603-0427-0637	1	S	Axle, LH Steering
3	710-1039	1	/P	Screw, Hex Cap 3/8-24 x 1.0 GR8
4	710-3085	1	/P	Screw, Hex Cap 3/8-16 x 3.5 GR5
5	711-1141	1		Shaft, Splined
6	712-0355	2	S	Nut, Hex Center Lock, 3/8-24
7	712-0431	1	S	Nut, Hex Flange Lock, 3/8-16
8	712-3103	2		Nut, Hex Flange Lock, M12 x 1.75
9	712-3104	1		Nut, Hex - RH, M12 x 1.75
10	712-3105	1		Nut, Hex - LH, M12 x 1.75
11	716-0102	2	S	Snap Ring, 1.0 Dia. Shaft
12	716-0188	1	/P	Retaining Ring, Internal, 2.0
13	719-3119A	1	/P	Pivot Axle
14	719-3120	1		Axle Carrier
15	721-0462	1	/P	Seal, Grease, 1.31 x 1.0
16	723-0462	1		Ball Joint, 12MM x 1.75 RH
17	723-0463	1		Ball Joint, 12MM x 1.75 LH
18	736-0163	2	S	Washer, Flat, 1.03 x 1.62 x .030
19	736-0247	1	/P	Washer, Flat, .406 x 1.25
20	737-3000	3	S	Fitting, Lube, 3/16 Drive
21	741-0131	1	S	Bearing, Ball
22	741-0363	1	S	Bearing, Needle
23	741-0558	4	S	Bearing, Flange
24	747-3348A	1	/P	Tie Rod, M12 x 1.75 RH & LH
25	748-3074	1		Steering Arm

3235 Tractor S/N 1K010G & After
Front PTO


Page 37 of 82



3235 Tractor S/N 1K010G & After
Front PTO

Page 38 of 82

Ref #	Part Number	Qty	S/P/F	Description
1	603-0442-0637	1	/P	Bracket, Idler
2	759-3867	1	/P	Bracket Assembly, Brake
3	703-3009-0637	1	/P	Bracket, PTO Mounting
4	703-3165-0637	1	/P	Belt Guide
5	703-3812-0716	1		Bracket, Solenoid Mounting
6	710-0237	2	/P	Screw, Hex Cap 5/16-24 x .625 GR5
7	710-0514	2	/P	Screw, Hex Cap 3/8-16 x 1.0 GR5
8	710-0520	1	/P	Screw, Hex Cap 3/8-16 x 1.5 GR5
9	710-0623	2	/P	Screw, Hex Wash. Hd. Tapp 3/8-16 x .75
10	710-0748	2	/P	Screw, Phil. Hd. Tapp #12-14 x .5
11	711-1196	1		Ferrule, Brake Adjustment
12	712-0324	1	/P	Nut, Hex Insert Lock, 1/4-20
13	712-0431	7	S	Nut, Flange Lock, 3/8-16
14	714-0104	2	S	Pin, Internal Cotter
15	716-0102	1	S	Snap Ring, 1.0 Dia Shaft
16	759-04258	1	/P	Solenoid, Kit Vacuum Actuator Replaces 725-3278
17	732-0470A	1	S	Spring, Extension, .530 x 4.74
18	738-0213	2	/P	Shoulder Screw, .498 x 1.45
19	738-3056	2	S	Shoulder Screw
20	741-0491	4		Bearing, Nylon Flange
21	747-3322	1		Rod, PTO Brake
22	750-0526	2		Spacer, .380 x .5 x .265
23	751-3173	1	S	Vacuum Actuator
24	754-3084	1	S	V-Belt, A-Section x 37.63 (Set of two belts)
25	756-3092	1		Pulley, PTO Drive. 6.75-Double
26	756-3094	1		Pulley, Flat Idler, 4.0




3235 Tractor S/N 1K010G & After
Front Wheels

Page 40 of 82

Ref #	Part Number	Qty	S/P/F	Description
1	734-3053-0499	2	S	Rim Assembly, Wheel
2	734-3193	2	S	Tire, Turf, 16 x 7.5 x 8.0
3	737-0224	2		Lube Fitting
4	741-3002	4	S	Bearing, Ball
5	710-3126	2	/P	Screw, Hex Cap, 1/2-13 x 1.0 GR5
6	731-3020	2	S	Hubcap
7	734-0255	2	S	Valve, Tubeless Air
8	736-0179	2	S	Washer, Flat, .531 x 1.25 x .1
9	736-3095	2	S	Washer, Flat, .535 x 1.92 x .060

3235 Tractor S/N 1K010G & After
Fuel System KH-730104

Page 41 of 82




3235 Tractor S/N 1K010G & After
Fuel System KH-730104

Page 42 of 82

Ref #	Part Number	Qty	S/P/F	Description
1	KH-52-353-20	2	S	Line, Fuel 10"
2	KH-25-237-14-S	4	/P	Clamp, Hose
3	KH-24-853-91-S	1		Kit, Carburetor w/Gasket (Includes 4-6)
4	KH-24-041-52-S	1	/P	Gasket, Carburetor
5		1		Carburetor Assembly Not available separately
6	KH-24-041-06	1	/P	Gasket, Air Cleaner Base
7	KH-M-651025-S	25		Screw, Hex Flange, M6 x 1.0 x 2
8	KH-24-050-02	1	S	Filter, Fuel
9	KH-24-353-12	1		Line, Fuel 11"
	KH-24-518-24-S	1		Lead, Ground Not Illustrated
	KH-24-757-01	1	/P	Kit, Solenoid Includes Solenoid Screw [qty. 2], O-Ring, O-Ring, O-Ring , Solenoid Assembly & Solenoid Seat.; Not Illustrated
	KH-24-757-02	1	S	Kit, Float Repair - Includes Carburetor Body Gasket, Float Screw, Float Assembly and Float Shaft.; Not Illustrated
	KH-24-757-03	1	S	Kit, Carburetor Repair - Includes Carburetor Gasket; Carburetor Body Screw; Idle Needle Spring; U-Ring; Slow Jet O-Ring; Main Jet Screw O-Ring; Solenoid O-Rings; Inlet Needle Valve Clip; Idle Needle and Inlet Needle Valve.; Not Illustrated
	KH-24-757-07	1		Kit, Choke Repair - Includes Choke Plate Screws; Choke Spring; Choke Lever; Choke Shaft; Choke Plate; Choke Bushings; and Choke Lever Cap.; Not Illustrated
	KH-24-757-08-S	1		Kit, Repair, (accelerator pump diaphragm) Not Illustrated
	KH-24-757-09-S	1		Kit, Repair, (accelerator pump seal & bushing) Not Illustrated

3235 Tractor S/N 1K010G & After
Fuel System KH-76524

Page 43 of 82




3235 Tractor S/N 1K010G & After
Fuel System KH-76524

Page 44 of 82

Ref #	Part Number	Qty	S/P/F	Description
1	KH-52-353-20	2	S	Line, Fuel 10"
2	KH-25-237-14-S	4	/P	Clamp, Hose
3	KH-24-853-59-S	1	/P	Kit, Carburetor w/Gasket (Includes 4-6)
4	KH-24-041-17	1	/P	Gasket, Carburetor
5		1		Carburetor Assembly Not available separately
6	KH-24-041-06	1	/P	Gasket, Air Cleaner Base
7	KH-M-0651030	2	/P	Screw, Hex Flange
8	KH-24-050-02	1	S	Filter, Fuel
9	KH-24-353-12	1		Line, Fuel 11"
	KH-24-757-01	1	/P	Kit, Solenoid Not Illustrated; Includes Solenoid Screw [qty. 2], O-Ring, O-Ring, O-Ring, Solenoid Assembly & Solenoid Seat.
	KH-24-757-02	1	S	Kit, Float Repair Not Illustrated; Includes Carburetor Body Gasket, Float Screw, Float Assembly and Float Shaft.
	KH-24-757-03	1	S	Kit, Carburetor Repair Not Illustrated; Includes Carburetor Gasket; Carburetor Body Screw; Idle Needle Spring; U-Ring; Slow Jet O-Ring; Main Jet Screw O-Ring; Solenoid O-Rings; Inlet Needle Valve Clip; Idle Needle and Inlet Needle Valve.
	KH-24-757-07	1		Kit, Choke Repair Not Illustrated; Includes Choke Plate Screws; Choke Spring; Choke Lever; Choke Shaft; Choke Plate; Choke Bushings; and Choke Lever Cap.

3235 Tractor S/N 1K010G & After
Fuel Tank

Page 45 of 82




3235 Tractor S/N 1K010G & After
Fuel Tank

Page 46 of 82

Ref #	Part Number	Qty	S/P/F	Description
1	726-0205	2	/P	Clamp, Hose
2	731-3268	1		Trim, Tank Protector
3	735-0149	1	S	Bushing, Rubber
4	751-0535-60	60in.	S	Fuel Line
5	751-3124B	1	S	Cap, Fuel
6	751-3144A	1	S	Tank, Fuel, 4.5 Gallon
7	751-3161	1		Sensor, Low Fuel
	751-3146	1	S	Grommet
8	751-3162A	1	/P	Fitting, Fuel Pickup

3235 Tractor S/N 1K010G & After Hood, Grille And Side Panels With Hood Latch

Page 47 of 82




3235 Tractor S/N 1K010G & After
Hood, Grille And Side Panels With Hood Latch

Page 48 of 82

Ref #	Part Number	Qty	S/P/F	Description
1	625-04001	1	S	Headlight Assembly
	725-0963	2	S	Bulb, Headlight
	725-1649	2	S	Socket Assembly, Headlight
2	703-05000A-0499	1	/P	Hood
3	703-2946-0499	1		Side Panel, RH
4	703-2947-0499	1		Side Panel, LH
5	703-2950-0499	1		Grille, Series 3000
	777I20314	1	/P	Graphic, Warning
6	703-2984-0716	1		Support, Grille - RH
7	703-2985-0716	1		Support, Grille - LH
8	703-3070B-0499	1	/P	Bracket, Upper Hood
	777S30538	1		Graphic, Hot Surface
9	703-3071	2		Bracket, Rod Retainer
10	703-3101B-0716	1	/P	Support, Hood
11	710-0351	8	/P	Screw, Truss Hd, Tapp, #10-16 x .5
12	710-0607	10	/P	Screw, Hex Wash. Hd. Tapp 5/16-18 x .5
13	710-0924	4	/P	Screw, Phil. Pan Hd. 1/4-20 x .75
14	726-3054	4		Nut, U Type Speed, 1/4-20
15	726-0139	2	/P	Nut, U-type Speed, #10
16	726-3056	4		Latch, 1/4 Turn
17	731-3227	1		Mount, Side Panel/Grille RH
18	731-3228	1		Mount, Side Panel/Grille LH
19	732-0936	4		Clip, Spring
20	732-0937	4		Spring, Compression
21	732-1178	1		Spring, Hood Latch
22	736-0400	2	S	Washer, Flat, .194 x .62 x .063
23	747-3478	1		Rod, Upper Hood
24	747-3338	1		Rod, Lower Hood
25	777D03265	1	/P	Graphic, Hood - RH
	777D03266	1	/P	Graphic, Hood - LH
26	777D03276	2		Graphic, 3235
27	703-4088-0716	2		Bracket, Hood Latch Support
28	710-0136	1	/P	Screw, Hex Cap, 1/4-20 x 1.75 GR5
29	710-0599	2	/P	Screw, Hex Wash Hd Tapp, 1/4-20 x .5
30	710-1005	4	S	Screw, Hex Wash Hd Tapp, 1/4-14 x .5
31	712-3051	1	/P	Nut, Hex Top Lock, 1/4-20
32	731-3232	1		Roller, Hood Latch
33	736-0342	1		Washer, Flat, .283 x .75 x .030
34	747-04085	1		Rod, Hood Support
35	728-0117	4		Rivet, Pop, .125 OD

3235 Tractor S/N 1K010G & After
Hood, Grille And Side Panels Without Hood Latch


Page 49 of 82



3235 Tractor S/N 1K010G & After
Hood, Grille And Side Panels Without Hood Latch

Page 50 of 82

Ref #	Part Number	Qty	S/P/F	Description
1	625-0053	1	S	Headlight Assembly (Lens glued to reflector)
	725-0963	2	S	Bulb, Headlight
	725-1649	2	S	Socket Assembly, Headlight
2	759-3865-0499	1		Hood w/Support Rod Assembly
3	703-2946-0499	1		Side Panel, RH
4	703-2947-0499	1		Side Panel, LH
5	703-2950-0499	1		Grille, Series 3000
	777I20314	1	/P	Graphic, Warning
6	703-2984-0716	1		Support, Grille - RH
7	703-2985-0716	1		Support, Grille - LH
8	703-3070A-0499	1	S	Bracket, Upper Hood
	777S30538	1		Graphic, Warning Hot Surface
9	703-3071	2		Bracket, Rod Retainer
10	703-3101A-0716	1	S	Support, Hood
11	710-0351	8	/P	Screw, Truss Hd, Tapp, #10-16 x .5
12	710-0607	10	/P	Screw, Hex Wash. Hd. Tapp 5/16-18 x .5
13	710-0924	4	/P	Screw, Phil. Pan Hd. 1/4-20 x .75
14	726-3054	4		Nut, U Type Speed, 1/4-20
15	726-0139	2	/P	Nut, U-type Speed, #10
16	726-3056	4		Latch, 1/4 Turn
17	731-3227	1		Mount, Side Panel/Grille RH
18	731-3228	1		Mount, Side Panel/Grille LH
19	732-0936	4		Clip, Spring
20	732-0937	4		Spring, Compression
21	732-1153	1		Spring, Extension
22	736-0400	2	S	Washer, Flat, .194 x .62 x .063
23	747-3337A	1	/P	Rod, Upper Hood
24	747-3338	1		Rod, Lower Hood
25	777D03265	1	/P	Graphic, Hood - RH
	777D03266	1	/P	Graphic, Hood - LH
26	777D03276	2		Graphic, 3235




3235 Tractor S/N 1K010G & After
Hydraulic Steering Pump

Page 52 of 82

Ref #	Part Number	Qty	S/P/F	Description
1	ET-14543-002	1		Screw, Hex Cap, 1.57" Lg.
2	ET-64455-000	1		Seal Kit (Includes All Parts Marked Ref. 2
3	ET-22991-003	1	S	Gerotor Assembly
4	ET-22919-005	1		Spacer, .240 Lg.
5	ET-22918-000	1		Drive
6	ET-9199-000	1		Plug, Manual Check
7	ET-285020-140	1		Ball, Manual Check
8	ET-64457-000	1		Bearing Kit
9	ET-64456-000	1		Spring Kit, Centering
10	~N/A	1		Spool, Sleeve and Housing Not Available as Replacement Parts. Order Complete Steering Pump

3235 Tractor S/N 1K010G & After
Hydraulic Valve And Lines


Page 53 of 82



3235 Tractor S/N 1K010G & After
Hydraulic Valve And Lines

Page 54 of 82

Ref #	Part Number	Qty	S/P/F	Description
1	703-1801	2		Bracket, Valve Mounting
2	703-1802	2		Clamp, Side Valve
3	703-1803	2	S	Clamp, Double Valve
4	703-3154	1	S	Bracket, Lift Valve
5	710-0597	2	/P	Screw, Hex Cap 1/4-20 x 1.0 GR5
6	710-0641	2	/P	Screw, Hex Cap 1/4-20 x 2.25 GR5
7	710-3013	5	/P	Screw, Hex Cap 1/4-20 x .50 GR5
8	710-3083	1	/P	Screw, Hex Cap 5/16-18 x 1.375 GR5
9	712-0429	1	S	Nut, Hex Insert Lock, 5/16-18
10	712-3027	4	S	Nut, Hex Flange Lock, 1/4-20
11	717-3452	1		Valve, Hydraulic
12	721-0492	4		O-Ring, Backup
13	721-3021	6	S	O-Ring
14	726-0197	3		Cable Tie
15	727-3056	1		T-Fitting, 9/16-18 Thrd.
16	727-3130	1		Tube, Hydraulic (Pump to Strng)
17	727-3131	1		Tube, Hydraulic (Aux. from Strng)
18	727-3162	1		Tube, Hydraulic (Strng Return)
19	727-3160	1		Tube, Hydraulic (Aux Return)
20	727-3161	1	/P	Tube, Hydraulic (Return to Pump)
21	731-3259	1		Knob, Lift
22	735-3007	3	S	Rubber Spacer
23	741-0491	2		Bearing, Nylon Flange
24	747-3349A	1	/P	Handle, Center Lift Valve
25	748-3081A	1	/P	Link, Lift
26	748-3082	1		Clamp, Handle
27	721-0493	3		O-Ring, .426 x .566 x .070
28	710-0751	1	/P	Screw, Hex Cap 1/4-20 x .62 GR5




3235 Tractor S/N 1K010G & After
Hydrostatic Transmission

Page 56 of 82

Ref #	Part Number	Qty	S/P/F	Description
1	HG-51206	1	/P	Shaft, Pump
2	HG-2000022	4	/P	Ring, Wire Retaining
3	HG-2000038	1	/P	Ring, Retaining
4	HG-2000023	1	/P	Spacer
5	HG-2000032	1	/P	Bearing, Ball
6	HG-2000036	1	S	Seal, Lip
7	HG-2000037	1	/P	Seal, Lip
8	HG-2000014	1	/P	Arm, Trunnion
9	HG-2000015	1	/P	Guide, Slot
10	HG-2510097	1		Housing Assembly
11	HG-50552	2	/P	Bearing Assembly, Thrust Ball
12	HG-2000024	2	/P	Washer, Block Thrust
13	HG-2000025	2	/P	Spring, Block
14	HG-2510014	1	/P	Kit, Pump Cylinder Block
15	HG-2000007	1	/P	Shaft, Motor
16	~N/A	1		Not Used In This Application
17	HG-2510098	1	/P	Kit, Center Section
18	HG-50641	2		Pin
19	HG-2000061	1	/P	Gasket, Center Section
20	HG-50203	1		Swashplate, Variable
21	HG-2510013	1	/P	Kit, Motor Cylinder Block
22	HG-9004100-1430	2	/P	O-Ring
23	HG-2510083	1	S	Kit, Auxiliary Charge Pump
24	HG-50761	1	/P	Gerotor & Housing Assembly
25	HG-2510050	1	/P	Kit, Check Valve
26	HG-2510034	1	/P	Kit, Check Valve w/ .044 Orifice
27	HG-2510081	1		Kit, Check Relief
28	HG-2510082	1		Kit, Auxiliary Relief Valve
29	HG-2510012	1	/P	Kit, Bypass Valve
30	HG-9005110-4400	2		Plug, 7/16-20
31	HG-2510090	1	/P	Kit, Auxiliary Filter
32	HG-50969	2		Screw, Flange Head Cap, M8 x 60
33	HG-9007314-0808	8	/P	Screw, Socket Head Cap
34	HG-9005110-3100	1		Plug, 5/16-24
35	HG-50994	1	S	Cover, Filter
36	HG-50408	2	/P	Pin
37	HG-2000044	1	/P	Shim, Charge Pump
38	~N/A	1		O-Ring Order Seal Kit P/N HG-2510010
39	~N/A	1		O-Ring Order Seal Kit P/N HG-2510010
40	~N/A	1		O-Ring Order Seal Kit P/N HG-2510010
	HG-2510010	1	/P	Kit, Overhaul Seal (Includes Ref. Nos. 2, 3, 4, 6, 7, 19, 22, 38, 39 & 40)

3235 Tractor S/N 1K010G & After
Ignition/Electrical KH-730104

Page 57 of 82




3235 Tractor S/N 1K010G & After
Ignition/Electrical KH-730104

Page 58 of 82

Ref #	Part Number	Qty	S/P/F	Description
1	KH-54-755-09	1	S	Kit, 15 Amp Stator (Incl. KH-24-126-71 Stator Bracket, Not Shown)
2	KH-M-0548025	2		Screw, Hex Cap M5 x 0.8 x 25
3	KH-24-584-01	2	S	Module, Ignition
4	KH-M-0545020	4	/P	Screw, Hex Socket Hd. M5 x 0.8 x
5	KH-24-025-01-S	1		Flywheel
9	KH-X-42-15	1	/P	Key
10	KH-12-468-03	1	/P	Washer, Plain 3/8"
11	KH-12-086-14	1		Screw, Hex Flange M10 x 1.5 x 46
12	KH-24-157-07-S	1	S	Fan
13	719-3096	1	/P	Adapter, Drive Shaft
14	KH-24-086-16	2	S	Screw, Hex Flange M10 x 1.5 x 90
16	KH-25-086-47	4	/P	Bolt, Shoulder, M6 x 1.0 x 16
17	KH-54-755-15	1	/P	Kit, Grass Screen (Includes Ref. Nos. 18-20)
18	KH-24-112-04	4		Spacer
19	KH-X-25-92	4		Washer, Plain 3/16"
20	KH-M-0403025	4		Screw, Hex Cap M4 x 0.7 x 25
21	KH-24-086-18	2		Screw, Phillips Hd. 11-16 x 7/8"
22	KH-X-25-92	2		Washer, Plain 3/16"
23	KH-25-403-03	1	S	Rectifier-regulator 15 Amp
24	KH-236602	1	S	Connector (3 Contact)
25	759-3336	2	/P	Spark Plug
26	KH-235173	1		Clip, Cable
27	KH-X-25-63	1	/P	Washer, Plain 1/4"
28	KH-48-154-02	2		Clip, Cable
	KH-24-176-08	1	S	Harness, Wire
	KH-24-518-12-S	1	/P	Lead
	KH-X-22-11	1		Washer, Lock, 1/4
	KH-25-086-91-S	2	/P	Screw, Tapping, #10-16 x .5
	KH-24-454-03-S	1		Tie, Wire

3235 Tractor S/N 1K010G & After
Ignition/Electrical KH-76524

Page 59 of 82




3235 Tractor S/N 1K010G & After
Ignition/Electrical KH-76524

Page 60 of 82

Ref #	Part Number	Qty	S/P/F	Description
1	KH-54-755-09	1	S	Kit, 15 Amp Stator (Incl. P/N KH-24-126-71 Stator Bracket,
2	KH-M-0548025	2		Screw, Hex Cap M5 x 0.8 x 25
3	KH-24-584-01	2	S	Module, Ignition
4	KH-M-0545020	4	/P	Screw, Hex Socket Hd. M5 x 0.8 x
5	KH-24-025-04	1	S	Flywheel
9	KH-X-42-15	1	/P	Key
10	KH-12-468-03	1	/P	Washer, Plain 3/8"
11	KH-12-086-14	1		Screw, Hex Flange M10 x 1.5 x 46
12	KH-24-157-03	1	S	Fan
13	719-3096	1	/P	Adapter, Drive Shaft
14	KH-24-086-16	2	S	Screw, Hex Flange M10 x 1.5 x 90
16	KH-25-086-47	4	/P	Bolt, Shoulder, M6 x 1.0 x 16
17	KH-54-755-15	1	/P	Kit, Grass Screen (Incl. 18-20 and P/N KH-24-113-18)
18	KH-24-112-04	4		Spacer
19	KH-X-25-92	4		Washer, Plain 3/16"
20	KH-M-0403025	4		Screw, Hex Cap M4 x 0.7 x 25
21	KH-24-086-18	2		Screw, Phillips Hd. 11-16 x 7/8"
22	KH-X-25-92	4		Washer, Plain 3/16"
23	KH-25-403-03	1	S	Rectifier-regulator 15 Amp
24	KH-236602	1	S	Connector (3 Contact)
25	759-3336	2	/P	Spark Plug
26	KH-235173	2		Clip, Cable
27	KH-X-25-63	1	/P	Washer, Plain 1/4"
28	KH-48-154-02	1		Clip, Cable
	KH-24-176-08	1	S	Harness, Wire
	KH-24-518-12-S	1	/P	Lead
	KH-X-22-11	1		Washer, Lock, 1/4
	KH-25-086-91-S	2	/P	Screw, Tapping, #10-16 x .5
	KH-47-154-01-S	1	/P	Clip, Cable

3235 Tractor S/N 1K010G & After
Lower Power Steering

Page 61 of 82




3235 Tractor S/N 1K010G & After
Lower Power Steering

Page 62 of 82

Ref #	Part Number	Qty	S/P/F	Description
1	703-3015-0716	1		Plate, Steering Pump Port
2	703-3189-0716	1	/P	Bracket, Cylinder Mounting
3	710-0514	2	/P	Screw, Hex Cap 3/8-16 x 1.0 GR5
4	710-3138	2	/P	Screw, Hex Cap M8-1.25 x 16MM GR5
5	710-3140	4		Screw, Hex Cap, M6 x 14MM
6	712-0431	2	S	Nut, Hex Flange Lock, 3/8-16
7	712-3103	2		Nut, Hex Flange Lock, M12 x 1.75
8	712-3104	2		Nut, Hex, M12 x 1.75 RH
9	717-3424	1		Cylinder, Steering
10	717-3442	1	S	Pump, Hydraulic Steering
11	723-0462	2		Ball Joint, 12MM x 1.75 RH
12	727-3012	1	/P	Fitting, 90 Degree Elbow
13	727-3126	1		Hose, Front Steering
14	727-3127	1		Hose, Rear Steering
15	727-3159	1		Fitting, 45 Degree
16	736-3084	1	/P	Washer, Flat, .51 x 1.12 x .060
17	721-0493	2		O-Ring, .426 x .566 x .070
18	736-0329	4	S	Washer, Lock, 1/4"

3235 Tractor S/N 1K010G & After
Oil Pan/Lubrication KH 730104

Page 63 of 82




3235 Tractor S/N 1K010G & After
Oil Pan/Lubrication KH 730104

Page 64 of 82

Ref #	Part Number	Qty	S/P/F	Description
1	KH-54-009-07	1		Plate, Closure Assembly (Includes 2-12, 17)
2	KH-24-038-10-S	1	/P	Dipstick
3	KH-24-755-121-S	1	/P	Tube, Dipstick (Includes 2)
4	KH-24-043-12	1	/P	Kit, Governor Gear (Includes 5)
5	KH-12-380-01	1	/P	Pin, Governor Regulating
6	KH-52-448-02	1	S	Tab, Locking
7	KH-12-144-02	1		Shaft, Governor Gear
8	KH-52-032-08	1	S	Seal, Oil (PTO End)
9	KH-24-153-08	1		O-Ring
10	KH-24-393-37-S	1	S	Oil Pump Assembly (Includes 11,12)
11	KH-24-153-01	1	/P	O-Ring, Oil Pick-Up
12	KH-24-381-04	1		Pick-Up, Oil
13	KH-M-0631005	2	S	Washer, Plain
14	KH-M-0645025	2	S	Screw, Hex Flange M6 x 1 x 25
15	KH-12-050-08	1	S	Filter, Oil
16	KH-24-136-05-S	1		Nipple, Oil Filter
17	KH-25-139-60-S	2	/P	Plug, Pipe 1/8"
18	KH-24-086-16	9	S	Screw, Hex Flange M8 x 1.25 x 45
19	KH-25-099-24	1	S	Switch, Pressure
20	KH-24-086-17	1	S	Screw, Hex Flange M8 x 1.25 x 45
21	KH-24-594-24-S	1		Cooler, Oil
22	KH-24-380-13-S	1	S	Pin, Locating
23	KH-24-041-29-S	1		Gasket, Adapter

3235 Tractor S/N 1K010G & After
Oil Pan/Lubrication KH-76524

Page 65 of 82




3235 Tractor S/N 1K010G & After
Oil Pan/Lubrication KH-76524

Page 66 of 82

Ref #	Part Number	Qty	S/P/F	Description
1	KH-54-009-07	1		Plate, Closure Assembly (Includes 2-12, 17)
2	KH-24-038-10-S	1	/P	Dipstick
3	KH-24-755-121-S	1	/P	Tube, Dipstick (Includes 2)
4	KH-24-043-12	1	/P	Kit, Governor Gear (Includes 5)
5	KH-12-380-01	1	/P	Pin, Governor Regulating
6	KH-52-448-02	1	S	Tab, Locking
7	KH-12-144-02	1		Shaft, Governor Gear
8	KH-52-032-08	1	S	Seal, Oil (PTO End)
9	KH-24-153-08	1		O-Ring
10	KH-24-393-10	1	S	Oil Pump Assembly (Includes 11,12)
11	KH-24-153-01	1	/P	O-Ring, Oil Pick-Up
12	KH-24-381-04	1		Pick-Up, Oil
13	KH-M-0631005	2	S	Washer, Plain
14	KH-M-0645025	2	S	Screw, Hex Flange M6 x 1 x 25
15	KH-12-050-08	1	S	Filter, Oil
16	KH-24-136-01	1		Nipple, Oil Filter
17	KH-25-139-60-S	2	/P	Plug, Pipe 1/8"
18	KH-24-086-16	9	S	Screw, Hex Flange M8 x 1.25 x 45
19	KH-25-099-24	1	S	Switch, Pressure
20	KH-24-086-17	1	S	Screw, Hex Flange M8 x 1.25 x 45

3235 Tractor S/N 1K010G & After
Pedestal And Connections


Page 67 of 82



3235 Tractor S/N 1K010G & After
Pedestal And Connections

Page 68 of 82


Ref #	Part Number	Qty	S/P/F	Description
1	603-0386A-0637	1	/P	Pedestal Assembly
2	603-0587	1		Handle, Tilt
	777I20861	1		Graphic, Tilt Steering Handle
3	710-0136	4	/P	Screw, Hex Cap 1/4-20 x 1.75 GR5
4	710-0597	2	/P	Screw, Hex Cap 1/4-20 x 1.0 GR5
5	710-1260A	6	/P	Screw, Hex Wash. Hd. Tapp 5/16-18 x .75
6	711-1180	1		Shaft, Lower Steering
7	712-0324	6	/P	Nut, Hex Insert Lock, 1/4-20
8	714-0104	2	S	Pin, Internal Cotter
9	716-0115	1	S	Ring, Retaining, .56 Dia Shaft
10	723-0467	1		Strap, Battery (Includes Ref No. 14)
11	725-3255	1	S	Battery
12	731-3225	1		Lever, Park Brake
13	731-3226	1		Lever, Cruise
14	732-0696	2		Hook, Wire Rectangular
15	732-0870	1	S	Spring, Compression, .676 x 2.57
16	732-0932	2		Spring, Extension
17	735-0258	1		Boot, Tilt Wheel Coupling
18	735-0269	1		Boot, Shaft Cover
19	736-3020	2	S	Washer, Flat, .271 x .63 x .065
20	738-3164	1		Shaft, Upper Steering
21	741-3085	1		Bearing, Sleeve, 1.44 x 1.5 x .812
22	747-3327	1		Rod, Cruise Control
23	747-3328	1		Rod, Parking Brake
24	747-3354	1		Rod, Cruise/Brake Pivot
25	748-3067	1		Housing, Tilt Wheel Coupling
26	748-3068	1		Coupling Half, Bottom
27	748-3069	1		Coupling Half, Top
28	748-3083	1		Index, Tilt Steering
29	748-3084A	1	/P	Block, Tilt Steering
30	736-0275	2	S	Washer, Flat, .344 x .688 x .065



3235 Tractor S/N 1K010G & After
Rear Wheels

Page 70 of 82

Ref #	Part Number	Qty	S/P/F	Description
1	734-3194	2	S	Tire, Turf, 24 x 10.5 - 12
2	634-3053-0499	2		Rim Assembly, Wheel
3	734-0255	2	S	Valve, Tubeless Air
4	712-3050	8	/P	Lug Nut, 7/16-14




3235 Tractor S/N 1K010G & After
Seat Assembly

Page 72 of 82

Ref #	Part Number	Qty	S/P/F	Description
1	703-3166A-0637	1	/P	Bracket, Seat Switch
2	703-3173-0637	1	/P	Bracket, Switch Mounting
3	703-3208	1		Track, Seat, w/o Latch
4	703-3431	1	/P	Track, Seat, w/Latch
5	703-3888	2	S	Bracket, Seat
6	710-0748	2	/P	Screw, Pan Torx Hd., #12-14 x .5
7	710-0759	4		Screw, Hex Wash. Hd. 5/16-18 x .625
8	710-1636	4		Carriage Bolt, 5/16-18 x .62
9	710-1669	4		Screw, Pan Torx Hd. 5/16-18 x 1.0
10	712-3004A	4	/P	Nut, Hex Flange Lock, 5/16-18
11	714-0507	1	S	Pin, Cotter, 3/32 x .75
12	726-0211	4	S	Speed Nut, U-Type, 5/16-18
13	731-3240A	1	S	Base, Seat
14	731-3244	1		Lid, Tlbox
15	732-1001	1		Spring, Compression
16	732-1163	2		Spring, Compression
?17	735-0271	2	S	Bumper
18	747-3357A	1	/P	Rod, Seat Pivot
19	757-04017	1	S	Seat, High Back (Ultra)
	757-3015	1		Seat, high back
	777D06883	1	/P	Graphic, Reflector
	777D01782	1	/P	Graphic, USA
20	735-04028	2	S	Cap, Spring

3235 Tractor S/N 1K010G & After
Starting System KH-25-098-08-S

Page 73 of 82




3235 Tractor S/N 1K010G & After
Starting System KH-25-098-08-S

Page 74 of 82

Ref #	Part Number	Qty	S/P/F	Description
1	KH-M-0841080	1	S	Nut, Hex Flange M8 x 1.25"
2	KH-M-839080	2	S	Screw, Hex Flange M8 x 1.25 x 80
3	KH-25-098-09-S	1	S	Starter assembly, solenoid shift (Delco) (Includes 4-7)
4	KH-25-435-05-S	1	S	Kit, Solenoid (Includes 3 Torx head screws)
	KH-25-086-113-S	3		Screw, external Torx head M4 x 0.7 x 26 (not shown)
5	KH-25-755-33-S	1		Kit, Pinion Drive (Includes 6)
6	KH-25-141-05-S	1		Ring, Retainer
7	KH-25-221-01-S	1		Kit, Brush
	KH-M-0841080	1	S	Nut, hex. flange M8x1.25 Delco-Remy SOLENOID SHIFT STARTER (25 098 08-S); Not shown
	KH-M-839080	2	S	Screw, hex. flange M8x1.25x80 Delco-Remy SOLENOID SHIFT STARTER (25 098 08-S); Not shown
	KH-25-098-08-S	1	S	Starter assembly, solenoid shift (Delco) Delco-Remy SOLENOID SHIFT STARTER (25 098 08-S); Not shown
	KH-25-435-04-S	1	/P/F	Kit, solenoid (plunger not part of solenoid) Delco-Remy SOLENOID SHIFT STARTER (25 098 08-S); Not shown
	~N/A	3		Screw, external Phillips head (purchase locally) Delco-Remy SOLENOID SHIFT STARTER (25 098 08-S); Not shown
	KH-25-755-33-S	1		Kit, pinion drive Delco-Remy SOLENOID SHIFT STARTER (25 098 08-S); Not shown
	KH-25-141-05-S	1		Ring, retainer Delco-Remy SOLENOID SHIFT STARTER (25 098 08-S); Not shown
	KH-25-221-01-S	1		Kit, brush Delco-Remy SOLENOID SHIFT STARTER (25 098 08-S); Not shown

3235 Tractor S/N 1K010G & After
Starting System KH-25-098-09S


Page 75 of 82



3235 Tractor S/N 1K010G & After
Starting System KH-25-098-09S

Page 76 of 82

Ref #	Part Number	Qty	S/P/F	Description
1	KH-M-0841080	1	S	Nut, Hex Flange M8 x 1.25"
2	KH-M-839080	2	S	Screw, Hex Flange M8 x 1.25 x 80
3	KH-25-098-09-S	1	S	Starter, Solenoid Shift Assembly (Includes 4-8)
4	KH-25-435-05-S	1	S	Kit, Solenoid (Includes 8)
5	KH-25-755-33-S	1		Kit, Pinion Drive (Includes 7)
6	KH-25-221-01-S	1		Kit, Brush
7	KH-25-141-05-S	1		Ring, Retainer
8	KH-25-086-113-S	3		Screw, External Torx Hd.



3235 Tractor S/N 1K010G & After
Transmission - Differential

Page 78 of 82

Ref #	Part Number	Qty	S/P/F	Description
	618-3235	1	S	Transmission Assembly Complete - DOES NOT include Ref. Nos. 2, 3, 6, 29, 33, 36, 37 and 56.
1	611-3024	1		Shaft, Differential Actuator
2	617-3001	1		Gear Assembly, Pinion 13T
	741-3037	1	S	Bearing, Ball
3	618-3214	1	S	Hydrostatic Transmission Assy For components see separate parts breakdown.
4	710-1633	1		Plug, Drain, M14 x 1.5 x .827
5	735-0277A	1		Grommet, Rubber
6	618-3210A	2	/P	Hub Assembly, Wheel
7	711-1308	1	S	Axle Shaft, 15.08 Long - RH
8	716-0172	4	S	Retaining Ring
9	717-1119	2		Gear, Spur, 14T
10	618-3155A	1	/P	Collar Assembly, Diff. Lock
11	711-1309	1		Axle Shaft, 15.08 Long - LH
12	716-3018	1		Retaining Ring
13	718-3099B	1	/P	Housing, Diff. Lock
14	732-0856	1		Spring, Compression
15	736-0615	1		Washer, Thrust, 1.007 x 1.542 x .03
16	619-3086	1		Housing, Diff. Cover
17	710-1254	4	/P	Hex Cap Screw, 3/8-24 x 2.25 GR8
18	717-1120	4		Gear, Differential 10T
19	717-1173	1		Shaft, Cross, .5 x 3.485
20	717-1178	2		Shaft, Cross, Special
21	717-1180	1		Differential Pinion Block
22	717-3466	1		Gear, Spur 60T
23	718-3101	4		Block, Thrust Miter
24	736-0558	2		Washer, Flat, 1.187 x 1.56 x .062
25	761-0215	1		Disc, Brake
26	710-1206	2	/P	Screw, Hex Wash. Hd. Tapp 1/4-20 x 2.375
27	710-0751	1	/P	Hex Cap Screw, 1/4-20 x .62 GR5
28	711-1385A	1	/P	Shaft, Output 9T
29	712-0682	2		Nut, Lock, 7/8-14
30	717-3449	1		Gear, Bevel 54T
31	718-3089	1		Arm, Diff. Lock Actuator
32	721-0393	1		Seal, Oil
33	723-3014	1	S	Filter, Oil
34	736-0208	3	S	Washer, Flat, .51 x 1.5 x .07
35	736-0270	1	/P	Washer, Belleville, .265 x .75 x .062
36	736-0619	1		Washer, Spring
37	737-3022	1	S	Fitting, Filter Nipple
38	735-0279	1		Grommet
39	712-0273	1	S	Nut, Hex Insert Lock, 5/16-24
40	717-0678	2	S	Pad, Brake
41	717-0682	1	S	Plate, Puck
42	732-0925	1		Spring, Torsion
43	736-0371	1	/P	Washer, Flat, .343 x .88 x .062
44	741-0343	2	S	Pin, Brake Actuator
45	761-0207A	1	/P	Yoke, Brake
46	761-0208	1		Bracket, Brake Anti-Rotation
47	761-3074	1		Arm, Brake Actuator


3235 Tractor S/N 1K010G & After
Transmission - Differential

Page 79 of 82

Ref #	Part Number	Qty	S/P/F	Description
48	619-3066	1	S	Housing, RH
49	619-3067	1		Housing LH
50	716-0180	2		Retaining Ring
51	721-3020A	2	S	Seal, Oil
52	741-3114	2		Bearing, Ball
53	741-3033A	4	S	Bearing, Ball
54	710-0573	14		Screw, Hex Cap Locking 5/16-18 x 1.25 GR5
55	721-0523	1		Seal, Oil 1.0 ID
56	721-0519	1		Seal, Gland O-Ring
57		1		UNKNOWN
	759-3958	1		Sealant, Loctite Black, 5.3 oz. Tube
	737-3120	5.5	/P	Drive System Fluid Plus - Quart
	737-3121	A/R	/P	Drive System Fluid Plus - Gallon

3235 Tractor S/N 1K010G & After
Transmission Mounting And Neutral Linkage

Page 80 of 82



3235 Tractor S/N 1K010G & After
Transmission Mounting And Neutral Linkage

Page 81 of 82

Ref #	Part Number	Qty	S/P/F	Description
1	603-0698	1		Bracket, Torque
2	703-3478	1		Plate, Hydro Neutral Return
3	703-3477	1		Link, Neutral Return Bearing
4	703-3187A	1	S	Spring Plate, Hydro Bypass
5	703-3175	1		Bracket, Cable Retainer
6	703-3183	1		Bracket, Pedal Brace
7	710-0433	1	/P	Screw, Hex Cap, 1/4-20 x .625 GR5 Lock
8	710-0514	7	/P	Screw, Hex Cap, 3/8-16 x 1.0 GR5
9	710-0599	2	/P	Screw, Hex Wash. Hd. Tapp, 1/4-20 x .5
10	710-0623	1	/P	Screw, Hex Wash. Hd. Tapp, 3/8-16 x .75
11	710-0465	4		Screw, Hex Cap, 1/2-20 x 4.5 GR5
12	710-3015	2	/P	Screw, Hex Cap, 1/4-20 x .75 GR5
13	710-3170	1		Ball Screw, 5/16-18 x .56
14	710-1506	4		Screw, Hex Wash. Hd. Tapp 5/16-18 x 5.5 GR5
15	710-3242	1		Screw, Set, 5/16 x .5
16	712-3059	1	/P	Nut, Hex Top Lock Jam, 1/2-20
17	712-0266	3	S	Nut, Hex Ctr. Lock Jam, 3/8-16
18	712-0431	4	S	Nut, Hex Flange Lock, 3/8-16
19	712-3004A	1	/P	Nut, Hex Flange Lock, 5/16-18
20	712-3006	1	/P	Nut, Hex, 1/4-20
21	712-3058	4	S	Nut, Hex Insert Lock, 1/2-20
22	714-0104	1	S	Pin, Internal Cotter
23	716-0104	1	S	E-Ring, .5 Dia. Shaft
24	718-3097	1		Arm, Hydro
25	748-3093	1		Adapter, Pump
26	721-0459	2		O-Ring, .426 ID x .566 OD x .070
27	726-0295	2		Clamp, Tube
28	726-0324	1	S	Clamp, Hose
29	727-3090	1	/P	Cylinder, Damper
30	727-3139	1		Tube, Hydro Pickup
31	727-3148	1		Dipstick, Transmission
32	731-1480	1	/P	Plastic Vent
33	731-1481	1		Vent Cap
34	731-3297	1		Fan, Pump
35	731-3245	1		Holder, Dipstick
36	731-3250	1		Pedal, Diff Lock
37	732-0429A	1	S	Spring, Extension
38	735-0279	1		Grommet
39	736-0227	3	S	Washer, Flat, .390 x 1.5 x .1
40	736-0253	1	S	Washer, Bell, .5 x 1.0 x .05
41	736-3019	4		Washer, Flat, .531 x 1.062 x .134
42	736-3090	1	/P	Washer, Flat, .26 x .72 x .06
43	737-3092	1		Fitting, Tube
44	738-0347	1	S	Spacer, Shoulder
45	738-0572	1	S	Shoulder Bolt
46	741-0155	2	S	Bearing, Ball
47	741-0491	2		Bearing, Nylon Flange
48	746-3081	1	S	Cable, Diff Lock
49	747-3424	1		Rod, Pump Bypass
50	747-3366	1		Shaft, Diff Lock
51	750-0434	1	/P	Spacer, .375 x .5 x 1.02

3235 Tractor S/N 1K010G & After
Transmission Mounting And Neutral Linkage

Page 82 of 82

Ref #	Part Number	Qty	S/P/F	Description
52	750-0497	2		Spacer, .375 x .624 x .445
53	750-3212	2		Spacer, Hydro, .3223 x .60 x 2.44
54	751-0588-8	8 in.		Fuel Line