


364
44" Deck Assembly

Page 1 of 43




44" Deck Assembly

Ref #	Part Number	Qty	S/P/F	Description
1	732-0556	1	S	Extension Spring .94 OD x 7.57
2	712-3006	1	/P	Hex Nut 1/4-20
3	710-0597	1	/P	Hex Cap Screw 1/4-20 x 1.0
4	710-3151	1	/P	Hex Cap Screw 5/8-18 x 4.25
5	736-0290	1	/P	Flat Washer 5/8 ID x 1.0 OD
6	741-0524	1	S	Bearing .625 ID x 1.574 OD
7	754-3091	1	S	Belt
8	716-3020	1	S	Snap Ring
9	750-3164	1		Spacer .635 ID x 2.0
10	712-0239	1	S	Hex Lock Nut 1/2-20
11	736-0179	1	S	Flat Washer 1/2 x 1.25
12	736-0188	1	/P	Flat Washer .76 ID x 1.49 OD
13	741-0338	1	/P	Flange Bearing 3/4 ID x .52
14	750-0656	1	/P	Spacer .50 OD x .75 ID
15	756-3108	1		Pulley
16	732-0850	1	S	Extension Spring 1.0 OD x 6.140
17	603-0743	1	S	Idler Assembly
18	736-0100	1	/P	Flat Washer .531 ID x 1.25 OD
19	737-3000	1	S	Grease Fitting
20	738-3172	1		Shoulder Screw
21	603-0741	1		Idler Arm Assembly
22	732-3067	1		Torsion Spring
23	756-3005	1	/P	Flat Pulley
24	712-0431	1	S	Flange Lock Nut 3/8-16
25	748-3100	1		Retainer Spring
26	603-0763	1	S	Deck Mounting Plate Assembly
27	712-3004A	1	/P	Flange Lock Nut 5/16-18
28	703-2559	1		Stop Bracket
29	710-3008	1	/P	Hex Cap Screw 5/16-18 x .75
30	726-3045	1	/P	Button Plug
31	703-3742	1		Belt Cover LH
32	712-3010	1	S	Hex Nut 5/16-18
33	736-0119	1	S	Lock Washer 5/16
34	738-0213	1	/P	Shoulder Screw .498 x 1.445
35	736-0192	1	S	Flat Washer .531 x .93
36	603-0766	1	S	Handle Assembly
37	710-1693	1	F	Spindle Bolt 3/4-16 x 5
	710-1852	1	F	Spindle Bolt 3/4-16 x 5 3/8
38	756-3089	1		Pulley
39	710-3144	1	/P	Hex Cap Screw 3/8-16 x 2.0
41	710-1611	1	S	Screw 5/16-18 x .750
42	748-3065	1	S	Spindle Spacer
43	715-3003	1	/P	Pin
44	747-3013	1	/P	Support Pin
45	732-0802	1		Compression Spring .63 OD x 6.3
46	710-1260A	1	/P	Hex Washer Screw 5/16-18 x .750
47	750-3119	1	/P	Spacer .406 ID x 1.0 OD
48	750-0150	1		Spacer .550 ID x .750 OD
49	603-0734	1		Deck Assembly
50	710-3178	1	/P	Carriage Bolt 3/8-16 x .75
51	754-3039	1	S	Belt
52	918-3129	1	S	Spindle Assembly
53	748-3101	1	F	Blade Spacer .31 Thk

364
44" Deck Assembly

Page 3 of 43


Ref #	Part Number	Qty	S/P/F	Description
54	948-3020	1	/P/F	Blade Spacer .70 Thk
	742-3036	1	S	Blade
	759-3949	1		High Lift Blade For Discharge Spindle (Optional)
55	712-3078	1	/P	Hex Flange Nut 3/4-16
56	736-0171	1	S	Lock Washer 7/16
57	712-3019	1	S	Hex Nut 7/16-14
58	736-0105	1	/P	Bell Washer .401 ID x .870 OD
59	703-1890	1	S	Deck Wheel
60	631-0094	1	S	Chute Assembly
61	738-3056	1	S	Shoulder Screw 1/2 x 2.5
62	703-3359	1		Skirt Baffle
63	710-0260	1	S	Carriage Bolt 5/16-18 x .62
64	731-3316	1		Mulching Plug
65	711-3314	1	S	Roller Pin
66	703-3743	1		Belt Cover RH
67	731-3005	1	/P	Front Roller
68	714-0115	1	S	Pin
69	736-0270	1	/P	Bell Washer .265 ID x .75 OD
70	710-0751	1	/P	Hex Cap Screw 1/4-20 x .620



364
44" Deck Spindle Assembly

Page 5 of 43


Ref #	Part Number	Qty	S/P/F	Description
13	721-3018	4	S	Seal, Oil, 1.25 x 1.874 x .25
22	741-3028	4	S	Cone, Bearing
23	741-3029	4	/P	Cup, Bearing
24	741-3031	2	S	Spacer, Bearing
28	750-3190	2	S	Spacer, Bearing, .780 x .963 x .7777
29	750-3191	2		Spacer, Bearing, 1.615 x 1.86 x .8427
36	918-3129	2	S	Spindle Assy



Ref #	Part Number	Qty	S/P/F	Description
1	629-3033	1		Wire Harness, Main Not Shown
2	723-0455	1		Foam Protector, Indicator Light
3	710-3013	1	/P	Hex Cap Screw 1/4-20 x .50
4	703-2809	1	S	Bracket, Indicator Bulb Mtg.
5	712-3027	1	S	Nut, Hex Flange Lock, 1/4-20
6	725-1718	1	S	Relay
7	703-2836	1		Bracket, Headlight Mtg.
8	710-0134	1	/P	Carriage Screw 1/4-20 x .62
9	725-3164A	1	S	Switch, Plunger Safety
10	725-0157	1	/P	Cable Tie
11	725-1347	1	/P	Cap, Ignition Switch
12	725-1346	1	S	Nut, Ignition Switch, 5/8-32
13	725-3163	1	S	Switch, Ignition
14	783-0462	1	/P	Bracket, PTO Switch Retainer
15	725-1722	1	S	Battery
16	725-3253	1	S	Switch, Seat
17	712-0397	1	S	Nut, Nylon Wing, 1/4-20
18	712-0271	1	/P	Nut, Hex Sems, 1/4-20
19	710-3015	1	/P	Screw, Hex Cap, 1/4-20 x .75 GR5
20	703-3149	1	S	Strip, Battery Retainer
21	747-3347	1		Rod, Battery Retainer
22	731-3233	1		Tray, Battery
23	725-3250	1	S	Headlight Assembly
	759-3864	1	S	Bulb, Headlight - Only
24	731-3184	1		Bezel, Headlight
25	732-0816	1		Spring, Switch Mounting
26	710-0425	1	/P	Screw, Machine, #10-24 x 5/8
27	712-0161	1	/P	Nut, Hex Insert Lock, #10-24
28	725-3251	1	S	Voltage Sensor
29	726-0349	1	S	Ratchet Retainer
30	710-3143	1	/P	Machine Screw #10-24
31	750-0539	1	S	Spacer .315 ID x .50 OD
32	725-3229	1		Hour Meter
33	725-0157	1	/P	Cable Tie
34	712-0161	1	/P	Lock Nut #10-24
	629-3036	1		Wire Harness, Engine (Not Shown)

364
Body Cover And Console

Page 8 of 43




Body Cover And Console

Ref #	Part Number	Qty	S/P/F	Description
1	731-3263	1	S	Control Handle
2	712-3004A	1	/P	Flange Lock Nut 5/16-18
3	710-0451	1	/P	Carriage Bolt 5/16-18
4	731-3185	1		Bellow
5	735-0251	1		Foot Pad
6	710-0642	1	/P	Hex Washer Screw 1/4-20 x .75
7	703-2648	1		Bellow Retainer Bracket
8	712-0431	1	S	Flange Lock Nut 3/8-16
9	703-2807B	1	S	Foot Pad Mounting Bracket
10	710-3168	1	/P	Carriage Bolt 3/8-16
11	749-3081	1		Cruise Control Tube
12	703-3288	1	S	Control Tube Mounting Bracket
13	710-0276	1	/P	Carriage Screw 5/16-18 x 1.0
14	731-3310	1		Consol
15	726-0289	1		Plug
16	731-3128A	1	/P	Lens
17	736-0242	1	/P	Bell Washer .340 ID x .872 OD
18	720-0241	1	S	Wingnut Knob
19	738-0754	1		Shoulder Screw
20	720-0302	1		Knob
21	731-3195B	1	/P	LH Control Panel Cover
22	603-0424	1	S	LH Control Panel Assembly
23	723-3042	1	/P	Snap Bushing
24	712-0453	1		Retainer Nut 1/4-20
25	726-3047	1	S	Push Nut
26	728-0117	1		Pop Rivet
27	726-0197	1		Cable Tie
28	732-0830	1	S	Spring Clip
29	731-3293	1		Rear Body
30	738-3163A	1	/P	Shoulder Screw 3/8-16
31	736-3039	1	S	Flat Washer .406 ID x 1.5 OD
32	731-3312	1		Floor Body
33	603-0578	1		Body Plate Assembly
34	703-3474	1	S	Body Clip
35	710-0376	1	/P	Hex Cap Screw 5/16-18 x 1.0
36	703-1345A	1	S	Key
37	725-3233	1	S	Electric PTO Switch
38	731-3196A	1	/P	RH Control Panel Cover
39	603-0425	1		RH Control Panel Assembly

364

Page 10 of 43

Choke & Throttle Cable, Muffler Assembly, PTO Clutch, Engine Acc's




Choke & Throttle Cable, Muffler Assembly, PTO Clutch, Engine Acc's

Ref #	Part Number	Qty	S/P/F	Description
1	751-3141	1	S	Oil Drain Extension Hose
2	751-3142	1		Oil Drain Cap
3	751-3140	1	S	Oil Drain
4	710-3009	1	/P	Tap Screw #10-24 x .75
5	746-3070	1		Throttle Cable
6	746-3069	1		Choke Cable
7	712-0161	1	/P	Hex Lock Nut #10 - 24
8	710-0751	1	/P	Hex Cap Screw 1/4-20 x .620
9	736-3006	1	/P	Lock Washer 1/4 x 3/4
10	736-0270	1	/P	Bell Washer .265 x .75
11	726-0205	1	/P	Hose Clamp
12	751-0535	1		Fuel Line Hose
13	725-3001	1	S	Solenoid Switch
14	712-0291	1	S	Hex Lock Nut 1/4-20
15	736-0119	1	S	Lock Washer 5/16
16	712-3010	1	S	Hex Nut 5/16-18
17	712-3071	1	S	Hex Nut #10-32
18	712-0431	1	S	Flange Lock Nut 3/8-16
19	703-2859	1		Muffler Bracket
20	710-3178	1	/P	Carriage Bolt 3/8-16 x .75
21	710-0642	1	/P	Hex Washer Screw 1/4-20 x .75
22	721-0460	1		Gasket
23	751-0650	1	S	Exhaust Pipe - RH
24	710-1314	1	S	Cap Screw 5/16-18 x .625
25	703-3004	1	S	Muffler Guard
26	751-0616	1	S	Muffler
27	710-0148	1	/P	Hex Washer Screw #8-32 x .375
28	751-0564	1	S	Muffler Deflector
29	751-0651	1	S	Exhaust Pipe - LH
30	747-3362	1		Rear Belt Retainer Rod
31	736-0258	1	/P	Flat Washer .385 x 1.0
32	603-0317	1	S	Clutch Retainer Ass'y
33	710-1237	1		Hex Washer Screw #10-32 x .625
34	751B221535	1	/P	Casing Clamp
35	726-3008	1	/P	Heat Shield Cable Clip
36	712-0291	1	S	Hex Lock Nut 1/4-20
37	710-1007	1	/P	Hex Washer Screw 3/8-16 x 1.5
38	710-1008	1		Hex Washer Screw 3/8-16 x 1.875
39	736-3010	1	/P	Flat Washer .407 x .812 x .135
40	754-3076	1	S	V-Belt
41	756-3060	1		Transmission Drive Pulley
42	714-0128	1	/P	Key 1/4 x 1.0
43	725-0157	1	/P	Cable Tie
44	717-3467	1	/P	Electric Clutch
45	750-3106	1		Spacer Clutch
46	736-0171	1	S	Lock Washer
47	710-3157	1	S	Hex Cap Screw 7/16-20 x 3.25
	629-3038A	1		Engine Harness Assembly (Not Shown)

364
Deck Lift Assembly

Page 12 of 43




Deck Lift Assembly

Ref #	Part Number	Qty	S/P/F	Description
1	711-0642A	1	/P	Handle Button
2	731-3158	1	/P	Handle Deck Lift Grip
3	732-3097	1		Compression Spring
4	747-3405	1		Front Lift Rod
5	738-0507B	1	S	Shoulder Screw .500 Dia x .434
6	710-0216	1	/P	Hex Cap Screw 3/8-16 x .75
7	603-0422	1	S	Shaft Mounting Bracket - LH
8	603-0370	1		Pivot Link Bearing Ass'y
9	603-0313	1	S	Lift Shaft Ass'y
10	703-2621	1		Adjustable Deck Lift Link
11	703-2780	1		Lift Parallel Link
12	603-0327	1		Handle Bearing Ass'y
13	703-2772	1		Deck Height Adjustable Plate
14	738-3150	1		Lift Handle Shoulder Screw
15	712-3020	1	S	Top Lock Jam Nut 3/8-16
16	603-0423	1		Shaft Mounting Bracket - RH
17	710-3083	1	/P	Hex Cap Screw 5/16-18 x 1.375
18	711-0773	1		Eye Bolt Adjustable Link
19	738-0380	1	S	Shoulder Screw 3/8-16
20	712-0206	1	S	Hex Nut 1/2-13
21	712-0431	1	S	Flange Lock Nut 3/8-16
22	738-3151	1		Shoulder Screw 3/8-16 .56 x .27
23	712-3015	1	S	Jam Nut 5/8-11
24	736-0158	1	S	Lock Washer 5/8
25	712-3016	1	/P	Lock Hex Nut 5/8-11
26	711-3266	1	S	Clevis Pin
27	703-3407	1	S	Front Lift Bracket
28	603-0401	1	S	Lift Arm Ass'y
29	738-0183	1	S	Shoulder Screw 3/8-16 .50 x .21
30	603-0257	1	/P	Fork Lift Ass'y
31	710-3011	1	/P	Hex Cap Screw 3/8-16 x 2.25
32	747-3276	1		Lift Link Rod
33	736-0300	1	S	Flat Washer .406 x .875
34	747-3267	1		Handle Arm
35	750-3200	1		Spacer .448 ID x .688 OD
36	712-0290	1	/P	Lock Nut 7/16-14
37	712-3009	1	S	Hex Center L-Nut 5/16-18
38	710-0431	1	/P	Hex Screw 3/8-16 x 1.50
39	737-0280	1	S	Grease Fitting
40	747-3406	1		Front Mounting Rod Bracket

364
Drive Assembly Complete

Page 14 of 43



364


Page 15 of 43

Drive Assembly Complete

Ref #	Part Number	Qty	S/P/F	Description
1	618-3110A	1	S	Drive Ass'y Complete
2	712-3004A	1	/P	Hex Flange Lock Nut 5/16-18
3	715-0136	1	S	Spirol Pin 3/16 x 1.25
4	717-3396	1	S	Spur Gear 14T
5	717-3455	1	S	Hydro Transmission
6	718-3053	1		Parking Brake Lever
7	721-0343	1		O-Ring 2.0 Dia.
8	727-3125	1	S	Cap Nut 3/8

364
Drive Controls & Support Tower

Page 16 of 43




Drive Controls & Support Tower

Ref #	Part Number	Qty	S/P/F	Description
1	603-0340	1	S	Bellcrank Ass'y Upper LH
2	603-0341	1	S	Bellcrank Ass'y Upper RH
3	603-0342	1	S	Bellcrank Ass'y Lower LH
4	603-0343	1	S	Bellcrank Ass'y Lower RH
5	603-0647	1	S	Support Ass'y Tower
6	603-0410	1		Rod Ass'y Control RH
7	603-0411	1		Rod Ass'y Control LH
8	710-0216	1	/P	Hex Cap Screw 3/8-16 x .75
9	710-3005	1	/P	Hex Cap Screw 3/8-16 x 1.25
10	710-3178	1	/P	Carriage Bolt 3/8-16 x .75
11	711-1111	1		Control Shaft
12	711-1124	1		Pin
13	712-0312	1	S	Hex Jam Nut LH 3/8-24
14	712-0365	1		Hex Center Lock Nut
15	712-0431	1	S	Hex Flange Lock Nut 3/8-16
16	712-0453	1		Retainer 1/4-20
17	712-0711	1	/P	Hex Jam Nut 3/8-24
18	712-3001	1	S	Hex Jam Nut 3/8-24
19	712-3004A	1	/P	Hex Flange Lock Nut 5/16-18
20	714-0104	1	S	Cotter Pin
21	723-0420	1	S	Spherical Rod End RH 3/8-24
22	723-0421	1	S	Spherical Rod End LH 3/8-24
23	727-3113	1		Damper Cylinder
24	732-3084	1		Spring Compression
25	736-0169	1	S	Lock Washer 3/8
26	736-0539	1		Thrust Washer .625 ID x 1.12 OD
27	736-3004	1	S	Flat Washer .406 ID x .875 OD
28	737-0280	1	S	Grease Fitting
29	737-3072	1		Grease Fitting w/Tube
30	737-3073	1		Adapter 1/4-20
31	738-0296	1	S	Shoulder Bolt .437 Dia. x .268
32	738-3153	1		Shoulder Bolt
33	741-3063	1		Sleeve Bearing
34	747-3281	1		Control Rod LH 31-5/8
35	747-3282	1		Control Rod RH 35-3/8
36	736-0300	1	S	Flat Washer .406 ID x .87 OD
37	703-3405	1		Support Plate

364
Engine

Page 18 of 43



Assemblies Include All Parts Shown In Frames

364
Engine

Page 19 of 43

Ref #	Part Number	Qty	S/P/F	Description
1	BS-691021	1		Choke Control Bracket
2	BS-94930	1	S	Screw (Choke Control Bracket)
3	BS-691022	1		Choke Link
4	BS-690960	1	S	Screw (Breather Assembly)
5	BS-690942	1	S	Breather Tube
6	BS-499601	1	S	Breather Assembly
7	BS-690937	1		Breather Gasket
8	BS-690960	1	S	Screw (Control Bracket)
9	BS-691023	1		Control Bracket
10	BS-690231	1		Cylinder Assembly
11	BS-499585	1	F	Bushing/Seal Kit (Magneto Side)
12	BS-391086	1	S	Oil Seal (Magneto Side)
13	BS-230192	1	S	Locating Pin
14	BS-499788	1	S	Air Cleaner Cover
15	BS-691008	1		Air Cleaner Knob
16	BS-499486S	1	/P	Air Cleaner Cartridge Filter
17	BS-273638S	1	/P	Pre-Cleaner Filter
18	BS-691005	1		Screw (Blower Housing)
19	BS-691004	1		Blower Housing
20	BS-491657	1	S	Oil Pressure Switch
21	BS-222698	1	S	Flywheel Key
22	BS-499588	1	S	Piston Assembly (Standard)
	BS-499589	1		Piston Assy. (.010 Oversize)
	BS-499590	1	S	Piston Assy. (.020 Oversize)
	BS-499591	1		Piston Assy. (.030 Oversize)
23	BS-499604	1		Ring Set (Standard)
	BS-499605	1		Ring Set (.010 Oversize)
	BS-499606	1		Ring Set (.020 Oversize)
	BS-499607	1		Ring Set (.030 Oversize)
24	BS-263181	1		Piston Pin Lock
25	BS-499583	1		Connecting Rod
26	BS-690976	1		Screw (Connecting Rod)
27	BS-690103	1		Label Kit
28	BS-690229	1		Piston Pin
29	BS-691046	1	S	Crankshaft
30	BS-94388	1	S	Timing Key
31	BS-690980	1		Timing Gear
32	BS-690981	1	/P	Rod-Push (Steel)
33	BS-690982	1	/P	Rod-Push (Aluminum)
34	BS-262679	1	S	Valve Tappet
35	BS-691010	1		Clip
36	BS-691012	1		Air Guide Cover (Cylinder #1)
37	BS-94930	1	S	Screw (Air Guide Cover)
38	BS-690960	1	S	Screw (Air Guide Cover)
39	BS-690978	1		Camshaft
40	BS-691011	1		Air Adapter
41	BS-691001	1		Air Cleaner Gasket
42	BS-690952	1		Carburetor Spacer
43	BS-690950	1		Intake Gasket
44	BS-691014	1		Air Guide Cover (Cylinder #2)
45	BS-690949	1		Intake Gasket
46	BS-693996	1		Intake Manifold
47	BS-94913	1	S	Screw (Intake Manifold)


364
Engine

Page 20 of 43

Ref #	Part Number	Qty	S/P/F	Description
48	BS-492932	1	S	Oil Filter
49	BS-94010	1	S	Nut (Carburetor)
50	BS-690951	1		Stud (Carburetor)
51	BS-690069	1		Engine Sump
52	BS-690770	1		Oil Pump Screen
53	BS-690954	1	/P	Oil Filter Nipple
54	BS-690945	1	S	Crankcase Gasket
55	BS-94239	1	S	Oil Drain Plug
56	BS-690947	1	S	Oil Seal (PTO Side)
57	BS-690552	1		Governor Crank Bushing
58	BS-690657	1		Governor Shaft Seal
59	BS-690283	1		Oil Plug
60	BS-499054	1	S	Oil Pump
61	BS-690956	1		Oil Collector
62	BS-690957	1		Breather Retainer
63	BS-691042	1		Pump Shaft
64	BS-499613	1		Oil Pump Cover
65	BS-690589	1	/P	O-Ring Seal (Oil Pump Cover)
66	BS-691033	1		Screw (Oil Pump Cover)
67	BS-690412	1	/P	Washer (Governor Gear)
68	BS-394348	1	S	Governor Gear
69	BS-690317	1	S	Governor Shaft Retainer
71	BS-695104	1		Emissions Label
72	BS-690308	1	S	Screw (Engine Sump)
73	BS-691015	1		Air Guide Cover
74	BS-499890	1	S	Valve Overhaul Kit
75	BS-690962	1	S	Cylinder Head Gasket
76	BS-690968	1	/P	Valve Seal
77	BS-690970	1	/P	Exhaust Gasket
78	BS-690971	1	/P	Rocker Cover Gasket
	BS-692714	1	S	Short Block


364
Final Drive Assembly

Page 21 of 43




Final Drive Assembly

Ref #	Part Number	Qty	S/P/F	Description
	618-3110A	1	S	Drive Ass'y Complete
1	611-3012	1	S	Axle Assembly
	710-0852	1	/P	Ribbed Neck Stud
2	618-3106	1	S	Carrier Assembly, Output
3	618-3107	1	S	Gear Assembly, 51T Internal & 20T
4	618-3109	1	S	Housing Ass'y
5	710-1342	1		Hex Washer Screw 1/4-20 x 1-1/8
6	711-1048	1		Brake Shaft
7	712-3027	1	S	Hex Flange Lock Nut 1/4-20
8	715-0156	1		Roll Pin
9	715-0219	1		Dowel Pin
10	715-3045	1	S	Bushing
11	716-3015	1		Inverted Retaining Ring
12	716-3018	1		Snap Ring
13	717-3395	1		Spur Gear 13T
14	717-3397	1		Ring Gear 46T
15	719-3114	1	S	Axle Outer Housing
16	721-0381	1	S	Oil Seal
17	721-0393	1		Oil Seal
18	727-3124	1	S	Elbow Fitting
19	732-0752	1		Brake Shoe Spring
20	736-0351	1	S	Shim Washer .76 x 1.5 x .030
	736-0492	1	S	Shim Washer .76 x 1.5 x .010
	736-0493	1	S	Shim Washer .76 x 1.5 x .020
21	741-0665	1	/P	Needle Bearing
22	741-3033A	1	S	Ball Bearing
23	741-3080	1		Needle Bearing
24	761-3049	1		Shoe Brake



Frame Assembly & Attachments

Ref #	Part Number	Qty	S/P/F	Description
1	712-0251	1		Retainer Nut 3/8-16
2	603-0720	1	S	Frame Assembly
3	712-0455	1		Retainer Nut 3/8-16
4	712-0431	1	S	Flange Lock Nut 3/8-16
5	710-0216	1	/P	Hex Cap Screw 3/8-16 x .75
6	710-3144	1	/P	Hex Cap Screw 3/8-16 x 2.0
7	712-3004A	1	/P	Flange Lock Nut 5/16-18
8	736-0258	1	/P	Flat Washer .385 x 1.0 x .135
9	749-3062	1		Upper Bumper
10	749-3061	1		Lower Bumper Tube
11	736-0451	1	S	Washer .320 ID x .93 OD
12	703-3504	1	S	Bumper Bracket
13	710-1250	1	/P	Carriage Bolt 5/16 x 1.5
14	710-0521	1	/P	Hex Cap Screw 3/8-16 x 3.0
15	710-0859	1	/P	Hex Cap Screw 3/8 - 16 x 2.5
16	719-3130	1		Counter Weight
17	726-0298	1		End Cap
18	603-0620A	1	S	Bumper Ass'y
19	736-3004	1	S	Flat Washer .406 ID x .875 OD
20	712-0431	1	S	Flange Lock Nut 3/8-16




Front Axle & Tire

Ref #	Part Number	Qty	S/P/F	Description
1	712-3075	1	/P	Hex Lock Nut, 1.0-14
2	736-0274	1	S	Flat Washer
3	603-0389A	1		Pin Ass'y, Pivot
4	737-3090	1	S	Adapter, 1/8 NPTF x 1/8 NPTF
5	737-3072	1		Grease Fitting, 65° w/Extension
6	712-0431	1	S	Hex Flange Lock Nut, 3/8-16
7	712-0229	1		Push Nut, 3/8 ID
8	710-3178	1	/P	Carriage Bolt, 3/8-16 x .75
9	710-0514	1	/P	Hex Cap Screw, 3/8-16 x 1.0
10	736-0169	1	S	Lock Washer 3/8
11	736-0227	1	S	Flat Washer 3/8 x 1.5
12	731-0374	1	S	Flange Bearing 1.0 ID
13	737-0280	1	S	Grease Fitting
14	603-0363	1		Castor Wheel Bracket
15	712-0239	1	S	Hex Center Lock Nut 1/2-20
16	710-0506	1	/P	Hex Cap Screw, 1/2-20 x 5.5
17	750-0456	1	S	Spacer, .79 ID x .347 Lg
18	634-3163	1	/P	Wheel Comp 11.0 x 4.0 x 5.0
18	741-3069	1		Bearing, Flange Not Shown
18	741-3070	1	S	Bearing, Roller Not Shown
19	750-3197A	1	/P	Wheel Spacer
20	603-0382	1	S	Front Axle Ass'y

364
Fuel Tank, Wheels, Rear

Page 27 of 43




364

Page 28 of 43

Fuel Tank, Wheels, Rear

Ref #	Part Number	Qty	S/P/F	Description
1	722-3020	1		Foam 1.25 x .62
2	710-1260A	1	/P	Hex Washer Screw 5/16-18.0 x .75
3	651-3004	1		Fuel Tank 4.0 gal
4	703-3490	1		Fuel Tank Mounting Bracket
5	712-0431	1	S	Flange Lock Nut 3/8-16
6	736-0231	1	S	Flat Washer .344 x 1.125
7	710-0216	1	/P	Hex Cap Screw 3/8-16 x .75
8	734-1596	1		Tire 20 x 8 - 8 (For model 364)
	734-3163	1		Tire 22 x 11 - 8 (For models 365 & 365L) Chevron
9	634-3005	1	S	Rim Ass'y 8 x 6.19 (For model 364)
	634-3030	1	S	Rim Ass'y 8 x 6.19 (For models 365 & 365L)
10	734-0255	1	S	Tubeless Air Valve
11	634-3050	1	S	Wheel Comp 20 x 8 - 8 (For model 364) Turf
	634-3051	1		Wheel Comp 22 x 11 - 8 RH (For models 365 & 365L) Chevron
	634-3052	1		Wheel Comp 22 x 11 - 8 LH (For models 365 & 365L) Chevron




Assemblies Include All Parts Shown In Frames

General Assembly

Ref #	Part Number	Qty	S/P/F	Description
1	BS-499587	1		Cylinder Head (Cylinder #1)
2	BS-499595	1	S	Cylinder Head (Cylinder #2)
3	BS-499586	1	/P	Valve Keeper
4	BS-690964	1	S	Valve Retainer
5	BS-499597	1	S	Intake Valve
6	BS-690968	1	/P	Valve Seal
7	BS-499596	1		Exhaust Valve
8	BS-690970	1	/P	Exhaust Gasket
9	BS-690963	1		Valve Spring
10	BS-262835	1	F	Guide Bushing
11	BS-690971	1	/P	Rocker Cover Gasket
12	BS-690972	1		Rocker Arm
13	BS-806038	1	S	Rocker Arm Pivot
14	BS-690967	1		Screw (Rocker Arm)
15	BS-690083	1		Rocker Arm Adjuster
16	BS-690949	1		Intake Gasket
17	BS-690962	1	S	Cylinder Head Gasket
18	BS-499599	1		Cover-Rocker (Cylinder #11)
19	BS-499600	1		Cover-Rocker (Cylinder #2)
20	BS-690360	1	/P	Screw (Cylinder Head)
21	759-3336	1	/P	Sparkplug
22	BS-691019	1		Governed Idle Spring
23	BS-691018	1		Governor Spring
24	BS-690960	1	S	Screw (Rocker Cover)
25	BS-691048	1	S	Governor Control Lever
26	BS-298049	1	S	Fuel Line (Cut to Required Length)
27	BS-691049	1		Fuel Line (Molded)
28	BS-95162	1	S	Hose Clamp
29	BS-493629	1	S	Fuel Filter
30	BS-690960	1	S	Screw (Fuel Pump)
31	BS-691034	1	S	Fuel Pump
32	BS-691040	1	S	Vacuum Hose
33	BS-691039	1		Fuel Pump Bracket
34	BS-690960	1	S	Screw (Fuel Pump Bracket)
35	BS-92278	1	S	Nut (Governor Control Lever)
36	BS-94942	1		Washer (Governor Control Lever)
37	BS-93853	1		Bolt (Governor Control Lever)
38	BS-691020	1		Throttle Link
39	BS-499811	1	S	Carburetor Kit
40	BS-690232	1		Main Jet
	BS-690989	1		Main Jet (High Altitude)
41	BS-690994	1		Float Bowl Gasket
42	BS-690950	1		Intake Gasket
43	BS-690234	1		Carburetor Cover Plate Gasket
44	BS-499808	1		Carburetor Nozzle
45	BS-499599	1		Cover-Rocker (Cylinder #1)
46	BS-690995	1		Nozzle Gasket
47	BS-690990	1		Screw (Carburetor Nozzle)
48	BS-690997	1		Sealing Washer
49	BS-690985	1	S	Float Needle Valve
50	BS-690984	1		Float Hinge Pin
51	BS-690998	1		Choke Shaft Seal
52	BS-691000	1		Throttle Shaft Seal

Ref #	Part Number	Qty	S/P/F	Description
53	BS-691045	1		Governor Crank
54	BS-690552	1		Governor Crank Bushing
55	BS-690553	1		Governor Crank Bushing
56	BS-690328	1	/P	E-Ring Retainer
57	BS-690442	1		Washer (Governor Crank)
58	BS-690657	1		Governor Shaft Seal
59	BS-690988	1		O-Ring Seal (Fuel Transfer Tube)
60	BS-499812	1	S	Carburetor Gasket Set
61	BS-499804	1	S	Carburetor
62	BS-690990	1		Screw (Cover Plate)
63	BS-690999	1		Cover Plate
64	BS-499802	1		Idle Speed Kit
65	BS-499807	1		Choke Shaft Kit
66	BS-805538	1		Screw (Choke Shaft)
67	BS-690986	1		Choke Valve
68	BS-690998	1		Choke Shaft Seal
69	BS-499805	1		Throttle Shaft Kit
70	BS-805538	1		Screw (Throttle Valve)
71	BS-690993	1		Throttle Valve
72	BS-691000	1		Throttle Shaft Seal
73	BS-499806	1		Carburetor Float
74	BS-499803	1		Fuel Transfer Tube
75	BS-690991	1		Screw (Fuel Transfer Tube)
76	BS-499810	1		Float Bowl
77	BS-690996	1		Solenoid Retainer
78	BS-690992	1		Screw (Float Bowl)
79	BS-691001	1		Air Cleaner Gasket
80	BS-499809	1		Fuel Solenoid



Assemblies Include All Parts Shown In Frames

General Breakdown

Ref #	Part Number	Qty	S/P/F	Description
1	BS-691055	1	S	Rotating Screen
2	BS-691215	1		Spacer
3	BS-691057	1		Screw (Rotating Screen)
4	BS-499602	1		Dipstick/Tube Assembly
5	BS-690960	1	S	Screw (Dipstick Tube)
6	BS-691037	1		Dipstick Tube
7	BS-691036	1		Dipstick
8	BS-691032	1		Dipstick Tube Seal
9	BS-499602	1		Dipstick/Tube Seal
10	BS-691243	1		Flywheel Fan
11	BS-691059	1		Nut (Flywheel)
12	BS-691056	1		Washer (Flywheel)
13	BS-94627	1		Screw (Fan-Retainer)
14	BS-93621	1	/P	Screw (Alternator)
15	BS-19203	1		Flywheel Puller
16	BS-691247	1		Fan Retainer
17	BS-393295	1	S	Alternator (Dual Circuit)
18	BS-393456	1		Alternator Connector/Wire
19	BS-691220	1		Wiring Harness
20	BS-691009	1		Back Plate
21	BS-690960	1	S	Screw (Back Plate)
22	BS-694123	1		Wire Clip
23	BS-690960	1	S	Screw (Regulator)
24	BS-394890	1	S	Regulator (Regulated-16 Amp)
26	BS-691283	1		Drive Cap
27	BS-691053	1		Flywheel
28	BS-499612	1		Gear-Ring
29	BS-94731	1		Screw (Magneto Armature)
30	BS-691060	1	/P	Magneto Armature
31	BS-493880	1	S	Sparkplug Terminal
32	BS-66538	1	S	Sparkplug Boot
33	BS-499889	1	S	Engine Gasket Set
34	BS-391086	1	S	Oil Seal (Magneto Side)
35	BS-690947	1	S	Oil Seal (PTO Side)
36	BS-691001	1		Air Cleaner Gasket
37	BS-690962	1	S	Cylinder Head Gasket
38	BS-690949	1		Intake Gasket
39	BS-690997	1		Sealing Washer
40	BS-690937	1		Breather Gasket
41	BS-690950	1		Intake Gasket
42	BS-690968	1	/P	Valve Seal
43	BS-690945	1	S	Crankcase Gasket
44	BS-690657	1		Governor Shaft Seal
45	BS-690589	1	/P	O-Ring Seal (Oil Pump Cover)
46	BS-690970	1	/P	Exhaust Gasket
47	BS-690971	1	/P	Rocker Cover Gasket
48	BS-94951	1	S	Screw (Drive Cap)
49	BS-691262	1	S	Starter Motor
50	BS-497606	1	S	Starter Drive
51	BS-263080	1	S	Retaining Ring
52	BS-693058	1	S	Pinion Gear
53	BS-398003	1	S	Drive Clutch
54	BS-497605	1	S	Brush Retainer

364

Page 34 of 43


General Breakdown

Ref #	Part Number	Qty	S/P/F	Description
55	BS-497608	1	/P	Brush Set
56	BS-693167	1		Nut (Brush Retainer)
57	BS-497607	1	S	End Cap
58	BS-92278	1	S	Nut (Brush Retainer)
59	BS-691262	1	S	Housing-Starter
60	BS-95035	1		Bolt (Starter Motor)
61		1		Armature (Serviced By Starter Only)

364

Hydraulic Drive, Lines And Hydraulic Filter

Page 35 of 43



Hydraulic Drive, Lines And Hydraulic Filter


Ref #	Part Number	Qty	S/P/F	Description
1	737-3069	1		Pipe Plug
2	737-3070A	1		Pipe Dipstick
3	603-0639	1		Hydraulic Tank Assembly
4	727-3116	1	S	Connection Fitting
5	721-0223	1	S	Seal
6	738-0940	1	/P	Drain Plug
7	727-3120	1		Inlet Tube LH
8	727-3155	1		Tee Fitting
9	727-3154	1		Outlet Hose RH
10	727-3121	1		Inlet Tube RH
11	727-3153	1		Outlet Hose LH
12	710-0216	1	/P	Hex Cap Screw 3/8-16 x .75
13	712-0455	1		Retainer Nut 3/8-16
14	747-3360	1	S	Belt Retainer Rod RH
15	710-0378	1	/P	Hex Cap Screw 5/16-18 x 2.5
16	736-3089	1	/P	Flat Washer 5/16
17	723-3071	1		Filter Element
18	731-1449A	1	S	Fan Blade
19	712-0333	1	S	Hex Nut 1/2-20
20	703-3168	1		Mounting Pulley Bracket
21	756-0625	1		Roller Cable
22	738-0924	1	S	Hex Shoulder Screw 1/4-28 x .375
23	703-3169	1		Retainer Cable Bracket
24	712-0117	1	S	Lock Nut 1/4-28
25	618-3165	1		Complete Transmission Assembly LH
26	712-3050	1	/P	Lug Nut
27	710-0347	1	/P	Hex Cap Screw 3/8-16 x 1.75
28	736-0258	1	/P	Flat Washer .385 ID x 1.0 OD
29	756-0627	1	S	Flat Idler Pulley 3.5 OD
30	703-3174	1		Mounting Bracket Cable
31	712-3019	1	S	Hex Nut 7/16-14
32	736-0171	1	S	Lock Washer 7/16
33	736-3015	1	S	Flat Washer .469 ID x .875 OD
34	603-0377A	1	S	Idler Arm Assembly
35	603-0102	1		Shoulder Screw
36	732-0478	1	S	Extension Spring 6.12 Lg
37	712-0431	1	S	Flange Lock Nut 3/8-16
38	712-3027	1	S	Lock Nut 1/4-20
39	703-3380	1	/P	Declutching Cable Bracket
40	736-0119	1	S	Lock Washer 5/16
41	738-0704	1	S	Shoulder Screw
42	710-3008	1	/P	Hex Cap Screw 5/16-18 x .75
43	710-3011	1	/P	Hex Cap Screw 3/8-16 x 2.25
44	603-0362	1	S	Idler Pulley Assembly 5.0"
45	703-2888	1	S	Idler Bracket
46	712-3004A	1	/P	Flange Lock Nut 5/16-18
47	710-3103	1	/P	Hex Cap Screw 5/16-18 x 2.0
48	727-3100	1	S	Connection Fitting 1/2 x 3/8
49	603-0358B	1	S	Skid Plate Assembly
50	747-3361	1		Belt Rod LH
51	603-0450	1	S	Support Pump Assembly
52	710-3178	1	/P	Carriage Bolt 3/8-16 x .75
53	749-3040	1		Frame Strut

Hydraulic Drive, Lines And Hydraulic Filter

Ref #	Part Number	Qty	S/P/F	Description
54	736-0921	1	S	Lock Washer 1/2
55	710-1189	1		Hex Washer Screw #12-24 x .625
56	756-0974	1	/P	Transmission Pulley
57	732-0729	1	/P	Wire Ring
58	736-0185	1	S	Flat Washer
59	710-3144	1	/P	Hex Cap Screw 3/8-16 x 2.0
60	618-3164	1		Complete Tranmission Assembly RH
61	710-0751	1	/P	Hex Cap Screw 1/4-20 x .62
62	703-2907	1		Bearing Cup
63	741-0600	1	S	Ball Bearing
64	756-3085	1		Idler Pulley 5.0"
65	712-0324	1	/P	Hex Lock Nut 1/4-20
66	750-3176	1		Idler Spacer
67	746-3083	1		Declutching Cable
68	712-3007	1	/P	Jam Nut 5/16-18

364
Labels


Page 38 of 43



364
Labels


Page 39 of 43

Ref #	Part Number	Qty	S/P/F	Description
777D03341	777D03341	1		LABEL-364 ZTT
777I20310	777I20310	1		LABEL-SEAT ADJUSTER
777D03355	777D03355	1		LABEL-18 HP B&S IND
777S30503	777S30503	1	/P	LABEL-DANGER CHUTE
777I20772	777I20772	1		LABEL-LUBE GUIDE 44"
777S30295	777S30295	1	/P	LABEL-ASSEMBLE CHUTE DEFLECTOR
777I20811	777I20811	1		LABEL-44" DECK
777S30014	777S30014	1	/P	LBL.CAUTION SPRING
777S30018	777S30018	1	/P	LABEL-DECK SAFETY
777S30145	777S30145	1	S	USE 977S30145



Parking Brake And Linkage

Ref #	Part Number	Qty	S/P/F	Description
1	603-0649	1		Parking Brake Shift Ass'y
2	714-3004	1		Cotter Pin
3	710-3178	1	/P	Carriage Bolt 3/8-16 x .75
4	741-0324	1	S	Hex Flange Bearing .506 ID x .590
5	703-3400	1		Brake Mounting Bracket
6	747-3404	1		Connecting Brake Rod
7	714-0104	1	S	Cotter Pin
8	710-0134	1	/P	Carriage Screw 1/4-20 x .62
9	712-3027	1	S	Hex Flange Lock Nut 1/4-20
10	703-3405	1		Support Plate
11	714-0101	1	S	Cotter Pin
12	703-2857	1		Retaining Rod Bracket
13	732-0827	1		Torsion Spring 5/16
14	747-3397	1		Parking Brake Retaining Rod
15	735-0664	1		Parking Brake Pad
16	603-0683	1		Brake Rod Ass'y
17	711-3357	1	S	Ferrule
18	712-0314	1		Jam Nut 1/4-28
19	736-0258	1	/P	Flat Washer .385 ID x 1.0 OD
20	712-0431	1	S	Flange Lock Nut 3/8-16
21	747-3266A	1	/P	Bracket Rod
22	732-0463	1	S	Extension Spring
23	732-0800	1		Extension Spring
24	747-3284	1		Release Pump Rod RH
25	747-3363	1		Release Pump Rod LH



364
Seat Assembly

Page 43 of 43

Ref #	Part Number	Qty	S/P/F	Description
1	757-0375B	1	S	Seat Ass'y
2	757-3009	1		Seat Arm Ass'y (If Equipped)
3	731-3154	1		Seat Slide
4	710-1260A	1	/P	Hex Washer Screw 5/16-18 x .750
5	738-0372	1	S	Shoulder Spacer
6	720-0190	1	S	Height Adjuster Knob
7	732-3098	1		Spring Index
8	712-3004A	1	/P	Flange Lock Nut 5/16-18
9	603-0294	1	S	Seat Base Bracket Ass'y
10	710-0788	1	/P	Hex Washer Screw 1/4-20 x 1.0
11	736-0463	1	S	Flat Washer .25 x .630
12	750-3274	1		Spacer
13	738-0296	1	S	Shoulder Screw
14	712-3005	1	S	Flange Lock Nut 3/8-16
15	732-3080	1	S	Compression Spring
16	750-0664	1		Spacer
17	603-0730	1	S	Seat Plate Ass'y
18	710-0560	1	/P	Hex Carriage Screw 3/8-16 x 1.75