


4000j Trimmer/Brushcutter UT-26022-B
Air Cleaner - Carburetor

Page 1 of 28




4000j Trimmer/Brushcutter UT-26022-B
Air Cleaner - Carburetor

Page 2 of 28

Ref #	Part Number	Qty	S/P/F	Description
1	0926039	1	S	Screw & Washer Torque Specs: 35-45 In/Lbs; 4-5 Nm
2	0926040	1		Cover, Cleaner
3	07753	1		Pal Nut
4	0926041	1		Holder
5	0926042	1		Element
6	07749	2		Screw & Washer Torque Specs: 35-45 In/Lbs; 4-5 Nm
7	0926043	1		Bracket
8	0926044	1		Base, Cleaner
9	07754	1		Label, Choke
10	0926045	1		Carburetor
11	0926046	1		Gasket, Carburetor
12	0926047	1		Primer Bulb
13	0926048	2		Screw & Washer Torque Specs: 35-45 In/Lbs; 4-5 Nm
14	0926049	1		Insulator
15	0926050	1		Gasket, Insulator

4000j Trimmer/Brushcutter UT-26022-B
Clutch

Page 3 of 28




4000j Trimmer/Brushcutter UT-26022-B
Clutch

Page 4 of 28

Ref #	Part Number	Qty	S/P/F	Description
1	GM030082	4	S	Bolt & Washer Torque Specs: 55-65 In/Lbs; 6.2-7.3 Nm
	GM400398	1		Clutch Case Assembly
2	GM040021	1		Washer
3	GM012302	1	S	Screw Torque Specs: 55-65 In/Lbs; 6.2-7.3 Nm
4	GM040119	1		Washer
5	GM406115	1		Clutch Case
6	GM062105	1	S	Snap Ring
7	GM070001	1		Bearing
8	GM062008	1	S	Snap Ring
9	GM406718	1		Clutch Drum
10	GM042802	2	/P	Washer
11	GM400609	1		Clutch Shoe Kit
12	GM407631	1		Clutch Spring
13	0926066	2		Bolt Torque Specs: 69-87 In/Lbs; 7.8-9.8 Nm
14	0926067	2		Washer
15	A08132A	1	/P	Stand Torque Specs: 55-65 In/Lbs; 6.2-7.3 Nm

4000j Trimmer/Brushcutter UT-26022-B
Deflector

Page 5 of 28




4000j Trimmer/Brushcutter UT-26022-B
Deflector

Page 6 of 28

Ref #	Part Number	Qty	S/P/F	Description
	GM24700A	1	/P	Blade Guard Assembly
1	GM245201	1		Bracket, Blade Guard
2	GM011417	2	/P	Screw Torque Specs: 25-35 In/Lbs; 2.8-4.0 Nm
3	GM040002	2		Washer Torque Specs: 25-35 In/Lbs; 2.8-4.0 Nm
4	GM247001	1	S	Guard
5	GM011423	4	S	Screw Torque Specs: 35-43 In/Lbs; 3.9-4.8 Nm
6	GM051012	2		Nut

4000j Trimmer/Brushcutter UT-26022-B
Driveshaft

Page 7 of 28




4000j Trimmer/Brushcutter UT-26022-B
Driveshaft

Page 8 of 28

Ref #	Part Number	Qty	S/P/F	Description
1	GM400373J	1	S	Driveshaft Tube Assembly (Model 4000J)
1	GM400373	1	S	Driveshaft Tube Assembly (Model 4000B)
2	GM400370	5		Bushing
3	A06261	1	/P	Grip
4	00737	2	/P	Spring
5	GM406717	1	/P	Driveshaft
6	GM410301	1		Hanger Assembly
7	GM050003	1		Nut Torque Specs: 5-30 In/Lbs; .5-3.4 Nm
8	GM041101	1	/P	Washer
9	GM010002	1	/P	Hex Bolt
10	GM400175	1		Harness

4000j Trimmer/Brushcutter UT-26022-B
Engine Internal

Page 9 of 28




4000j Trimmer/Brushcutter UT-26022-B
Engine Internal

Page 10 of 28

Ref #	Part Number	Qty	S/P/F	Description
1	0926013	1		Plug Guard
2	07723	1		Screw & Washer Torque Specs: 35-45 In/Lbs; 4-5 Nm
3	07763	1		Screw & Washer Torque Specs: 35-45 In/Lbs; 4-5 Nm
4	07723	1		Screw & Washer Torque Specs: 35-45 In/Lbs; 4-5 Nm
5	0926014	1		Top Cover
6	A0926016	1		Cylinder
7	0926018	1		Gasket, Cylinder
8	0926019	4		Bolt & Washer Torque Specs: 35-45 In/Lbs; 4-5 Nm
9	0926020	2		Stud
10	A0926021	1		Piston Assembly
11	0926023	1		Pin, Piston
12	0926024	2		Ring, Piston
13	0926025	2	/P	Clip, Piston Pin
14	0926026	1		Crankshaft
15	0926027	1	/P	Needle Bearing
16	0926028	1		Woodruff Key
17	07734	2		Nut Torque Specs: 69-87 In/Lbs; 7.8-9.8 Nm
18	07708	1	/P	Oil Seal
19	0926029	1		Case, Starter
20	0926030	2		Ball Bearing
21	07709	2		Dowel Pin
22	0926031	1		Case, Drive
23	0926032	4		Screw & Washer Torque Specs: 35-45 In/Lbs; 4-5 Nm
24	0926033	1		Oil Seal
25	0926034	1		Cover, Crankcase
26	0926035	2		Pad, Fuel Tank
27	07710	2		Dowel Pin
28	0926036	1		Case, Fan
29	07725	1		Clamp
30	0926038	4		Screw & Washer Torque Specs: 35-45 In/Lbs; 4-5 Nm

4000j Trimmer/Brushcutter UT-26022-B
Exhaust System


Page 11 of 28



4000j Trimmer/Brushcutter UT-26022-B
Exhaust System

Page 12 of 28


Ref #	Part Number	Qty	S/P/F	Description
1	0926053	1		Muffler Assembly
2	0926054	2		Screw & Washer
3	0926055	1		Tail Pipe Torque Specs: 35-45 In/Lbs; 4.5 Nm
4	0926056	1		Gasket, Tail Pipe Torque Specs: 35-45 In/Lbs; 4.5 Nm
5	0926057	1		Gasket, Muffler
6	0926058	1	S	Screw & Washer
7	0926059	2		Nut, Flange Torque Specs: 35-45 In/Lbs; 4.5 Nm
8	0926060	1		Screw & Washer Torque Specs: 35-45 In/Lbs; 4.5 Nm
9	0926061	1		Cover, Muffler
10	0926062	1	S	Screw & Washer Torque Specs: 35-45 In/Lbs; 4.5 Nm



4000j Trimmer/Brushcutter UT-26022-B
Fuel Tank

Page 14 of 28

Ref #	Part Number	Qty	S/P/F	Description
1	0926063	1		Fuel Tank Assembly
2	0926064	1		Tube, Fuel
3	0926065	1		Tube, Fuel
4	07789	1		Plug
5	07792	1		Bushing
6	07793	1		Filter, Fuel
7	07784	1		Cap, Fuel Tank
8	07794	1	/P	Screw & Washer Torque Specs: 35-45 In/Lbs; 4.5 Nm




4000j Trimmer/Brushcutter UT-26022-B
Gearcase

Page 16 of 28

Ref #	Part Number	Qty	S/P/F	Description
	GM410307	2	S	Gearcase Assembly
1	09142	1	/P	Bearing
2	GM300625	1	S	Gear Set Kit
3	GM406714	1		Shaft, Gear
4	09146	1	/P	Bearing
5	GM060007	1		Snap Ring
6	09143	1	/P	Bearing
7	GM400225	1	/P	Bolt 55-65 In/Lbs; 6.2-7.3 Nm
8	GM040007	1	S	Washer
9	GM041003	1	/P	Washer
10	GM406715	1	/P	Flange Washer
11	GM406716	1		Flange Washer
12	GM406729	1		Collar
13	09145	1	S	Bearing
14	GM300610	1	/P	Housing Set
15	GM286710	1		Grease Fitting
16	82459	1	/P	Screw, Self Tapping 35-45 In/Lbs; 4-5 Nm
17	825491	7	S	Screw, Self Tapping 55-65 In/Lbs; 6.2-7.3 Nm

4000j Trimmer/Brushcutter UT-26022-B
Handles

Page 17 of 28




4000j Trimmer/Brushcutter UT-26022-B
Handles

Page 18 of 28

Ref #	Part Number	Qty	S/P/F	Description
1	A08266	1	S	Handle Assembly R.H. Model 4000B
2	GM400386	1		Throttle Switch Assembly Model 4000B
3	GM040025	2	/P	Washer Model 4000B
4	GM012302	2	S	Screw Model 4000B Torque Specs: 5-20 In/Lbs; .5-2.3 Nm
5	GM405504	1		Grip R.H. Model 4000B
6	GM406801	1		Handle Model 4000B
7	GM403501	1		Tube W/Wire Harness Model 4000B
8	GM400374	1		Handle Joint Assembly Model 4000B
9	GM030101	4	S	Bolt Model 4000B Torque Specs: 25-35 In/Lbs; 2.8-4.0 Nm
10	GM406112	1		Handle Joint, Bottom Model 4000B Torque Specs: 35-43 In/Lbs; 3.9-4.8 Nm
11	GM012301	1	S	Screw & Washer Model 4000B
12	GM405506	2		Isolating Rubber Model 4000B
13	GM406113	1		Pipe Fitting Model 4000B
14	GM406114	1		Pipe Fitting Model 4000B Torque Specs: 25-35 In/Lbs; 2.8-4.0 Nm
15	GM406111	1		Handle Joint, Top Model 4000B
16	GM032803	4	/P	Bolt Model 4000B
17	GM400378	1		Handle Assembly L.H. Model 4000B
18	GM405505	1		Grip L.H. Model 4000B
19	A08475	1	S	Handle Assembly (Model 4000J)
20	GM306805	1	S	Handle (Model 4000J); Torque Specs: 55-65 In/Lbs; 6.2-7.3 Nm
21	GM300142	1	S/P	Grip (Model 4000J)
22	GM300629	1		Bracket Assembly (Model 4000J)
23	GM011309	1	S	Bolt (Model 4000J)

4000j Trimmer/Brushcutter UT-26022-B
Ignition

Page 19 of 28




4000j Trimmer/Brushcutter UT-26022-B
Ignition

Page 20 of 28

Ref #	Part Number	Qty	S/P/F	Description
1	0926051	1		Rotor
2	0926052	1		Ignition Coil
3	07737	1	/P	Plug Cap
4	07738	1		Grommet
5	07739	1		Grommet Cap
6	GM190036	1	/P	Spark Plug
7	07734	1		Nut Torque Specs: 69-87 In/Lbs; 7.8-9.8 Nm
8	GM030104	2		Screw & Washer Torque Specs: 35-45 In/Lbs; 4-5 Nm
9	07740	1		Wire Leads

4000j Trimmer/Brushcutter UT-26022-B
Optional Accessories

Page 21 of 28




4000j Trimmer/Brushcutter UT-26022-B
Optional Accessories

Page 22 of 28

Ref #	Part Number	Qty	S/P/F	Description
1	DG07800	1	/P	Fixed Line Head
2	GM325205	1		Arbor Bolt
3	DG07809	1	/P	Green Line .105 X 20"
4	A08323	1		Rotor Puller
5	GM309951	1		Pusher, Piston Pin
6	GM309732	1		Flywheel Holder
7	DG07815	1	/P	Saw Blade
8	DG07817	1		XRT Blade
?9	GM94110	1	/P	Cover, Blade
?10	DG08461	1	/P	50'/.095 Line/6" Spool (Not Shown)

4000j Trimmer/Brushcutter UT-26022-B
Starter

Page 23 of 28




4000j Trimmer/Brushcutter UT-26022-B
Starter

Page 24 of 28

Ref #	Part Number	Qty	S/P/F	Description
1	0926001	1		Starter Assembly
2	07772	1		Guide
3	GM287305	1	/P	Rope
4	GM287306	1	/P	Grip
5	0926002	1		Plate
6	0926003	1		Spring
7	0926004	1		Reel
8	0926005	1		Washer
9	0926006	1		Screw & Washer Torque Specs: 35-45 In/Lbs; 4-5 Nm
10	07734	1		Nut Torque Specs: 52-69 In/Lbs; 5.9-7.8 Nm
11	0926007	1		Pulley Assembly
12	0926008	1		Snap Ring
13	0926009	1		Spring, Return
14	0926010	1		Ratchet
15	0926011	4	/P	Screw & Washer Torque Specs: 35-45 In/Lbs; 4-5 Nm
16	0926012	1		Bracket
17	07778	1		Pad, Bracket

4000j Trimmer/Brushcutter UT-26022-B
Stringhead / Blade & Standard Tools

Page 25 of 28




4000j Trimmer/Brushcutter UT-26022-B
Stringhead / Blade & Standard Tools

Page 26 of 28

Ref #	Part Number	Qty	S/P/F	Description
	GM20735	1	S	6" TFC Head Assembly
1	GM300312	1	S	6" Head Body
2	GM226702	1	S	Arbor Bolt
3	GM166903	1		Spring Plate
4	GM167901	1	S	Spring
5	GM166903	1		Plate, Spring
6	GM305203	1		6" Spool
7	GM305202	1	S	6" Cap
8	DG07816	1	/P	Quad Blade
9	GM300190	1		Spanner Wrench
10	GM400605	1		Tool Kit

4000j Trimmer/Brushcutter UT-26022-B
Throttle Assembly

Page 27 of 28



4000j Trimmer/Brushcutter UT-26022-B
Throttle Assembly

Page 28 of 28

Ref #	Part Number	Qty	S/P/F	Description
1	A08423B	1	S	Throttle Assembly (4000j)
2	GM400386	1		Throttle Switch Assembly (4000b)
3	08197	1	S	Throttle Cable (4000j)
	GM287101	1	S	Throttle Cable (4000b)