

For Parts Call 606-678-9623 or 606-561-4983




**BACKPACK BLOWER
MODEL NO. BM08570
REPAIR SHEET**

www.mymowerparts.com

BLACK MAX BACKPACK BLOWER - MODEL NO. BM08570

FIGURE A




BLACK MAX BACKPACK BLOWER – MODEL NO. BM08570

PARTS LIST (FIGURE A)

KEY NO.	PART NUMBER	DESCRIPTION	QTY	KEY NO.	PART NUMBER	DESCRIPTION	QTY
1	580694002	Elbow Tube.....	1	14	300758006	Fuel Cap Assembly	1
2	580693002	Bellows.....	1	15	570547003	Backpack Frame	1
3	570543002	Straight Tube (Upper Tube)	1	16	570546001	Vibration Isolators	3
4	570564002	Nozzle (Lower Tube).....	1	17	678186002	Washer	4
5	518481002	Bushing	1	18	678109001	Spring Washer.....	4
6	518624003	Air Filter Cover	1	19	678190002	Hex Nut (1/4-20).....	4
7	580692003	Throttle Control Handle.....	1	20	308645001	Tube Clamp	3
8	900962003	Shoulder Harness Assembly	1	21	940734035	Starting Label.....	1
9	900963001	Waist Harness	1	22	940647032	Choke Label	1
10	900964001	Mesh Backing	1	23	940627005	Warning Label	1
11	518273002	Throttle Control Handle Screw.....	1		987000504	Operator's Manual (960702003).....	1
12	900972001	Cable Tie	2		12-12-08		
13	870174001	Spark Plug (Champion RCJ6Y).....	1		(REV:00)		

BLACK MAX BACKPACK BLOWER - MODEL NO. BM08570

FIGURE B



BLACK MAX BACKPACK BLOWER – MODEL NO. BM08570

PARTS LIST (FIGURE B)

KEY NO.	PART NUMBER	DESCRIPTION	QTY	KEY NO.	PART NUMBER	DESCRIPTION	QTY
1	678117001	Vacuum Door Hinge Spring	1	31	308004001	Pulley Assembly.....	1
2	650026002	Hinge Pin	1	32	901206001	Insulator Gasket.....	1
3	518268001	Vacuum Door Housing.....	1	33	640570016	Cylinder.....	1
4	660734001	Screw (M4 x 16 mm).....	2	34	630002021	Plate for Cylinder	1
5	518170001	Vacuum Door Hinge	1	35	660351002	Screw and Washer (M5 x 10 mm).....	2
6	660674001	Screw (#10-14 x 7/8 in.).....	10	36	660342001	Screw (M5 x 22 mm).....	2
7	518266006	Outer Volute Housing	1	37	900709001	Cylinder Gasket	1
8	678128002	Retaining Washer Nut.....	1	38	290702001	Ignition Lead Harness Assembly	1
9	678126001	Washer.....	2	39	660349001	Screw (M4 x 22 mm).....	2
10	518265001	Blower Fan.....	1	40	290178008	Coil & Boot Assembly	1
11	660759002	Screw (M5 x 8 mm Cap Hd.)	4	41	638183001	Muffler Gasket	1
12	678124001	Bushing Sleeve	4	42	900955003	Heat Shield	1
13	570544002	Vibration Isolator.....	4	43	300748016	Muffler Assembly	1
14	518270001	Inner Volute Housing.....	1	44	638027001	Heat Shield	1
15	678108001	Square Nut.....	2	45	660347001	Screw (M5 x 50 mm).....	2
16	308068002	Crankshaft Extension.....	1	46	308345005	Control Assembly (Inc. Key Nos. 47-60).....	1
17	678171002	Washer (2 mm).....	1	47	518272002	Throttle Control Housing (RH).....	1
18	570624001	Rubber Grommet.....	1	48	660665001	Screw (#8-14 x 19 mm).....	2
19	690688001	Woodruff Key (S43C)	1	49	660629001	Screw (#10-14 x 25 mm).....	1
20	640574001	Rotor	1	50	760363003	Switch	1
21	300749004	Crankcase Assembly	1	51	518150001	Trigger Lock	1
22	660454006	Bolt (M5 x 44 mm)	2	52	518255005	Trigger	1
23	518623001	Air Box Base	1	53	518160005	Cruise Lever.....	1
24	308054021	Carburetor Assembly.....	1	54	678125001	Washer.....	1
25	901552001	Heat Dam Gasket	1	55	660666001	Screw (#8-14 x 25 mm)	1
26	660344003	Screw and Washer (M5 x 31 mm).....	2	56	309993001	Throttle Cable Assembly.....	1
27	518596001	Heat Dam.....	1	57	518210002	Tube	1
28	518324004	Engine Shroud Housing	1	58	290703001	Lead Assembly (Red).....	1
29	660351001	Screw (M5 x 16 mm).....	4	59	290703002	Lead Assembly (Black)	1
30	308430007	Starter Assembly	1	60	518271002	Throttle Control Housing (LH)	1
				61	308342005	Fuel Tank Assembly	1