




Illustrated Parts List	2001-10
	I0102029

# 6022 SH B

954222695




Repair Parts Manual

Walk Mower

# REPAIR PARTS

## ROTARY LAWN MOWER - - MODEL NUMBER 6022SH (6022SHB)



# REPAIR PARTS

## ROTARY LAWN MOWER - - MODEL NUMBER 6022SH (6022SHB)

KEY NO.	PART NO.	DESCRIPTION
1	532 06 36-01	Locknut 1/4-20
2	532 17 65-63	Control Bar
3	<b>532 17 95-85</b>	Rope Guide
4	532 17 36-93	Upper Handle (with Foam Grip)
5	532 17 42-91	Lower Handle
6	532 06 36-01	Locknut 1/4-20
7	532 13 19-59	Handle Bolt 5/16-18
8	532 14 49-29	Hex Washer Head Screw 1/4-20 x 2-1/8
9	532 16 41-37	Throttle Control
11	532 13 31-07	Engine Zone Control Cable
12	532 75 00-97	Hex Washer Head Screw #10-24 x 1/2
13	532 12 51-62	Up-Stop Bracket
14	532 21 31-46	Cable Clamp
15	532 08 38-16	Screw #10 x 5/8
16	532 13 63-76	Handle Knob
19	532 05 17-93	Hairpin Cotter
21	532 16 58-58	Rear Deflector
22	532 06 64-26	Wire Tie
23	532 17 65-61	Discharge Guard
27	532 16 08-32	Torsion Spring
30	532 16 08-33	Hinge Rod
33	532 06 31-24	Locknut 5/16-18
34	532 17 44-13	Wheel Bracket Support (Left)
35	532 17 44-14	Wheel Bracket Support (Right)
36	532 16 57-04	Wheel Bracket Adjuster
39	532 16 85-99	Selector Spring
40	532 08 78-77	Selector Knob
43	819 11 22-22	Washer
44	532 16 08-28	Shoulder Bolt
45	532 75 20-63	Wheel Assembly (Rear)
46	532 08 39-23	Locknut 1/16-18

KEY NO.	PART NO.	DESCRIPTION
47	532 75 05-50	Wheel Assembly (Front)
48	532 05 71-43	Washer
50	532 07 74-00	Hubcap
51	874 76 05-14	Hex Head Bolt 5/16-18x
52	532 15 04-06	Hex Head Thread Rolling Screw 3/8-16 x 1
55	532 10 73-39	Danger Decal
59	532 17 65-65	Lawn Mower Housing (Includes Key #55)
61	532 85 15-14	Blade Adapter
62	532 14 11-14	22" Blade
63	532 85 10-74	Hardened Washer
64	532 85 02-63	Helical Lockwasher 3/8
65	532 85 10-84	Screw Hex Head 3/8-24 x 1-3/8 (Grade 8)
67	- - -	Engine, Briggs & Stratton, Model No. 12H802 (Order parts from engine manufacturer)
70	532 16 86-01	Axle Arm Assembly (LR)
71	532 16 86-02	Axle Arm Assembly (RR)
72	532 16 86-05	Axle Arm Assembly (LF)
73	532 16 86-04	Axle Arm Assembly (RF)
74	532 75 11-53	Nut
75	532 17 65-62	Plate, Mulcher
76	532 17 65-60	Clip, Closeout
77	874 76 04-12	Screw
78	532 16 42-65	Foam Grip
79	<b>532 06 15-37</b>	Washer
80	<b>532 13 20-04</b>	Nut, Hex 1/4-20
--	<b>532 18 03-11</b>	Owner's Manual (English/French)
--	532 16 23-00	Warning Decal (Not Shown)

**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm