


YT125



1. 1990


Spare parts

Pièces détachées

CHASIS
GROUND

Your tractor is equipped with a special alternator system. The lights are not connected to the battery but have their own electrical source. The brightness of the lights will change with the engine speed. At idle the lights will become dimmer. As the engine becomes faster the lights become brighter.

ELECTRICAL



**KEY PART
NO. NO.**

DESCRIPTION

1	532123198	Wing Nut, 1/4-20
2	819091016	Washer, 9/32 x 5/8 x 16 Ga
3	532102476	Guard, Terminal
4	872240460	Battery Bolt, Carriage 1/4-20 x 7-1/2
5	532121537	Battery
6	532124886	Battery Tray
7	532123827	Harness, Ignition
8	874760416	Nut, Crownlock 1/4 - 20
9	873680400	Bolt, Hex Fin 1/4 - 20 x 1
10	532110859	Harness, Light Socket
11	532124893	Bulb, Light
12	532105687	Tube, Battery Tray
13	532124756	Cable Tie
14	532104445	Switch, Interlock, Clutch
15	532124503	Cable, Battery (Battery to Solenoid)
16	532102972	Ignition Switch
18	532109788	Nut, Ignition
19	532122147	Key
20	532124564	Regulator
21	532110712	Switch, Light
22	873680400	Nut, Crownlock 1/4-20
24	811050600	Washer, Lock, Ext. Tooth - 3/4
27	532124773	Cable, Battery (Battery to Ground)
30	817021008	Screw, Tap. Hex Hd. No. 10-24 UNC
32	532109596	Clamp, Hose

**KEY PART
NO. NO.**

DESCRIPTION

35	874780408	Bolt, Hex 1/4-20 x 1/2 Gr. 5
37	874760412	Bolt, Hex 1/4-20 x 3/4
39	873220400	Nut, Hex 1/4-20
43	810040400	Lockwasher, 1/4
45	532108824	Fuse, 30 Amp.
46	532124900	Ammeter
47	532124901	Bracket, Ammeter
48	810101000	Lockwasher, No. 10
49	873911000	Nut
50	819070818	Washer, 7/32 x 1/2 x 18 Ga.
51	532102501	Loop, Wire Tiller Attachment
52	532124995	Clip, Insulated
55	532126016	Switch, PTO
56	532124932	Nut, Hex
57	532109787	Bezel, Ignition
58	532121305	Switch, Plunger
59	532121264	Caps, Battery Set
60	532121549	Decal, Battery
—	532124498	Operator's Manual (English)
—	532126891	Parts Manual (English)
—	532126834	Owner's Manual, Engine, Kawasaki (English)
—	532101539	Sheet - Instruction, Tractor 15° Slope (English)
—	532124499	Owners Manual (French)
—	532101572	Sheet, Instruction, Tractor 15° Slope (French)

YARD TRACTOR

Exploded view diagram of a mechanical assembly. The components are labeled A through Z, with their respective part numbers and quantities indicated.

- A:** 49
- B:** 57
- C:** 109, 113
- GG:** 76, 115, 74
- HH:** 124, 125
- F:** 53, 51, 51, 52
- G:** 59, 120, 114
- H:** 60, 62
- J:** 76, 34
- K:** 65
- L:** 50, 51, 52
- M:** 95, 34
- N:** 44, 123
- O:** 65
- R:** 72
- S:** 73, 34
- V:** 37, 110
- W:** 112, 49
- Y:** 103, 52
- Z:** 84, 52


For Husqvarna Parts Call 606-678-9623 or 606-561-4983

REPAIR PARTS

YARD TRACTOR

CHASSIS AND ENCLOSURES


KEY PART NO. NO.	DESCRIPTION	KEY PART NO. NO.	DESCRIPTION
1 532120068	Adjustment Knob	60 532123481	Bolt, Shoulder 1/4-20
2 532124485	Decal, Side Panel	62 873680400	Nut, Crownlock 1/4 - 20
3 532124905	Panel, Side, L.H.	65 817490608	Screw, Hex Wsh. Thdrol. 3/8 - 16 x 1/2
4 532124991	Dash Plate	66 532124294	Pan, Seat
5 532124182	Dashboard	67 532110356	Cap, Snap. Black
6 532104783	Dash Assembly, Lower	68 532110357	Washer, Cap, Snap
7 532109821	Decal, Instruction	69 817490608	Screw, Hex Wsh. Thdrol. 3/8 x 16 x 1/2
8 532110853	Bracket Assembly, R.H.	72 817431008	Screw, Hex Head Self Tapping, No.10 - 16 x 1/2 Type B
9 532106965	Plate, Support, Battery	73 874760532	Bolt, Hex 5/16-18 x 2 Gr 2
10 532124130	Support Assembly, Dash	74 873510500	Nut, Keps 5/16-18
12 532124480	Decal, Hood, L.H.	75 532105509	Bracket Assembly, Fender
13 532106784	Strap Assembly, Hinge, Rear	76 874180512	Screw, Mach. 5/16-18 x 3/4
14 532104618	Strap Assembly, Hinge, Front	79 532120822	Decal, Caution
15 532125007	Hood	81 532121794	Cover, Access
16 532124250	Lens, L.H.	82 819171912	Washer, 17/32 x 1-3/16 x 12 Ga.
17 532124251	Lens, R.H.	84 872270606	Bolt, Carriage 3/8 - 16 x 3/4
18 532124483	Decal, Grill	85 532108256	Pad, Footrest
19 532126689	Grill Assembly	86 874191008	Screw, Cross Recess Pan Hd.Machine 10-24 x 1/2
20 532126025	Support Assembly, Grill	87 810071000	Washer, Lock, No. 10
22 532124481	Decal, Hood, R.H.	88 532125004	Nut, Weld
23 532110852	Bracket Assembly, L.H.	89 532109808	Latch, Hood
24 532125063	Panel, Side, R.H.	90 874981020	Screw, Machine Cross Recess 10 - 24 x 1-1/4
25 532110828	Panel, Dash, R.H.	91 532007206	Spacer, Split 10 x 3/4
26 532125036	Footrest, R.H.	92 873731000	Nut, Keps 10-24
27 532121277	Chassis	93 532105511	Strap Assembly, Fender
28 532121306	Drawbar	94 532105513	Bracket, Pivot, Seat
30 532121248	Bushing, Snap	95 532105529	Bolt, Shoulder 5/16-18
31 532124118	Panel, Dash, L.H.	96 532105531	Nut, Push
32 532124722	Footrest, L.H.	97 819070818	Washer, 7/32 x 1/2 x 18 Ga .
33 532121144	Bolt, Shoulder	98 532109199	Decal, V-Belt Drive, Schematic
34 873680500	Locknut, Gripco, 5/16-18	101 532124485	Decal, Side Panel
36 532124800	Saddle	103 819131614	Washer, 13/32 x 1 x 14 Ga.
37 811030400	Lockwasher, 1/4 Int./Ext.	104 532124934	Grommet
39 532124720	Bushing, Steering	107 532110436	Grommet, Split
40 532106202	Reflector, Taillight	109 811050400	Lockwasher, 1/4 Int. Ext.
41 532124181	Spring, Compression	110 873490400	Wing Nut, 1/4-20
42 532124484	Decal, Fender	111 811050600	Lockwasher, 3/8 Ext. Tooth
43 532124186	Seat	112 532001260	Spacer
44 872170410	Bolt, Carriage 1/4 - 20 x 11/4	113 873220400	Nut, Hex 1/4 - 20
45 532124974	Fender	114 532121235	Spacer
46 532101892	Decal, Clutch/Brake	115 819111116	Washer, 11/32 x 11/16 x 16 Ga.
47 532005479	Plug, Button	116 532005320	Clip, Insulated
48 532008022	Plug, Dash	117 532124996	Clip, Insulated
49 873510400	Nut, Hex Keps 1/4 - 20 UNC (A)	119 532121251	Foam Strip
50 874760612	Bolt, Hex 3/8 - 16 x 3/4	120 819091216	Washer 9/32 x 3/4 x 16 Ga.
51 819131312	Washer, 13/32 x 13/16 x 12 Ga.	121 532121249	Spacer Split, 0.28 x 0.88
52 873680600	Nut, Crownlock 3/8 - 16	122 532121250	Spring, Compression
53 874760616	Bolt, Hex 3/8 - 16 x 1	123 532123976	Nut, Hex, Flanged 1/4-20 UNC
57 817490612	Screw, Hex Washer Hd. Thd. Rolling 3/8 - 16 x 3/4 Type TT	124 874641008	Screw, Slotted Pan Head, #10-32 x 1/2
58 532121236	Spacer	125 873951000	Nut, Keps, #10-32 UNF
59 874760440	Bolt, 1/4 - 20 x 2 1/2	126 532004171	Clip, Insulated



REPAIR PARTS

YARD TRACTOR

POWER AND MECHANICAL CONTROLS GROUP



For Husqvarna Parts Call 606-678-9623 or 606-561-4983

REPAIR PARTS

YARD TRACTOR

POWER AND MECHANICAL CONTROLS GROUP


KEY PART NO. NO.	DESCRIPTION	KEY PART NO. NO.	DESCRIPTION
1 532124872	Pedal Cover	39 532120183	Bearing, Nylon
2 532123102	Bracket Assembly, Clutch	40 532110447	Trunnion, Lift
3 532123816	Muffler	41 532124516	Shaft Assembly, Lift
4 532124055	Control, Throttle/Choke	42 532110807	Nut, Hex Special
5 532124462	Fuel Cap Assembly	43 532124670	Retainer Spring
7 532106020	Tank, Fuel	44 532109413	Grip, Handle
8 532123487	Hose Clamp	45 532122364	Plunger, Lever, Hand
9 532101335	Fuel Line	46 532124874	Spring
10 532123817	Engine 12.5 HP	47 532121002	Lever Assembly, Hand Kit (Include Key No. 21)
11 819131316	Washer, 13/32 x 13/16 x 16 Ga.	48 819211616	Washer, 21/32 x 1.00 x 16 Ga.
12 819131016	Washer 13/32 x 5/8 x 16 Ga.	49 532121891	Handle, Adjust, Lift
13 819112410	Washer 11/32 x 1 1/2 x 10 Ga.	50 812000022	E-Ring
14 532123934	Scale, Height Indicator	51 532006431	Pad, Spacer
15 810040500	Washer, Lock Hvy. Hel. Spring	54 532123789	Arm Assembly, Idler
16 874780516	Bolt, Fin Hex 5/16 - 18 UNC x 1	55 532123766	Pulley, Idler
17 532123935	Plug, Hole	56 873680600	Locknut, 3/8 - 16
18 872140606	Bolt, Carriage, 3/8-16 x 3/4	57 532110029	Link, Lift
21 532121006	Rod Assembly, Lever	58 532110729	Rod, Adjust, Lift
22 532104777	Retainer, Belt, Chassis, L.H.	59 532105706	Bearing
23 532110810	Trunnion, Stop, Depth	60 532123205	Retainer Belt
24 819151216	Washer, 15/32 x 3/4 x 16 Ga.	61 874760624	Bolt, Hex 3/8 - 16 x 1-1/2
25 812000037	Klip Ring	62 532110812	Washer, Hardened
26 817720410	Screw, Hex Washer Hd Thd. Cutting 1/4-20 x 5/8	63 812000039	Ring, Klip
27 532125637	Rod, Brake, Park	64 532105709	Spring, Return, Clutch
28 532071673	Plunger Cap	65 532105710	Link, Clutch
29 819292016	Washer, 29/32 x 1 - 1/4 x 16 Ga	66 876020412	Pin, Cotter 1/8 x 3/4
30 817490612	Screw, Hex Washer Thd Rolling 3/8- 1 6 x 3/4	73 873360700	Nut, Hex Jam 7/16 - 20
31 532124526	Button, Plunger	77 873350600	Nut, Hex Jam 3/8 - 16
32 819131312	Washer, 13/32 x 13/16 x 12 Ga.	78 532101326	Deflector, Muffler
33 876020308	Cotter Pin, 3/32 x 1/2	79 873680400	Screw, Spiderlock Hex Hd. #8 x 1/2
34 532125006	Screw, Hex Washer Hd. Thd. Rolling M8 x 1.25 x 25 MM	80 532006999	Clamp, Hose
35 532110448	Lift Link, Adjustable	81 874780624	Bolt, Hex Hd. 3/8 - 16 x 1-1/2
36 532122424	Shaft Asm. Pedal Foot	84 873710700	Nut, Crownlock 7/16-20
37 532001572	Roll Pin 3/16 x 1	85 532123110	Spark Arrestor Kit
		86 532126819	Filter, Fuel

For Husqvarna Parts Call 606-678-9623 or 606-561-4983

REPAIR PARTS

YARD TRACTOR

DRIVE




REPAIR PARTS

YARD TRACTOR

DRIVE


KEY PART NO. NO.	DESCRIPTION	KEY PART NO. NO.	DESCRIPTION
1	532109070 Retainer, Belt	25	532125005 Bolt, Hex 7/16 - 20 x 4
2	532108236 Bracket, Switch	26	810040700 Washer, Lock 7/16
3	817021008 Screw, Tap. Hex Hd. 10-24 x 1/2	27	874760644 Bolt, Hex 3/8-16 x 2 - 3/4
4	532105730 Keeper, Belt, Engine	28	532004470 Spacer
5	532125907 V-Belt, Drive	29	532106190 Clamp
6	819131316 Washer, 13/32 x 13/16 x 16 Ga.	30	532123770 Strap, Locator
7	532105864 Bracket, Suspension	31	532123662 Keeper, Belt, L. H.
11	873680600 Nut, Crownlock 3/8-16	32	532123663 Keeper, Belt, R.H.
14	872140606 Bolt, Carriage 3/8-16 x 3/4	33	532004921 Spring, Retainer
15	819171516 Washer, 17/32 x 15/16 x 16 Ga.	34	874760512 Bolt, Hex 5/16-18 x 3/4
16	532121599 Arm Assembly, Suspension, L.H.	35	873680500 Nut, Lock 5/16-18
17	532009135 Retainer, Spring	36	874760616 Bolt, Hex 3/8 -16 x 1
18	532123674 Idler, Flat	37	532108218 Clutch, Electric
19	873220800 Nut, Hex 1/2 -13	38	873980600 Nut, Centerlock Flange - 3/8-16
20	532106308 Trunnion, Lift, Lower	39	532126197 Washer, 15/32 x 1-1/2 x 1/4
22	532121598 Arm Assembly, Suspension, R.H.	40	532109169 Retainer, Clutch
23	532105848 Bolt, Shoulder 3/8 -16	42	532110739 Spring Washer
24	532109841 Pulley, Engine	43	872140506 Bolt, Carriage - 5/16-18 x 3/4
		44	532121218 Keeper, Belt, Engine
		45	819131312 Washer, 13/32 X 13/16 X 12 Ga.



REPAIR PARTS

YARD TRACTOR

STEERING, FRONT AXLE AND WHEELS



For Husqvarna Parts Call 606-678-9623 or 606-561-4983

REPAIR PARTS

YARD TRACTOR


STEERING, FRONT AXLE AND WHEELS

KEY PART NO. NO.	DESCRIPTION	KEY PART NO. NO.	DESCRIPTION
1 532124416	Insert, Steering Wheel	25 532074580	Spacer
2 873940800	Nut, Hex Toplock Jam 1/2-20	26 532071208	Bushing, Steering Rod
3 532100712	Washer, 17/32 x 2-1/4 x .160	27 532109432	Bracket Assembly, Steering
4 532124415	Steering Wheel, 13"	28 532108684	Gear, Sector
5 532100711	Adapter, Wheel, Steering	29 532106126	Woodruff Key, 3/16 x 3/4
6 812000029	Klip Ring	30 532101930	Washer, Hardened
7 532121749	Washer, 25/32 x 1 1/4 x 16 Ga.	31 532002882	Drive Pin, 3/16 X 1
8 532009040	Bearings, Wheel, Front	32 532124931	Bearing, Thrust
9 532106222	Tire, Rib Tread 15 x 6.00-6 (Tubeless)	33 532108683	Rod, Steering
10 532059904	Tube, Tire (not furnished with Tractor)	34 532105656	Spindle Assembly, L.H.
11 532124801	Rim Assembly, 6 Front (Inc. 2 each Key No. 8)	35 532122819	Screw, Special
12 532065139	Stem, Valve	36 873901000	Nut, Lock Flange, 5/8-11
13 532059192	Cap, Valve	37 532003366	Bearing
14 532108075	Axle Assembly, Front	38 532124836	Fitting, Grease
15 874761060	Bolt, Hex 5/8-11 x 3-3/4	39 532124577	Cover, Wheel, 6", Front
16 532105654	Spindle Assembly, R.H.	40 532000278	Grease Fitting
17 873810500	Nut, Hex 5/16-24	41 532121748	Washer, 25/32 x 1-5/8 x 16 Ga.
18 819272016	Washer, 27/32 X 1-1/4 X 16 Ga.	44 532105664	Support, Saddle, Front
19 532121334	Tie Rod	45 532105663	Support, Saddle, Rear
20 532110438	Bearing, Spacer	46 817490508	Screw, Hex Washer Thd. Rolling - 5/16-18 X 1/2
21 810040600	Lockwasher, 3/8	47 810040500	Lockwasher, 5/16
22 873610600	Nut, Hex 3/8-24	49 532109816	Nyliner, Snap In
23 532105727	Drag Link	50 532108685	Gear, Pinion
24 532109556	Shaft Assembly, Steering	51 819111216	Washer, 11/32 X 3/4 X 16 Ga.
		52 532121232	Spindle Cap

REPAIR PARTS

YARD TRACTOR

TRANSAXLE AND REAR WHEEL



REPAIR PARTS

YARD TRACTOR

TRANSAXLE AND REAR WHEEL

KEY PART NO. NO.	DESCRIPTION
1 532124723	Rim Assembly 8" Rear
2 532106268	Tire, 18 x 9.50 - 8 (Tubeless)
2A 532124926	Tube, Tire (not furnished with Tractor)
3 532109502	Spacer, Split
4 532123583	Key, Square 3/16 x 2.5
5 532124162	Transaxle, 6 Speed, Model No.4360-19
8 532121274	Knob, Control
9 876020412	Cotter Pin, 1/8 x 3/4
10 532106919	Plate, Rod, Shift
11 532124461	Rod, Shifter
12 532105700	Spring, Torsion
13 819151216	Washer, 15/32 x 3/4 x 16 Ga.
14 876020416	Pin, Cotter 1/8 x 1
15 532105701	Washer, Shift Plate
16 819091210	Washer, 9/32 x 3/4 x 10 Ga.
17 871040412	Bolt, Hex 1/4- 28 x 3/4, Gr.8
18 810040400	Washer, Lock 1/4
20 532106888	Spring, Rod, Brake
21 532110437	Rod, Brake
22 819131316	Washer, 13/32 x 13/16 x 16 Ga
23 532106157	Plate, Strap, Torque

KEY PART NO. NO.	DESCRIPTION
24 532110422	Spring, Brake Return
25 532124996	Clip
30 532121520	Strap, Torque
32 532109167	Bracket, Transaxle
34 812000028	Ring, Klip
35 532121749	Washer, 25/32 x 1-1/4 x 16 Ga.
37 532123666	Pulley, Transaxle
38 532059192	Cap, Valve
39 532065139	Stem, Valve
41 812000001	E-Ring
52 874760644	Bolt, Hex 3/8-16 x 2-3/4
53 873680600	Nut, Lock 3/8-16
55 874760612	Bolt, Hex 3/8 - 16 x 3/4
58 817490512	Screw, Hex Washer Hd. Thd Forming, Type TT 5/16 18 UNC x 3/4
74 532124578	Cap, Hub, Rear
75 873800600	Nut, Lock, Hex, Washer Insert, 3/8-16
76 532121748	Washer, 25/32 x 1-5/8 x 16 Ga.
77 874760616	Bolt, Hex 3/8-16 x 1
78 873350600	Nut, Hex Jam, 3/8 - 16

38" MOWER




REPAIR PARTS

YARD TRACTOR

38" MOWER


KEY PART NO. NO.	DESCRIPTION	KEY PART NO. NO.	DESCRIPTION
1 532106085	V-Belt	34 532109646	Bracket, Nose Roller, L.H.
2 532121458	Housing Assembly, Mower	35 532121687	Mandrel Assembly
3 532008417	Runner, R.H.	36 532100668	Plate, Support, Mandrel
4 873680600	Nut, Lock, 3/8-16	37 817490620	Screw - Hex Washer Hd. 3/8-16 x 1 1/4
5 819111216	Washer, 11/32 x 3/4 x 16 Ga.	38 819131210	Washer, 13/32 x 3/4 x 10 Ga.
6 872140505	Bolt, Carr., 5/16-18 x 5/8	39 532121263	Blade, 38"
7 532105896	Bracket, Deflector	40 819132012	Washer, 13/32 x 1-1/4 x 12 Ga.
8 532110452	Nut	41 810030600	Washer, Lock, 3/8
9 532106734	Spring, Deflector	42 874610624	Bolt, Hex 3/8-24 x 1-1/2 Gr.5
10 532106735	Rod, Hinge	43 532102727	Spring, Extension
11 532106736	Deflector, Shield	50 872140606	Bolt, Carriage 3/8-16 x 3/4
12 532108682	Decal, V-Belt Schematic	51 532110445	Plate, Support
13 532105304	Cap	54 532105857	Bracket, Susp., Rear, R.H.
14 532105662	Link, Parallel	55 532108673	Bracket, Susp., Rear, L.H.
15 532105744	Pin, Hinge, Front	63 819111016	Washer, 11/32 x 5/8 x 16 Ga.
16 532004921	Spring, Retainer	65 532125074	Runner, L.H.
18 532109835	Pin, Hinge, Rear	67 872140610	Bolt, Carr. 3/8-16 x 1-1/4
20 873680500	Nut, Lock 5/16-18	68 532121349	Decal, Warning
21 532109598	Bracket, Lift, R.H.	69 819131316	Washer, 13/32 x 13/16 x 16 Ga.
22 532109597	Bracket, Lift, L.H.	75 532109647	Bracket, Nose Roller, R.H.
23 872140506	Bolt, Carriage 5/16-18 x 3/4	76 532109776	Pin, Pivot
24 532109820	Decal, Instruction, Caution	77 532109729	Roller, Nose
25 532109503	Support, Arm	78 819151610	Washer, 15/32 x 1 x 10 Ga.
26 532109504	Stop, Deck, Front	79 819161616	Washer, 1/2 x 1 x 16 Ga.
27 532109984	Decal, Safety Standard (served)	80 874760512	Bolt, Hex 5/16-18 x 3/4
29 874760636	Bolt - 3/8-16 x 2 1/4	81 876020412	Cotter Pin, 1/8 x 3/4
30 532123552	Arm, Idler	532123928	Mower Assembly, Complete
31 532106902	Spacer		
32 532121316	Pulley, Idler		
33 532106513	Washer, Wear, 1/16		



REPAIR PARTS

LAWN TRACTOR TRANSAXLE FOOTE DANA - MODEL NUMBER 4360-19

TRANSAXLE



REPAIR PARTS

LAWN TRACTOR TRANSAXLE FOOTE DANA - MODEL NUMBER 4360-19

TRANSAXLE

KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	3865-A	Housing, Upper	38	4193	Assy., Gear, Comb., 12 T & 35 T
2	1919	Screw, Tapping 1/4 - 20 x .734 Lg.	39	3967	Shaft, Idler
3	1151	Ball, Detent	40	1708	Washer, Plain, .631 x 1.00 x .015
4	3626	Spring, Detent	41	3645	Sprocket, 9 T
5	3623	Screw, Set	42	3589	Gear, Bevel, 42 T
6	4458	Assembly, Shifter	43	3749	* Washer, Plain, .758 x 1.12 x .010
7	3789	V-Ring		3652	* Washer, Plain, .758 x 1.12 x .015
8	3907	Puck, Friction		3693	* Washer, Plain, .758 x 1.12 x .020
9	3906	Washer, Plain, .325 x .750 x .059		3653	* Washer, Plain, .758 x 1.12 x .025
10	1099	Ring, Retaining		3408	* Washer, Plain, .758 x 1.25 x .020
11	1959	* Washer, Plain, .632 x 1.00 x .010		3732	* Washer, Plain, .758 x 1.25 x .025
	1441	* Washer, Plain, .632 x 1.00 x .020		3184	* Washer, Plain, .758 x 1.25 x .031
	1423	* Washer, Plain, .632 x 1.00 x .026		3733	* Washer, Plain, .758 x 1.25 x .035
	1082	* Washer, Plain, .632 x 1.00 x .031		3198	* Washer, Plain, .758 x 1.25 x .040
	1424	* Washer, Plain, .632 x 1.00 x .036		3734	* Washer, Plain, .758 x 1.25 x .045
	1068	* Washer, Plain, .632 x 1.00 x .041		3735	* Washer, Plain, .758 x 1.25 x .050
	1425	* Washer, Plain, .632 x 1.00 x .046	44	3973	Shaft, Drive
	1358	* Washer, Plain, .632 x 1.00 x .050	45	3724	Screw, Tapping, 5/16 x 18 x 1.44 Lg.
	1145	* Washer, Plain, .632 x 1.00 x .060			
	1319	* Washer, Plain, .632 x 1.00 x .082	46	3707	Gear, Spur, 15 T
12	3312	O-Ring	47	3866	Gear, Spur, 20 T
13	3876	Washer, Plain, .632 x 1.38 x .046	48	3719	Gear, Spur, 25 T
14	1374	Key, Woodruff # 9	49	3868	Gear, Spur, 28 T
15	4171	Assembly, Kit, Input Shaft	50	3683	Gear, Spur, 31 T
16	3725	Pinion, Bevel, 14 T	51	1145	Washer, Plain, .632 x 1.00 x .060
17	3624	Ring, Retaining	52	3191	Seal, Felt
18	3625	Chain, 24 Pitches	53	3180	Washer, Plain, .758 x 1.25 x .062
19	1542	Bearing, Flange	54	3880	Axle, L.H.
20	3709	Gear, Spur, 14T	55	3871	Gear, Miter, 15 T
21	3631	Collar, Clutch	56	3656	Ring, Retaining
22	3828	Key, Clutch	57	3839	Gear, Spur, 32 T
23	1369	Key, Woodruff # 3	58	3919	Shaft, Cross
24	3976	Shaft, Intermediate	59	3726	Gear, Miter, 15 T
25	1375	Key, Woodruff # 61	60	3881	Axle, R.H.
26	3627	Ring, Retaining	61	3864-B	Housing, Lower
27	3830	Sprocket, 18 T	62	3920	Puck, Friction
28	3841	Spacer	63	3276	Disc, Brake
29	3787	Gear, Spur, 40 T	64	3758	Spacer
30	3785	Gear, Spur, 35 T	65	3916	Jaw, Brake
31	3876	Gear, Spur, 30 T	66	3843	Pig, Jowel
32	3783	Gear, Spur, 25 T	67	3915	Screw, Tapping, 5/16 - 18 x 2.25
33	3869	Gear, Spur, 22 T	68	3768	Lever, Actuating
34	3741	Gear, Spur, 19 T	69	3760	Washer, Plain, .321 x 1.00 x .055
35	3628	Washer, Plain, .640 x 1.37 x .061	70	3917	Bracket, Anti-Rotation
36	1423	Washer, Plain, .632 x 1.00 x .026	71	3847	Nut, Lock 5/16 - 24
37	3422	Spacer, .630 x 1.00 x .169	72	4300	Grease

* Use in various combinations to maintain proper clearances.

** Order Key No. 15.

For Husqvarna Parts Call 606-678-9623 or 606-561-4983



Husqvarna Forest & Garden Co.
A Division of White Consolidated Industries
907 W. Irving Park Rd.
Itasca, IL 60143

www.mymowerparts.com