




Illustrated Parts List	1990-01
	I9002003

Ride Mower

LT 125

HVLT 125 AE




Repair Parts Manual

For Husqvarna Parts Call 606-678-9623 or 606-561-4983

ORIGINAL FILE COPY

ELECTRICAL




KEY NO.	PART NO.	DESCRIPTION
1	532123198	Wing Nut 1/4-20
2	819091016	Washer 9/32 x 5/8 x 16 Ga
3	532102476	Guard-Terminal
4	872240460	Battery Bolt (Bolt-Carriage, Rd. Hd. Sq. Neck 1/4 20 x 7-1/21)
5	532121537	Battery
6	532124886	Battery Tray
7	532123827	Harness - Ignition (includes item 30 A)
10	532110859	Harness-Light Socket
11	532124893	Bulb-Light
12	532100541	Tube-Battery Tray
13	532124756	Cable Tie
14	532104445	Switch - Interlock - Clutch
15	532124503	Cable-Battery (Battery to Solenoid)
16	532102972	Ignition Switch
18	532109788	Nut - Ignition
19	532122147	Key
20	532109081	Solenoid
21	532110712	Switch-Light
22	873680400	Nut - Crownlock 1/4-20
24	532124780	Cable - Battery (Solenoid to Starter)
26	532124783	Terminal Cover (For Solenoid)
27	532124770	Cable-Battery (Battery to Ground)
30	817021008	Screw-Tap. Hex Hd. No. 10-24 UNC
30A	532109748	Relay
31	532124996	Clip-Fuel Line


KEY NO.	PART NO.	DESCRIPTION
32	532109596	Clamp-Hose
33	810090400	Lockwasher 1/4
34	873350400	Nut-Hex Jam 1/4-20
35	874780408	Bolt-Hex 1/4-20 x 1/2 Gr. 5
36	873510400	Nut - Keps, Hex 1/4-20
37	874760412	Bolt-Hex 1/4-20 x 3/4
39	873220400	Nut-Hex 1/4-20
40	811050400	Washer-Lock 1/4 Ext. Tooth
43	810040400	Lockwasher 1/4
45	532108824	Fuse-30 Amp.
46	532124900	Ammeter
47	532124901	Bracket-Ammeter
48	810101000	Lockwasher No. 10
49	873911000	Nut
50	819070818	Washer 7/32 x 1/2 x 18 Ga.
51	532102501	Loop-Wire Tiller Attachment
52	532124995	Clip - Insulated
53	811030400	Lockwasher - Int/Ext. Tooth, 1/4
54	532106315	Diode Assembly
55	532126016	Switch PTO
56	532124932	Nut-Hex
57	532109787	Bezel, Ignition
58	532121305	Switch, Plunger
59	532121264	Caps, Battery Set
60	532121549	Decal - Battery

ENCLOSURES

KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	532120068	Adjustment Knob	57	817490612	Screw - Hex Washer Hd. Thd. Rolling 3/8 - 16 x 3/4 Type TT
2	532126035	Decal - Side Panel			Spacer
2a	532125586	Decal - Side Panel, RH	58	532121236	Screw - Hex Washer Hd. Thd. Rolling 5/16-18 x 3/4 Type TT
3	532124845	Panel - Side, L.H.	59	817490512	Bolt - Shoulder 1/4-20
4	532124721	Dash Plate			Stud 1/4 Turn
5	532124182	Dashboard	60	532124815	Nut - Crownlock 1/4 - 20
6	532124846	Dash Assembly - Lower	61	532105751	Bolt - Hex 3/8 - 16 x 1-1/4
7	532109821	Decal - Instruction	62	873680400	Nut - Keps 3/8-16
8	532110853	Bracket Assembly R.H.	63	874760620	Screw - Hex Washer Hd. Thd. Forming - 3/8 - 16 x 1/2 Type TT
9	532106965	Plate - Support, Battery	64	873510600	Pan - Seat
10	532124130	Support Assembly - Dash	65	817490608	Muffler Guard
11	532121251	Foam Strip			Retainer - 1/4 Turn
12	532124297	Decal - Hood, L.H.	66	532124849	Receptacle - 1/4 Turn
13	532106784	Strap Assembly - Hinge, Rear	67	532108885	Washer - Lock, 3/8
14	532104618	Strap Assembly - Hinge, Front	68	532105838	Screw - Hex Head Self Tapping, No. 10 - 16 x 1/2 Type B
15	532125007	Hood	69	532105839	Bolt-Hex 5/16-18 x 2 Gr 2
16	532104613	Bezel Assembly	70	810040600	Nut - Keps 5/16-18
17	532106395	Lens	72	817431008	Bracket Assembly - Fender
18	532110855	Support - Grill, L.H.			Screw - Mach. 5/16-18 x 3/4
19	532126689	Grill Assembly	73	874760532	Screw-Hex Washer Hd. 1/4-20 x 3/4
20	532105419	Strap - Grill	74	873510500	Decal - OPEI, Caution
21	532110854	Support - Grill, R.H.	75	532105509	Cover - Access
22	532124298	Decal - Hood, R.H.	76	874180512	Washer - 17/32 x 1-1/16 x 20 Ga.
23	532110852	Bracket Assembly L.H.	78	817190412	Washer 13/32 x 3/4 x 12 Ga.
24	532124847	Panel - Side, R.H.	79	532120822	Bolt - Carriage 3/8 - 16 x 3/4
25	532110828	Panel - Dash, R.H.	81	532121794	Pad - Footrest
26	532105464	Footrest - R.H.	82	819171720	Screw - Cross Recess Pan Hd. Machine 10-24 x 1/2
27	532121277	Chassis	83	819131212	Washer - Lock, No. 10
28	532121306	Drawbar	84	872140606	Nut - Weld
29	532121248	Bushing Snap	85	532121251	Latch - Hood
31	532124850	Panel - Dash, L.H.	86	874191008	Screw - Machine Cross Recess 10 - 24 x 1-1/4
32	532105465	Footrest - L.H.			Spacer - Split 10 x 3/4
33	532121144	Shoulder Bolt	87	810071000	Nut - Keps 10-24
34	873680500	Locknut - Gripco, 5/16-18	88	532125004	Strap Assembly - Fender
35	819151616	Washer 15/32 x 1 x 16 Ga.	89	532109808	Bracket - Pivot, Seat
36	532124848	Saddle	90	874981020	Bolt - Shoulder 5/16-18
37	811030400	Lock Washer 1/4 Int./Ext.	91	532007206	Nut - Push
38	532124720	Bushing - Steering	92	873731000	Washer 7/32 x 1/2 x 18 Ga.
40	532106202	Reflector - Tail light	93	532105511	Decal - V-Belt Drive, Schematic, Tractor
41	532124181	Spring - Compression	94	532105513	Baffle-Rear, Upper
42	532125584	Decal - Fender	95	532105529	Baffle-Rear, Lower
43	532124186	Seat	96	532105531	Decal - Strip
44	872170410	Bolt, Roundhead 1/4 - 20 x 11/4	97	819070818	Washer 13/32 x 1 x 14 Ga.
45	532124749	Fender	98	532109199	Grommet
46	532126677	Decal - Clutch/Brake	99	532109740	Screw - Hex Washer Hd., Thd. Rolling 3/8 - 16 x 1
47	532005479	Plug - Button	100	532108105	Washer - Lock 1/4
48	810090400	Washer - Lock 1/4	101	532121589	Grommet
49	873490400	Wing Nut 1/4 - 20	103	819131614	Screw - Slotted Pan Head, #10-32 x 1/2
50	874760612	Bolt - Hex 3/8 - 16 x 3/4	104	532124934	Nut - Keps, #10-32 UNF
51	819131312	Washer 13/32 x 13/16 x 12 Ga.	105	817490616	Clip - Insulated *
52	873680600	Nut - Crownlock 3/8 - 16	106	810040400	Bracket - Switch Mount
53	874760616	Bolt - Hex 3/8 - 16 x 1	107	532110436	
54	819131616	Washer 13/32 X 1 X 16 Ga.	108	532121251	
55	817211010	Screw - Hex Washer Hd. Tapping 10 - 16 x 5/8	109	811050400	
56	532104755	"J" Fastener	110	873490400	
			111	811050600	
			112	819091216	
			113	873220400	
			115	819111116	
			116	532005320	
			117	532124966	
			118	819111212	
			119	532121251	
			120	819111216	
			121	532121249	
			122	532121250	
			123	532123976	
			124	874641008	
			125	873951000	
			126	532004171	
			127	532121246	



POWER & MECHANICAL CONTROLS GROUP



- | | | | | | | | |
|----------|----------|----------|----------|----------|----------|----------|----------|
| A | B | C | D | E | F | G | H |
| 6 | 26 | 34 | 18 | 30 | 14 | 70 | 13 |
| | 72 | | 56 | 32 | 14 | 71 | 83 |
| | | | | | 13 | | 12 |

85
OPTIONAL EQUIPMENT
 Spark Arrester Kit

For Husqvarna Parts Call 606-678-9623 or 606-561-4983

www.mymowerparts.com


POWER & MECHANICAL CONTROLS GROUP

KEY PART NO.	PART NO.	DESCRIPTION	KEY PART NO.	PART NO.	DESCRIPTION
1	532124872	Pedal Cover	44	532109413	Grip- Handle
2	532123102	Bracket Assembly - Clutch	45	532122364	Plunger- Lever, Hand
3	532125799	Muffler	45	532124526	Button - Plunger
4	532124055	Control, Throttle/Choke	46	532124874	Spring
5	532124462	Fuel-Cap Assembly	47	532121002	Lever Assembly, Hand Kit (Include Key No. 21)
6	817020806	Screw - Hex Hd. Thd. Cutting 8-32 x 3/8, Type T	48	819211616	Washer 21/32 x 1 x 16 Ga.
7	532106020	Tank-Fuel	49	532121891	Handle - Adjust, Lift
8	532123487	Hose Clamp	50	812000022	E-Ring
9	532005277	Fuel Line	51	532006431	Pad - Spacer
10	532400707	Engine 14 HP, Type No. 1211-01 <i>B & S</i>	54	532123789	Bellcrank Assembly
11	819131316	Washer 13/32 x 5/8 x 16 Ga.	55	532123766	Pulley - Idler
16	813280336	Std. Pipe Nipple	56	873680600	Locknut 3/8 - 16
17	813200300	90 Elbow 3/8 NPT	57	532110029	Link - Lift
18	872140606	Bolt Rd. Hd Sq. Neck 3/8 16 x 3/4	58	532110729	Rod-Adjust, Lift
19	532008545	Gasket, Muffler	59	532105706	Bearing
21	532121006	Rod Assembly - Lever	60	532123205	Retainer Belt
22	532104777	Retainer. Belt, Chassis, L.H.	61	874760624	Bolt - Hex 3/8 - 16 x 1-1/2
23	532110810	Trunnion - Stop, Depth	62	532110812	Washer- Hardened
24	819151216	Washer 15/32 x 3/4 x 16 Ga.	63	812000039	Ring- Klip
25	812000037	Klip Ring	64	532105709	Spring- Return, Clutch
26	817720410	Screw- Hex Washer Hd Thd. Cutting 1/4-20 x 1/2	65	532105710	Link- Clutch
27	532105844	Rod- Brake, Park	66	876020412	Pin- Cotter 1/8 x 3/4
28	532071673	Plunger Cap	68	532003645	Bushing
29	819292016	Washer 29/32 x 1 - 1/4 x 16 Ga	69	532008710	Stem-Tank, Fuel
30	817490612	Screw - Hex Washer Thd Rolling 3/8- 1 6 x 3/4	70	874780408	Bolt - Hex 1/4 - 20 x 1/2
31	532104917	Baffle . Vertical	71	810040400	Lockwasher 1/4
32	819131312	Washer 13/32 x 13/16 x 12 Ga.	73	873360700	Nut Hex Jam 7/16 - 20
33	876020308	Cotter Pin 3/32 x 1/2	74	874780412	Bolt - Hex 1/4 - 20 x 1/4
34	532125005	Screw - Hex Washer Hd. Thd. Rolling 3/8-16 x 1-1/4 Type TT	75	532100229	Tube Assembly - Exhaust
35	532110448	Lift Link - Adjustable	76	532091084	Plug - Oil Drain
36	532122424	Shaft Pedal Foot	77	873350600	Nut - Hex Jam 3/8 - 16
37	532001572	Roll Pin 3/16 x 1	78	532110013	Bracket - Heat Shield
39	532120183	Bearing, Nylon	79	532110012	Heat Shield
40	532110447	Trunnion, Lift	80	817490508	Bolt - Hex Thread Cutting 5/16 - 18 x 1/2
41	532124516	Shaft Assembly- Lift	81	874780624	Bolt, Hex Hd. 3/8 - 16 x 1-1/2
42	532110807	Nut - Hex Special	82	532005320	Clip, Insulated
43	532124670	Retainer Spring	83	873510600	Nut, Keps 3/8 - 16
			84	873710700	Nut, Crownlock 7/16-20
			85	532124803	Spark Arrestor Kit

www.mymowerparts.com

For Husqvarna Parts Call 606-678-9623 or 606-561-4983


DRIVE GROUP



4A

DRIVE GROUP


KEY PART NO.	PART NO.	DESCRIPTION
1	532109070	Retainer Belt
2	532108236	Bracket- Switch
3	817021008	Screw-Tap. Hex Hd. 10-24 x 1/2
4	532105730	Keeper- Belt, Engine
4a	532121218	Keeper- Belt, Engine
5	532125907	V-Belt, Drive
6	819131312	Washer 13/32 x 13/16 x 12 Ga.
7	532105864	Bracket - Suspension
11	873680600	Nut - Crownlock 3/8-16
14	872140606	Bolt - Rd. Hd. Sq. Neck 3/8-16 x 3/4
15	819171516	Washer 17/32 x 15/16 x 16 Ga.
16	532121599	Arm Assembly - Suspension, L.H.
17	532009135	Retainer - Spring
18	532123674	Idler - Flat
19	873220800	Nut - Hex 1/2-13
20	532106308	Trunnion - Lift, Lower
22	532121598	Arm Assembly - Suspension, R.H.
23	532105848	Bolt - Shoulder 3/8-16
24	532109841	Pulley- Engine
25	532125005	Bolt - Hex 7/16-20 x 4
26	810040700	Washer- Lock 7/16
27	874760644	Bolt - Hex 3/8-16 x 2 - 3/4
28	532004470	Spacer
29	532106190	Clamp
30	532123770	Strap - Locator
31	532123662	Keeper - Belt, L. H.
32	532123663	Keeper - Belt, R. H.
33	532004921	Spring - Retainer
34	874760512	Bolt - Hex 5/16-18 x 3/4
35	873680500	Nut - Lock 5/16-18
36	874760616	Bolt - Hex 3/8-16 x 1
37	532108218	Clutch - Electric
38	873980600	Centerlock Flange Nut - 3/8-16
39	532126197	Washer - 15/32 x 1-3/8 x 1/4
40	532109169	Locator - Clutch
41	819382616	Washer
42	532110739	Spring Washer
43	872140506	Bolt Rd. Sq. Neck - 5/16-18 x 3/4



STEERING, FRONT AXLE AND WHEELS

KEY NO.	PART NO.	DESCRIPTION
1	532124416	Insert - Steering Wheel
2	873940800	Nut - Hex Toplock Jam 1/2-20
3	532100712	Washer 17/32 x 2-1/4 x .160
4	532124415	Steering Wheel - 13"
5	532100711	Adapter - Wheel, Steering
6	812000029	Klip Ring
7	532121749	Washer - 25/32 x 1 1/4 x 16 Ga.
8	532009040	Bearings - Wheel, Front
9	532106222	Tire - Rib Tread 15 x 6.00-6 (Tubeless)
10	532059904	Tube - Tire (not furnished with Tractor)
11	532106732	Rim Assembly - 6 Front (Inc. 2 each Key No. 8)
12	532065139	Stem - Valve
13	532059192	Cap - Valve
14	532108075	Axle Assembly - Front
15	874761060	Bolt - Hex 5/8-11 x 3-3/4
16	532105654	Spindle Assembly. - R.H.
17	873810500	Nut- Hex 5/16-24
18	819272016	Washer - 27/32 X 1-1/4 X 16 Ga.
19	532121334	Tie Rod
20	532110438	Bearing
21	810040600	Lockwasher - 3/8
22	873610600	Nut - Hex 3/8-24
23	532105727	Drag Link
24	532109557	Shaft Assembly - Steering
25	532074580	Spacer
26	871253208	Bushing - Steering Rod
27	532109432	Bracket Assembly - Steering
28	532108684	Gear - Sector
29	532106126	Woodruff Key - 3/16 x 3/4
30	532101930	Washer - Hardened
31	532002882	Drive Pin - 3/16 X 1
32	532124931	Bearing - Thrust
33	532108683	Rod - Steering
34	532105656	Spindle Assembly - L.H.
35	532122819	Screw - Hex Washer Hd. - Thread Forming - Type TT - 3/8 - 16 x 3/4
36	873901000	Nut- Lock Flange, 5/8-11
37	532003366	Bearing
39	532124577	Cover - Wheel, 6", Front
40	532000278	Grease Fitting
41	532121748	Washer 25/32 x 1-5/8 x 16 Ga.
42	532106943	Spacer - Shaft, Steering
43	532106945	Tube - Shaft, Steering
44	532105664	Support - Saddle, Front
45	532105663	Support - Saddle, Rear
46	817490508	Screw - Hex Washer Thd. Rolling - 5/16-18 X 1/2
47	810040500	Lockwasher - 5/16
48	817490616	Screw - Hex Washer Hd. Thread Forming - Type TT - 3/8-16 x 1
49	532109816	Nyliner - Snap In
50	532108685	Gear - Pinion
51	819111216	Washer -11/32 X 3/4 X 16 Ga.
52	532121232	Spindle Cap


TRANSAXLE AND REAR WHEEL



For Husqvarna Parts Call 606-678-9623 or 606-561-4983

TRANSAXLE AND REAR WHEEL

KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	532106108	Rim Assembly 8" Rear	24	532110422	Spring - Brake Return
2	532106268	Tire 18 x 9.50 - 8 (Tubeless)	25	532124996	Clip
2A	532124926	Tube - Tire (not furnished with Tractor)	30	532105842	Strap - Torque
3	532109502	Spacer - Split	32	532109167	Bracket - Transaxle
4	532123583	Key - Square 3/16 x 2	34	812000028	Ring - Klip
5	532109978	Transaxle - 6 Speed, Model No.4150-61	35	532121749	Washer - 25/32 x 1-1/4 x 16 Ga. (2 to 4 as required)
8	532121274	Knob - Control	36	532125096	Woodruff Key - 3/16 x 34
9	876020412	Cotter Pin - 1/8 x 3/4	87	532123666	Pulley -Transaxle
10	532108843	Plate - Rod, Shift	38	532059192	Cap - Valve
11	532124379	Rod - Shifter	39	532065139	Stem - Valve
12	532105700	Spring - Torsion	41	812000001	E-Ring
13	819151216	Washer 15/32 x 3/4 x 16 Ga.	52	874760644	Bolt - Hex 3/8-16 x 2-3/4
14	876020416	Pin, Cotter 1/8 x 1	53	873680600	Nut - Lock 3/8-16
15	532106362	Washer - Shift Plate	55	874760612	Bolt- Hex 3/8 - 16 x 3/4
16	819091210	Washer 9/32 x 3/4 x 10 Ga.	58	817490512	Screw Hex Washer Hd. Thd Forming, Type TT 5/16 18 UNC x 3/4
17	871040412	Bolt - Hex 1/4- 28 x 3/4, Gr.8	74	532124578	Cap - Hub, Rear
18	810040400	Washer - Lock 1/4	75	873680600	Nut- Centerlock 3/8-16
20	532106888	Spring- Rod, Brake	76	532121748	Washer 25/32 x 1-5/8 x 16 Ga.
21	532110437	Rod - Brake	77	874760616	Bolt - Hex 3/8-16 x 1
22	819131316	Washer 13/32 x 13/16 x 16 Ga	78	873350600	Nut - Hex Jam, 3/8 - 16
23	532106157	Plate - Strap, Torque			



www.mytractorparts.com

For Husqvarna Parts Call 606-678-9623 or 606-561-4983

38" MOWER

PART NO.	DESCRIPTION	KEY PART NO.	DESCRIPTION
1 532106085	V-Belt	33 532106513	Washer - Wear, 1/16
2 532121259	Housing Assembly - Mower	34 532109646	Bracket - Nose Roller, L.H.
3 532008417	Runner - R.H.	35 532121687	Mandrel Assembly
4 873680600	Nut - Lock, 3/8-16	36 532100668	Plate - Support, Mandrel
5 819111216	Washer - 11/32 x 3/4 x 16 Ga.	37 817490614	Screw - Hex Washer Hd. 3/8-16 x 7/8
6 872140505	Bolt - Rd. Hd. Sq. Neck., 5/16-18 x 5/8	39 532121263	Blade - 38"
7 532105896	Bracket - Deflector	40 819132012	Washer - 13/32 x 1-1/4 x 12 Ga.
8 532110452	Nut	41 810030600	Washer - Lock, 3/8
9 532106734	Spring - Deflector	42 874610624	Bolt - Hex 3/8-24 x 1-1/2 Gr.5
10 532106735	Rod - Hinge	43 532108250	Spring - Ext.
11 532106736	Deflector - Shield	50 872140606	Bolt - Rd. Hd. Sq. Neckiage 3/8-16 x 3/4
12 532105814	Decal - V-Belt Schematic	51 532110445	Plate - Support
13 532105304	Cap	54 532105857	Bracket - Suspension., Rear, R.H.
14 532105662	Link - Parallel	55 532108673	Bracket - Suspension., Rear, L.H.
15 532105744	Pin - Hinge, Front	63 819111016	Washer - 11/32 x 5/8 x 16 Ga.
16 532004921	Spring - Retainer	65 532125074	Runner - L.H.
18 532109835	Pin - Hinge, Rear	67 872140610	Bolt - Rd. Hd. Sq. Neck. 3/8-16 x 1-1/4
20 873680500	Nut - Lock 5/16-18	68 532121349	Decal - Warning
21 532109598	Bracket - Lift, R.H.	69 819131316	Washer - 13/32 x 13/16 x 16 Ga.
22 532109597	Bracket - Lift, L.H.	71 819141610	Washer - 7/16 x 1 x 10 Ga.
23 872140506	Bolt - Rd. Hd. Sq. Neckiage 5/16-18 x 3/4	72 872110606	Bolt - Rd. Hd. Sq. Neckiage 3/8-16 x 3/4
24 532109820	Instruction - Caution Decal	75 532109647	Bracket - Nose Roller, R.H.
532109503	Support - Arm	76 532109776	Pin - Pivot
532109504	Stop - Deck, Front	77 532109729	Roller - Nose
532126192	Decal - Safety Standard (Model YT140CR)	78 819151610	Washer - 15/32 x 1 x 10 Ga.
29 874760632	Bolt - 3/8-16 x 2	79 819151616	Washer - 15/32 x 1 x 16 Ga.
30 532123552	Arm - Idler	80 874760512	Bolt - Hex 5/16-18 x 3/4
31 532106902	Spacer	81 876020412	Cotter Pin - 1/8 x 3/4
32 532121316	Pulley - Idler		

