

For Husqvarna Parts Call 606-678-9623 or 606-561-4983



**Illustrated Parts
List**

LT 125


H 12538 C

Ride Mower

For Husqvarna Parts Call 606-678-9623 or 606-561-4983
REPAIR PARTS

12.5 HP 38" RIDING LAWN TRACTOR -- MODEL NO. LT125
ELECTRICAL

H 12538C



REPAIR PARTS


12.5 HP 38" RIDING LAWN TRACTOR -- MODEL NO. LT125

H12538C

ELECTRICAL

KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	532123198	Wing Nut 1/4 - 20	30	874760412	Bolt, Hex 1/4 - 20 x 3/4
2	819091016	Washer 9/32 x 5/8 x16 Ga.	31	873220400	Nut, Hex 1/4 - 20
3	532102476	Terminal Guard	32	811050400	Washer, Lock 1/4 - 20 Ext. Tooth
4	872240460	Carriage Bolt 1/4 - 20 x 7-1/2	33	532108824	Fuse
5	532121265	Battery (Shipped Dry, Purchase Battery Acid Locally)	34	532124900	Ammeter
6	532124886	Battery Tray	35	532124901	Bracket, Ammeter
7	532127332	Ignition Harness	36	810101000	Washer, Lock Ext. 3/4
8	532110859	Harness, Light Socket	37	873911000	Nut
9	532124893	Light Bulb	38	819070818	Washer, 7/32 x 1/2 x 18 Ga.
10	532124924	Tube, Battery Tray	39	532102501	Loop, Wire
11	532124756	Cable Tie	40	532124995	Clip, Insulated
12	532109553	Switch, Interlock, Attachment Clutch	41	874641008	Slotted Pan Head Screw #10-32
13	532124770	Cable, Battery (Battery to Solenoid)	42	532104445	Switch, Interlock, Clutch Pedal
14	532125104	Switch, Ignition	43	871031008	Hex Washer Head Screw
15	532109788	Nut, Ignition	44	873350400	Nut, Keps #10-32 UNF
16	532122147	Key	45	532109787	Bezel, Ignition
17	532109081	Solenoid	46	532121305	Switch, Plunger
18	532110712	Switch, Light	47	817021008	Screw, Hex Tapping #10-24 x 1/2
19	873680400	Nut, Hex 1/4 - 20	48	532121264	Battery Caps Set
20	532124967	Clip Wire	50	810090400	Washer, Lock 1/4
21	532124780	Cable, Battery (Solenoid to Starter)	51	873951000	Nut, Keps
22	532124783	Terminal Cover (For Solenoid)	--	532121549	Decal, Battery, Caution
23	532124773	Cable, Battery (Battery to Ground)	--	532127227	Manual, Operators (English)
24	874780408	Screw 10/32 x 1/2 Pan Head UNF	--	532127694	Manual, Operator's (French) <i>N/L</i>
25	532109596	Clamp, Hose	--	532127294	Manual, Parts (English)
26	810040400	Lock Washer 1/4	--	532127800	Manual, Parts (French) <i>N/L</i>
27	811050600	Washer, Lock Ext. Tooth	--	532101539	Sheet, Instruction, Tractor 15 Slope (English)
28	874780408	Bolt, Hex 1/4 - 20 x 1/2 Gr. 5	--	532101572	Sheet, Instruction, Tractor 15 Slope (French)
29	873510400	Nut, Keps, Hex 1/4- 20			

NOTE: All component dimensions given in U.S. inches.
1 inch = 25.4 mm




For Husqvarna Parts Call 606-678-9623 or 606-561-4983

REPAIR PARTS

12.5 HP 38" RIDING LAWN TRACTOR - - MODEL NO. LT125


H12538C

ENCLOSURES



ENCLOSURES

KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	810040400	Washer, Lock 1/4	55	817431008	Screw, Hex Head Self Tapping #10-16 x 1/2 Type B
2	873510400	Nut, Hex Keps 1/4-20	56	874780512	Bolt, Hex 5/16-18 x 3/4 Gr. 5
3	532124905	Panel, Side L.H.	57	873510500	Nut, Keps 5/16-18
4	532124948	Plate, Dashboard	58	532105509	Bracket Assembly, Fender
5	532124182	Dashboard	59	874180512	Screw, Truss Hd. 5/16-18 x 3/4
6	532104783	Dash, Lower	62	532121441	Guide, Belt, Lower, Engine, Pulley, R.H.
7	532127321	Grill Assembly	63	532121794	Cover, Access
8	532106965	Plate, Support, Battery	64	819132012	Washer 13/32 x 1-1/4 x 12 Ga.
9	532104786	Support Assembly, Dash	65	872140606	Bolt, Carriage 3/8-16 x 3/4
10	532104915	Foam, Strip	66	532108256	Pad, Footrest
11	532110356	Cap, Snap	67	874191008	Screw, Cross Recess Pan Hd. Mach. #10 - 24 x 1/2
12	532106784	Strap Assembly, Hinge, Rear	68	810071000	Washer, Lock #10
13	532104618	Strap Assembly, Hinge, Front	69	532125004	Nut, Weld
14	532125007	Hood	70	532109808	Latch, Hood
15	532124250	Lens, L.H.	71	874981020	Screw, Machine Cross Recess #10 - 24 x 1 - 1/4
16	532124251	Lens, R.H.	72	532007206	Spacer, Split #10 x 3/4
17	532121610	Bracket Assembly Frame Pivot L.H.	73	873731000	Nut, Keps #10 - 24
18	532127324	Grill	74	532105511	Strap Assembly, Fender
19	532126025	Support, Grill Assembly	75	532126656	Bracket, Pivot, Seat
20	532110852	Bracket Assembly Frame Pivot R.H.	76	532105529	Bolt, Shoulder
21	532110357	Washer, Snap Cap	77	819070818	Washer 7/32 x 1/2 x 18 Ga.
22	532125063	Panel, Side, R.H.	79	532124996	Clip, Fuel Line
23	532106976	Panel, Dash, R.H.	80	819131614	Washer 13/32 x 1 x 14 Ga.
24	532124914	Footrest, R.H.	81	532127018	Bolt, Shoulder 5/16 x 18 UNC x .62
25	532127213	Chassis	82	532120068	Knob - 1/2
26	532121306	Drawbar	83	819171912	Washer 17/32 x 13/16 x 12 Ga.
27	532109665	Panel, Dash, L.H.	84	819111116	Washer 11/32 x 11/16 x 16 Ga.
28	532124899	Footrest, L.H.	88	872170410	Bolt Carriage 1/4 - 20 x 1-1/4
29	873680500	Nut, Crownlock 5/16-18	90	532121251	Foam Strip
30	532124800	Saddle	91	532121250	Spring
31	819091216	Washer 9/32 x 3/4 x 16 Ga.	92	532121249	Spacer
32	532121440	Guide, Bell, Lower, Engine Pulley, L.H.	93	532121246	Bracket, Switch Mount
33	532124720	Bushing, Steering	94	532121248	Snap Bushing
34	532106202	Reflector, Taillight	95	873490400	Wing Nut 1/4-20
36	532124185	Seat	96	532123976	Nut, Hex Large Flange Lock
37	532124892	Fender	102	811030400	Washer, Lock, Int./Ext. 1/4
39	532124181	Spring, Seat	--	532124480	Decal, Hood L.H.
40	873220400	Nut, Hex 1/4-20	--	532124481	Decal, Hood, R.H.
41	874760612	Bolt, Hex 3/8-16 x 3/4	--	532124484	Decal, Rear Fender
42	819131312	Washer 13/32 x 13/16 x 12 Ga.	--	532120822	Decal, Operating Instructions, Front Fender
43	873680600	Nut, Crownlock 3/8-16	--	532101892	Decal, Clutch/Brake, Under Footrest
44	874760616	Bolt, Hex 3/8-16 x 1	--	532109821	Decal, Dash
46	532121235	Spacer	--	532109199	Decal, V - Belt Ground Drive, Footrest
47	817490612	Screw, Hex Washer Hd. Thd. Rolling 3/8-16 x 3/4 Type TT	--	532127481	Decal, Side Panel
48	874760440	Bolt, Hex Fin. 1/4-20 x 2-1/2	--	532124483	Decal, Grill
49	532123481	Bolt, Shoulder 1/4-20			
50	873680400	Nut, Crownlock 1/4-20			
51	874760620	Bolt, Hex 3/8-16 x 1-1/4			
52	873510600	Nut, Keps 3/8-16			
53	817490608	Screw, Hex Washer Hd. Thd. Forming 3/8-16 x 1/2 Type TT			
54	532124294	Pan, Seat			




REPAIR PARTS

12.5 HP 38" RIDING LAWN TRACTOR -- MODEL NUMBER LT125

H12338C

POWER AND MECHANICAL CONTROLS GROUP



For Husqvarna Parts Call 606-678-9623 or 606-561-4983

REPAIR PARTS

12.5 HP 38" RIDING LAWN TRACTOR -- MODEL NUMBER LT125


POWER AND MECHANICAL CONTROLS GROUP

KEY NO.	PART NO.	DESCRIPTION
1	532123533	Pedal Cover
2	813310300	Elbow, Street 45°
3	532127519	Control, Throttle
4	532124912	Fuel Cap
5	532121281	Support, Tank, Fuel
6	532121280	Tank, Fuel
7	532123487	Hose Clamp
8	532124923	Fuel Line
9	532127690	Engine Briggs & Stratton
10	819131016	Washer 13/32 x 5/8 x 16 Ga.
11	532121304	Muffler
12	532125593	Gasket, Exhaust
13	813240300	90° Street Elbow 3/8 NPT
14	813280328	Std. Pipe Nipple 3/8-18 NPT x 3-1/2
15	813200300	90° Elbow 3/8 NPT
17	819151616	Washer
18	532102727	Spring, Extension
19	532121719	Rod Assembly, Lever
20	532104777	Retainer, Belt, Chassis L.H.
21	532121744	Screw, Hex.Hd. Cap 5/16 - 18
23	532106983	Handle, Clutch Attachment
24	532124917	Grip, Handle
26	819292016	Washer 29/32 x 1 - 1/4 x 16 Ga.
27	817490612	Screw, Hex Washer Thd. Rolling 3/8-16 x 3/4
28	532126423	Baffle, Vertical
29	819131312	Washer 13/32 x 13/16 x 12 Ga.
30	817490620	Screw, Hex Washer Hd. Thread Rolling 3/8 - 16 x 1 - 1/4 Type TT
31	532110448	Link, Lift, Adjustable
32	532122424	Shaft, Pedal, Foot
33	532124963	Roll Pin 3/16 x 1
34	532120183	Bearing, Nylon
36	819131316	Washer 13/32 x 13/16 x 16 Ga.
37	532110447	Trunnion, Lift
38	532120174	Shaft, Assembly Lift
39	873360700	Nut, Hex Jam 7/16 - 20
40	532124670	Retainer Spring
41	532109413	Grip, Handle
42	532124526	Plunger, Lever, Hand
43	532124874	Spring
44	532121718	Lever Assembly, Hand Kit (Inc. Key No 19)

KEY NO.	PART NO.	DESCRIPTION
45	532104799	Brace, Tank
46	532121891	Handle, Adjust Lift
47	532105037	Strip, Foam
48	874780512	Bolt, Hex 5/16 - 18 x 3/4 Gr. 5
49	873680500	Locknut 5/16 - 18 Gr. B
50	532123766	Idler, V. Groove
51	73680600	Locknut 3/8 - 16
52	532110029	Link, Lift
53	532110729	Rod, Adjust, Lift
54	532105706	Bearing
55	532123205	Retainer, Belt
57	532110812	Washer, Hardened
58	812000039	Ring, Klip
59	532105709	Spring, Return Clutch
60	532105710	Link, Clutch
61	876020412	Pin, Cotter 1/8 x 3/4
62	532123789	Bellcrank Assembly (Inc. Key No. 54)
63	874760624	Bolt Hex 3/8 - 16 x 1 - 1/2
64	532108056	Bushing, Handle, Clutch
65	819121612	Washer 3/8 x 1 x 12 Ga.
66	532124997	Woodruff Key 1/4 x 1
67	823180606	Set Screw, Hex Socket Forged Headless 3/8 - 16 x 3/8
68	532110810	Trunnion, Stop, Depth
69	819151216	Washer 15/32 x 3/4 x 16 Ga.
70	812000037	Klip Ring
71	17720410	Screw Hex Washer Head Thread Cutting 1/4 - 20 x 1/2
72	532125637	Rod, Brake, Park
73	532071673	Plunger Cap
74	876020308	Cotter Pin 3/32 x 1/2
75	819211616	Washer 21/32 x 1 x 16 Ga.
76	812000022	E-Ring
77	532006431	Pad, Spacer
78	811050600	Washer, Lock 3/8 - Ext.Tooth
79	873350600	Nut, Hex Jam 3/8 - 16
80	532110807	Nut, Special
83	-----	Oil Drain Plug (Order From Engine Manufacturer)
84	532121851	Spark Arrester Kit
85	873710700	Nut, Jam Crownlock 7/16 - 20
88	532121742	Heat Shield, Muffler
91	532122364	Button, Plunger
--	532129057	Decal, Engine

NOTE: All component dimensions given in U.S. inches.
1 inch = 25.4 mm


For Husqvarna Parts Call 606-678-9623 or 606-561-4983



DRIVE GROUP

KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	532109070	Keeper, Belt	23	871130720	Bolt, Hex 7/16 - 20 x 1 - 1/4 G8
2	532108236	Bracket, Switch	24	810040700	Washer, Lock
3	817021008	Screw, Tap. Hex Hd. #10 - 24 x 1/2	25	874760644	Bolt, Hex 3/8 - 16 x 2 - 3/4
4	532105730	Keeper, Belt, Engine	26	532124965	Spacer
5	532125907	V-Belt, Drive	27	532106190	Clamp
6	819131312	Washer 13/32 x 13/16 x 12 Ga.	28	532123770	Strap, Locator
8	532106444	Bracket, Bellcrank	29	532123662	Keeper, Belt, L.H.
9	532108451	Rod Assembly, Clutch Primary	30	532123663	Keeper, Belt, R.H.
10	873680600	Nut, Crownlock 3/8 - 16	31	532124961	Spring, Retainer
11	532109728	Bellcrank Assembly	32	874760512	Bolt, Hex 5/16 - 18 x 3/4
12	874760612	Bolt, Hex 3/8 - 16 x 3/4	33	873680500	Locknut 5/16 - 18
14	819171516	Washer 17/32 x 15/16 x 16 Ga.	34	874760616	Bolt, Hex 3/8 - 16 x 1
15	532121599	Arm Assembly, Suspension, L.H.	35	876020412	Pin, Cotter 1/8 x 3/4
16	532124960	Retainer, Spring	36	819131410	Washer, 13/32 x 7/8 x 10 Ga.
17	532123674	Idler, Flat	37	532124898	Clip, Insulated
18	873220800	Nut, Hex 1/2-13	38	532110739	Washer, Spring
19	532106308	Trunnion, Lift Lower	39	873980600	Locknut, Flange 3/8
20	532121598	Arm Assembly, Suspension R.H.	41	532121218	Keeper, Belt, Engine
21	532105848	Bolt, Shoulder 3/8 - 16			
22	532105731	Pulley, Engine			


NOTE: All component dimensions given in U.S. inches.
1 inch = 25.4 mm



For Husqvarna Parts Call 606-678-9623 or 606-561-4983
REPAIR PARTS

12.5 HP 38" RIDING LAWN TRACTOR - - MODEL NO. LT125
STEERING, FRONT AXLE AND WHEELS

1+12538C



12.5 HP 38" RIDING LAWN TRACTOR -- MODEL NO. LT125 412538C

STEERING, FRONT AXLE AND WHEELS

KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	532124416	Insert, Steering Wheel	26	532124035	Support Shaft
2	873940800	Nut, Hex Jam Toplock 1/2-20	28	532124036	Bracket Assembly, Steering
3	532100712	Washer 17/32 x 2-1/4 x .160	29	532124034	Gear, Sector
4	532124415	Steering Wheel	31	532126684	Washer, Shim
5	532110711	Adapter, Steering Wheel	32	532124931	Bearing Thrust
6	532109816	Nyliner, Snap-in	33	532124033	Shaft, Pitman
7	812000029	Ring, Klip	34	532105656	Spindle Assembly, L.H.
8	532121749	Washer 25/32 x 1-1/4 x 16 Ga.	35	817490612	Screw, Hex Washer Hd. Thread Forming Type TT 3/8-16 x 3/4
9	532124959	Bearings, Wheel, Front			
10	532106222	Tire	36	873601000	Nut, Flange 5/8 - 11
11	532059904	Tube, Tire	37	532124937	Bearing
12	532125102	Rim Assembly (Inc. 2 each Key No. 9)	38	532104757	Cap, Axle, Front
13	532065139	Stem, Valve	39	532124957	Grease Fitting
14	532059192	Cap, Valve	40	532121748	Washer 25/32 x 1-5/8 x 16 Ga.
15	532108076	Axle Assembly, Front	46	819111216	Washer 11/32 x 3/4 x 16 Ga.
16	874761060	Bolt, Hex 5/8-11 x 3-3/4	47	810040500	Washer, Lock 1/4
17	532105654	Spindle Assembly, R.H.	48	532124037	Gear, Pinion
18	873810500	Nut, Hex Nylon 5/16-24 UNF	49	532057079	Washer
19	532121321	Tie Rod	50	819272016	Washer 27/32 x -1/4 x 16 Ga.
20	532124836	Fitting, Grease	51	532121232	Spindle Cap
21	532110438	Spacer Bearing, Front Axle	53	819212010	Washer
22	810040600	Lock Washer 3/8	54	810040400	Washer, Lock
23	873610600	Nut, Hex 3/8-24	55	871070410	Screw, Socket Hex
24	532124032	Drag Link			
25	532124042	Shaft, Steering			



NOTE: All component dimensions given in U.S. inches.
1 inch = 25.4 mm



REPAIR PARTS

12.5 HP 38" RIDING LAWN TRACTOR - - MODEL NUMBER LT125
TRANSAXLE AND REAR WHEEL

H12538C



For Husqvarna Parts Call 606-678-9623 or 606-561-4983

REPAIR PARTS

12.5 HP 38" RIDING LAWN TRACTOR - - MODEL NUMBER LT125

1412538C

TRANSAXLE AND REAR WHEEL


KEY PART
NO. NO. DESCRIPTION

1	532124999	Rim Assembly
2	532106268	Tire
3	532124926	Tube, Tire
4	532109502	Spacer, Split
5	532123583	Key, Square 3/16 x 2
6	532120898	Transaxle 6 Speed
7	810040400	Washer, Lock 1/4
8	819091210	Washer 9/32 x 3/4 x 10 Ga.
9	532121274	Knob, Control
10	876020412	Cotter Pin 1/8 x 3/4
11	532106919	Plate, Rod, Shift
12	532121728	Rod, Shifter
13	532105700	Spring, Torsion
14	819151216	Washer 15/32 x 3/4 x 16 Ga.
15	876020416	Pin, Cotter 1/8 x 1
16	532105701	Washer, Shift Plate
17	871040412	Bolt, Hex 1/4-28 x 3/4 Gr. 8
18	532106888	Spring, Rod, Brake
19	532110437	Rod, Brake
20	819131316	Washer 13/32 x 13/16 x 16 Ga.
21	532121520	Strap, Torque

KEY PART
NO. NO. DESCRIPTION

22	873350600	Nut, Hex Jam 3/8-16
23	532109167	Bracket, Transaxle
24	812000028	Ring, Retainer
25	532121749	Washer 25/32 x 1-1/4 x 16 Ga.
27	532123666	Pulley, Input Transaxle
28	532059192	Cap, Valve
29	532065139	Stem, Valve
30	812000001	E-Ring
31	874760644	Bolt, Hex 3/8-16 x 2-3/4
32	873680600	Nut, 3/8-16
33	874760612	Bolt, Hex 3/8-16 x 3/4
34	817490512	Screw Hex Washer Hd. Thd. Form. Type TT 5/16-18 UNC x 3/4
35	532104757	Cap, Axle
36	532121748	Washer 25/32 x 1-5/8 x 16 Ga.
37	532110422	Spring, Brake Return
39	873800600	Locknut, Hex W/Wsh. 3/8-16 UNC

NOTE: All component dimensions given in U.S. inches.
1 inch = 25.4 mm




12.5 HP 38" RIDING LAWN TRACTOR - - MODEL NO. LT125

112538C


MOWER

KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	532106085	V-Belt	42	874610624	Bolt, Hex 3/8 - 24 x 1 - 1/2 Gr. 5
2	532121259	Housing	43	532108250	Spring, Ext.
3	532124962	Runner R.H.	44	532108235	Rod, Clutch, Mower
4	873680600	Locknut 3/8 - 16	45	532109729	Roller, Nose
5	819111216	Washer 11/32 x 3/4 x 16 Ga.	46	876020616	Pin, Cotter 3/16 x 1
6	872140505	Bolt, Carr. 5/16-18 x 5/8	47	532124066	Assembly, Rock Shaft
7	532105896	Bracket, Deflector	48	532124915	Spacer 1/2 x 9/16
8	532110452	Push Nut	49	532108247	Rod, Brake, Primary
9	532106734	Spring, Deflector	50	872140606	Bolt, Carriage 3/8 - 16 x 3/4
10	532106735	Rod, Hinge	51	819151610	Washer 15/32 x 1 x 10 Ga.
11	532106736	Deflector, Shield	52	532108243	Bracket, Pivot R.H.
12	532109646	Bracket, Nose Roller L.H.	53	532108241	Bracket, Pivot L.H.
13	532105304	Cap	54	532105857	Bracket, Susp., Rear R.H.
14	532105662	Link, Parallel	55	532108673	Bracket, Susp., Rear L.H.
15	532105744	Pin, Hinge, Front	56	532106578	Brake Assembly
16	532124961	Spring, Retainer	57	532106463	Rod, Brake, Secondary L.H.
18	532109835	Pin, Hinge, Rear	58	532108249	Rod, Brake, Secondary R.H.
20	873680500	Locknut 5/16 - 18	59	532106456	Bracket, Brake, Pivot
21	532109598	Bracket, Lift R.H.	60	532100672	Spacer, Brake
22	532109597	Bracket, Lift L.H.	61	532100673	Bracket, Support
23	872140506	Bolt, Carriage 5/16 - 18 x 3/4	62	819161616	Washer 1/2 x 1 x 16 Ga.
24	532109647	Bracket, Nose Roller R.H.	63	819111016	Washer 11/32 x 5/8 x 16 Ga.
25	532109503	Support, Arm	64	874760688	Bolt 3/8 - 16 x 5 - 1/2
26	532109504	Stop, Deck, Front	65	532125074	Runner L.H.
27	532109776	Pin, Pivot	66	819131614	Washer 13/32 x 1 x 14 Ga.
28	532126756	Guide, Belt	67	872140610	Bolt, Carriage 3/8 - 16 x 1-1/4
29	874760632	Bolt 3/8 - 16 x 2	68	876020412	Pin, Cotter 1/8 x 3/4
30	532127163	Arm, Idler Assembly	69	874760512	Bolt, Hex Hd. 5/16 - 18 UNC x 3/4
31	532106902	Spacer	70	532122314	Spacer
32	532123688	Pulley, Idler	75	876020308	Pin, Cotter 3/32 x 1/2
33	532106513	Washer, Wear 1/16	76	872110506	Bolt, Carriage 5/16 - 18 x 3/4
34	532102669	Keeper, Belt	77	874760412	Bolt Hex 1/4 x 20 x 3/4
35	532121676	Mandrel, Assembly	78	532109893	Washer, Special
36	532100668	Plate, Support, Mandrel	79	873680400	Locknut 1/4-20
37	817490614	Screw, Hex Washer Hd. 3/8 - 16 x 7/8	80	532110445	Plate, Support L.H.
38	817490620	Screw, Hex Washer Hd. 3/8 - 16 x 1-1/4	81	819131316	Washer, 13/32 x 13/16 x 16 Ga.
39	532121263	Blade	--	532123928	Mower Deck, Complete
40	819132012	Washer 13/32 x 1 - 1/4 x 12 Ga.	--	532105814	Decal, V-Belt Mower Drive
41	810030600	Washer, Lock 3/8	--	532121349	Decal, Danger Warning
			--	532109820	Decal, Instruction Caution

NOTE: All component dimensions given in U.S. inches.
 1 inch = 25.4 mm



1712538C



TRANSAXLE FOOTE-MODEL NO. 4360-7

KEY PART NO. NO.	DESCRIPTION	KEY PART NO. NO.	DESCRIPTION
1 3865	Housing, Upper	40 3901	Spacer .635 x .875 x .755
2 1919	Screw, Tapping, Lg. 1/4-20 x .734	41 3645	Sprocket, 9 Teeth
3 1151	Ball, Detent	42 3853	Gear, Bevel, 42 Teeth
4 3626	Spring, Detent	43 3749	* Washer, Plain .758 x 1.12 x .010
5 3623	Screw, Set	43 3652	* Washer, Plain .758 x 1.12 x .015
6 4336	Assembly, Shifter	43 3693	* Washer, Plain .758 x 1.12 x .020
7 3884	O-Ring	43 3653	* Washer, Plain .758 x 1.12 x .025
8 3885	* Washer, Plain .505 x .942 x .006	43 3408	* Washer, Plain .758 x 1.25 x .020
8 3886	* Washer, Plain .505 x .942 x .010	43 3732	* Washer, Plain .758 x 1.25 x .025
8 3887	* Washer, Plain .505 x .942 x .015	43 3184	* Washer, Plain .758 x 1.25 x .031
8 3888	* Washer, Plain .505 x .942 x .020	43 3733	* Washer, Plain .758 x 1.25 x .035
8 3889	* Washer, Plain .505 x .942 x .026	43 3198	* Washer, Plain .758 x 1.25 x .040
8 3121	* Washer, Plain .505 x .942 x .030	43 3734	* Washer, Plain .758 x 1.25 x .045
8 3890	* Washer, Plain .505 x .942 x .040	43 3735	* Washer, Plain .758 x 1.25 x .050
9 1100	Ring, Retaining	43 3736	* Washer, Plain .758 x 1.25 x .055
10 1099	Ring, Retaining	43 3180	* Washer, Plain .758 x 1.25 x .062
11 1959	* Washer, Plain .632 x 1.00 x .010	44 3882	Shaft, Drive
11 1441	* Washer, Plain .632 x 1.00 x .020	45 3646	Gear, Spur, 12 Teeth
11 1423	* Washer, Plain .632 x 1.00 x .026	46 3707	Gear, Spur, 15 Teeth
11 1082	* Washer, Plain .632 x 1.00 x .031	47 3866	Gear, Spur, 20 Teeth
11 1424	* Washer, Plain .632 x 1.00 x .036	48 3719	Gear, Spur, 25 Teeth
11 1068	* Washer, Plain .632 x 1.00 x .041	49 3868	Gear, Spur, 28 Teeth
11 1425	* Washer, Plain .632 x 1.00 x .046	50 3683	Gear, Spur, 31 Teeth
11 1358	* Washer, Plain .632 x 1.00 x .050	51 1145	Washer, Plain .632 x 1.00 x .060
11 1145	* Washer, Plain .632 x 1.00 x .060	52 3191	Seal, Felt
11 1319	* Washer, Plain .632 x 1.00 x .082	53 3180	Washer, Plain .758 x 1.25 x .062
12 3312	O-Ring	54 3880	Axle, L.H.
13 3876	Washer, Plain .632 x 1.38 x .046	55 3780	Gear, Miter, 15 Teeth
14 1374	Key, Woodruff #9	56 3656	Ring, Retaining
15 4134	Assembly, Kit, Input Shaft	57 3839	Gear, Spur, 32 Teeth
16 3590	Pinion, Bevel, 14 Teeth	58 3919	Shaft, Cross
17 3624	Ring, Retaining	59 3781	Gear, Miter, 15 Teeth
18 3625	Chain, 24 Pitches	60 3881	Axle, R.H.
19 1542	Bearing, Flange	61 3864	Housing, Lower
20 3773	Gear, Spur, 14 Teeth	62 3920	Puck, Friction
21 3631	Collar, Clutch	63 3276	Disc, Brake
22 3828	Key, Clutch	64 3758	Spacer
23 1369	Key, Woodruff	65 3916	Jaw, Brake
24 3883	Shaft, Intermediate	66 3843	Pin, Dowel
25 1375	Key, Woodruff #61	67 3915	Screw, Tapping, Lg. 5/16-18 x 2.25
26 3627	Ring, Retaining	68 3768	Lever, Actuating
27 3830	Sprocket, 18 Teeth	69 3760	Washer, Plain .321 x 1.00 x .055
28 3841	Spacer	70 3917	Bracket, Anti-Rotation
29 3786	Gear, Spur, 37 Teeth	71 3847	Locknut 5/16-24
30 3785	Gear, Spur, 35 Teeth	72 3724	Screw, Tapping, Lg. 5/16-18 x 1.44
31 3867	Gear, Spur, 30 Teeth	73 3906	Washer, Plain .343 x .81 x .059
32 3783	Gear, Spur, 25 Teeth	74 3907	Puck, Friction
33 3869	Gear, Spur, 22 Teeth	75 4300	Grease
34 3741	Gear, Spur, 19 Teeth		
35 3628	Washer, Plain .640 x 1.37 x .061		
36 1423	Washer, Plain .632 x 1.00 x .026		
37 3422	Spacer .630 x 1.00 x .169		
38 4286	Assembly, Gear, Combination 12 Teeth and 35 Teeth		
39 3877	Shaft, Idler		

*Use in various combinations to maintain proper clearances.

**Order Key No. 15.

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm