

# 262



## 1.1996

**Spare parts**

**Ersatzteile**

**Pièces détachées**

**Reserve onderdelen**

**Repuestos**

**Reservdelar**

Replaces

Ersetzt

Remplace

Vervangt

Reemplaza

Ersätter

106 22 67-64

# For Husqvarna Parts Call 606-678-9623 or 606-561-4983

## MODEL NUMBER 262

| PART NUMBER  | SQUARE | NOTE | PART NUMBER  | SQUARE | NOTE | PART NUMBER  | SQUARE | NOTE | PART NUMBER  | SQUARE | NOTE |
|--------------|--------|------|--------------|--------|------|--------------|--------|------|--------------|--------|------|
| 501 45 27-02 | K      |      | 501 91 14-01 | N      |      | 503 54 38-02 | K      |      | 720 12 33-00 | A      |      |
| 501 45 41-01 | K      |      | 503 08 20-01 | M      |      | 503 54 39-01 | L      |      | 720 12 40-20 | E      |      |
| 501 45 74-02 | JY     |      | 503 08 52-01 | H      |      | 503 54 40-03 | K      |      | 720 13 07-10 | K      |      |
| 501 46 84-01 | M      |      | 503 08 54-01 | N      |      | 503 54 41-01 | D      |      | 720 13 14-20 | E      |      |
| 501 46 85-01 | M      |      | 503 10 87-01 | M      |      | 503 54 42-01 | D      |      | 721 42 52-50 | A      |      |
| 501 46 87-01 | M      |      | 503 16 66-01 | J      |      | 503 54 43-01 | D      |      | 724 32 24-05 | H (G)  |      |
| 501 48 54-02 | H      |      | 503 16 73-01 | J      |      | 503 54 45-01 | L      |      | 724 33 25-56 | K      |      |
| 501 48 56-01 | H      |      | 503 17 63-01 | M      |      | 503 54 54-01 | F      |      | 725 52 91-56 | H      |      |
| 501 49 24-03 | H (G)  |      | 503 17 89-02 | L      |      | 503 54 61-02 | E      |      | 725 52 92-06 | J      |      |
| 501 49 27-03 | H      |      | 503 20 02-12 | F      |      | 503 54 62-01 |        |      | 725 52 94-55 | H      |      |
| 501 49 76-01 | K      |      | 503 20 25-20 | K      |      | 503 54 62-02 |        |      | 725 53 25-55 | K      |      |
| 501 51 72-01 | K      |      | 503 20 26-16 | A      |      | 503 54 65-01 | M      |      | 725 53 29-55 | K      |      |
| 501 54 41-02 | J      |      | 503 20 34-16 | L      |      | 503 54 67-01 | M      |      | 725 53 31-55 | C      |      |
| 501 59 74-04 | H      |      | 503 20 55-06 | F      |      | 503 55 22-01 | C      |      | 725 53 32-55 | K      |      |
| 501 59 80-02 | JY     |      | 503 20 64-12 | FD     |      | 503 55 55-03 | F      |      | 725 53 37-55 | K      |      |
| 501 60 02-02 | N      |      | 503 20 64-16 | L      |      | 503 55 55-04 | F      |      | 725 53 41-55 | KK     |      |
| 501 61 58-01 | J      |      | 503 20 67-28 | B      |      | 503 55 55-05 | F      |      | 725 53 87-55 | F      |      |
| 501 62 43-01 | J      |      | 503 21 05-25 | E      |      | 503 55 70-01 | H (G)  |      | 734 11 24-01 | H      |      |
| 501 62 93-05 | H (G)  |      | 503 21 06-25 | E      |      | 503 55 77-01 | H (G)  |      | 734 48 51-01 | H      |      |
| 501 63 02-02 | L      |      | 503 21 28-06 | H      |      | 503 55 78-01 | J      |      | 735 31 08-20 | A      |      |
| 501 63 06-01 | L      |      | 503 21 28-10 | A      |      | 503 55 86-01 | N      |      | 737 43 12-00 | C      |      |
| 501 63 44-03 | H      |      | 503 21 29-06 | JH     |      | 503 55 86-02 | N      |      | 738 22 02-25 | G      |      |
| 501 63 48-01 | H      |      | 503 21 29-10 | LH     |      | 503 56 23-01 | M      |      | 740 44 05-00 | K      |      |
| 501 66 49-01 | J      |      | 503 21 32-16 | L      |      | 503 56 24-01 | M      |      | 740 48 27-02 | K      |      |
| 501 66 61-01 | M      |      | 503 22 00-01 | A      |      | 503 56 34-01 | M      |      |              |        |      |
| 501 66 62-01 | M      |      | 503 22 10-11 | H      |      | 503 57 71-01 | J      |      |              |        |      |
| 501 66 69-01 | M      |      | 503 23 00-04 | J      |      | 503 57 74-01 | J      |      |              |        |      |
| 501 66 70-01 | M      |      | 503 23 00-35 | L      |      | 503 57 76-01 | E      | N    |              |        |      |
| 501 66 72-01 | M      |      | 503 23 00-42 | H      |      | 503 60 78-01 | M      |      |              |        |      |
| 501 66 73-01 | M      |      | 503 23 51-08 | C      |      | 503 61 48-01 | M      |      |              |        |      |
| 501 66 77-01 | M      |      | 503 23 72-02 | H      |      | 503 61 98-03 | L      |      |              |        |      |
| 501 66 78-01 | M      |      | 503 25 34-01 | JY     |      | 503 61 98-04 | L(G)   |      |              |        |      |
| 501 66 83-01 | M      |      | 503 26 30-11 | E      |      | 503 63 10-02 | A      |      |              |        |      |
| 501 66 84-01 | M      |      | 503 28 16-05 | DM     |      | 503 63 82-01 | M      |      |              |        |      |
| 501 67 32-01 | H      |      | 503 28 90-15 | C      |      | 503 64 29-01 | Y      |      |              |        |      |
| 501 67 33-02 | N      |      | 503 40 47-01 | E      |      | 503 64 66-03 | J      |      |              |        |      |
| 501 68 68-01 | K      |      | 503 40 56-01 | F      |      | 503 64 66-04 | J      |      |              |        |      |
| 501 69 17-01 | N      |      | 503 44 32-01 | E      |      | 503 66 04-01 | H (G)  |      |              |        |      |
| 501 76 56-02 | K      |      | 503 44 72-01 | B      |      | 503 66 84-01 | K      |      |              |        |      |
| 501 76 80-01 | A      |      | 503 44 72-03 | B      |      | 503 66 91-01 | F      |      |              |        |      |
| 501 76 81-01 | A      |      | 503 44 72-04 | B      |      | 503 66 96-01 | M      |      |              |        |      |
| 501 79 50-01 | K      |      | 503 45 39-01 | Y      |      | 503 66 98-01 | M      |      |              |        |      |
| 501 79 51-02 | H (G)  |      | 503 49 69-03 | D      |      | 503 66 99-01 | M      |      |              |        |      |
| 501 81 92-01 | K      |      | 503 49 74-01 | E      |      | 503 68 42-42 | K      |      |              |        |      |
| 501 81 96-02 | E      |      | 503 50 86-02 | F      |      | 503 69 69-01 | F      |      |              |        |      |
| 501 81 99-01 | H      |      | 503 50 93-02 | E      |      | 503 70 43-01 | A      | N    |              |        |      |
| 501 83 29-01 | M      |      | 503 50 94-01 | E      |      | 503 70 44-01 | A      | N    |              |        |      |
| 501 83 98-01 | H      |      | 503 51 48-01 | E      |      | 503 70 45-01 | A      | N    |              |        |      |
| 501 86 00-02 | K      |      | 503 52 08-01 | A      |      | 503 70 48-02 | C      |      |              |        |      |
| 501 86 00-04 | K      |      | 503 52 12-02 | J      |      | 503 70 49-01 | A      | N    |              |        |      |
| 501 86 18-01 | CG     |      | 503 52 39-01 | A      |      | 503 70 63-01 | C      |      |              |        |      |
| 501 86 24-01 | D      |      | 503 52 41-01 | K      |      | 503 71 53-01 | C      |      |              |        |      |
| 501 86 25-02 | D      | N    | 503 52 94-01 | H      |      | 503 71 79-01 | H      |      |              |        |      |
| 501 86 41-01 | Y      |      | 503 52 94-02 | H(G)   |      | 503 71 81-01 | H      |      |              |        |      |
| 501 86 69-01 | Y      |      | 503 53 11-71 | C      |      | 503 72 31-01 | A      | N    |              |        |      |
| 501 86 90-02 | D      |      | 503 53 33-03 | E      |      | 503 72 74-01 | A      |      |              |        |      |
| 501 87 05-01 | K      |      | 503 54 01-03 | E      |      | 503 73 58-01 | E      |      |              |        |      |
| 501 87 21-01 | J      |      | 503 54 07-01 | E      |      | 503 74 70-72 | A      | N    |              |        |      |
| 501 87 23-01 | J      |      | 503 54 09-01 | K      |      | 503 78 24-01 | K      | N    |              |        |      |
| 501 87 24-01 | K      |      | 503 54 10-01 | E      |      | 503 80 27-01 | A      |      |              |        |      |
| 501 87 31-01 | E      |      | 503 54 16-01 | L      |      | 503 90 79-71 | C      | N    |              |        |      |
| 501 87 47-01 | A      |      | 503 54 17-01 | L      |      | 504 52 30-02 | J      |      |              |        |      |
| 501 87 53-03 | A      | N    | 503 54 21-01 | B      |      | 505 27 57-19 | K      |      |              |        |      |
| 501 87 62-01 | M      |      | 503 54 23-01 | B      |      | 505 30 36-94 | Y      |      |              |        |      |
| 501 87 65-01 | J      |      | 503 54 26-02 | K      |      | 505 30 51-25 | L      |      |              |        |      |
| 501 87 68-05 | D      |      | 503 54 31-01 | D      |      | 505 31 67-17 | M      |      |              |        |      |
| 501 87 79-01 | M      |      | 503 54 32-01 | D      |      | 505 52 01-25 | M      |      |              |        |      |
| 501 87 80-01 | M      |      | 503 54 34-01 | B      |      | 506 02 72-07 | H      |      |              |        |      |
| 501 87 90-01 | M      |      | 503 54 35-01 | B      |      | 506 16 48-01 | A      | N    |              |        |      |
| 501 87 95-01 | K      |      | 503 54 37-01 | K      |      | 506 18 19-72 | G      |      |              |        |      |


1=503 54 62-02  
2=501 66 84-01

Set of gaskets  
Dichtungssatz  
Jeu de joints  
Juego de juntas  
Packningssats


Y=See Square y  
Siehe Viereck y  
Voyez Carreau y  
Vease Cuadro y  
Se Ruta y

N=New part  
Neues teil  
Nouvelle piece  
Nueva pieza  
Ny detalj


(G)=Generator




## C \*compl 503 54 11-72




## G \*compl 506 18 19-72




## K \*compl 501 86 00-04



**D**




**H**




**E**

\*compl 503 49 74-01




**L**

\*compl 503 54 16-01



**M** compl 503 28 16-05


**Walbro HDA-120**




**② 501 66 84-01**  
**Packningssats**  
**Set of gaskets**  
**Dichtungssatz**  
**Jeu de joints**  
**Juego de juntas**

**N** \*compl 501 67 33-02

**Tillbehör**  
**Accessories**  
**Zubehöre**  
**Accessoires**  
**Accesorios**




Y



≥ = Up to Tot  
Bis A  
A T.o.m.

Serial no.≥ 3450001



Serial no.≥ 4450041

