


 **Husqvarna**



225L/LD/R/RD/RJ



1.1996

Spare parts

Ersatzteile

Pièces détachées


Reserve onderdelen

Repuestos

Reservdelar


A







*compl 503 78 05-03




B

*compl 502 19 58-03
 **compl 503 72 43-03







J compl 503 71 73-03




K compl 502 21 92-03



L *compl 502 19 59-01




M *compl 502 18 95-01



- *502 21 25-06 (R)
- *502 21 25-07 (RD)
- *502 21 25-08 (L)
- *502 21 25-09 (LD)
- *502 21 25-10 (RJ)

N



P

Accessories
Zubehöre
Accessoires
Acessorios
Tillbehör

