


For Husqvarna Parts Call 606-678-9623 or 606-561-4983

 **Husqvarna**



Royal 43/43S/43SE



1.1997

Spare parts

Ersatzteile

Pièces détachées

Reserve onderdelen



Repuestos

Reservdelar


D

Royal 43

Royal 43 S




E




F

Royal 43 SE




G

Royal 43 SE



H



For Husqvarna Parts Call 606-678-9623 or 606-561-4983

MODEL NUMBER R43

PART NUMBER	SQUARE	NOTE	PART NUMBER	SQUARE	NOTE	PART NUMBER	SQUARE	NOTE	PART NUMBER	SQUARE	NOTE
510 65 89-00	H		514 85 09-00	B							
510 65 90-00	B		514 85 10-00	D,F							
510 65 91-00	H		514 85 19-01	E							
510 66 03-01	A		514 85 24-00	E							
510 66 03-05	A		514 85 26-00	B							
510 66 09-01	A		514 85 28-00	B							
510 66 23-00	II		514 85 51-00	B							
510 67 06-00	D,F		514 85 52-01	B							
510 67 26-64	B		514 85 98-00	C							
511 77 85-00	C		514 86 36-01	D,F							
511 80 35-00	D		514 88 25-00	B							
511 80 35-01	D,F		514 88 31-00	E							
511 80 37-00	D,F		514 88 37-00	E							
512 68 67-00	B		514 88 76-00	D,F							
512 68 80-00	E		514 89 43-02	G							
512 68 84-00	E		514 89 43-03	G							
512 70 32-00	C		514 91 08-00	E							
512 73 77-00	H		514 91 67-00	B							
512 73 78-01	F	N	514 92 33-00	H							
512 73 82-00	E		514 92 75-01	D,F							
512 73 91-00	B		514 92 77-00	H							
512 73 97-00	H		514 93 04-00	E							
512 74 11-00	D,F		514 93 11-00	DF	N						
512 74 30-00	E	N	514 93 72-00	D,F							
512 74 31-01	E	N	514 93 73-00	D,F							
512 74 31-02	E	N	514 94 35-00	F							
512 74 61-01	B		514 94 51-00	A	N						
512 75 17-00	E		514 94 53-00	D,F							
512 75 18-00	F		514 94 77-00	A							
512 75 19-00	E		514 94 93-00	F							
512 75 30-61	E		514 94 94-00	F							
512 75 49-00	D		514 94 98-00	D,F							
512 75 49-01	D,F		514 94 99-00	F							
512 75 50-05	D	N	514 94 99-01	D							
512 75 50-06	D	N	514 95 00-00	F							
512 75 51-03	F	N	514 95 01-00	D							
512 76 64-00	B,C		516 87 46-07	DF	N						
512 83 44-00	E		531 00 50-38	C							
513 77 09-00	E		531 00 50-39	B							
513 77 30-00	E										
513 77 31-00	E										
513 77 98-01	B										
513 78 01-00	B										
513 78 02-00	E										
513 78 45-00	B										
513 80 50-00	E										
513 80 50-01	E										
513 82 37-00	B										
513 82 48-00	B										
513 82 58-01	B										
513 82 68-00	D,F										
513 82 96-00	D,F										
513 82 97-00	D,F										
513 83 05-00	B										
513 83 10-00	H										
513 83 92-00	D,F										
513 84 10-00	D,F										
513 84 11-00	F										
513 85 57-00	A	N									
513 85 58-00	A	N									
513 85 60-00	A	N									
514 00 53-00	B										
514 02 81-01	E	N									
514 63 14-00	DF	N									
514 66 72-00	F										
514 66 77-09	C										
514 67 31-00	B	N									
514 71 80-00	D,F										
514 84 78-00	B										
514 84 85-00	E										
514 85 06-01	E										

N=New part
 Neues teil
 Nouvelle piece
 Nieuw onderdeel
 Nueva pieza
 Ny detalj

Y=See Square Y
 Siehe Viereck Y
 Voyez carreau Y
 Zie afbeelding Y
 Vease cuadro Y
 Se ruta Y