

MODEL } 181  
MODÈLE }

## NEW COLOURS ON HUSQVARNA CHAIN SAWS

In order to receive a better colour co-ordination between different components on Husqvarna chain saws, a colour alteration is introduced.

This means that the Husqvarna orange colour has been made slightly darker and more alike the Husqvarna original saw colour.

Due to this, the following part numbers have been changed.

<u>New parts</u>	<u>Description</u>	<u>Excluded parts</u>
501 80 59-02	Cylinder cover compl.	501 80 59-01
501 80 03-05	Crankcase compl.	501 80 03-61
501 80 19-02	Air conductor	501 80 19-01
501 80 91-02	Fuel tank compl.	501 80 91-01
501 81 00-03	Starter compl.	501 81 00-02
501 81 01-03	Starter housing	501 81 01-02
501 80 80-04	Chainbrake compl.	501 80 80-01
501 80 81-02	Clutch cover	501 80 81-01
501 80 89-02	Clutch cover	501 80 89-01
501 53 70-01	Sticker	501 66 54-01
501 62 89-05	Handle insert SE	501 62 89-01
501 62 93-03	Handle insert SG	501 62 93-01

The change was introduced from serial number SE: 5333858  
SG: 5100451