



OCT 14 1995

SERVICE



13

SX 85.102-96 A

Enclosure to the spare parts list 106 20 38-98

Annexe à la liste des pièces détachées 106 20 38-98

SPARE PARTS CHANGES ON MODELL 36 R

<u>Parts Number</u>	<u>Denomination</u>	<u>Square</u>	<u>Replaces</u>
502 05 21-03	Air filter	A	502 05 21-01
502 04 25-03	Clutch cover	G	502 04 25-01
502 05 02-01	Crankcase gasket	H	New part
740 42 03-00	O-ring	H	is excluded
501 81 28-01	Ignition coil	J	501 51 62-03
501 81 27-01	Ignition module	J	501 63 29-92
502 05 62-01	Cable clip	J	is excluded
729 22 79-01	Screw	J	is excluded
725 52 93-55	Screw	J	725 52 99-05
502 05 35-04	Flywheel compl.	J	502 05 35-02
503 23 00-05	Washer	J	New part
502 10 43-01	Short circuit lead	J	New part
502 10 44-01	Lead	J	New part
502 04 07-04	Driver	L	502 03 70-01
502 03 10-03	Support flange	L	502 03 10-01
735 31 09-20	Lock washer	N	502 02 31-01
502 03 64-01	Transportation guard 12"	N	New part