



MODEL 244 RX, 36 R

CRANKCASE, IGNITION SIDE

In order to further explain the service bulletin X 85.106-96.

When assembling the AM7 ignition system, do as follows:

1. Remove the old ignition system compl.
2. Mount the ignition coil in the hole, 4 mm from the partition line on the crankcase.
3. Make sure that the ignition coil is placed horizontally and do a mark, where the other screw should be mounted. Then remove the ignition coil and drill and thread for the metric 4 (M4).
4. Assemble the ignition module with the "text-side" facing up. If the air gap is difficult to set, an angle can be made on the posts where the module is mounted ($2 \times 45^\circ = 0.3 \text{ mm}$).
5. Assemble the cables.

NOTE! Be careful. The cables can easily be squeezed under the module.

