

MODEL 40

STOP SWITCH

A stop switch, which is assembled with screw and nut, is now available as a spare part. Reference number 503 44 04-01 spare part kit, stop switch.

The stop switch is delivered in a kit consisting of:

Stop switch		
Ground lead	503 44 06-01	
Screw	723 12 22-55	503 44 04-01
Washer	734 11 24-01	
Nut	731 23 10-01	

Assembly: File the notch for the stop switch in the crankcase to 28 mm,



Use the stop switch as a template and mark out the hole. Drill a hole  $\emptyset$  3 mm and assemble according to the illustration.



3: X 86.108-26 7.4 9-86

## www.mymowerparts.com