



SERVICE 		8 X 88.110-96
--	--	-------------------------

MODELS } **238/242/254/266/268/281**
 MODÈLE }

HANDLE HEATING

Functional disorder which are caused by a poor contact between the resistance wire in the handle insert and the sleeve can be repaired according to the below:

1. Place the locking washer between the wire and the handle insert. This should be done on both handle inserts.
2. Shorten the sleeve approx. 1,5 mm (0.05") in order to compensate for the two washers.
3. Mount the two handle inserts.

POIGNÉE CHAUFFANTE

En cas d' interruption causée par mauvais contact entre le fil de résistance dans l' insert de poignée et la douille, il faut procéder ainsi:

1. Placer la rondelle entre le fil et l' insert. NOTA: Dans les deux poignées.
2. Raccourcir la douille d' environ 1,5 mm, pour compenser les deux rondelles.
3. Monter les deux inserts.

