





<b>SERVICE</b> 		<div data-bbox="1388 56 1436 123"><b>8</b></div> <div data-bbox="1316 156 1508 201"><b>X 90.122-26</b></div>
--	--	--

## Winterkit - Preheating for intakeair H 262

To avoid running problems during wintertime caused by cold weather and/or powder snow we recommend the following steps:

1. A hole  $\varnothing$  18 mm (0.71 inch) has to be drilled in the cylindercoverwall. According to the illustration.

At temperatures over 0° C the hole has to be plugged. Use winterplug (268) ref. no. 503 40 59-01. Note! The widest side of the plug should be mounted against the carburettorside.

2. During December a special cover will be available as sparepart. The cover has to be mounted on the starter cover to prevent large amounts of snow to be sucked in.

