



## MODELS 42/242

### AIR CONDUCTOR AND STARTER HOUSING

The air conductor is changed in order to receive a better cooling of the cylinder. The starter housing is also adjusted to the new air conductor from production code G.

#### NOTE!

The new air conductor ref. no. 503 51 14-01 does not fit older starter housings with production code to F.

New ref. no.	Description	Excluded ref. no.	Remark
503 51 14-01	Air conductor	501 66 15-02	*

\* remains as a spare part

Introduced in our production from serial number: 42 1050409  
242 1050444

