

VACUUM PARTS - IDC LV130

Item	Part No.	Description
1	612605	Hanger
2	683881	Drive Housing Assembly
3	145569	Screw, Anti-Rotation
4	145569	Screw, Oil Hole
5	683882	Drive Shaft Assembly
6	153597	Lower Clamp Assembly
7	153318	Mounting Screw Assembly
8	180107	Housing Assembly, Upper
9	683884	Discharge Clamp Assembly
10	612929	Adapter
11	612930	Clamp
12	180108	Vacuum Bag Assembly (includes items 10 and 11)
13	145570	Retaining Ring
14	145567	Washer
15	683886	Housing and Bushing Assembly
16	612931	Impeller Shaft
17	180197	Impeller
18	683887	Nut and Washer Assembly
19	612933	Shield
20	180109	Housing, Lower
21	683662	Mounting Screw Assembly
22	180110	Vacuum Tube Assembly

