

Item	Part No.	Description
1	612605	Hanger
2	180104	Drive Shaft Housing Assembly
3	683608	Drive Shaft Assembly
4	153597	Lower Clamp Assembly
5	153318	Mounting Screw Assembly
6	180105	Upper Housing Assembly
7	145570	Retaining Ring
8	145567	Washer
9	145569	Screw, Oil Hole
10	145569	Screw, Anti-Rotation
11	683660	Housing, Bushing Assembly
12	612559	Shaft Impeller
13	180196	Impeller
14	683661	Nut and Washer Assembly
15	180106	Housing, Lower
16	683662	Mounting Screw Assembly
17	612562	Edge Guard

