


**ENGINE PARTS - MODEL TB250B**  
**2-CYCLE GAS BLOWER**

PPN 41AR290G766

Part Numbers On Following Page




## ENGINE PARTS - MODEL TB250B (cont.)

### 2-CYCLE GAS BLOWER

PPN 41AR290G766

| <u>Item</u> | <u>Part No.</u> | <u>Description</u>                  | <u>Item</u> | <u>Part No.</u> | <u>Description</u>                        |
|-------------|-----------------|-------------------------------------|-------------|-----------------|-------------------------------------------|
| 1           | 753-04518       | Screw                               | 37          | 753-04554       | Washer                                    |
| 2           | 753-04519       | Screw                               | 38          | 753-04555       | Impeller Nut                              |
| 3           | 753-04742       | Engine Cover                        | 39          | 753-04556       | Shroud Screws                             |
| 4           | 753-04521       | Pull Handle Bushing                 | 40          | 753-04557       | Needle Bearing                            |
| 5           | 753-04522       | Pull Handle                         | 41          | 753-04558       | Retaining Ring                            |
| 6           | 753-04523       | Rope Guide                          | 42          | 753-04559       | Piston Spacer                             |
| 7           | 753-04524       | Rope                                | 43          | 753-04560       | Piston Pin                                |
| 8           | 753-04525       | Recoil Case                         | 44          | 753-04561       | Piston                                    |
| 9           | 753-04526       | Recoil Spring                       | 45          | 753-04562       | Piston Ring                               |
| 10          | 753-04527       | Recoil Pulley                       | 46          | 753-04563       | Cylinder Gasket                           |
| 11          | 753-04528       | Washer                              | 47          | 753-04564       | Screw                                     |
| 12          | 753-04529       | Screw                               | 48          | 753-04565       | Screw                                     |
| 13          | 753-04530       | Recoil Assembly (includes 4-12)     | 49          | 753-04566       | Muffler Cover                             |
| 14          | 753-04531       | Fuel Line Grommet                   | 50          | 753-04567       | Muffler Bolt                              |
| 15          | 791-181828      | Fuel Line                           | 51          | 753-04568       | Spark Arrestor Screw                      |
| 16          | 753-04533       | Fuel Filter                         | 52          | 753-04569       | Spark Arrestor Hood                       |
| 17          | 753-04534       | Fuel Cap                            | 53          | 753-04570       | Spark Arrestor                            |
| 18          | 753-04535       | Screw                               | 54          | 753-04571       | Muffler Assembly (includes 51-53)         |
| 19          | 753-04536       | Spacer                              | 55          | 753-04572       | Muffler Gasket                            |
| 20          | 753-04537       | Washer                              | 56          | 753-04573       | Screw                                     |
| 21          | 753-04538       | Fuel Tank Assembly (includes 14-17) | 57          | 753-04574       | Cylinder Cover                            |
| 22          | 753-04539       | Pawl Assembly                       | 58          | 753-04575       | Cylinder Bolt                             |
| 23          | 753-04540       | Upper Oil Seal                      | 59          | 753-04576       | Cylinder                                  |
| 24          | 753-04541       | Upper Crankcase                     | 60          | 753-04577       | Module                                    |
| 25          | 753-04542       | Bearing                             | 61          | 753-04578       | Module Screw                              |
| 26          | 753-04543       | Keyed Powershaft Assembly           | 62          | 753-04579       | Spark Plug                                |
| 27          | 753-04544       | Flywheel Key                        | 63          | 753-04580       | Insulator Gasket                          |
| 28          | 753-04545       | Crankshaft Gasket                   | 64          | 753-04581       | Insulator                                 |
| 29          | 753-04546       | Lower Crankcase                     | 65          | 753-04583       | Insulator Screw                           |
| 30          | 753-04547       | C-Clip                              | 66          | 753-04582       | Carburetor Gasket                         |
| 31          | 753-04548       | Lower Oil Seal                      | 67          | 753-04584       | Carburetor                                |
| 32          | 753-04549       | Crankshaft Screw                    | 68          | 753-04585       | O-Ring                                    |
| 33          | 753-04550       | Flywheel                            | 69          | 753-04586       | Air Cleaner Assembly (includes 72 and 73) |
| 34          | 753-04551       | Spacer                              | 70          | 753-04587       | Washer                                    |
| 35          | 753-04552       | Spark Wire Grommet                  | 71          | 753-04588       | Air Cleaner Screw                         |
| 36          | 753-04743       | Lower Engine Cover                  | 72          | 753-04589       | Air Filter                                |
|             |                 |                                     | 73          | 753-04590       | Air Filter Cover                          |

**IMPELLER HOUSING PARTS - MODEL TB250B**  
**2-CYCLE GAS BLOWER**  
**PPN 41AR290G766**



| <u>Item</u> | <u>Part No.</u> | <u>Description</u>     |
|-------------|-----------------|------------------------|
| 1           | 753-04591       | Blower Handle          |
| 2           | 753-04186       | Weldnut                |
| 3           | 753-04592       | Spacer                 |
| 4           | 753-04593       | Upper Impeller Housing |
| 5           | 753-04594       | Blower Tube            |
| 6           | 791-182409      | Washer                 |
| 7           | 753-04595       | Housing Screw          |
| 8           | 791-181904      | Handle Washer          |
| 9           | 791-683606      | Handle Screw           |
| 10          | 753-04596       | Impeller               |
| 11          | 753-04597       | Washer                 |
| 12          | 753-04598       | Lock Washer            |
| 13          | 753-04599       | Bolt                   |
| 14          | 753-04600       | Lower Impeller Housing |
| 15          | 753-04601       | Intake Deflector       |
| 16          | 791-182474      | Deflector Screw        |