



No Diagram Available

Parts List Only


Ref #	Part Number	Qty	Description
	91753		Case - Carrying
	88756		Scrench
	83687		Guide - Timing
	90256		Kit - Tune Up
	68915A		Kit - Piston Tool
	84992		Kit - Reed Muffler
	85933		Kit - Spark Arrester Screen (Reed Muffler)
	85924		Kit - Spark Arrester (PM6 Type)
	89685		Screen - Spark Arrester



Ref #	Part Number	Qty	Description
	90918	1	Carburetor Asy
1	83755	2	Screw - Plate
2	68556	1	Plate - Choke
3	85033	1	Shaft - Choke
4	100302	1	Ball - Choke friction
5	67504	1	Spring - Choke friction
6	68553	1	Plate - Throttle
7	70798	1	Screw - Clip
8	68554	1	Clip - Throttle shaft
9	90471	1	Shaft Asy - Throttle
10	68566	1	Screw - Idle speed
11	86446	1	Needle - Idle
12	86447	1	Needle - High speed
13	67502	2	Spring - Needle
14	68564	4	Screw Asy - Body
15	91347	1	Cover Asy - Pump
15A	85629	1	Kit - Vent screen
16	68563	1	Diaphragm - Fuel pump
17	85035	1	Gasket - Pump diaphragm
18	85030	1	Body - Fuel pump
19	85036	1	Diaphragm - Metering
20	85034	1	Gasket - Diaphragm
21	67500	1	Screw - Lever pin
22	67508	1	Pin - Lever
23	85059	1	Kit - Needle & lever
24	68567	1	Spring - Lever
25	68559	1	Plug - Welsh 7/16
26	83758	1	Kit - Check valve
27	68560	1	Plug - Welsh 1/2
28	89785	1	Spring - Throttle return
29	86463		Repair Kit




Ref #	Part Number	Qty	Description
	92594		CHAIN BRAKE Asy
1	102762	1	Screw - Hx hd 10-24 x 1/2
2	101194	1	Washer - Lock #10
3	110712	1	Washer
4	90580	1	Band & Lever
5	90587A	1	Spring - Brake Actuator
6	90588	1	Guide - Spring
7	90967	1	Washer - Actuating Lever
8	92592	1	Kit - Housing/Spring
9	103047	1	Pin
10	100001	1	Washer
11	110946	1	Screw Drive - 6 x 5/16
12	110955	1	Screw - Set 8-32 x 1/2
13	90658	1	Screw - Adjusting
14	110907	1	Ring - Retaining
15	84929	1	Nut - Bar adjusting
16	90576	1	Lever - Actuator



General

Ref #	Part Number	Qty	Description
1	92588	1	Grinder Asy - AUTO SHARP
2	92587	1	Wheel Asy - Grinding
3	110968	1	Ring - Retaining
4	92582	1	Knob
5	110676	1	Nut - Hx 1/4-28
6			CHAIN BRAKE Asy See "Chain Brake Assembly" illustration and parts list.
7	92600N	1	Chain - AS 370G
8	90550	1	Bar - 14" Mini Pro
9	92743	1	Clutch Assembly
10	69358	1	Spring - Clutch
11	91050	2	Shoe - Clutch
12	110709	2	Rivet
13	85064	2	Plate
14	92721	1	Spider
15	90150A	1	Drum/Spkt/Brg Asy - .375P
16	91222	1	Bearing
17	92671	1	Plate - Name
18	110953	1	Screw - Hx hd 12-24 x 5/8
19	110686	1	Screw - Hx hd 13-16 x 2
20	84791	1	Frame & Grip Asy
21	110639	2	Screw - Hx hd 12-24 x 1
22	88591	1	Cover - Fuel & Oil tank
23	91454A	1	Kit - Fuel & Oil tank
24	91283	2	Cap - Fuel & Oil
25	91148	1	Seal - Fuel vent
26	84956	1	Pickup - Fuel
27	83900A	1	Piston - Manual oiler
28	83946	1	Spring - Piston
29	85557	1	Body - Oiler
30	84611	1	Rod - Manual oiler
31	91853	1	Cover - Air cleaner
32	91796	1	Screw - Air cleaner
33	85127	1	Filter - Air
34	84918	1	Washer - Air seal
35	110672	1	Screw - Oval hd 4-40 x 1
36	83870	1	Knob - Choke
37	110953	2	Screw - Hx hd 12-24 x 5/8
38	84520A	1	Plate - Washer
39	84519	2	Sleeve - Handle
40	83852A	1	Handle
41	110953	3	Screw - Hx hd 12-24 x 5/8
42	92589	1	Shroud
43	83878	1	Trigger
44	83940	1	Spring - Trigger
45	83935	1	Contact - Switch
46	83936	1	Protector - Switch
47	83934	1	Button - Switch
48	110959	3	Screw - Hx hd 8-32 x 1/2
49	90425	1	Cover - Starter
50	110706	1	Screw - Pan hd 8-18 x 1/2
51	68497	1	Washer - Special
52	92316	1	Drum/Rope Asy
53	83203	1	Rope - Starter
54	83078	1	Spring - Rewind

Ref #	Part Number	Qty	Description
55	91255	1	Kit - Starter handle
56	105490	1	Washer
57	92581	1	Bracket - AUTO SHARP
58	110597	2	Screw - Pan hd 8-32 x 1/2 (SEMS)
59			Powerhead Asy See "Powerhead Assembly" illustration and parts list



Ref #	Part Number	Qty	Description
1	83898	1	Connector - Outlet
2	84613	1	Connector - Pump
3	83896	1	Bail - Mounting
4	83886	1	Pump Asy - Pulse
5	105603	1	"O" Ring
6	85769	1	Ring - Pump Piston
7	92204	1	Piston Asy - Pump
8	83891	1	Spring - Pump
9	83890	1	Sleeve - Pump
10	110651	1	Screw - Adjustment
11	83887	1	Body Asy - Pump
12	110653	1	"O" Ring
13	110674	1	Screw - Hx hd 10-24 x 1/2
14	89684	1	Cover - Muffler
15	110928	2	Screw - Hx hd 10-24 x 1/2
16	89682	1	Body - Muffler
17	63097	1	Spark Plug
18	89274	1	Rod - Throttle
19	89059	1	Hose - Fuel
20	90660	1	Adapter
21	110908	1	"O" Ring
22	110970	1	Nut - Hx 5/16-24
23	91961	1	Flywheel & Pawl Asy
24	68796	2	Pin - Pawl
25	92898	2	Spring - Pawl
26	91872	2	Pawl - Starter
27	102164	1	Key - Woodruff
28	110586	3	Screw - Pan hd 8-32 x 1-3/4
29	105976	3	Washer - #8
30	67177	3	Washer - Insulator
31	68198	3	Tube - Insulator
32			Carburetor Asy See "Carburetor Assembly" illustration and parts list.
33	68197	1	Gasket - Carburetor
34	90713	1	Insulator - Carburetor
35	90714	1	Gasket - Insulator
36	84957	1	Coil & Lamination Asy
37	50120	1	Wire Asy - Spark plug
38	110364	1	Screw - Pan hd 6-32 x 5/8
39	69344	1	Wire Asy - Primary
40	110041	1	Screw - Pan hd 8-32 x 1/2 s/t
41	85358	1	Condenser
42	100035	1	Nut - Hx 6-32
43	84502	1	Connector - Stop switch
44	67841	1	Cover - Breaker box
45	69323	1	Seal - Breaker box
46	110969	2	Screw - Hx hd 8-32 x 1/2
47	69322	1	Washer - Special
48	105976	1	Washer - #8
49	88811	1	Breaker Asy
50	84505A	1	Kit - Breaker Box
51	92037	1	Washer
52	110639	4	Screw - Hx hd 12-24 x 1
53	90665B	1	Cyl/C'Case Asy
54	83856	1	Bolt - Bar mounting

Ref #	Part Number	Qty	Description
55	66867	1	Pin - Piston
56	68098	1	Piston Asy
57	87165	1	Ring Set - Piston
58	110538	2	Bearing - Needle
59	68097	1	Connecting Rod Asy
60	66853	2	Screw - Special
61	68095	1	Roller - Needle (Set of 20)
62	83859	2	Seal - Oil
63	66854	2	Bearing - Needle
64	91932	1	Crankshaft