


No  
Diagram  
Available  
  
Parts List  
Only


Ref #	Part Number	Qty	Description
	216058		Key - Socket - 9/64
	216063		Key - Socket - 5/32
	84453		Kit - Piston Tool
	69191		Kit - Pressure Test Adaptor
	214223		Spark Plug (Standard)
	63432		Spark Plug (Cooler)
	62827		Wrench/Screwdriver
	214221		Scrench
	91226		Wrench - Clutch/Flywheel
	86419		Guide - Timing
	92993		Spark Arrester Screen

No  
Diagram  
Available  
  
Parts List  
Only

Ref #	Part Number	Qty	Description
	94074		16" Speed Mac Bar
	89502		16" Mac 10 Bar
	93778		20" Speed Mac Bar
	89503		20" Mac 10 Bar
	86846		24" Speed Mac Bar
	89504		24" Mac 10 Bar
	86847		28" Speed Mac Bar
	89505		28" Mac 10 Bar
	88167-12		16" PM370GX 60 C.L. Chain
	89974-12		16" SPR370GX 60 C.L. Chain
	88173-12		20" PM370GX 71 C.L. Chain
	89979-12		20" SPR370GX 71 C.L. Chain
	88175-12		24" PM370GX 81 C.L. Chain
	89981-12		24" SPR370GX 81 C.L. Chain
	93552-12		28" PM370GX 93 C.L. Chain
	89984-12		28" SPR370GX 93 C.L. Chain
	218739		File Plate No.
	218738		File Plate No.
	56698-23		7/32 Round File No. 1 Doz. Pak
	219161		7/32 Round File No. Twin Pak




Ref #	Part Number	Qty	Description
	87666	1	CARBURETOR ASY (WALBRO)
1		1	Screw - Pump Cover Not available separately.
2		4	Cover - Pump Not available separately.
3		1	Gasket - Cover Not available separately.
4		1	Diaphragm - Check Valve Not available separately.
5		1	Diaphragm - Fuel Pump Not available separately.
6		3	Screw - Plate Not available separately.
7		1	Plate - Throttle Not available separately.
8		1	Clip - Shaft Not available separately.
9		1	Shaft Asy - Throttle Not available separately.
10		1	Plate - Choke Not available separately.
11		1	Shaft Asy - Choke Not available separately.
12		1	Ball - Choke Friction Not available separately.
13		1	Spring - Choke Not available separately.
14		1	Needle - High Speed Not available separately.
15		1	Needle - Idle Not available separately.
16		2	Spring - Needle Not available separately.
17		4	Screw - Diaphragm Cover Not available separately.
18		1	Cover - Diaphragm Not available separately.
19		1	Diaphragm - Metering Not available separately.
20		1	Gasket - Diaphragm Not available separately.
21		1	Screw - Lever Pin Not available separately.
22		1	Pin - Lever Not available separately.
23		1	Lever - Metering Not available separately.
24		1	Spring - Lever Not available separately.
25		1	Valve - Needle Not available separately.
26		1	Plug - 3/8 Not available separately.
27		1	Plug - 5/16 Not available separately.
28		1	Kit - Valve & Seat Asy Not available separately.
29		1	Screen - Fuel Not available separately.
	217080		Major Repair Kit
	217078		Gasket/Diaphragm Kit




Ref #	Part Number	Qty	Description
	217694	1	CHAIN BRAKE Asy
1	216634	1	Screw - Pan Hd 10-24 x 1/2
2	216633	1	Washer - Special
3	215911	1	Lever Asy
4	214366	1	Pin Asy - Roller
5	93085	1	Spring - Brake
6	217235	1	Latch
7	93669	1	Pivot - Latch
8	93081	1	Band - Brake
9	93082	1	Pin - Band Anchor
10	216771	1	Housing Asy - Brake
11	216636	1	Screw - Fil Hd 10-24 x 2-3/4
12	110582	1	Washer - #10
13	61705	1	Nut - Bar Adjusting
14	100002	1	Washer - #10
15	102067	1	Nut - Hx 10-24
16	91246	1	Pin - Lever Pivot
17	91245	1	Washer - Thrust






Ref #	Part Number	Qty	Description
	216050	1	FAN HOUSING/STARTER ASY
1	110646	3	Screw - Oval Hd 8-32 x 1-1/8
2	91084	1	Cover - Starter
3	110928	1	Screw - Hx Hd 10-24 x 1/2
4	68162	1	Rope - Starter
5	110470	1	Rivet - Rope
6	83959	1	Drum - Starter
7	87680	1	Spring - Rewind
8	86053	1	Shield - Spring
9	83748	1	Shaft - Starter
10	57535	2	Bushing - Starter
11	216051	1	Housing - Fan
12	214192	1	Guard - Sawdust
13	214699	1	Insert - Handle
14	93137	1	Handle - Starter




Ref #	Part Number	Qty	Description
1	89320	1	Insert - Handle Grip
2	216126	1	Button & Rod Assembly
3	95615	1	Button - Oiler
4	216127	1	Kit - Fuel Tank/Control
5	110378	1	Pin - Roll 3/16 x 15/16
6	92152	1	Spring - Trigger
7	214679	1	Trigger - Throttle
8	105654	1	Pin - Roll 1/8 x 7/8
9	92154	1	Spring - Trigger Release
10	214680	1	Release Asy - Trigger
11	111012	1	Screw - Pn Hd 4-40 x 5/16
12	110706	1	Screw - Pn Hd 8-18 x 1/2
13	214692	1	Wire Asy - Stop Switch
14	62451	1	Control - Switch
15	214691	1	Base - Switch
16	68846	1	Button - Switch
17	85107	1	Rod - Throttle
18	214701	1	Seal - Throttle Rod
19	105673	2	Pin - Roll 3/32 x 9/16
20	69041	1	Button - Choke
21	105614	1	"O" Ring
22	69042	1	Rod - Choke
23	69043	1	Snubber - Rod
24	219280	1	Set - Gaskets (L.H. and R.H.)



Ref #	Part Number	Qty	Description
1	216640	2	Nut - Hx 5/16-24
2		1	CHAIN BRAKE See "Chain Brake Assembly" illustration and parts list.
3		1	Chain Assembly See "Bar/Chain/Chain Sharpening Tools" parts list.
4		1	Bar Assembly See "Bar/Chain/Chain Sharpening Tools" parts list.
5	64330	1	Set - Bar Plates (2)
6	93668	1	Spike
7	216683	2	Washer - Special
8	213042	2	Screw - Skt Hd 10-24 x 5/8
9	216682	2	Nut - Hx Lock 10-24
10	216677	2	Screw - Hx Hd 10-24 x 7/8
11	100352	2	Washer - #10
12	89727	1	Retainer - Frame
13	216638	1	Screw - Hx Hd 1/4-20 x 1-1/2
14	100153	1	Washer - Lock 1/4
15	216639	1	Clamp - Frame
16	214549	1	Frame & Grip Assembly
17	86113	1	Nut - Hx 3/8-24 (L.H.)
18	214301	1	Clutch Assembly
19	64583	2	Retainer - Spring
20	83223	2	Spring - Clutch
21	67233	1	Kit - Clutch Shoe
22	214300	1	Rotor - Clutch
23	95165	1	Drum & Sprocket Asy 7T .375P
24	86951	1	Sprocket - 77 .375P
25	86958	1	Washer - Sprocket
26	110971	1	Bearing - Sprocket
27	91543	1	Cover Asy - Air Cleaner
28	110565	1	Ring - Retaining
29	68529	1	Knob - Cover
30	216138	1	Plate - Name
31	216054	1	Plate - Instruction
32	69922	1	Filter - Air
33	110741	2	Screw - Pan Hd 10-24 x 1/2
34	87871	3	Screw - Special
35		1	Fan Housing/Starter Asy See "Fan Housing/Starter Assembly" illustration and parts list.
36	216053	1	Cap Asy - Fuel W/Retainer
37	216678	1	Screw - Oval Hd 10-24 x 2-3/8
38	101986	2	Screw - Oval Hd 10-24 x 1
39	87840	1	Spacer
40	88650	1	Cover - Fuel Tank
41	87932	1	Screw - Idle Adjustment
42	87665	1	Boot - Carburetor Adjustment
43	69345	1	Gasket - Cover
44	215208	1	Hose Asy - Fuel
45	215714	1	Pickup Asy - Fuel
46	69952	1	Bracket - Air Cleaner
47	103357	2	Bolt - Hx Hd 10-24 x 2-1/4
48		1	Carburetor Asy See "Carburetor Assembly" illustration and parts list.

Ref #	Part Number	Qty	Description
49	86189	1	Gasket - Carburetor
50	84078	1	Spacer - Carburetor
51	84081	1	Gasket - Spacer
52	110567	2	Screw - Hx Hd 12-24 x 1-1/4
53	68582	1	Plate - Lock
54	102115	2	Washer - #12
55	110568	1	Screw - Hx Hd 12-24 x 1-1/8
56	69516	1	Plate - Lock
57	100352	1	Washer - Special
58	110713	1	Screw - Skt Hd 10-24 x 7/8
59	100003	1	Washer - #10
60	69772	1	Spacer - Fuel Tank
61	216632	1	Screw - Pn Hd 10-24 x 1-1/4
62		1	Fuel Tank Asy See "Fuel Tank Assembly" illustration and parts list.
63	84082	1	Gasket - Fuel Tank
64	84080	1	Insulator - Fuel Tank
65	68594	1	Gasket - Insulator
66	216679	1	Screw - Hx Hd 10-24 x 5/8
67	68508	1	Plate - lock
68	216679	1	Screw - Hx Hd 10-24 x 5/8
69	85007	1	Brace - Handle
70	214702	1	Shroud
71	110563	2	Screw - Skt Hd 8-32 x 1/4
72	92996-01	1	Stop - Reed
73	85585-01	1	Valve - Reed
74	101563	1	Screw - Skt Hd 10-24 x 1-1/4
75	110439	1	Screw - Skt Hd 10-24 x 1
76	92995	1	Cover - Spark Arrestor
77	110529	1	Screw - Hx Hd 10-24 x 1/2
78	68187	1	Screw - Special
79	67922	1	Plate - Lock
80	92989	1	Body Muffler
81	84007	1	Gasket - Muffler
82		1	Powerhead Asy See "Powerhead Assembly" illustration and parts list.
	215720		Bearing Kit





Ref #	Part Number	Qty	Description
1	110703	1	Nut - Hx 3/8-24
2	216739	1	Flywheel Assembly
3	93464	2	Screw - Pawl
4	93198	2	Pawl - Starter
5	93469	2	Washer - Pawl
6	214102	2	Spring - Pawl
7	100106	1	Key - Woodruff
8	110127	1	Screw - Hx Hd 10-24 x 7/8 (Sems)
9	100002	2	Washer - #10
10	83512	1	Stud - Special
11	84686-01	1	Wire Assembly - Ground
12	95553	1	Ignition - Electronic
13	95269	1	Wire Asy - Spark Plug
14	102556	1	Connector
15	95266	1	Boot
16	110995	1	Grommet
17	110338	2	Screw - Pn Hd 8-32 x 1/2
18	110613	2	Washer - #8
19	100955	1	Nut - Hx 8-32
20	84156	1	Housing - Pump
21	215151	1	Cap - Housing
22	62266	1	Plunger - Pump
23	105614	1	"O" Ring
24	66687	1	Spring - Pump
25	91669	1	Gasket - Pump
26	91668	1	Valve - Pump
27	110291	1	Screw - Pn Hd 10-24 x 2-5/8
28	110921	1	Washer - Sealing
29	218707	1	Cover - Oil Tank
30	86306	1	Gasket - Cover
31	216052	1	Cap - Oil Tank
32	101148	1	"O" Ring
33	91672	1	Hose Assembly - Oil
34	51506	1	Screen - Hose
35	215339	1	Kit - Pulse Pump
36	92874	1	Seal - Pulse Pump
37	214278	1	Piston Assembly - Pump
38	86182	1	Ring - Piston
39	105603	1	"O" Ring
40	60259	1	Spring - Piston
41	62227	1	Sleeve - Adjustment
42	91259	1	Pad - Pump
43	91774	1	Sleeve
44	216677	1	Screw - Hx Hd 10-24 x 7/8
45		1	Spring - Outlet Valve Not avaiable separately.
46		1	Ball Not avaiable separately.
47	110386	1	Screw - Hx Hd 8-32 x 1
48		2	Eyelets Not avaiable separately.
49			Clip - Sealing Not avaiable separately.
50	62106	4	Screw - Sealing
51	111025	4	Washer - Sealing
52	110288	1	Screw - Hx Hd 8-32 x 3/4
53	214671	1	Cylinder/C'Case Assembly
54	110288	2	Screw - Hx Hd 8-32 x 3/4
55	110618	1	Screw - Hx Hd 8-32 x 1-3/8

Ref #	Part Number	Qty	Description
56	62065	2	Bolt - Bar Mounting
57	110851	1	Pin - Dowel
58	94273	1	Valve - DSP
59	214765	1	Washer - Valve
60	110681	1	Screw - Skt Hd 10-24 x 1/4
61	87152	1	Insert - Bearing
62	69020	1	Pin - Piston
63	85239	1	Piston Assembly
64	89732	1	Ring Set - Piston
65	111021	2	Bearing - Needle
66	85352	1	Rod Assembly - Connecting
67	61627-01	2	Screw - Skt Hd Special
68	63225	1	Roller - Needle (Set of 20)
69	216909	1	Crankshaft Assembly
70	61618	1	Seal - Oil
71	63464	1	Ring - Snap
72	63429-02	1	Bearing - Ball
73	110260	1	Seal - Oil
74	104357	1	Bearing - Needle
75	214223	1	Spark Plug
	215246	1	Kit - Oil Pump Clip