



Ref #	Part Number	Qty	Description
1	235217	1	Bar Retaining Nut - M6
2	235620	1	Spike
3	214234	1	Guide Bar - 12 Inches
3	214235	1	Guide Bar - 14 Inches
3	214236	1	Guide Bar - 16 Inches
4	218095N	1	Saw Chain - 12 Inches
4	218096N	1	Saw Chain - 14 Inches
4	218097N	1	Saw Chain - 16 Inches
4	218098N	1	Saw Chain - 16 Inches
5	235207	2	Screw - M5 x 14
6	235377	1	Starter Assembly
7	235430	1	Screw
8	235048	2	Starter - Washer
9	235431	1	Nut
10	235372	1	Drum & Rope Assembly
11	83203	1	Starter Rope
12	235371	1	Spring - Rewind
13	235043	1	Starter Handle
14	235643	1	Fan Baffle
15	235032	1	Cover - Air Filter
16	235030	1	Knob - Filter Cover
17	235526	1	Air Filter
18	235216	1	Nut - M5
19	235189	1	Washer - Air Filter
20	235225	1	Washer - Wavy
21	235020	1	Plate - Choke
22	235187	1	Kit - Choke Knob
23	235033	1	Bushing - Choke
24	235707	1	Grommet - Air Filter
25	235216	1	Nut - M6
26	235189	1	Kit - Manual Oil Lever
27	235281	1	Clip - Lever Retaining
28	235193	1	Rod - Manual Oiler
29	235207	1	Top Cover Screw - M5 x 4
30	235028	1	Top Cover - Engine
31	235697	1	Gasket - Foam
32	235216	2	Carburetor Bolt Nut - M5
33	235029	1	Bolt - Carburetor (Left)
34	235183	1	Bolt - Carburetor (Right)
35	235234	1	Gasket - Carburetor Cover
36	235522	1	Guide - Screwdriver
37	235449	1	Carburetor Assembly
38	235016	1	Gasket - Carburetor
39	235120	1	Valve - Reed
40	235015	1	Gasket - Reed
41	235370	1	Kit - Carburetor Repair
42		1	Diaphragm Not available separately.
43		1	Gasket - Diaphragm Not available separately.
44		1	Lever - Inlet Control Not available separately.
45		1	Needle - Inlet Not available separately.
46		1	Welch Plug & Strainer Not available separately.
47		1	Gasket - Fuel Pump Not available separately.
48	235254	1	Diaphragm - Fuel Pump
49	235261	1	Handle - Front
50	235210	1	Screw - Sstd. Hd. M5 x 25

Ref #	Part Number	Qty	Description
51	235248	1	Washer - M5
52	235216	1	Nut - Hex Head M5
53	235244	1	Screw - Slt. Hd. M5 x 45
54	235248	1	Washer
55	235642	1	Nut - Hex Head M5
56	235106	1	Bushing
57	235105	1	Shock Mount - Rubber
58	235107	1	Washer
59	235239	1	Screw - Slt. Hd. M5 x 20
60	235248	1	Washer
61	235642	1	Nut - Hex Head M5
62	235106	1	Bushing
63	235105	1	Shock Mount - Rubber
64	235107	1	Washer
		1	REAR HANDLE ASSEMBLY
65	235210	1	Screw - Slt. Hd. M5 x 25
66	235107	1	Washer
67	235105	1	Shock Mount - Rubber
68	235106	1	Bushing
69	235210	1	Screw - Slt. Hd. M5 x 25
70	235107	1	Washer
71	235105	1	Shock Mount - Rubber
72	235106	1	Bushing
73	235205	4	Screw - Slt. Hd.
74	235482	1	Kit - Rear Handle
75	235519	1	Safety Trigger
76	235104	1	Spring
77	235521	1	Throttle Trigger
78	235022	1	Rod - Throttle Trigger
79	235281	1	Retainer - Throttle Rod
80	235212	2	Screw - Clutch Cover M5 x 35
81	235427	1	Cover - Clutch
82	235155	1	Spacer
83	235170	1	Plug
84	235153	1	AUTO SHARP Assembly
85	218218	1	Wheel Assembly - Grinding
86		1	Washer Not available separately.
87		1	Cotter Pin Not available separately.
88	235114	1	AUTO SHARP Knob
89	235121	1	Spring
90	235205	1	Screw - Brake Box
91	235653	1	Lever - CHAIN BRAKE
92	235177	1	Brake Box
93	235530	1	Screw - Skt. Hd. M6 x 35
94	235512	1	Brake Bushing
95	235226	1	Pivot - Brake Band
96	214368	1	Bearing - Roller
97	235812	1	Screw - Brake Band
98	235224	1	Ring - Seeger
99	235073	1	Brake Band
100	235287	1	Washer - Clutch
101	235164	1	Washer
102	215252	1	Drum/Sprocket Assembly
103	235115	1	Clutch
104	235701	1	Sawdust Shield

Ref #	Part Number	Qty	Description
105	235076	1	Spring - Brake Latch
106	235669	1	Muffler Assembly
107	235213	2	Screw - M5 x 50
108	235665	1	Spark Arrester Screen
109	214223	1	Spark Plug
110	235214	4	Cylinder Screw - M6 x 20
111	235479	1	Kit - Cylinder
112	235135	1	Gasket - Cylinder
113	235478	1	Piston Assembly
114	235008	2	Ring - Snap
115	235178	2	Ring - Piston
116	235007	1	Wrist Pin
117	235801	3	Screw - M4 x 16 TCE
118	235513	1	Kit - Oil Pump
119	235159	1	Gasket - Oil Pump
120	235051	1	Gasket - Oil Pump
121	235173	1	Screw - Oil Flow Adjustment
122	235438	1	Screen - Oil Filter
123	235186	1	Check Ball - Oil Pump
124		1	Gasket - Oil Pump Not available separately.
125		1	Cover - Oiler Body Not available separately.
126	235138	1	Flywheel/Pawl Assembly
127	235516	2	Pin - Pawl
128	235517	1	Pawl - Starter
129	235516	2	Spring - Pawl
130	235218	1	Nut - M8
131	235215	1	Screw - M6 x 90 (Crankcase)
132	235211	6	Screw - M5 x 30 (Crankcase)
133	235726	1	Kit - Crankcase
134	94006	1	Brake Latch
135	235075	1	Later - Pivot
136	235225	2	Seal
137	235424	2	Pin - Guide Bar
138	235641	1	Oil Vent
139	235222	1	Chair Catcher
140	235574	1	Kit - Chain Tension Adjusting
141		1	Gasket - Crankcase Not available separately.
142	235672	1	Support - Rubber
143		1	Gasket - Crankcase Not available separately.
144	235190	1	Bushing
145	235221	1	Pin
146	235765	1	Kit - Crankshaft
147	235230	2	Bearing - Ball
148		1	Connecting Rod Not available separately.
149		1	Bearing - Needle Not available separately.
150	102164	1	Key - Woodruff
151	235674	1	Support
152	235670	1	Protective Shield - Fuel Tank
153	235729	1	Fuel Tank Assembly
154	235861	1	Fuel Tank Neck
155	235510	1	"O" Ring
156	235436	1	Kit - ON/OFF knob
157	235239	2	Screw - Ignition Bracket
158	235429	1	Bracket - Ignition
159	235368	1	Contact - Ignition

Ref #	Part Number	Qty	Description
160	235034	1	Electronic Ignition System
161	235238	1	High Tension Wire
162	235675	1	Grommet - Fuel Tank
163	93720	1	Filter - Fuel Tank
164	235673	1	Screw - Fuel Line Vent
165	235713	1	Fuel Hose
166	235741	1	Valve - Fuel Line vent
167	235758	1	Fuel Line Vent Assembly
168	235788	1	Fuel Cap
169	235510	1	"O" Ring
170	235789	1	Oil Cap
171	235061	1	Gasket - Oil Cap