

No
Diagram
Available


Parts List
Only

Ref #	Part Number	Qty	Description
	214221		Scrench - 13mm x 5/8
	84453		Kit - Piston Tools
	63432		Spark Plug
	62827		Wrench/Screwdriver
	214194		Metal Lubri-gun
	214195		Plastic Lube Gun
	215697		Air Filter - Felt
	216147		Key - Socket 1/8
	216335		Key - Socket 3/32
	216063		Key - Socket 5/32
	214283		Spark Screen & Cap Asy


No
Diagram
Available

Parts List
Only


Ref #	Part Number	Qty	Description
	94074-00		16" Speed Mac Bar
	86830		Replacement - Sprocket Tip
	89974-12		SPR370GX Chain 60 CL
	94074-05		16" Speed Mac Bar
	219975		Replacement - Sprocket Tip
	89974-12		SPR370GX Chain 60 CL
	93778-00		Speed Mac Bar
	86830		Replacement - Sprocket Tip
	89979-12		SPR370GX Chain 71 CL
	93778-05		20" Speed Mac Bar
	219975		Replacement - Sprocket Tip
	89979-12		SPR370GX Chain 71 CL
	86846-00		24" Speed Mac Bar
	86830		Replacement - Sprocket Tip
	89981-12		SPR370GX Chain 81 CL
	86846-05		24" Speed Mac Bar
	219975		Replacement - Sprocket Tip
	89981-12		SPR370GX Chain 81 CL
	86847-00		28" Speed Mac Bar
	86830		Replacement - Sprocket Tip
	89984-12		SPR370GX Chain 92 CL
	86847-05		28" Speed Mac Bar
	219975		Replacement Sprocket Tip
	89984-12		SPR370GX Chain 92 CL
	89505		28" Mac 10 Bar
	89985-12		SPR370GX Chain 93 CL
	91284		33" Speed Mac Bar
	86830		Replacement - Sprocket Tip
	92101-12		SPR370GX Chain 106 CL
	91284-01		33" Speed Mac Bar
	219975		Replacement - Sprocket Tip
	92101-12		SPR370GX Chain 106 CL
	218738		File Plate
	219161		7/32" (5.5mm) Round File Sharpening Tool for GX Chain
	56698-23		7/32" (5.5mm) Round File Sharpening Tool for GX Chain
	89503		20" Mac 10 Bar
	88173-14		PM370G Chain 71 CL
	86846		24" Speed Mac Bar
	86830		Replacement - Sprocket Tip
	88175-14		PM370G Chain 81 CL
	89505		28" Mac 10 Bar
	93552-14		PM370G Chain 93 CL
	219161		7/32" (5.5mm) Round File Sharpening Tool for G Chain
	56698-23		7/32" (5.5mm) Round File Sharpening Tool for G Chain




Ref #	Part Number	Qty	Description
	218616	1	Carburetor Assembly
1		4	Screw - Pump Cover Not available separately.
2		1	Cover - Pump Not available separately.
3		1	Gasket - Cover Not available separately.
4		1	Diaphragm - Check Valve Not available separately.
5		1	Diaphragm - Fuel Pump Not available separately.
6		2	Screw - Plate Not available separately.
7		1	Plate - Throttle Not available separately.
8		1	Clip - Shaft Not available separately.
9		1	Shaft Asy - Throttle Not available separately.
10		1	Spring - Throttle Shaft Not available separately.
11		1	Plate - Choke Not available separately.
12		1	Shaft Asy - Choke Not available separately.
13		1	Ball - Choke Friction Not available separately.
14		1	Spring - Choke Friction Not available separately.
15		1	Needle - High Speed Not available separately.
16		1	Needle - Low Speed Not available separately.
17		2	Spring - Needle Not available separately.
18		1	Screw - Idle Speed Not available separately.
19		1	Spring - Idle Screw Not available separately.
20		2	Screw - Idle Bracket Not available separately.
21		1	Bracket - Idle Not available separately.
22		4	Screw - Diaphragm Cover Not available separately.
23		1	Cover - Diaphragm Not available separately.
24		1	Diaphragm - Metering Not available separately.
25		1	Gasket - Diaphragm Not available separately.
26		1	Screw - Lever Pin Not available separately.
27		1	Pin - Lever Not available separately.
28		1	Lever - Metering Not available separately.
29		1	Spring - Lever Not available separately.
30		1	Valve - Needle Not available separately.
31		1	Plug - 3/8" Not available separately.
32		1	Plug - 5/16" Not available separately.
33		1	Valve & Seat Asy Not available separately.
34		1	Washer - Check Valve Not available separately.
35		1	Screen - Check Valve Not available separately.
36		1	Screen - Fuel Not available separately.
	219247	1	Repair Kit
	219248	1	Gasket/Diaphragm Kit




Ref #	Part Number	Qty	Description
	217695	1	CHAIN BRAKE Assembly
1	216634	1	Screw - Pan hd 10-24 x .50
2	216633	1	Washer .210 I.D.
3	215911	1	Lever Assembly
4	214366	1	Pin Assembly - Roller
5	93085	1	Spring - Brake
6	217235	1	Latch - Chain Brake
7	94144	1	Pivot - Latch
8	93081	1	Band - Brake
9	93082	1	Pin - Band Anchor
10	215699	1	Housing - Brake
11	216636	1	Screw - Fil hd 10-24 x 2.75
12	216635	1	Washer .203 I.D.
13	61705	1	Nut - Bar Adjusting
14	100002	1	Washer - #10
15	102067	1	Nut - Hx 10-24
16	91246	1	Pin - Lever Pivot
17	91245	1	Washer - Thrust



Ref #	Part Number	Qty	Description
	215706	1	Fan Housing/Starter Asy
1	216625	3	Screw - Oval 10-24 x 1.25
2	215707	1	Cover Assembly - Starter
3	87670	1	Rope - Starter
4	110928	1	Screw - Hx hd 10-24 x .50
5	105841	1	Pin - Roll
6	87689	1	Drum - Starter
7	87680	1	Spring - Rewind
8	86053		Shield - Spring
9	95412	1	Shaft - Starter
10	215705	1	Fan Housing
11	214192	1	Guard - Sawdust
12	214699	1	Insert - Handle
13	93137	1	Handle - Starter




Ref #	Part Number	Qty	Description
1	218701	2	Screw Skt hd 10-24 x 2 35-40 in. lb. torque
2	110964	2	Washer - Plain
3		1	Carburetor Assembly See "Carburetor Assembly" illustration and parts list.
4	86189	1	Gasket - Carburetor
5	218610	1	Grommet - Mix Adj.
6	215708	1	Hose Assembly - Fuel
7	215714	1	Pickup Assembly - Fuel
8	89320	1	Insert - Handle Grip
9	218620	1	Tank/Control Assembly
10	216603	1	Rod - Oiler
11	105673	2	Pin - Roll .099 x .562
12	95615	1	Button - Oiler
13	95614	1	Button - Choke
14	218604	1	Rod - Choke
15	69597	1	Boot - Control Rod
16	69043	1	Snubber - Rod
17	110706	1	Screw - Pn hd 8-18 x .50
18	83661	1	Wire Assembly - Stop Switch
19	62451	1	Contact - Switch
20	214691	1	Base - Switch
21	68846	1	Button - Switch
22	218605	1	Rod - Throttle
23	105654	1	Pin - Roll .131 x .875
24	92154	1	Spring - Trigger Release
25	94275	1	Release Assembly - Trigger
26	111012	1	Screw - Pn hd 4-40 x .31
27	110378	1	Pin - Roll .196 x .937
28	92152	1	Spring - Trigger
29	218609	1	Trigger Assembly - Throttle
30	215874	3	Screw M4 x 9.5 Torx
31	218599	1	Clamp Assembly - Boot
32	218600	1	Boot - Fuel Tank
33	218601	1	Ring - Boot



Ref #	Part Number	Qty	Description
1	216645	2	Nut - M8 Hx Flange
2		1	CHAIN BRAKE Asy See "Chain Brake Assembly" illustration and parts list.
3	64325	1	Plate - Bar Guide
4		1	Chain Assembly See "Bar/Chain/Chain Sharpening Tools" parts list.
5		1	Bar Assembly See "Bar/Chain/Chain Sharpening Tools" parts list.
6	86113	1	Nut - Hx 3/8-24 Left Hand 200-210 in. lb. torque
7	214301	1	Clutch Assembly
8	214300	1	Rotor - Clutch
9	67233	1	Kit - Clutch Shoe
10	83223	2	Spring - Clutch
11	64583	2	Retainer - Clutch Spring
12	95166	1	Kit - Drum & Sprocket 7T .375P
13	86344	1	Sprocket - 7T .375P Rim
14	86958	1	Washer - Shim
15	110971	1	Bearing - Sprocket
16	84978-01	1	Shield - Sawdust
17	213055	1	Screw - 10-24 x 1.50 55-60 in. lb. torque
18	216638	1	Screw - Hx hd 1/4-20 x 1-1/2 90-100 in. lb. torque
19	216542	1	Lockwasher - .250
20	216639	1	Clamp - Frame
21	103353	2	Screw - Hx hd 10-24 x 1.50
22	95679	1	Clamp - Frame
23	216682	2	Nut - Hx Lock 10-24
24	83828-01	1	Wire Assembly - Ground
25	92701	1	Clamp - Lower Mount Bottom
26	92700	1	Clamp - Lower Mount top
27	216648	1	Screw - Hx hd 1/4-20 x 2 90-100 in. lb. torque
28	216647	1	Washer - Plain
29	84661	1	Grommet
30	85898	1	Mount - Lower
31	95636	2	Washer - 1/4
32	95514	1	Frame & Grip Assembly
33	216634	5	Screw - Pn 10-24 x .50
34	216649	5	Nut - Hx Lock 10-24
35	216103	1	Shield - Frame Brace
36	216090	1	Brace - Frame
37	93032	1	Grommet - Frame Brace
38	214764	1	Washer
39	89403	2	Bumper - Lower
40	95418	1	Cover Assembly - Air Cleaner
41	110565	1	Ring Retaining
42	95420	1	Knob Cover
43	218762	1	Label - Warning
44	215681	1	Filter - Air
45	216670	4	Screw - Skt 10-24 x .50 40-45 in. lb. torque
46	216624	3	Screw - Oval 8-32 x 2.26 35-40 in. lb. torque
47		1	Fan Housing/Starter Asy See "Fan Housing & Starter" illustration and parts list.
48	216053	1	Cap Assembly - Fuel
49	110746	2	Screw Hx hd 10-24 x .50 Rear Mt 55-60 in. lb. torque

Ref #	Part Number	Qty	Description
50	216644	2	Screw - Hx hd 1/4-20 x 5/8 110-120 in. lb. torque
51	216542	2	Lockwasher - .250
52	216646	2	Washer - .250
53	105603	1	"O" Ring - .114 x .070
54	218612	1	Shield - Spit Back
55	110959	3	Screw Hex 8-32 x .50 35-40 in. lb. torque
56	218611	1	Bracket - Air Filter
57	218598	1	Plate - Spacer
58		1	Fuel Tank Assembly See "Fuel Tank Assembly" illustration and parts list.
59		1	Powerhead/Oiler See "Powerhead & Oiler" illustration and parts list.
60		1	Muffler Assembly See "Powerhead & Oiler" illustration and parts list.
61	93668	1	Spike
62	213042	2	Screw - Skt 10-24 x .62
63	216683	2	Washer - Special 10
64	216682	2	Nut - Hx Lock 10-24
65	219058	1	Label - Safety



Ref #	Part Number	Qty	Description
1	83811	1	Screw - Special 90-100 in. lb. torque
2	69924	1	Lockplate
3	93925	1	Mount - Rear
4	84619	1	Insulator
5	218617	1	Shroud - Upper
6	110713	2	Screw 10-24 x .88 35-40 in. lb. torque
7	216635	2	Washer - Plain .203 I.D.
8	218708	1	Insulator - Inlet
9	88740	1	Gasket - Insulator
10	216670	1	Screw - Skt 10-24 x 1/2 55-60 in. 1b, torque
11	216669	1	Screw - Skt 10-24 x 3/4 55-60 in. lb. torque
12	216643	2	Washer - #10
13	218706	1	Shroud - Rear
14	93460	1	Washer - Insulator
15	110703	1	Nut - Hex 3/8-24 265-325 in. lb. torque
16	95481	1	Flywheel Assembly
17	93464	2	Screw - Pawl
18	93198	2	Pawl - Starter
19	93469	2	Washer - Pawl
20	214102	2	Spring - Pawl
21	100106	1	Key - Woodruff
22	110127	1	Screw - Hx hd 10-24 x .88 (SEMS) 55-60 in. lb. torque
23	100002	3	Washer - #10
24	95603	1	Stud - Special 55-60 in. lb. torque
25	85798	1	Wire Assembly - Ground
26	95553	1	Electronic Ignition Assembly
27	95269	1	Wire Assembly - Spark Plug
28	102556	1	Connector
29	95266	1	Boot
30	110995	1	Grommet
31	110291	1	Screw - Skt 10-24 x 2-5/8 35-50 in. lb. torque
32	110921	1	Washer - Sealing
33	218707	1	Cover - Oil Tank
34	86306	1	Gasket - Cover
35	101143	1	Nut - Hx Lock 1/4-20
36	102523	1	Washer - 1/4
37	69832	1	Bumper - Front
38	93926	1	Mount - Front
39	216052	1	Cap - Oil Tank
40	101148	1	"O" Ring
41	110890	1	Screw - Fil 10-24 x .88 25-30 in. lb. torque
42	100003	1	Washer - #10
43	215339	1	Pump Assembly - Pulse
44	91774	1	Sleeve
45	215246	1	Kit - Oil Pump Clip
46	92874	1	Seal - Pulse Pump
47	214278	1	Piston Assembly - Pump
48	86182	1	Ring - Piston
49	105603	1	"O" Ring
50	60259	1	Spring - Piston
51	62227	1	Sleeve - Adjustment
52	91259	1	Pad - Oil Pump
53	110386	1	Screw - Hx hd 8-32 x 1
54		1	Spring - Outlet Valve Not available separately.
55		1	Ball - Outlet Valve Not available separately.

Ref #	Part Number	Qty	Description
56	63432	1	Spark Plug - Ac-C542T 120 in. lb. torque
57	216160	1	Kit - Muffler
58	214283	1	Spark Screen & Cap Assembly
59	216087	1	Strap - Muffler
60	216682	1	Nut - Hex Lock 10-24
61	104895	3	Screw - Skt 10-24 x .62 65-75 in. lb. torque
62	110713	1	Screw - Skt 10-24 x .88 65-75 in. lb. torque
63	95387	1	Gasket - Muffler
64	216047	1	Spacer
65	110644	1	Screw - Hx hd 8-32 x 1.50 35-40 in. lb. torque
66	62106	4	Screw - 12-24 x 1.75 70-75 in. lb. torque
67	215713	1	Kit - Cylinder-C'case, Piston
68	111025	4	Washer - Sealing
69	92459	2	Bolt - Bar
70	69600	1	Nipple - Pulse line
71	110851	1	Pin - Dowel
72	87152	1	Insert - Bearing
73	92518	1	Piston Assembly "A"
74	85414	1	Ring Set - Piston
75	111021	1	Bearing - Needle
76	110338	2	Screw - Hx Hd 8-32 x .532 15-20 in. lb. torque
77	110613	2	Washer - No. 8 Hard
78	84156	1	Housing - Pump
79	215151	1	Cap - Housing
80	92902	1	Plunger - Pump
81	105614	1	"O" Ring
82	66687	1	Spring - Pump
83	91669	1	Gasket - Pump
84	91668	1	Valve - Pump
85	91672	1	Hose - Oil
86	51506	1	Screen - Hose
87	100955	1	Nut - Hx Lock 8-32
88	69020	1	Pin - Piston
89	215245	1	Connecting Rod Assembly
90	61627-01	2	Screw - Connecting Rod 65-70 in. torque
91	215150	2	Roller (Set of 11)
92	61618	1	Seal - Oil
93	63464	1	Ring - Snap
94	63429-02	1	Bearing - Ball
95	110260	1	Seal - Oil
96	104357	1	Bearing - Needle
97	95386	1	Crankshaft
98	215673	1	Valve - Compression Release 110-120 in. lb. torque
99	218614	2	Clamp - Hose
100	218602	1	Line - Pulse