






Ref #	Part Number	Qty	Description
1	223439	1	Brake Assembly-Chain
	111047	1	Screw-8-32 x .625 Dealer stocked. Fast to medium moving part.
2	94709	1	Band-Brake Factory stocked. Slow moving part.
3	216755	1	Latch Dealer stocked. Fast to medium moving part.
4	215721	1	Spring Dealer stocked. Fast to medium moving part.
5	93602	1	Pivot-Latch Dealer stocked. Fast to medium moving part.
6	216549	1	Pivot-Lever Dealer stocked. Fast to medium moving part.
7	216268	1	Lever-Actuating Dealer stocked. Fast to medium moving part.
8	214368	1	Bearing-Roller Dealer stocked. Fast to medium moving part.
9	213907	1	Pin-Roller Distributor stocked. Medium to slow moving part.
10	90658	1	Screw-Adjusting Factory stocked. Slow moving part.
11	110907	1	Ring-Retaining Factory stocked. Slow moving part.
12	68656	1	Nut-Bar Adjusting Factory stocked. Slow moving part.
13	223438	1	Housing-Yellow Dealer stocked. Fast to medium moving part.




Ref #	Part Number	Qty	Description
1	120029	2	Nut - Flange M6.3 x 1.0
2		1	Chain Brake Asy See "Chain Brake Assembly" illustration and parts list
3		1	Chain - Saw Not available separately.
4		1	Bar - Guide Not available separately.
5	93148	1	Spacer - Bar Pad
6	215695	1	Screw - M5 x .50
7	120028	1	Screw - M6.3 x 1. x 20
8	93021-01	1	Lever - Wraparound
9	213278	1	Kit - Clutch
10	94244	1	Nut - Clutch (160-170 in. lb. torque)
11	94243	1	Plate - Dust
12		1	Rotor - Clutch Not available separately.
13		2	Shoe - Clutch Not available separately.
14	95646	1	Drum/Sprocket/Bearing Asy
15	91222	1	Kit - Needle Bearing
16	215259	1	Washer - Sprocket
17	120096	1	Screw - M5 x .8 x 55 (35-40 in. lb. torque)
18	120095	1	Screw - M5 x .8 x 20 (40-50 in. lb. torque)
19	120098	1	Screw - M5 x .8 x 20 (35-40 in. lb. torque)
20	216816	1	Frame Assembly
21	216064	1	Bolt - M5 T-Head
22	216585	1	Nut - Lock M5 (35-40 in. lb. torque)
23	120045	3	Washer - M5
24	110989	2	Grommet
25	93152	1	Link
26	93057	2	Spacer - Mount
27	216585	2	Nut - M5
28	218510	2	Screw - M4 x 25 (15-20 in. lb. torque)
29	216486	1	Starter Assembly
30	216485	1	Housing Assembly
31	216064	1	Bolt - M5 T-Head
32	110041	1	Screw - 8-32 x .50
33	68497	1	Washer
34	213257	1	Drum/Rope Asy
35	83203	1	Rope - (31.75" - 33.75")
36	83078	1	Spring - Rewind
37	87851	1	Handle/Washer Asy
38	105490	1	Washer - Handle
39	215481	1	Cover/Screw Asy - Air Filter
40	213118	1	Screw - Air Filter Cover
41	215456	1	Filter - Air
42	215482	1	Box Asy - Air
43	213411	1	Plate - Choke
44	215455	1	Bracket - Choke
45	213420	1	Spacer
46	213105	1	Screw - M5 x 55 (30-40 in. lb. torque)
47	213104	1	Screw - M5 x .8 x 50 (30-40 in. lb. torque)
48		1	Carburetor Assembly See "Carburetor Assembly" illustration and parts list
49	218556	1	Housing - Fan
50	213542	1	Hose - Pulse
51	94501	1	Nut - M5 x .8 Thin
52	94302	1	Clip - Spring

Ref #	Part Number	Qty	Description
53	92747	1	Flange - Carb. Mounting
54	92746	1	Boot - Carburetor
55	95656	1	Eyelet
56	111002	1	Screw - 10-16 x 5
57	93720	1	Pickup - Fuel
58	93997	1	Hose - Fuel
59	90869	1	Filter - Vent
60	216665	1	Fuel Tank
61	216157	1	Cap - Fuel w/ Retainer
62			Handle Assembly See "Handle Assembly " illustration and parts list
63	213172	4	Screw - M6 x 17 (torque 90-100 in. lb.)
64	213021	4	Washer - Conical
65	223054	1	Shroud - Top
66	214350	2	Insulator
67	218555	1	Shroud - Bottom
68	120095	1	Screw - M5 x .8 x 20 (torque 40-50 in. lb.)
69	94192	1	Grommet
70	120034	2	Nut - M6.3 x 1.0
71	120132	1	Screw - 5 x 5/8 (torque 8-10 in. lb.)
72	94540	1	Rod - Oiler
73	100001	1	Washer - Plain
74	222509	1	Knob - Oiler
75	93634-01	1	Spring - Compression
76	120095	2	Screw - M5 x .8 x 20 (torque 35-40 in. lb.)
77	216095	1	Cap Asy Oil w/ Retainer
78	216696	1	Tank Asy - Oil
79	94405	1	Hose - Oil Pickup
80	93998	1	Spring - Oil Hose
81	92465	1	Pickup - Oil
82	219058	1	Decal - Safety
83	218558	1	Decal - Instruction
84		1	Powerhead Assembly See "Powerhead Assembly" illustration and parts list



Ref #	Part Number	Qty	Description
1	93529	2	Bolt-Shoulder
2	93530-01	4	Spring-Mount
3	92704	1	Mount
4	94038	1	Hub-Mount
	213235	1	Handle Assembly
5	111032	5	Screw-10-15 x .625
6	92704	1	Mount
7	94039	1	Hub-Mount
8	213224	1	Handle-Long Right
9	213226	1	Handle-Long Left
10	216649	1	Nut-Lock 10-24
11	216632	1	Screw-10-24 x 1.25
12	95042	1	Weight-Handle
13	93310	1	Trigger-Safety
14	93515	1	Spring-Trigger
15	213232	1	Trigger-Throttle
16	213233	1	Wire-Throttle
17	110706	1	Screw-8-18 x .50
18	52451	1	Contact-Switch
19	94039	2	Wire-Stop Switch
20	68846	1	Button-Stop Switch



Ref #	Part Number	Qty	Description
1	93150	1	Bail
2	217168	1	Connector - Outlet
3	219990	1	Pump Asy - Oiler
4	215196	1	Connector - Hose
5	94115	1	Valve - Oiler
6	215151	1	Cap - Oil Pump
7	93301	1	Plunger - Oil Pump
8	105614	1	Ring - "O" .239x.070
9	93632	1	Spring
10	219566	1	Piston Asy - Oiler
11		1	Ring - Oil Pump Piston Not available separately.
12	105603	1	Ring - "O"
13	83891	1	Spring - Return
14	216423	1	Sleeve - Oil Pump
15	216422	1	Eyelet
16	110653	1	Ring - "O"
17	215411	1	Muffler/Deflector Asy
18	110681	2	Screw - 10-24x.25 (torque 40-45 in. lb.)
19	215394	2	Screw - Special M6 (torque 70-80 in. lb.)
20	92961	1	Deflector - Exhaust
21	214204	1	Kit - Spark Arrestor
22	101987	1	Screw - 6-32x.Z5 (torque 25 in. lb.)
23	216645	1	Nut - Flange M8 (torque 200-220 in. lb.)
24	219211	1	Flywheel/Pawl Asy
25	216984	2	Pin - Pawl
26	216982	2	Spring - Pawl
27	93469	2	Washer
28	216983	2	Pawl - Starter
29	102164	1	Key - Flywheel
30	120098	1	Screw - M5x.8x18 (torque 40-50 in. lb.)
31	93795	1	Wire - Ground
32	120112	2	Screw - M5x.8x40 (torque 70-80 in. lb.)
33	216591	1	Washer - Flat M5
34	219215	1	Ignition Assembly
35	102556	1	Connector
36	95266	1	Boot
37	214356	1	Spacer
38	215601	1	Manifold - Carburetor
39	92778	1	Gasket-Manifold
40	120097	4	Screw-M5x.8x25 (torque 70-80 in. lb.)
41	215762	1	Cylinder /C'Case Asy
42	92777	1	Bolt-Bar
43	94660	1	Piston Assembly
44	95427	1	Piston
45	94136	2	Rings
46	92836	1	Pin-Piston
47	111026	2	Ring-Snap
48	94135	1	Rod-Connecting
49	94654	2	Screw-Connecting Rod (torque 35-40 in. lb.)
50	110984	1	Bearing-Needle
51	68095	1	Bearing-Needle (20)
52	92750	1	Crankshaft
53	213282	2	Bearing-Crankshaft
54	83859	2	Beal-Crankshaft
55	62345	1	Plug-Spark (torque 120 in. lb.)

Ref #	Part Number	Qty	Description
56	213327	2	Screw-Special

No
Diagram
Available

Parts List
Only

Ref #	Part Number	Qty	Description
	93797		Wrench - Screwdriver
	216063		Key - Socket 5/32"
	214194		Lube Gun
	91226		Tool - Flywheel Holder
	94415		Adaptor - Pressure Test Intake (Cyl)
	94416		Adaptor - Pressure Test Intake (Airbox)
	68917		Plate - Block Off Exhaust
	85229		Kit - Pressure Test
	84453		Kit - Piston Tools
	215432		Tool - Pressure Test