

No Diagram Available


Parts List Only

Ref #	Part Number	Qty	Description
	94364-01		Carrying Case 18"
	93797		Wrench - Screwdriver
	91226		Wrench - Flywheel Clutch
	85229		Kit - Pressure Test MM6
	215432		Tool Pressure Test


No
Diagram
Available

Parts List
Only


Ref #	Part Number	Qty	Description
	214236-01		Bar, 16" Spkt. Tip
	219276-01		Bar, 18" Spkt. Tip
	218097-12		Chain, MP 370 GLX 55 CL
	219275-12		Chain, MP 370 GLX 60 CL
	219131		File Plate
	214217		Round File



Ref #	Part Number	Qty	Description
	94496	1	Carburetor
1		1	Shaft Asy - Throttle Not available separately.
2		1	Spring - Throttle Return Not available separately.
3		1	Plate - Throttle Not available separately.
4		1	Screw - Plate Not available separately.
5		1	Ring - "F" Not available separately.
6		1	Kit - Diaphragm/Gasket Not available separately. Contained in Major Repair Kit P/N 300460. Factory stocked. Slow moving part. Contained in Gasket/Diaphragm Kit P/N 300467. Factory stocked. Fast to medium moving part.
7	94206	1	Cover Asy - Pump Dealer stocked. Slow moving part.
8		1	Screw - Idle Speed Not available separately.
9		1	Insert - Friction Not available separately.
10		4	Screw - Pump Cover Not available separately.
11		1	Needle - Inlet Not available separately.
12		1	Spring - Lever Not available separately.
13		1	Lever - Inlet Needle Not available separately.
14		1	Pin - Lever Not available separately.
15		1	Screw - Lever Pin Not available separately.
16		1	Diaphragm Asy - Metering Not available separately.
17		1	Cover - Diaphragm Not available separately.
18		4	Screw Diaphragm Cover Not available separately.
19		1	Screw - Idle Adjust Not available separately.
20		1	Screw - Main Adjust Not available separately.
21		2	Spring - Needle Not available separately.
22		1	Screen - Filter Not available separately.
23		1	Gasket - Metering Diaph. Not available separately.
24		1	Plug - Welch Not available separately.
25		1	Orifice - Main Fuel Not available separately.
	300460		Major Repair Kit.
	300467		Gasket/Diaphragm Kit.




Ref #	Part Number	Qty	Description
	223615	1	Brake Assembly - Chain
1	111047	1	Screw - Fil 8-32 x .625 TT
2	94709	1	Band - Brake
3	215721	1	Spring - Compression
4	93602	1	Pivot Latch
5	216755	1	Latch - Chain Brake
6	216549	1	Pivot - Lever
7	216268	1	Lever - Actuating
8	214368	1	Bearing - Roller
9	213907	1	Pin - Roller
10	223088	1	Screw - Adjusting
11	110907	1	Ring Retaining
12	68656	1	Nut - Bar Adjusting
13		1	Housing - Brake Not available separately.




Ref #	Part Number	Qty	Description
1	120029	3	Nut - M6 .3 x 1.0 Flg.
2		1	Chain Brake Assembly See "Chain Brake Assembly" illustration and parts list.
3		1	Chain - 18" See "Bar And Chain Information" illustration and parts list.
4		1	Bar - 18" See "Bar And Chain Information" illustration and parts list.
5	223087	1	Spike
6	223074	1	Spacer - Bar Pad
7	215695	1	Screw - Hx Spec M5
8	120028	1	Screw - Hx M6 .3 x 1.0 x 20
9	93021-01	1	Lever - Wraparound
10	213278	1	Kit - Clutch Assembly
11	94244	1	Nut - Clutch
12	94243	1	Plate - Dust
13		1	Clutch Assembly Not available separately.
14	215252	1	Sprocket/Drum Asy
15	91117	1	Bearing - Clutch
16	215259	1	Washer - Sprocket
17	120096	1	Screw - Hx M5 x .8 x 55
18	120095	2	Screw - Hx M5 x .8 x 20
19	120098	1	Screw - Hx M5 x .8 x 18
20	216481	1	Frame
21	216064	1	Bolt - M5 T-Head
22	216585	2	Nut - Lock M5
23	120045	3	Washer - M5
24	110989	2	Grommet
25	93152	1	Link
26	93057	2	Spacer - Mount
27	218510	2	Screw - Pn M4 x 25 SEMS
28	223836	1	Starter Assembly
29	216064	1	Bolt - M5 T-Head
30	110041	1	Screw - Pn 8-32 x .50
31	68497	1	Washer
32	223835		Drum/Rope Assembly
33	83203	1	Rope - Starter
34	83078	1	Spring - Starter Rewind
35	216485	1	Housing Asy Starter
36	87851	1	Handle - Starter
37	223944		Bushing - Starter
38	215481	1	Cover Asy - Air Filter
39	213118	1	Screw - Air Filter Cover
40	322001	1	Filter - Air
41	215482	1	Airbox Assembly
42	213411		Plate - Choke
43	215455		Bracket - Choke
44	213420	1	Spacer
45	213105	1	Screw - Pan M5 x 55
46	213104	1	Screw - Spec M5 .8 x 50
47		1	Carburetor Assembly See "Carburetor" illustration and parts list.
48	223962	1	Kit - Fan Housing
49	218556-01	1	Housing - Fan

Ref #	Part Number	Qty	Description
50	213234-01	1	Wire Assembly - Throttle
51	213542-01		Hose - Pulse
52	217159		Nut - Hx M5
53	93469	4	Washer
54	94302	1	Clip - Spring
55	92747	1	Flange - Carb. Mounting
56	92746	1	Boot - Carburetor
57	95656	1	Eyelet
58	111002	1	Screw - Pan 10-16 x .5
59	93720		Pickup - Fuel
60	219971	1	Hose - Fuel
61	90869	1	Filter - Vent
62	216665	1	Tank Fuel
63	216157	1	Cap Asy - Fuel w/Retainer
64		1	Handle Assembly See "Handle Assembly" illustration and parts list.
65	213172	4	Screw - Hx M6 x 17
66	213021	4	Washer - Ramp Conical
67	223054	1	Shroud - Top
68	214350	2	Insulator - Baked
69	218555	1	Shroud - Bottom
70	120095	1	Screw - Hx M5 x .8 x 20
71	94192	1	Grommet
72	120034	2	Nut - Hx M6 .3 x 1.0
73	94540	1	Rod - Oiler
74	100001	1	Washer - Plain 6
75	222509	1	Kit - Oil Knob
76	110999	1	Screw - Hx 6-20 x 16 WH S
77	93634-01	1	Spring - Compression
78	120095	2	Screw - Hx M5 x .8 x 20
79	216095	1	Cap - Asy Oil w/Retainer
80	223052	1	Tank Assembly - Oil
81	94405	1	Hose - Pickup
82	93998	1	Spring - Oil Hose
83	225062	1	Pickup - Oil
84	219058	1	Decal - Safety
85	218558		Plate - Instruction
86		1	Powerhead Assembly See "Power Assembly" illustration and parts list.



Ref #	Part Number	Qty	Description
1	93529		Bolt - Shoulder
2	93530-01		Spring - Mount
3	92704		Mount
4	94038		Hub - Mount
5	213230		Handle Assembly
6	111032		Screw - Pan 10-16 x .625
7	92704		Mount
8	94038		Hub - Mount
9	213229		Handle - Right Half
10	213228		Handle - Left Half
11	93310		Trigger - Safety
12	93515		Spring - Trigger
13	213232		Trigger - Throttle
14	213234-01		Wire Asy - Throttle
15	110706		Screw - Pn 8-18 x .50 St H
16	62451		Contact - Ignition Switch
17	93505-01		Wire - Stop Switch
18	68846		Button - Stop Switch



Ref #	Part Number	Qty	Description
1	93150		Bail
2	217168		Connector - Oil Pump Outlet
3	219990-01		Pump Assembly - Oiler
4	215196		Connector Hose
5	94115		Valve - Oiler
6	215151		Cap - Oil Pump
7	93301		Plunger - Oil Pump
8	105614		"O" Ring .239 x .070
9	93632		Spring
10	217765		Screw - Adjustment
11	223651		Piston Assembly - Oiler
12			Ring - Oil Pump Not available separately.
13	105603		"O" Ring - .114 x .070
14	83891		Spring - Return
15	216423		Sleeve - Oil Pump
16	216422		Eyelet
17	110653		"O" Ring
18	223610		Kit - Muffler
19	223635		Screw - Skt Hd 10-24 x .5
20	215394		Screw - Special Muffler
21	223611		Cover/Deflector Asy
22	215410		Body/Cover Asy
23	223637		Spacer - .21 ID x .44 OD x .12
24	223827		Spacer - Muffler
25	83407		Screen - Spark Arrestor
26	223828		Screw - Pn Hd 6-32 x .750
27	213169		Nut - Hx Flange M8
28	219211		Flywheel/Pawl Assembly
	222778		Flywheel/Pawl Assembly
29	216984		Pin - Starter Pawl
30	216982		Spring - Starter Pawl
31	93469		Washer - Starter Pawl
32	216983		Pawl - Starter
33	102164		Key - Flywheel
34	120098		Screw - Hx M5 x .8 x 18
35	93514-01		Wire Assembly - Ground
36	120112		Screw - Skt M5 x .8 x .40
37	216591		Washer - Flat M5
38	219215		Ignition Assembly
	223707		Kit Ignition
39	102556		Connector - Spark
40	95266		Boot - Spark Plug
41	214356		Spacer - Baked
42	215601		Manifold - Carburetor
43	92778		Gasket - Manifold
44	120097		Screw - Hx M5 x .8 x 25
45	223719		Cylinder/C'Case Assembly
46	92777		Bolt - Bar
47	223048		Piston - Mach
48	91703	2	Set - Piston Rings
49	92836		Pin - Piston
50	111026		Ring - Snap
51	94135		Connecting Rod/Bearing Asy
52	94654		Screw - Connecting Rod
53	110984		Bearing - Needle

Ref #	Part Number	Qty	Description
54	68095	20	Set - Needle Roller
55	92750		Crankshaft
56	213282		Bearing - Crankshaft
57	83859		Seal - Crankshaft
58	63432		Spark - Plug