

No
Diagram
Available


Parts List
Only

Ref #	Part Number	Qty	Description
	215432		Pressure Test Tool
	63137		Adaptor - Exhaust
	94415		Adaptor - Intake
	84223		Kit - Piston Tools
	214226		Air Filter - Felt
	214221		Scrench
	214195		Gun-Lube (Disposable)
	214194		Gun-Lube (Deluxe)
	214208		Kit - Spike
	69794		Locquic
	110083		R.T.V. Sealant
	94121		Kit - Carrying Case 20 Inches
	214203		Scabbard 20 Inches
	87885		Case 12-1 Qt. Bottles 40:1 Custom Lubricant
	93770		Case 48-6 ounces cans 40:1 Custom Lubricant


No
Diagram
Available

Parts List
Only

Ref #	Part Number	Qty	Description
	214237		Bar - Sprocket Tip 16"
	218839-12		Chain - PMR 370GLX-60CL
	219132		File Plate, Round File Size - 7/32"
	217025		Bar - Sprocket Tip 18"
	218062-12		Chain - PMR 370GLX-66CL
	219132		File Plate, Round File Size - 7/32"
	214238		Bar - Sprocket Tip 20"
	218069-12		Chain - PMR 370GLX-70CL
	219132		File Plate, Round File Size - 7/32"
	86846-00		Sprocket Nose 24" Replacement Nose Assembly Order P/N 86830
	218070-14		PMR 370G-81CL
	86826		File Guide, Round File Size - 7/32"
	86846-05		Sprocket Nose 24" Replacement Nose Assembly Order P/N 219975
	218070-14		PMR 370G-81CL
	86826		File Guide, Round File Size - 7/32"
	219161		7/32" Round File Twin Pack
	56698-23		7/32" Round File 12-Pack Order




Ref #	Part Number	Qty	Description
	95763		Carburetor Asy. (Zama C-25)
1		1	Screw - Pump Cover Not available separately
2	214954	1	Cover - Pump
3		1	Kit - Pump Diaphragm Not available separately; Contained in Repair Kit, P/N 214959 and Gasket/Diaphragm Kit, P/N 218892
4		1	Screen - Filter Not available separately; Contained in Repair Kit, P/N 214959
5		2	Screw - Adjustment Not available separately; Contained in Repair Kit, P/N 214959
6		2	Spring - Adjustment Screw Not available separately; Contained in Repair Kit, P/N 214959
7		1	Screw - Throttle Adjustment Not available separately
8		1	Piece - Friction Not available separately
9	93945	4	Screw - Diaphragm Cover
10	214945	1	Cap
11		1	Diaphragm - Main Not available separately; Contained in Repair Kit, P/N 214959 and Gasket/Diaphragm Kit, P/N 218892
12		1	Gasket - Main Contained in Repair Kit, P/N 214959 and Gasket/Diaphragm Kit, P/N 218892
13		1	Disk Not available separately; Contained in Repair Kit, P/N 214959
14		1	Screw Pin Lever Not available seperately; Contained in Repair Kit, P/N 214959
15		1	Pin - Arm Not available seperately; Contained in Repair Kit, P/N 214959
16		1	Arm - Needle Valve Not available seperately; Contained in Repair Kit, P/N 214959
17		1	Spring - Arm Not available seperately; Contained in Repair Kit, P/N 214959
18		1	Valve - Needle Not available seperately; Contained in Repair Kit, P/N 214959
19		1	Plug - Welsh Not available seperately
20		1	Orifice - Main Fuel Not available seperately; Contained in Repair Kit, P/N 214959
21		1	Screw - Plate Not available seperately
22		1	Valve - Throttle Not available seperately
23		1	Screw Not available seperately
24		1	Lever - Throttle Adjustment Not available seperately
25		1	Shaft Assembly - Throttle Not available seperately
26		1	Spring - Throttle Return Not available seperately
	214959		Repair Kit
	218892		Gasket/Diaphragm Kit




Chain Brake

Ref #	Part Number	Qty	Description
	217697	1	Brake Assembly
1	216634	1	Screw 10-24 x .50
2	216633	1	Washer - Plain
3	217115	1	Flag Assembly - Brake
4	214366	1	Pin Assembly - Roller
5	93085	1	Spring - Brake
6	91246	1	Pin - Lever Pivot
7	91245	1	Washer - Thrust
8	94144	1	Pivot - Latch
9	217235	1	Latch - Chain Brake
10	93082	1	Pin - Band Anchor
11	93081	1	Band - Brake
12	216687	1	Screw - M5 x 14.25
13	92178	1	Stop - Chain
14	92086	1	Snubber - Brake Housing
15	217698	1	Housing - Brake




Ref #	Part Number	Qty	Description
1	216154	1	Housing - Fan
2	216157	1	Cap/Retainer Asy - Fuel
3	94707	1	Gasket - Fuel Cap
4	93251	1	Seal - Fuel Vent
5	92161	1	Seal - Air Box
6	120068	2	Screw - Pan Hd M4 x 12 (Sems)
7	94901	1	Tank Asy - Fuel
8	94899	1	Hose Asy - Fuel
9	100440	1	Washer - .340ID x .065
10	63932	1	Filter - Fuel



Ref #	Part Number	Qty	Description
1	216645	1	Nut - Hex Flange M8 (Hand Tighten Securely)
2		1	Brake Asy - Chain See "Brake Chain" illustration and parts list.
3	64325	1	Plate - Bar Guide
4		1	Chain Asy See "Bar/Chain/Chain Sharpening Tools" illustration and parts list.
5		1	Bar Asy See "Bar/Chain/Chain Sharpening Tools" illustration and parts list.
6	92457	1	Nut - Hex Flange M10
7	214301	1	Clutch Asy
8	64583	2	Retainer - Spring
9	83223	2	Spring
10	67233	1	Kit - Clutch Shoe (2)
11	214300	1	Rotor
12	214979	1	Drum/Sprocket Asy
13	86958	1	Washer - Shim
14	110971	1	Bearing - Needle
15	92354	1	Jacket - Cylinder
16	120081	4	Screw - M4 x 16 (15-20 in. lb. torque)
17	219159	1	Starter/Drum Asy
18	219976	1	Housing
19	111038	1	Nut - 1/4" 20
20	95401	1	Washer
21	215848	1	Bolt - Step
22	219163	1	Drum Asy
23	87670	1	Rope
24	217730	1	Bushing
25	216589	1	Spacer - Starter
26	87680	1	Spring - Rewind
27	93137	1	Handle - Starter
28	214699	1	Insert - Handle
29	120002	1	Screw - M5 x 14 (30-35 in. lb. torque)
30	93232	1	Screw - M5 x 40 (45-50 in. lb. torque)
31	93233	1	Screw - M5 x 30 (45-50 in. lb. torque)
32	93234	1	Screw - M5 x 30 (45-50 in. lb. torque)
33		1	Fan Hsg./Fuel Tank Asy See "Fan Housing & Fuel Tank" illustration and parts list.
34	217651	1	Cover Asy. - Air Filter
35	91991	1	Knob
36	110565	1	Ring - Knob Retaining
37	95216	1	Box Asy - Air
38	93261	1	Grommet - Choke
39	69597	1	Boot - Control Rod
40	92065	1	Isolator
41	93253	1	Grommet - Strut
42	95218	1	Filter - Air
43	120004	2	Screw - M5 x 56 (35-40 in. lb. torque)
44	91938	1	Bracket - Air Filter
45	94151	1	Choke - Carb
46	94171	1	Rod - Choke
47		1	Carburetor See "Carburetor" illustration and parts list.
48	91924	1	Gasket - Carburetor
49	91995-01	1	Grommet - Carburetor Needle

Ref #	Part Number	Qty	Description
50	93458	1	Clip - Oiler Button
51	92067-01	1	Button/Rod Asy - Oiler
52	105614	1	Ring - "O"
53	215266	2	Screw - M5 x 0.80 (25-30 in. lb. torque)
54	110990	4	Washer
55	93252-01	1	Strut - Handle
56	93253	1	Grommet - Strut
57	111015	2	Screw - 1/4-14 x 2.5 (70-80 in. lb. torque)
58	92071	2	Spacer
59	92066	2	Cup - Isolator
60	102115	1	Washer - Plain
61	111014	1	Screw - 1/4-14 x 1.75 (70-80 in. lb. torque)
62	111027	1	Washer - Flat
63	93913	1	Isolator
64	94140	1	Isolator
65	111027	1	Washer - Flat
66	91951	1	Frame
67	214723	1	Handle Asy - Rear
68	110994	2	Pin - Roll
69	93771	1	Spring - Trigger
70	93538-01	1	Trigger Assembly
71	111013	1	Screw - Set
72	91955	1	Release - Trigger
73	214504	1	Rod - Throttle
74	93459	1	Boot - Handle
75	92161	1	Seal - Air Box
76	120037	1	Screw - M5-25 (35-40 in. lb. torque)
77	120039	2	Screw - M5 x 30 (35-40 in. lb. torque)
78	93460	1	Washer - Insulator
79	94018	1	Gasket - Air Box
80	94017-01	1	Insulator - Carburetor
81	91933	1	Gasket - Insulators
82	91934	1	Insulator - Air Box
83	92038	1	Gasket - Insulator
84	120037	2	Screw - M5 x 25 (45-50 in. lb. torque)
85	93460	2	Washer - Insulator
86	104810	1	Nut - Hex 15/32-32 (30-35 in. lb. torque)
87	218561	1	Shroud - Cyclinder
88	93890	1	Switch - Ignition
89	92466	1	Wire Asy - Switch
90	120002	4	Screw - M5 x 14 (45-50 in. lb. torque)
91	214670	1	Shroud - Bottom
92		1	Powerhead Asy See "Powerhead & Oiler Assembly" illustration and parts list.
93	120002	2	Screw - M5 x 14
94	120044	2	Nut - Hex M5
95	93668	1	Spike - Bucking
96	219058	1	Decal - Safety



Ref #	Part Number	Qty	Description
1	120036	4	Screw - M4 x 16
2	67177	4	Washer - Insulating
3	219991	1	Pump Asy - Oiler
4	215151	1	Cap
5	93933	1	Plunger
6	105614	1	Ring - "O"
7	66687	1	Spring - Plunger
8	110706	3	Screw - 8-18 x 1/2
9	216354	1	Gasket - Washer
10	217218	1	Cover - Diaphragm
11	216992	1	Diaphragm
12		1	Valve Not available separately
13	91945	1	Piston Asy
14	94322	1	Spring - Return
15	91944	1	Sleeve
16	218530	1	Screw - 6-40 x .875
17	219336	1	Body Asy
18	91950	1	Gasket - Oil Pump
19	216052	1	Cap/Retainer Asy - Oil
20	101148	1	Ring - "O"
21	120006	4	Screw - M6.3 x 24
22	100004	4	Washer - Plain 1/4"
23	218583	1	Tank Asy - Oil
24	110950	1	Nut - Lock
25	102115	1	Washer - Plain
26	91982	1	Nut - Bar Adjustment
27	94362	1	Screw - Bar Adjustment
28	92459	2	Bolt - Bar
29	92616	1	Hose - Oil Pickup
30	92465	1	Pickup - Oil
31	120037	2	Screw - M5 x 25 (55-60 in. lb. torque)
32	84686-01	1	Wire Asy - Ground
33	95553	1	Ignition Asy - CDI
34	95270	1	Wire Asy - Spark
35	102556	1	Connector - Spark Plug
36	95266	1	Boot - Spark Plug
37	110995	1	Grommet - Spark Plug Wire
38	219372	1	Nut - Flange M10 (265-325 in. lb. torque)
39	95324	1	Flywheel/Pawl Asy
40	95362	2	Screw - Pawl
41	95361	2	Pawl - Starter
42	213253	2	Washer - Spring
43	93144	2	Spring - Pawl
44	100106	1	Key - Woodruff
45	62106	4	Screw - 12-24 x 1 3/4 (70-75 in. lb. torque)
46	111025	4	Washer - Sealing
47	94536	1	Cyl/C'Case Asy
48	92096	1	Nipple - Oil Line
49	94130	1	Piston Asy
50	95223	1	Piston
51	94132	1	Ring Set - Piston (2)
52	111021	2	Bearing - Needle
53	69020	1	Pin - Piston
54	85352	1	Rod Asy - Connecting
55	61627-01	2	Screw - Connecting Rod (55-65 in. lb. torque)

Ref #	Part Number	Qty	Description
56	63225	1	Roller - Needle (Set of 20)
57	110260	1	Seal - Oil
58	104357	1	Bearing - Needle
59	67906	1	Seal - Oil
60	67905	1	Bearing - Ball
61	63464	1	Ring - Snap
62	217041	1	Crankshaft
63	102762	1	Screw - 10-24 x 1/2 (55-60 in. lb. torque)
64	217606	1	Deflector - Exhaust
65	120038	2	Screw - M4 x 8 (35-45 in. lb. torque)
66	93481	1	Plate - Deflector
67	214205	1	Screen - Muffler
68	216627	2	Screw - 6-32 x .25 (30-35 in. lb. torque)
69	93482	1	Cover - Chamber
70	93605	1	Screen - Muffler
71	95445	1	Screw - Muffler (55-60 in. lb torque)
72	216254	1	Chamber Asy - Muffler
73	95444	2	Screw - Muffler (65-15 in. lb. torque)
74	93603	1	Muffler Asy
75	84007	1	Gasket - Muffler
76	62345	1	Spark Plug - DJSJ Champion
	93017	1	Spark Plug - RDJ6 Champion (120 in. lb. torque)