



No
Diagram
Available

Parts List
Only

Ref #	Part Number	Qty	Description
	90745		Bar - 10" Mini Pro
	90641N		Chain Asy - 10" MP 370G
	90630		Bar - 10" Mini Mac
	90638N		Chain Asy - 10" MM370G
	90770		Bar - 12" Mac 6
	88033N		Chain Asy - 12" SM250G
	90549		Bar - 12" Mini Pro
	90642N		Chain Asy - 12" MP3706
	90639N		Chain Asy - 12" MM370G
	90550		Bar - 14" Mini Pro
	90640N		Chain Asy - 14" MM370G
	83687		Guide-Timing
	91753		Case-Carrying
	88756		Scrench
	68747		Gasket-Spark arrester
	84992		Kit-Reed Muffler
	85924		Kit-Spark Arrester (PM6 type)
	89685		Screen-Spark arrester
	85062		Kit-Piston Tool




Ref #	Part Number	Qty	Description
	90918	1	Carburetor Asy
1	83755	2	Screw-Plate
2	68556	1	Plate-Choke
3	85033	1	Shaft-Choke
4	100302	1	Ball-Choke friction
5	67504	1	Spring-Choke friction
6	68553	1	Plate - Throttle
7	70798	1	Screw-Clip
8	68554	1	Clip-Throttle shaft
9	90471	1	Shaft Asy - Throttle
10	68566	1	Screw-Idle speed
11	86446	1	Needle-Idle
12	86447	1	Needle-High speed
13	67502	2	Spring-Needle
14	68564	4	Screw Asy-Body
15	91347	1	Cover Asy-Pump
15A	85629	1	Kit-Vent screen
16	68563	1	Diaphragm-Fuel pump
17	85035	1	Gasket-Pump diaphragm
18	85030	1	Body-Fuel pump
19	85036	1	Diaphragm-Metering
20	85034	1	Gasket-Diaphragm
21	67500	1	Screw-Lever pin
22	67508	1	Pin-Lever
23	85059	1	Kit-Needle & lever
24	68567	1	Spring-Lever
25	68559	1	Plug-Welsh 7/16
26	83758	1	Kit-Check valve
27	68560	1	Plug-Welsh 1/2
28	89785		Spring - Throttle return
	86463		Repair Kit



Ref #	Part Number	Qty	Description
	90570B		CHAIN BRAKE Asy
1	102762	1	Screw-Hx hd 10-24 x 1/2
2	101194	1	Washer-Lock #10
3	110712	1	Washer
4	90580	1	Band & Lever
5	90587A	1	Spring-Brake Actuator
6	90588	1	Guide-Spring
7	90967	1	Washer-Actuating Lever
8	90571C	1	Kit-Housing/Spring
9	103047	1	Pin
10	100001	1	Washer
11	110946	1	Screw Drive-6 x 5/16
12	110955	1	Screw-Set 8-32 x 1/2
13	90658	1	Screw-Adjusting
14	110907	1	Ring-Retaining
15	84929	1	Nut-Bar adjusting
16	90576A	1	Lever-Actuator
17	110913	1	Fastener-Springtip

Ref #	Part Number	Qty	Description
1	110676	1	Nut-Hx 1/2-28
2			CHAIN BRAKE Asy See "Chain Brake Assembly" illustration and parts list.
3	90636	1	Guard Asy-Clutch
4	90658	1	Screw-Pan hd 8-32 x 1-1/8
5	110907	1	Ring-retaining
6	84929	1	Nut-Bar adjusting
7			Chain Asy See "Accessories" parts list.
8			Bar See "Accessories" parts list.
9	92727	1	Clutch Asy
10	69358	1	Spring - Clutch
11	85202	2	Kit-Clutch Shoe
12	110957	2	Rivet
13	85064	2	Plate
14	92721	1	Spider
9	85450	1	Clutch Asy
10	69358	1	Spring-Clutch
11	85202	2	Kit-Clutch Shoe
12	110709	2	Rivet
13	85064	2	Plate
14	85449	1	Spider
15	90150	1	Drum/Spkt/Brng Asy
16	91222	1	Kit - Needle Brng
15	85504	1	Drum & Sprocket Asy
16	67650	1	Bearing-Sprocket
17	67303	1	Washer-Sprocket
18	110953	1	Screw-Hx hd 12-24 x 5/8
19	110686	1	Screw-Hx hd 13-16 x 2
20	84791	1	Frame & Grip Asy
21	110639	2	Screw-Hx hd 12-24 x 1
22	88591	1	Cover-Fuel & Oil tank
23	91454A	1	Tank Kit -Fuel & Oil
24	91283	2	Cap-Fuel & Oil (Unvented)
24	90922	2	Cap-Fuel & Oil (Vented)
25	91148	1	Seal-Fuel vent
26	84956	1	Pickup-Fuel
27	83900A	1	Piston-Manual oiler
28	83946	1	Spring-Piston
29	85557	1	Body-Oiler
30	86438	1	Valve-Manual oil pump
31	84653	1	Connector-Manual oiler
32	84611	1	Rod-Manual oiler
33	91859	1	Kit-Shroud Asy
34	91853	1	Cover-Air cleaner
35	91796	1	Screw-Air cleaner
36	90383	1	Cover-Air cleaner
37	83882	1	Retainer-Cover
38	85127	1	Filter-Air
39	84918	1	Washer-Air seal
40	110672	1	Screw-Oval hd 4-40 x 1
41	83870	1	Knob-Choke
42	110953	2	Screw-Hx hd 12-24 x 5/8
43	84520A	1	Plate-Washer
44	84519	2	Sleeve-Handle
45	83852A	1	Handle & Grip Asy

Ref #	Part Number	Qty	Description
46	64872	1	Grip-Handle
47	110953	3	Screw-Hx hd 12-24 x 5/8
48	83878	1	Trigger
49	83940	1	Spring-Trigger
50	83935	1	Contact-Switch
51	83936	1	Protector-Switch
52	83934	1	Button-Switch
53	110959	3	Screw-Hx hd 8-32 x 1/2
54	90425	1	Cover-Starter
55	110706	1	Screw-Rd hd 8-32 x 5/8
56	68497	1	Washer-Special
57	83876	1	Drum-Starter
57	92316	1	Drum/Rope Asy
58	83203	1	Rope-Starter
59	83078	1	Spring-Rewind
60	91255	1	Kit-Starter handle
61	105490	1	Washer-Starter handle
62			Powerhead Asy See "Powerhead Assembly" illustration and parts list.
63	91694	1	Plate - Name
63	91693	1	Plate - Name
	91454A		Fuel and Oil Tank Kit



Ref #	Part Number	Qty	Description
1	83898	1	Connector-Outlet
2	84613	1	Connector-Pump
3	83896	1	Ball-Mounting
4	83886	1	Pump Asy-Oiler
5	105603	1	"O" Ring
6	85769	1	Ring-Pump piston
7	92204	1	Piston Asy-Pump
8	83891	1	Spring- Pump
9	83890	1	Sleeve-Pump
10	110651	1	Screw-Adjustment
11	83887	1	Body Asy-Pump
12	110653	1	"O" Ring
13	110674	1	Screw-Hx hd 10-24 x 1/2
14	89684	1	Cover-Muffler
15	110928	1	Screw-Hx hd 10-24 x 1/2
16	89682	1	Body- Muffler
17	63097	1	Spark Plug
18	89274	1	Rod - Throttle
19	89059	1	Hose-Fuel
20	90661	1	Kit-Fuel Hose
19	90659	1	Hose-Fuel
21	90660	1	Adaptor-Fuel hose
22	110908	1	"O" Ring
23	87826	1	Clamp
24	110970	1	Nut-Hx 5/16-24
24	110931	1	Nut-Hx 3/8-24
25	91961	1	Flywheel & Pawl Asy
26	68796	2	Pin-Pawl
27	92898	2	Spring-Pawl
28	91872	2	Pawl-Starter
25	69806	1	Flywheel & Pawl Asy
26	68796	2	Pin-Pawl
27	67814	2	Spring-Pawl
28	69103	2	Pawl-Starter
29	102164	1	Key-Woodruff
29	100106	1	Key-Woodruff
30	110586	3	Screw-Pan hd 8-32 x 1-3/4
31	105976	3	Washer-#8
32	67177	3	Washer-Insulating
33	68198	3	Tube-Insulating
34			Carburetor Asy See "Carburetor Assembly" illustration and parts list.
35	68197	1	Gasket-Carburetor
36	90713	1	Insulator-Carburetor
37	90714	1	Gasket-Insulator
38	84957	1	Coil & Lamination Asy
39	50120	1	Wire Asy-Spark plug
40	110364	1	Screw-Pan hd 6-32 x 5/8
41	69344	1	Wire Asy-Coil
42	110041	1	Screw-Pan hd 8-32 x 1/2 s/t
43	85358	1	Condenser
44	100035	1	Nut-Hx 6-32
45	84502	1	Connector-Stop switch
46	67841	1	Cover-Breaker box
47	69323	1	Seal-Breaker box

Ref #	Part Number	Qty	Description
48	110969	2	Screw- Hx hd 8-32 x 1/2
49	69322	1	Washer-Special
50	105976	1	Washer-#8
51	88811	1	Breaker Asy
52	84505A	1	Kit-Breaker Box
53	92037	1	Washer
54	110639	4	Screw-Hx hd 12-24 x 1
55	92279	1	Kit-Cyl/C'Case/Piston
56	83856	1	Bolt-Bar mounting
57	92274	1	Piston Asy
58	92752	1	Set-Piston Rings
59	110538	2	Bearing- Needle
57	84981	1	Piston Asy
58	87164	1	Set-Piston Rings
59	110538	2	Bearing-Needle
60	66867		Pin-Piston
61	68097	1	Connecting Rod Asy
62	66853	2	Screw-Special
63	68095	1	Roller-Needle (Set of 20)
64	83859	2	Seal-Oil
65	66854	2	Bearing-Needle
66	91932	1	Crankshaft
66	86439A	1	Crankshaft