
No Diagram Available

Parts List Only


| Ref# | Part Number | Qty Description |
|------|-------------|-------------------------|
| | 21423533 | BAR MPG370GLX49cl 14" |
| | 21423633 | BAR MPG370GLX54cl 16" |
| | 21927633 | BAR MPG370GLX60cl 18" |
| | 21491933 | CHAIN MPG370GLX49cl 14" |
| | 21492533 | CHAIN MPG370GLX54cl 16" |
| | 21927533 | CHAIN MPG370GLX60cl 18" |
| | 30199233 | FILE AND GUIDE |
| | 21421733 | FILE |



K&T Saw Shop 606-678-9623 or 606-561-4983

| Ref# | Part Number | Qty | Description |
|------|-------------|-----|--|
| | 32365304 | | Carburetor Walbro WT 438 Distributor stocked. Medium to slow moving part. |
| | 32365404 | | Carburetor Walbro WT 439 Distributor stocked. Medium to slow moving part. |
| 1 | | 1 | Strainer Not available individually, included in Carburetor Asy. |
| 2 | | 1 | Plug Welch Not available individually, included in Carburetor Asy. |
| 3 | | 1 | Valve Check Not available individually, included in Carburetor Asy. |
| 4 | | 1 | Retainer, Check Valve Not available individually, included in Carburetor Asy. |
| 5 | | 1 | Nozzle Asy Check Valve Not available individually, included in Carburetor Asy. |
| 6 | | 1 | Shaft Asy, Throttle Not available individually, included in Carburetor Asy. |
| 7 | | 1 | Spring Throttle Return Not available individually, included in Carburetor Asy. |
| 8 | | 1 | Valve, Throttle Not available individually, included in Carburetor Asy. |
| 9 | | 1 | Diaphragm Asy, metering Not available individually, included in Carburetor Asy. |
| 10 | | 1 | Diaphragm, Pump Not available individually, included in Carburetor Asy. |
| 11 | | 1 | Gasket, metering Chamber Not available individually, included in Carburetor Asy. |
| 12 | | 1 | Gasket Pump Not available individually, included in Carburetor Asy. |
| 13 | | 1 | Cover Pump Not available individually, included in Carburetor Asy. |
| 14 | | 1 | Valve Inlet Needle Not available individually, included in Carburetor Asy. |
| 15 | | 1 | Spring, metering Lever Not available individually, included in Carburetor Asy. |
| 16 | | 1 | Lever metering Not available individually, included in Carburetor Asy. |
| 17 | | 1 | Pie Not available individually, included in Carburetor Asy. |
| 18 | | 1 | Cover metering Chamber Not available individually, included in Carburetor Asy. |
| 19 | | 2 | Spring Adjust Screw Not available individually, included in Carburetor Asy. |
| 20 | | 1 | Screw Main Mixture Not available individually, included in Carburetor Asy. |
| | | | |


| Ref# | Part Number | Qty Description |
|------|------------------|---|
| 21 | | Screw, Idle Mixture Not available individually, included in Carburetor Asy. |
| 22 | | Screw Throttle Adjust Not available individually, included in Carburetor Asy. |
| 23 | | 4 Spring Friction Not available individually, included in Carburetor Asy. |
| 24 | | Shaft Asy Choke Not available individually, included in Carburetor Asy. |
| 25 | | Valve, Choke Not available individually, included in Carburetor Asy. |
| 26 | | Screw, Pin Not available individually, included in Carburetor Asy. |
| 27 | | Screw Throttle/Choke Valve Not available individually, included in Carburetor Asy. |
| 28 | | Screw metering Chamber Not available individually, included in Carburetor Asy. |
| 29 | | Screw, Pump Cover Not available individually, included in Carburetor Asy. |
| 30 | | Ball, Steel Not available individually, included in Carburetor Asy. |
| 31 | | Collar Not available individually, included in Carbureto Asy. |
| 32 | | Lever, Throttle Not available individually, included in Carburetor Asy. |
| 33 | | Screw Throttle Lever Not available individually, included in Carburetor Asy. |
| 34 | | 2 Washer Limiter Not available individually, included in Carburetor Asy. |
| 35 | 325465 | Cap, Limiter, Hi Included in Carburetor Asy.; Distributor stocked. Medium to slow moving part. |
| 36 | 325466 | Cap Limiter Lo Included in Carburetor Asy.; Distributor stocked. Medium to slow moving part. |
| 37 | | Retainer, Limiter Not available individually, included in Carburetor Asy. |
| | 324013 324009 | Kit, Carburetor Repair A1128WT Kit, Gasket/Diaphragm B1110WT |
| | | |



K&T Saw Shop 606-678-9623 or 606-561-4983


| Ref# | Part Number | Qty Description | |
|------|-------------|--------------------------------|---|
| | 32365303 | • | Zama CU1M28C Distributor stocked. slow moving part. |
| | 32365403 | | Zama CU1M33C Distributor stocked. slow moving part. |
| | 32494701 | - | Zama C1QM36 Distributor stocked. slow moving part. |
| 1 | | 1 Strainer No Carburetor | ot available individually. Included in Asy. |
| 2 | | 1 Plug, Welch Carburetor | n Not available individually. Included in Asy. |
| 3 | | 1 Valve, Chec Carburetor | ck Not available individually. Included in Asy. |
| 4 | | | heck Valve Not available individually. Carburetor Asy. |
| 5 | | | , Check Valve Not available individually. Carburetor Asy. |
| 6 | | 1 Shaft Asy, T in Carbureto | Throttle Not available individually. Included or Asy. |
| 7 | | . • | ottle Return Not available individually. Carburetor Asy. |
| 8 | | 1 Valve, Thro Carburetor | ttle Not available individually. Included in Asy. |
| 9 | | | Asy, metering Not available individually. Carburetor Asy. |
| 10 | | 1 Diaphragm, in Carbureto | Pump Not available individually. Included or Asy. |
| 11 | | | tering Chamber Not available individually. Carburetor Asy. |
| 12 | | 1 Gasket, Pur Carburetor | mp Not available individually. Included in Asy. |
| 13 | | 1 Cover, Pum Carburetor | np Not available individually. Included in Asy. |
| 14 | | 1 Valve, Inlet in Carbureto | Needle Not available individually. Included or Asy. |
| 15 | | . • | ering Lever Not available individually. Carburetor Asy. |
| 16 | | 1 Lever, mete Carburetor | ering Not available individually. Included in Asy. |
| 17 | | 1 Pin Not ava Asy. | ailable individually. Included in Carburetor |
| 18 | | | ering Chamber Not available individually. Carburetor Asy. |
| 19 | | . • | ust Screw Not available individually. Carburetor Asy. |

| Ref# | Part Number | Qty Description |
|------|------------------|---|
| 20 | | Screw, Main Mixture Not available individually. Included in Carburetor Asy. |
| 21 | | Screw, Idle Mixture Not available individually. Included in Carburetor Asy. |
| 22 | | Screw, Throttle Adjust Not available individually. Included in Carburetor Asy. |
| 23 | | 4 Spring, Friction Not available individually. Included in Carburetor Asy. |
| 24 | | Shaft Asy, Choke Not available individually. Included in Carburetor Asy. |
| 25 | | Valve, Choke Not available individually. Included in Carburetor Asy. |
| 26 | | Screw, Pin Not available individually. Included in Carburetor Asy. |
| 27 | | Screw, Throttle/Choke Valve Not available individually. Included in Carburetor Asy. |
| 28 | | Screw, metering Chamber Not available individually. Included in Carburetor Asy. |
| 29 | | Screw, Pump Cover Not available individually. Included in Carburetor Asy. |
| 30 | | Ball, Steel Not available individually. Included in Carburetor Asy. |
| 31 | | Collar Not available individually. Included in Carburetor Asy. |
| 32 | | Lever, Throttle Not available individually. Included in Carburetor Asy. |
| 33 | | Screw, Throttle Lever Not available individually. Included in Carburetor Asy. |
| 34 | | 2 Washer, Limiter Not available individually. Included in Carburetor Asy. |
| 35 | 111216 | Cap, Limiter, Hi Included in Carburetor Asy.; Distributor stocked. Medium to slow moving part. |
| 36 | 111217 | Cap, Limiter, Lo Included in Carburetor Asy.; Distributor stocked. Medium to slow moving part. |
| 37 | | Retainer, Limiter Not available individually. Included in Carburetor Asy. |
| | 301041 301042 | Kit, Carburetor Repair RB-39 Kit, Gasket/Diaphragm GND-35 |
| | | |



| Ref # | Part Number | Qty Description |
|-------------|-------------|--|
| 1 | 301558 | Brake Kit Asy, Yellow Choose appropriate color; Factory stocked. Slow moving part. |
| | 301557 | Brake Kit Asy, Black Choose appropriate color; Factory stocked. Slow moving part. |
| 2 | 301559 | Housing Kit Asy, Yellow Choose appropriate color; Factory stocked. Slow moving part. |
| | 301560 | Housing Kit Asy, Black Choose appropriate color; Factory stocked. Slow moving part. |
| 3 | 216755 | Latch, Chain Brake Factory stocked. Slow moving part. |
| 4 5 6 | 301038 | Dowel, Spring Not available individually. Pin, Dowel Not available individually. Lever, Actuating Distributor stocked. Medium to slow moving part. |
| 7 8 | 111226 | Pin, Dowel Not available individually. Screw, 10-24 x .62 Tr Hd Torx Dealer stocked. Fast to medium moving part. |
| 9 | 323082 | Guard, Hand Dealer stocked. Fast to medium moving part. |
| 10 | 224849 | Roller Distributor stocked. Medium to slow moving part. |
| 11 | 224847 | Screw, Shoulder Distributor stocked. Medium to slow moving part. |
| 12 | 224848 | Stop, Brake Distributor stocked. Medium to slow moving part. |
| 13 | 300294 | Screw, 8-16 x .75 Tr Hd Plastite Dealer stocked. Fast to medium moving part. |
| 14 | 301037 | Band, Brake Dealer stocked. Fast to medium moving part. |
| 15 16 | 322204 | Pin, Spring (.125 x .50) Not available individually. Spring, Compression Dealer stocked. Fast to medium moving part. |
| 17 | 218005 | Nut, Square 10-24 Dealer stocked. Fast to medium moving part. |
| 18 | 300275 | Shield Distributor stocked. Medium to slow moving part. |
| 19 | 300271 | Spacer, Bar Pad Distributor stocked. Medium to slow moving part. |
| 20 | 111101 | Screw, 4-40 x 5/16 Taptite Factory stocked. Slow moving part. |
| 21 | 322194 | Seal, Foam Dealer stocked. Fast to medium moving part. |
| 22 | 300299 | Screw, 8-16 x 1.0 Tr Hd Plastite Distributor stocked. Medium to slow moving part. |

| Ref # | Part Number | Qty Description |
|-------|-------------|---|
| 23 | 4670341 | Label, Safety Distributor stocked. Medium to slow moving part. |
| 24 | 322181 | Spike, Bucking Optional equipment; Distributor stocked. Medium to slow moving part. |



K&T Saw Shop 606-678-9623 or 606-561-4983

| Ref# | Part Number | Qty Description |
|--------|-------------|---|
| 1 | | Powerhead Asy See "Powerhead Assembly" illustration and parts list. |
| 2 | | Chain Brake Asy See "Chain Brake Assembly" illustration and parts list. |
| 3 | 300858 | Starter Housing Asy, Grey Choose appropriate color; Factory stocked. Slow moving part. |
| | 300264 | Starter Housing Asy, Yellow Choose appropriate color; Dealer stocked. Fast to medium moving part. |
| | 301078 | Starter Housing Asy, Black Choose appropriate color; Factory stocked. Slow moving part. |
| 4 | 301651 | Housing/Rope Guide Asy, Grey Choose appropriate color; Factory stocked. Slow moving part. |
| | 301044 | Housing/Rope Guide Asy, Yellow Choose appropriate color; Distributor stocked. Medium to slow moving part. |
| | 301654 | Housing/Rope Guide Asy, Black Choose appropriate color; Factory stocked. Slow moving part. |
| 5 6 | 300475 | Rope Guide Not available individually Spring, Starter Rewind Dealer stocked. Fast to medium moving part. |
| 7 | 301043 | Rope/Drum Asy (32cc) Dealer stocked. Fast to medium moving part. |
| 8 | 300300 | Rope, Starter 50 inch Dealer stocked. Fast to medium moving part. |
| 9 | 87851 | Handle, Starter Dealer stocked. Fast to medium moving part. |
| 10 | 223944 | Bushing, Starter Dealer stocked. Fast to medium moving part. |
| 11 | 300297 | Washer, 19 ID x 68 OD Dealer stocked. Fast to medium moving part. |
| 12 | 300294 | Screw, 8-16 x .75 Torx Hd Plast Dealer stocked. Fast to medium moving part. |
| 13 | 300294 | 4 Screw, 8-16 x .75 Torx Hd Plastite Dealer stocked. Fast to medium moving part. |
| 14 | 300260 | Oil Tank Asy Distributor stocked. Medium to slow moving part. |
| 15 | 300289 | Hose, Oil Pick-up Dealer stocked. Fast to medium moving part. |
| 16 | 225062 | Filter, Oil Dealer stocked. Fast to medium moving part. |
| 17 | 300256 | Valve, Duckbill Dealer stocked. Fast to medium moving part. |
| 18 | 300565 | Oil Cap Asy w/Retainer Dealer stocked. Fast to medium moving part. |

| Ref # | Part Number | Otv | Description |
|-------|-------------|-----|--|
| 19 | 300269 | 1 | • |
| 20 | 300259 | 1 | Filter, Foam Dealer stocked. Fast to medium moving part. |
| 21 | 322195 | 1 | Spacer, Oil Tank Distributor stocked. Medium to slow moving part. |
| 22 | 300259 | 1 | Filter, Foam Dealer stocked. Fast to medium moving part. |
| 23 | 22424202 | 1 | Primer, Remote Dealer stocked. Fast to medium moving part. |
| 24 | 300298 | 1 | Hose Dealer stocked. Fast to medium moving part. |
| 25 | 301056 | 1 | |
| 26 | 111098 | 1 | Pin, Roll 1/4 x 1.0 L Distributor stocked. Medium to slow moving part. |
| 27 | 224821 | 1 | Trigger, Throttle Dealer stocked. Fast to medium moving part. |
| 28 | 224822 | 1 | Latch, Throttle Distributor stocked. Medium to slow moving part. |
| 29 | 224823 | 1 | Spring, Torsional Dealer stocked. Fast to medium moving part. |
| 30 | 111128 | 1 | "O" Ring Distributor stocked. Medium to slow moving part. |
| 31 | 322409 | 1 | Cable, Throttle Distributor stocked. Medium to slow moving part. |
| 32 | 111226 | 4 | Screw, 10-24 x .62 Tr Hd Torx Dealer stocked. Fast to medium moving part. |
| 33 | 32394761 | 1 | Engine Housing, Left, AV, Blk Choose Appropriate Color; Distributor stocked. Medium to slow moving part. |
| | 32394762 | 1 | Engine Housing, Left, AV, Grey Choose Appropriate Color; Factory stocked. Slow moving part. |
| 34 | 300294 | 5 | Screw, 8-16 x .75 Tr Hd, Plastite Dealer stocked. Fast to medium moving part. |
| 35 | 322164 | 1 | Handle, Left Rear, Black, AV Distributor stocked. Medium to slow moving part. |
| 36 | 322178 | 1 | Contact, Ground Stud, AV Distributor stocked. Medium to slow moving part. |
| 37 | 68846 | 1 | Button, Stop Switch Dealer stocked. Fast to medium moving part. |
| 38 | 223357 | 2 | Screw, 8-16 Plastite Dealer stocked. Fast to medium moving part. |
| 39 | 224844 | 1 | Contact, Ignition Distributor stocked. Medium to slow moving part. |

| Ref # | Part Number | Otv | Description |
|-------|-------------|----------|--|
| 40 | 322193 | <u> </u> | Description Isolator, Rubber Dealer stocked. Fast to medium |
| 10 | 322100 | • | moving part. |
| 41 | 322163 | 1 | Handle, Right Rear, Black Dealer stocked. Fast to medium moving part. |
| 42 | 32216201 | 1 | Handle, Front Dealer stocked. Fast to medium moving part. |
| 43 | 322165 | 1 | Spring, Extension Dealer stocked. Fast to medium moving part. |
| 44 | 218005 | 3 | Nut, Square 10-24 Dealer stocked. Fast to medium moving part. |
| 45 | 300292 | 2 | Retainer, Nut Dealer stocked. Fast to medium moving part. |
| 46 | 111226 | 2 | Screw, 10-24 x .62 Tr Hd Torx Dealer stocked. Fast to medium moving part. |
| 47 | 322166 | 2 | Spring, Extension Dealer stocked. Fast to medium moving part. |
| 48 | 300294 | 4 | Screw, 8-16 x .75 Tr hd Plastite Dealer stocked. Fast to medium moving part. |
| 49 | 217935 | 1 | Screw, 10-24 x .50 Tr Torx Dealer stocked. Fast to medium moving part. |
| 50 | 218083 | 1 | Screw, 10-24 x 2.0 Tr Torx Dealer stocked. Fast to medium moving part. |
| 51 | 322176 | 1 | Washer, 2.0 x 7.8 in. OD Dealer stocked. Fast to medium moving part. |
| 52 | 322175 | 1 | Spacer, 0.2 ID x 1.0 Lg Distributor stocked. Medium to slow moving part. |
| 53 | 111135 | 1 | Nut, Hex Lock 10-24 Distributor stocked. Medium to slow moving part. |
| 54 | 218005 | 2 | Nut, Square 10-24 Dealer stocked. Fast to medium moving part. |
| 55 | 300292 | 2 | Retainer, Nut Dealer stocked. Fast to medium moving part. |
| 56 | 224830 | 1 | Cover, Air Filter Choose appropriate color; Distributor stocked. Medium to slow moving part. |
| | 322834 | 1 | Cover, Air Filter, Grey Choose appropriate color; Factory stocked. Slow moving part. |
| 57 | 111099 | 2 | Screw, 10-24 x .625 Pn Hd Torx Dealer stocked. Fast to medium moving part. |
| 58 | 22482601 | 1 | Rod, Choke Dealer stocked. Fast to medium moving part. |
| 59 | 300294 | 5 | Screw, 8-16 x .75 Tr Hd Plastite Dealer stocked. Fast to medium moving part. |
| 60 | 300297 | 1 | Washer, .19 ID x .68 OD Dealer stocked. Fast to medium moving part. |


K&T Saw Shop 606-678-9623 or 606-561-4983

| Ref # | Part Number | Qty Description |
|-------|-------------|--|
| 61 | 300294 | 1 Screw, 8-16 x .75 Tr Hd Plastite Dealer stocked. Fast to medium moving part. |
| 62 | 93469 | 3 Washer, .469 OD x .222 ID Dealer stocked. Fast to medium moving part. |

No Diagram Available

Parts List Only

| Ref# | Part Number | Qty Description |
|------|-------------|----------------------------------|
| | 32223502 | Loctite Kit |
| | 322236 | Retaining Compound 620 (10 ml) |
| | 322237 | Thread Locker 242 (10 ml) |
| | 322238 | Gasket Eliminator 518 (50 ml) |
| | 32223901 | Black Max 380 (3 ml) |
| | 323749 | Thread Locker 262 (10 ml) |
| | 323762 | Anti-Seize lubricant 767 (30 ml) |



K&T Saw Shop 606-678-9623 or 606-561-4983


| Ref # | Part Number | Qty | Description |
|-----------------------|-------------------|------------------|---|
| 1 | 301304 | 1 | Oil Pump Asy Dealer stocked. Fast to medium moving part. |
| 2 | 322182 | 2 | Fitting Distributor stocked. Medium to slow moving part. |
| 3 | 301084 | 1 | Kit, Gear/Plunger Asy Dealer stocked. Fast to medium moving part. |
| 4 5 6 7 8 | 110582 322187 | 1 1 1 1 | Washer Dealer stocked. Fast to medium moving part. O-Ring Not available individually Spring Not available individually Pin, Dowel Not available individually Plug, Oil Pump Distributor stocked. Medium to slow |
| 0 | 322107 | ı | moving part. |
| 9 | 111226 | 2 | Screw, 10-24 x .62 Tr Hd Torx Dealer stocked. Fast to medium moving part. |
| 10 | 224814 | 1 | Worm Gear Dealer stocked. Fast to medium moving part. |
| 11 | 224840 | 1 | Spring, Compression Dealer stocked. Fast to medium moving part. |
| 12 | 300295 | 1 | Seal, Foam, Oil Pump Dealer stocked. Fast to medium moving part. |
| 13 | 300288 | 1 | Connecting Hose Dealer stocked. Fast to medium moving part. |
| 14 | 301055 | 1 | Cyl/C'case/Bar Bolt Asy, 38cc Dealer stocked. Fast to medium moving part. |
| 15 16 | 8385601 300257 | 2 | Bolt, Bar Dealer stocked. Fast to medium moving part. Fitting Distributor stocked. Medium to slow moving part. |
| 17 | 111083 | 4 | Screw, 12-24 x 1.0 Hx Wshr Hd Dealer stocked. Fast to medium moving part. |
| 18 19 | 323923 111054 | 1 | Baffle, Air Factory stocked. Slow moving part. Screw, 10-24x.625 Dealer stocked. Fast to medium moving part. |
| 20 | 110676 | 2 | Nut, Hx 1/4-28 Flange Dealer stocked. Fast to medium moving part. |
| 21 | 302140 | 1 | Crankshaft/Bearing Asy Distributor stocked. Medium to slow moving part. |
| 22 | 213282 | 2 | Bearing, C'shaft Dealer stocked. Fast to medium moving part. |
| 23 | 83859 | 2 | Seal, C'shaft Oil Dealer stocked. Fast to medium moving part. |
| 24 | 9413501 | 1 | Connecting Rod/Bearing Asy Dealer stocked. Fast to medium moving part. |
| 25 | 94654 | 2 | Screw, Conn Rod Distributor stocked. Medium to slow moving part. |

| moving part. | Ref# | Part Number | Qty | Description |
|---|------|-------------|--------|---|
| slow moving part. 28 30076301 2 Kit, Flywheel Pawls Dealer stocked. Fast to n moving part. 29 216982 2 Spring, Starter Pawl Dealer stocked. Fast to n moving part. 30 111131 2 Washer, Sp. 469 OD x. 222 ID Factory stock moving part. 2 Pawls Not available individually 32 322721 2 Pawls Not available individually 33 102164 1 Key, Flywheel Dealer stocked. Fast to medium part. 34 30105401 1 Kit, Piston, 38cc Dealer stocked. Fast to medium part. 35 323930 1 Bearing, Needle- Drawn Cup Factory stocker moving part. 36 323943 1 Pin, Piston Dealer stocked. Fast to medium repart. 37 111026 2 Ring, Snap Dealer stocked. Fast to medium repart. 38 1 Piston, Ring, 38cc Not available individually 1 Nut, Hx 5/16-24 Dealer stocked. Fast to medium repart. 40 217936 2 Screw, Tr 10-24 x 75 Torx Dealer stocked. Fast to medium rowing part. 41 300555 1 Wire Asy, Ground Distributor stocked. Mediumoving part. 42 300556 1 Wire Asy, Ground Distributor stocked. Mediumoving part. 43 302138 1 Ignition Asy Dealer stocked. Fast to medium part. 44 223884 1 Kit, Plug Wire Dealer stocked. Fast to medium part. 45 102556 1 Connector Dealer stocked. Fast to medium part. 46 95266 1 Boot Dealer stocked. Fast to medium part. 47 110995 1 Grommet Not used on these models; Distributocked. Medium to slow moving part. | 26 | 68095 | 1 | Set, Roller Pins Distributor stocked. Medium to slow moving part. |
| moving part. 29 216982 2 Spring, Starter Pawl Dealer stocked. Fast to 1 moving part. 30 111131 2 Washer, Sp. 469 OD x. 222 ID Factory stock moving part. 31 2 Pawls Not available individually 32 322721 2 Pin, Starter Pawl Dealer stocked. Fast to mediun part. 33 102164 1 Key, Flywheel Dealer stocked. Fast to mediun part. 34 30105401 1 Kit, Piston, 38cc Dealer stocked. Fast to mediun part. 35 323930 1 Bearing, Needle- Drawn Cup Factory stocker moving part. 36 323943 1 Pin, Piston Dealer stocked. Fast to medium repart. 37 111026 2 Ring, Snap Dealer stocked. Fast to medium repart. 38 1 Piston, Ring, 38cc Not available individually 39 110961 1 Nut, Hx 5/16-24 Dealer stocked. Fast to medium repart. 40 217936 2 Screw, Tr 10-24 x 75 Torx Dealer stocked. Fast to medium moving part. 41 300555 1 Wire Asy, Ground Distributor stocked. Medium moving part. 42 300556 1 Wire Asy, Ground Distributor stocked. Medium moving part. 43 302138 1 Ignition Asy Dealer stocked. Fast to medium part. 44 223884 1 Kit, Plug Wire Dealer stocked. Fast to medium part. 45 102556 1 Connector Dealer stocked. Fast to medium part. 46 95266 1 Boot Dealer stocked. Fast to medium moving Part. 48 2155301 1 Grommet Not used on these models; Distributor stocked. Medium to slow moving part. | 27 | 302220 | 1 | Flywheel/Pawl Asy Distributor stocked. Medium to slow moving part. |
| moving part. 2 Washer, Sp. 469 OD x .222 ID Factory stock moving part. 2 Pawls Not available individually 32 322721 2 Pin, Starter Pawl Dealer stocked. Fast to mediun part. 33 102164 1 Key, Flywheel Dealer stocked. Fast to mediun part. 34 30105401 1 Kit, Piston, 38cc Dealer stocked. Fast to mediun part. 35 323930 1 Bearing, Needle- Drawn Cup Factory stocked moving part. 36 323943 1 Pin, Piston Dealer stocked. Fast to medium repart. 37 111026 2 Ring, Snap Dealer stocked. Fast to medium repart. 38 1 Piston, Ring, 38cc Not available individually Nut, Hx 5/16-24 Dealer stocked. Fast to medium repart. 40 217936 2 Screw, Tr 10-24 x 75 Torx Dealer stocked. Fast to medium removing part. 41 300555 1 Wire Asy, Ground Distributor stocked. Mediumoving part. 42 300556 1 Wire Asy, Stop Switch Distributor stocked. Mediumoving part. 43 302138 1 Ignition Asy Dealer stocked. Fast to medium part. 44 223884 1 Kit, Plug Wire Dealer stocked. Fast to medium part. 45 102556 1 Connector Dealer stocked. Fast to medium part. 46 95266 1 Boot Dealer stocked. Fast to medium naving Part. 47 10995 1 Grommet Not used on these models; Distributor kocked. Medium to slow moving part. | 28 | 30076301 | 2 | Kit, Flywheel Pawls Dealer stocked. Fast to medium moving part. |
| moving part. 2 Pawls Not available individually 32 322721 2 Pin, Starter Pawl Dealer stocked. Fast to medium part. 33 102164 1 Key, Flywheel Dealer stocked. Fast to medium part. 34 30105401 1 Kit, Piston, 38cc Dealer stocked. Fast to medium part. 35 323930 1 Bearing, Needle- Drawn Cup Factory stocked moving part. 36 323943 1 Pin, Piston Dealer stocked. Fast to medium repart. 37 111026 2 Ring, Snap Dealer stocked. Fast to medium repart. 38 1 Piston, Ring, 38cc Not available individually 39 110961 1 Nut, Hx 5/16-24 Dealer stocked. Fast to medium repart. 40 217936 2 Screw, Tr 10-24 x 75 Torx Dealer stocked. Fast to medium moving part. 41 300555 1 Wire Asy, Ground Distributor stocked. Medium moving part. 42 300556 1 Wire Asy, Stop Switch Distributor stocked. Medium opart. 43 302138 1 Ignition Asy Dealer stocked. Fast to medium part. 44 223884 1 Kit, Plug Wire Dealer stocked. Fast to medium part. 45 102556 1 Connector Dealer stocked. Fast to medium part. 46 95266 1 Boot Dealer stocked. Fast to medium part. 47 110995 1 Grommet Not used on these models; Distributor stocked. Medium to slow moving part. 48 21553301 1 Grommet Not used on these models; Distributor stocked. Medium to slow moving part. | 29 | 216982 | 2 | Spring, Starter Pawl Dealer stocked. Fast to medium moving part. |
| 32 322721 2 Pin, Starter Pawl Dealer stocked. Fast to memoving part. 33 102164 1 Key, Flywheel Dealer stocked. Fast to mediun part. 34 30105401 1 Kit, Piston, 38cc Dealer stocked. Fast to mediun part. 35 323930 1 Bearing, Needle- Drawn Cup Factory stocked moving part. 36 323943 1 Pin, Piston Dealer stocked. Fast to medium repart. 37 111026 2 Ring, Snap Dealer stocked. Fast to medium repart. 38 1 Piston, Ring, 38cc Not available individually Nut, Hx 5/16-24 Dealer stocked. Fast to medium repart. 40 217936 2 Screw, Tr 10-24 x 75 Torx Dealer stocked. Fast to medium moving part. 41 300555 1 Wire Asy, Ground Distributor stocked. Medium moving part. 42 300556 1 Wire Asy, Stop Switch Distributor stocked. Medium part. 43 302138 1 Ignition Asy Dealer stocked. Fast to medium part. 44 223884 1 Kit, Plug Wire Dealer stocked. Fast to medium part. 45 102556 1 Connector Dealer stocked. Fast to medium part. 46 95266 1 Boot Dealer stocked. Fast to medium moving Part. 47 10995 1 Grommet Not used on these models; Distributor stocked. Medium to slow moving part. 48 21553301 1 Grommet Not used on these models; Distributor stocked. Medium to slow moving part. | 30 | 111131 | 2 | Washer, Sp .469 OD x .222 ID Factory stocked. Slow moving part. |
| part. 34 30105401 1 Kit, Piston, 38cc Dealer stocked. Fast to medimoving part. 35 323930 1 Bearing, Needle- Drawn Cup Factory stocked moving part. 36 323943 1 Pin, Piston Dealer stocked. Fast to medium repart. 37 111026 2 Ring, Snap Dealer stocked. Fast to medium repart. 38 1 Piston, Ring, 38cc Not available individually 1 Nut, Hx 5/16-24 Dealer stocked. Fast to medium moving part. 40 217936 2 Screw, Tr 10-24 x 75 Torx Dealer stocked. Fast to medium moving part. 41 300555 1 Wire Asy, Ground Distributor stocked. Medium moving part. 42 300556 1 Wire Asy, Stop Switch Distributor stocked. Medium moving part. 43 302138 1 Ignition Asy Dealer stocked. Fast to medium part. 44 223884 1 Kit, Plug Wire Dealer stocked. Fast to medium part. 45 102556 1 Connector Dealer stocked. Fast to medium part. 46 95266 1 Boot Dealer stocked. Fast to medium moving part. 47 110995 1 Grommet Not used on these models; Distributor stocked. Medium to slow moving part. | | 322721 | | Pin, Starter Pawl Dealer stocked. Fast to medium |
| moving part. 35 323930 1 Bearing, Needle- Drawn Cup Factory stocked moving part. 36 323943 1 Pin, Piston Dealer stocked. Fast to medium repart. 37 111026 2 Ring, Snap Dealer stocked. Fast to medium repart. 38 1 Piston, Ring, 38cc Not available individually Nut, Hx 5/16-24 Dealer stocked. Fast to medium moving part. 40 217936 2 Screw, Tr 10-24 x 75 Torx Dealer stocked. Fast to medium moving part. 41 300555 1 Wire Asy, Ground Distributor stocked. Medium moving part. 42 300556 1 Wire Asy, Stop Switch Distributor stocked. Mislow moving part. 43 302138 1 Ignition Asy Dealer stocked. Fast to medium part. 44 223884 1 Kit, Plug Wire Dealer stocked. Fast to medium part. 45 102556 1 Connector Dealer stocked. Fast to medium part. 46 95266 1 Boot Dealer stocked. Fast to medium noving part. 47 110995 1 Grommet Not used on these models; Distributor stocked. Medium to slow moving part. | 33 | 102164 | 1 | Key, Flywheel Dealer stocked. Fast to medium moving part. |
| moving part. 36 323943 1 Pin, Piston Dealer stocked. Fast to medium repart. 37 111026 2 Ring, Snap Dealer stocked. Fast to medium repart. 38 1 Piston, Ring, 38cc Not available individually 39 110961 1 Nut, Hx 5/16-24 Dealer stocked. Fast to medium repart. 40 217936 2 Screw, Tr 10-24 x 75 Torx Dealer stocked. Fast to medium moving part. 41 300555 1 Wire Asy, Ground Distributor stocked. Medium moving part. 42 300556 1 Wire Asy, Stop Switch Distributor stocked. Mislow moving part. 43 302138 1 Ignition Asy Dealer stocked. Fast to medium part. 44 223884 1 Kit, Plug Wire Dealer stocked. Fast to medium part. 45 102556 1 Connector Dealer stocked. Fast to medium repart. 46 95266 1 Boot Dealer stocked. Fast to medium moving part. 47 110995 1 Grommet Not used on these models; Distributor stocked. Medium to slow moving part. | 34 | 30105401 | 1 | Kit, Piston, 38cc Dealer stocked. Fast to medium moving part. |
| part. 2 Ring, Snap Dealer stocked. Fast to medium repart. 3 Piston, Ring, 38cc Not available individually 1 Nut, Hx 5/16-24 Dealer stocked. Fast to medium moving part. 40 217936 2 Screw, Tr 10-24 x 75 Torx Dealer stocked. Fast to medium moving part. 41 300555 1 Wire Asy, Ground Distributor stocked. Mediumoving part. 42 300556 1 Wire Asy, Stop Switch Distributor stocked. Mediumoving part. 43 302138 1 Ignition Asy Dealer stocked. Fast to medium part. 44 223884 1 Kit, Plug Wire Dealer stocked. Fast to medium part. 45 102556 1 Connector Dealer stocked. Fast to medium part. 46 95266 1 Boot Dealer stocked. Fast to medium moving part. 47 110995 1 Grommet Not used on these models; Distributor stocked. Medium to slow moving part. 48 21553301 1 Grommet Not used on these models; Distributor stocked. Medium to slow moving part. | 35 | 323930 | 1 | Bearing, Needle- Drawn Cup Factory stocked. Slow moving part. |
| part. 1 Piston, Ring, 38cc Not available individually 1 Nut, Hx 5/16-24 Dealer stocked. Fast to med moving part. 2 Screw, Tr 10-24 x 75 Torx Dealer stocked. Fast to medium moving part. 300555 1 Wire Asy, Ground Distributor stocked. Medium moving part. 300556 1 Wire Asy, Stop Switch Distributor stocked. Medium moving part. 302138 1 Ignition Asy Dealer stocked. Fast to medium part. Kit, Plug Wire Dealer stocked. Fast to medium part. Kit, Plug Wire Dealer stocked. Fast to medium part. Connector Dealer stocked. Fast to medium part. Connector Dealer stocked. Fast to medium part. Boot Dealer stocked. Fast to medium moving fart. Grommet Not used on these models; Distributor stocked. Medium to slow moving part. | 36 | 323943 | 1 | Pin, Piston Dealer stocked. Fast to medium moving part. |
| 1 Nut, Hx 5/16-24 Dealer stocked. Fast to med moving part. 2 Screw, Tr 10-24 x 75 Torx Dealer stocked. Fast to medium moving part. 300555 1 Wire Asy, Ground Distributor stocked. Mediu moving part. 300556 1 Wire Asy, Stop Switch Distributor stocked. Mediu moving part. 302138 1 Ignition Asy Dealer stocked. Fast to medium part. Kit, Plug Wire Dealer stocked. Fast to medium part. Kit, Plug Wire Dealer stocked. Fast to medium part. Connector Dealer stocked. Fast to medium nart. Boot Dealer stocked. Fast to medium moving Grommet Not used on these models; Distributor stocked. Medium to slow moving part. Grommet Not used on these models; Distributor stocked. Medium to slow moving part. | 37 | 111026 | 2 | Ring, Snap Dealer stocked. Fast to medium moving part. |
| medium moving part. 1 Wire Asy, Ground Distributor stocked. Medium oving part. 2 300556 1 Wire Asy, Stop Switch Distributor stocked. Medium oving part. 3 302138 1 Ignition Asy Dealer stocked. Fast to medium part. 4 223884 1 Kit, Plug Wire Dealer stocked. Fast to medium part. 4 102556 1 Connector Dealer stocked. Fast to medium part. 4 1 Boot Dealer stocked. Fast to medium moving part. 4 1 Grommet Not used on these models; Distributor stocked. Medium to slow moving part. 4 21553301 1 Grommet Not used on these models; Distribut stocked. Medium to slow moving part. | | 110961 | | Nut, Hx 5/16-24 Dealer stocked. Fast to medium |
| moving part. 42 300556 1 Wire Asy, Stop Switch Distributor stocked. M slow moving part. 43 302138 1 Ignition Asy Dealer stocked. Fast to medium part. 44 223884 1 Kit, Plug Wire Dealer stocked. Fast to medium part. 45 102556 1 Connector Dealer stocked. Fast to medium part. 46 95266 1 Boot Dealer stocked. Fast to medium moving 110995 1 Grommet Not used on these models; Distribut stocked. Medium to slow moving part. 48 21553301 1 Grommet Not used on these models; Distribut stocked. Medium to slow moving part. | 40 | 217936 | 2 | Screw, Tr 10-24 x 75 Torx Dealer stocked. Fast to medium moving part. |
| slow moving part. 1 Ignition Asy Dealer stocked. Fast to medium part. 1 Kit, Plug Wire Dealer stocked. Fast to medium part. 1 Connector Dealer stocked. Fast to medium part. 1 Connector Dealer stocked. Fast to medium part. 1 Boot Dealer stocked. Fast to medium moving Grommet Not used on these models; Distribut stocked. Medium to slow moving part. 1 Grommet Not used on these models; Distribut stocked. Medium to slow moving part. | 41 | 300555 | 1 | Wire Asy, Ground Distributor stocked. Medium to slow moving part. |
| part. 44 223884 1 Kit, Plug Wire Dealer stocked. Fast to medium part. 45 102556 1 Connector Dealer stocked. Fast to medium mark. 46 95266 1 Boot Dealer stocked. Fast to medium moving 110995 1 Grommet Not used on these models; Distribut stocked. Medium to slow moving part. 48 21553301 1 Grommet Not used on these models; Distribut stocked. Medium to slow moving part. | 42 | 300556 | 1 | Wire Asy, Stop Switch Distributor stocked. Medium to slow moving part. |
| part. 102556 1 Connector Dealer stocked. Fast to medium no part. 1 Boot Dealer stocked. Fast to medium moving the part. 1 Boot Dealer stocked. Fast to medium moving the part. 1 Grommet Not used on these models; Distribution stocked. Medium to slow moving part. 1 Grommet Not used on these models; Distribution stocked. Medium to slow moving part. | 43 | 302138 | 1 | Ignition Asy Dealer stocked. Fast to medium moving part. |
| part. 46 95266 1 Boot Dealer stocked. Fast to medium moving 1 Grommet Not used on these models; Distribution 1 Stocked. Medium to slow moving part. 48 21553301 1 Grommet Not used on these models; Distribution 1 Grommet Not used on these models; Distribution 1 Stocked. Medium to slow moving part. | 44 | 223884 | 1 | , |
| 1 Grommet Not used on these models; Distribution stocked. Medium to slow moving part. 1 Grommet Not used on these models; Distribution stocked. Medium to slow moving part. | 45 | 102556 | 1 | 3 |
| stocked. Medium to slow moving part. | | | 1 1 | Boot Dealer stocked. Fast to medium moving part. Grommet Not used on these models; Distributor stocked. Medium to slow moving part. |
| 40 222200 1 Sport Divis DD IZV Depley stocked Foot to m | 48 | 21553301 | 1 | Grommet Not used on these models; Distributor stocked. Medium to slow moving part. |
| moving part. | 49 | 322208 | 1 | Spark Plug RDJ7Y Dealer stocked. Fast to medium moving part. |

K&T Saw Shop 606-678-9623 or 606-561-4983

| Ref# | Part Number | Qtv | Description |
|------|-------------|-----|---|
| 50 | 301045 | | Muffler Asy Distributor stocked. Medium to slow |
| | | | moving part. |
| 51 | 300280 | | Body Factory stocked. Slow moving part. |
| 52 | 300281 | | Plate, Reinforcing Factory stocked. Slow moving part. |
| 53 | 300284 | | Spacer Factory stocked. Slow moving part. |
| 54 | 300282 | 1 | Baffle, Inner Muffler Factory stocked. Slow moving part. |
| 55 | 300286 | | Screen, Spark Arrester Distributor stocked. Medium to slow moving part. |
| 56 | 300283 | | Baffle, Outer Factory stocked. Slow moving part. |
| 57 | 323637 | | Cover, Muffler Factory stocked. Slow moving part. |
| 58 | 111093 | 3 | Screw, 10-24 x 1.75 Tr Hd Torx Distributor stocked. Medium to slow moving part. |
| 59 | 300265 | 1 | Gasket, Insulator Dealer stocked. Fast to medium moving part. |
| 60 | 224820 | 1 | Insulator, Carburetor Dealer stocked. Fast to medium moving part. |
| 61 | 218315 | 3 | Nut, Hx 10-24 Dealer stocked. Fast to medium moving part. |
| 62 | 322188 | 2 | Spacer, Rubber Dealer stocked. Fast to medium moving part. |
| 63 | 224850 | 1 | Seal, Foam Dealer stocked. Fast to medium moving part. |
| 64 | 217937 | 2 | Screw, Tr 10-24 x 1.00 Torx Distributor stocked. Medium to slow moving part. |
| 65 | 217936 | 1 | Screw, Tr 10-24 x .75 Torx Dealer stocked. Fast to medium moving part. |
| 66 | 300293 | | Gasket, Carburetor Dealer stocked. Fast to medium moving part. |
| 67 | | 1 | Carburetor/Choke Asy See "Carburetor Assembly" illustrations and parts lists. |
| 68 | 218083 | 2 | Screw, Tr 10-24 x 2.0 Torx Dealer stocked. Fast to medium moving part. |
| 69 | 224824 | 1 | Box, Air Filter Factory stocked. Slow moving part. |
| 70 | 224831 | | Filter, Air Dealer stocked. Fast to medium moving part. |
| 71 | 224825 | 1 | Shield, Carburetor Distributor stocked. Medium to slow moving part. |
| 72 | 111055 | 1 | Screw, 10-14 x .625 Plastite Dealer stocked. Fast to medium moving part. |
| 73 | 223088 | 1 | Screw, Adjusting Dealer stocked. Fast to medium moving part. |
| 74 | 110907 | 1 | Ring, Retaining Dealer stocked. Fast to medium moving part. |

| Ref # | Part Number | Qty | Description |
|----------|-------------|-----|---|
| 75 | 68656 | 1 | Nut, Bar Adjusting Dealer stocked. Fast to medium moving part. |
| 76 | 302768 | 1 | Drum/Sprocket/Bearing Asy Dealer stocked. Fast to medium moving part. |
| 77 | 91117 | 1 | Bearing Dealer stocked. Fast to medium moving part. |
| 78 | 215259 | 1 | Washer, Sprocket Distributor stocked. Medium to slow moving part. |
| 79 | 301463 | 1 | Kit, Clutch Asy Dealer stocked. Fast to medium moving part. |
| 80 | 300276 | 1 | Plate, Dust Distributor stocked. Medium to slow moving part. |
| 81 | 111079 | 1 | Nut, Clutch, 5/16-24 LH Dealer stocked. Fast to medium moving part. |
| 82 | 301834 | 1 | Fuel Tank Asy Dealer stocked. Fast to medium moving part. |
| 83 | 300289 | 1 | Hose, Fuel Pickup Dealer stocked. Fast to medium moving part. |
| 84 | 216985 | 1 | Filter, Fuel Dealer stocked. Fast to medium moving part. |
| 85 | 322199 | 1 | Valve, Duckbill Dealer stocked. Fast to medium moving part. |
| 86 | 300290 | 1 | Hose, Primer Retain Dealer stocked. Fast to medium moving part. |
| 87 | 300564 | 1 | Cap, Fuel Asy, w/Retainer Dealer stocked. Fast to medium moving part. |
| 88 | 300267 | 1 | Gasket, Fuel Cap Dealer stocked. Fast to medium moving part. |
| 92 93 | | | UNKNOWN UNKNOWN |



| Ref# | Part Number | Qty Description |
|----------|-------------|---|
| 111124 | 111124 | T-27 Torx Dr 3.5 in. |
| 222785 | 222785 | T-25 Torx Dr 3.5 in. |
| 217720 | 217720 | Torx Dr Set |
| 323754 | 323754 | Torx Dr Bit Sizes: Tx 10, 15, 20, 25, 27, 30 (Set of 6) |
| 323330 | 323330 | Ignition Tester |
| 21543201 | 21543201 | Pressure Test Tool |
| 91424 | 91424 | Tachometer |